

G9

C1

FRENTE

Street / General

Walk-around photography. Markets, parks, towns, beaches. The 'pick up and shoot' mode.

!! SETUP FISICO -- VERIFICAR ANTES DE FOTOGRAFAR

[ ] Mode dial

C1

[ ] Focus lever

AFS

front of camera, top position

[ ] Drive dial

Single Shot

top-left dial, first position

AJUSTAR NO CAMPO

> Rear dial

= Aperture

the ONLY thing you adjust

> f/2.8-4 → blurs background, isolates subject

> f/8-11 → everything sharp (street scenes, architecture)

> Bright sun: close down (f/8+). Shade: open up (f/2.8-4)

> Camera sets shutter speed automatically — just shoot

--- fold here --- cut along card borders --- front above, back below (inverted) ---

G9

C1

VERSO

Street / General

PARÁMETRO SALVO VALOR RACIONAL

Exposure mode

A (Aperture)

You pick DoF; camera handles speed

ISO

AUTO

Adapts to light automatically

Af Mode

Full Area

Camera picks best focus point

Af Detection

ON

Auto subject detection

IS

ON Mode 1

Standard stabilization

Shutter Type

Auto (CSHTR)

Electronic 1st curtain — sharper

Photo Style

Standard

Neutral, balanced look

WB

AWB

Adapts to mixed lighting

Metering

Multi

Evaluative, whole frame

Flash

Forced Off

Available light only

DICAS

- Tap touchscreen to move Af point to your subject

- If S5 drops below 1/60 in the viewfinder, brace camera or open aperture

POR QUE ESTE MODO FUNCIONA

Aperture Priority: aperture is the creative decision (how much blur?) while shutter speed is just technical (fast enough to avoid shake). Control the one thing that matters, let the camera handle the rest. In good light the camera will never pick a bad shutter speed.

G9

C2

FRENTE

Portrait / People

People, environmental portraits, group photos. Face/eye detection does the hard work.

!! SETUP FISICO -- VERIFICAR ANTES DE FOTOGRAFAR

[ ] Mode dial

C2

[ ] Focus lever

AFS

front of camera, top position

[ ] Drive dial

Single Shot

top-left dial, first position

AJUSTAR NO CAMPO

> Rear dial

= Aperture

controls background blur (bokeh)

> f/1.7-2.8 → creamy blur for individual portraits

> f/5.6-8 → group photos (everyone in focus)

> Camera detects faces/eyes automatically — trust the AF

> Move your feet, don't zoom — step back for full body, closer for headshot

--- fold here --- cut along card borders --- front above, back below (inverted) ---

G9

C2

VERSO

Portrait / People

PARÂMETRO SALVO VALOR RACIONAL

|               |              |                           |
|---------------|--------------|---------------------------|
| Exposure mode | A (Aperture) | Aperture controls bokeh   |
| ISO           | AUTO         | Adapts to light           |
| Af Mode       | Full Area    | Finds faces across frame  |
| Af Detection  | ON — Human   | Face/eye detection active |
| IS            | ON Mode 1    | Standard stabilization    |
| Shutter Type  | Auto (CSHTR) | Sharper, no vibration     |
| Photo Style   | Standard     | Balanced skin tones       |
| WB            | AWB          | Adapts to scene           |
| Metering      | Multi        | Evaluative metering       |
| Flash         | Forced OFF   | Natural light             |

DICAS

- Open shade gives the most flattering light on faces

- Check eyes are sharp after each shot — re-shoot if AF missed

POR QUE ESTE MODO FUNCIONA

Face/eye detection locks onto eyes with remarkable accuracy. Wide apertures (f/1.7-2.8) separate the person from the background — the classic portrait look. For groups, close down to f/5.6-8 so everyone is in the focal plane.

G9

C3-1

FRENTE

Landscape

Scenery, vistas, nature. Maximum sharpness across the entire frame.

!! SETUP FISICO -- VERIFICAR ANTES DE FOTOGRAFAR

[ ] Mode dial

C3

then rear dial to select C3-1

[ ] Focus lever

AFS

front of camera, top position

[ ] Drive dial

Single Shot

top-left dial, first position

AJUSTAR NO CAMPO

> Rear dial

= Aperture

controls depth of field across scene

> f/8-11 → SWEET SPOT for MFT — sharpest landscapes

> Never go past f/16 — diffraction softens the image

> Focus 1/3 into the scene, NOT on the horizon

> Golden hour (sunrise/sunset) = best landscape light

--- fold here --- cut along card borders --- front above, back below (inverted) ---

G9

C3-1

VERSO

Landscape

PARÁMETRO SALVO VALOR RACIONAL

|               |              |                                  |
|---------------|--------------|----------------------------------|
| Exposure mode | A (Aperture) | You control DoF across scene     |
| ISO           | AUTO         | Stays at ISO 200 in good light   |
| Af Mode       | Full Area    | Tap screen to pick focus point   |
| Af Detection  | OFF          | No subject to detect in scenery  |
| IS            | ON Mode 1    | Stabilized handheld              |
| Shutter Type  | Auto (CSHTR) | Sharper at slow speeds           |
| Photo Style   | Scenery      | Enhanced greens, blues, contrast |
| WB            | AWB          | Or set Daylight for golden hour  |
| Metering      | Multi        | Evaluative, whole frame          |
| Flash         | Forced OFF   | Natural light only               |

DICAS

- If shutter drops below 1/60, use tripod or brace firmly

- Photo Style Scenery boosts colors — great for nature

POR QUE ESTE MODO FUNCIONA

Landscapes need front-to-back sharpness. On MFT sensors, f/8-11 gives deep DoF without diffraction softening (which starts past f/16). Focus 1/3 into the scene to maximize DoF coverage — not on the horizon.

Macro + Flash

Handheld close-ups: insects, frogs, snakes, lizards. Off-camera flash is the light source.

!! SETUP FISICO -- VERIFICAR ANTES DE FOTOGRAFAR

|                       |                           |                                       |
|-----------------------|---------------------------|---------------------------------------|
| [ ] Mode dial         | <b>C3</b>                 | then rear dial to select C3-2         |
| [ ] Focus lever       | <b>MF</b>                 | front of camera, bottom position      |
| [ ] Drive dial        | <b>Single Shot</b>        | top-left dial, first position         |
| [ ] Lens              | <b>90mm f/3.5 IS PRO</b>  | or swap: 60mm f/2.8 for small insects |
| [ ] Lens IS switch    | <b>ON</b>                 | on the lens barrel                    |
| [ ] Flash: X3 trigger | <b>Mount on hot shoe</b>  | turn ON, check channel                |
| [ ] Flash: AD100Pro   | <b>Turn ON</b>            | match channel/group with X3           |
| [ ] Flash: ML-CD15    | <b>Attach to AD100Pro</b> | diffuser — softer light               |

AJUSTAR NO CAMPO

!! DO NOT TOUCH camera dials — all exposure settings are FIXED

- > Flash power                    **Adjust on X3 only**                    start Manual 1/128
- > Too bright → lower X3 power. Too dark → raise X3 power
- > TTL works 0.5x-1x on Mkl. Above 1x: switch X3 to M 1/128
- > Focus: rock your body in/out. Focus ring for coarse adjust

--- fold here --- cut along card borders --- front above, back below (inverted) ---

POR QUE ESTE MODO FUNCIONA

In flash macro, the flash is the light system. Ambient is irrelevant — the flash fires at ~1/10000s, freezing motion and providing all illumination. Everything is fixed: f/20 for max DoF, 1/200 for sync, ISO 200 for clean files. Open to f/11 when you can nail focus. The only variable is flash power, adjusted on the X3 trigger.

DICAS

- 90mm = safer working distance (frogs, snakes). 60mm = more magnification (insects)
- Flash fires at ~1/10000s — freezes all motion regardless of shutter speed

|               |                    |                                                                    |
|---------------|--------------------|--------------------------------------------------------------------|
| Exposure mode | <b>M (Manual)</b>  | Flash is the light; ambient irrelevant                             |
| Aperture      | <b>f/20</b>        | Max DoF for tiny subjects. Go down to f/11 if you can focus easily |
| Shutter Speed | <b>1/200s</b>      | Max flash sync speed                                               |
| ISO           | <b>200 (fixed)</b> | Low noise; flash provides light                                    |
| Focus         | <b>MF</b>          | Af hunts at macro — rock to focus                                  |
| Shutter Type  | <b>Mechanical</b>  | Required for flash sync                                            |
| Flash         | <b>ON / TTL</b>    | Flash fires every shot                                             |
| Flash Adjust  | <b>0 EV</b>        | Fine-tune per session                                              |
| IS            | <b>ON Mode 1</b>   | Helps frame while rocking                                          |
| Photo Style   | <b>Natural</b>     | Accurate nature colors                                             |

PARÂMETRO SALVO VALOR RACIONAL

Macro + Flash

G9

C3-3

FRENTE

Wildlife / Action

Birds, animals in motion. Continuous tracking, high-speed burst.

!! SETUP FISICO -- VERIFICAR ANTES DE FOTOGRAFAR

[ ] Mode dial

[ ] Focus lever

[ ] Drive dial

[ ] Lens

C3

AFC

Burst I (H)

Lumix 35-100mm f/2.8

then rear dial to select C3-3

front of camera, middle position

top-left dial, burst position

AJUSTAR NO CAMPO

> Front dial

= Aperture

open wider in shade for lower ISO

> Rear dial

= Shutter speed

raise for faster subjects

> f/2.8 in shade (max light) → f/4-5.6 in bright sun

> 1/1000 baseline. Raise to 1/2000-1/4000 if enough light

> Half-press and HOLD to track — AF locks on animal automatically

> Zoom out slightly — crop later. In frame > missed entirely

> Accept ISO 3200-6400. Noisy sharp > clean blurry

--- fold here --- cut along card borders --- front above, back below (inverted) ---

G9

C3-3

VERSO

Wildlife / Action

PARÁMETRO SALVO VALOR RACIONAL

|               |                 |       |                                   |
|---------------|-----------------|-------|-----------------------------------|
| Exposure mode | M (Manual)      | f/2.8 | Lock aperture + speed; ISO floats |
| Aperture      |                 |       | Wide open for max light           |
| Shutter Speed | 1/1000s         |       | Freezes animal motion             |
| ISO           | AUTO (max 6400) |       | Camera adjusts exposure           |
| Min SS        | 1/1000s         |       | Floor — won't go slower           |
| AF Detection  | ON — Animal     |       | Detects animals/birds             |
| AF Mode       | Zone            |       | Large tracking area               |
| Shutter Type  | Electronic      |       | Max burst speed, silent           |
| IS            | ON Mode 1       |       | Standard stabilization            |
| Photo Style   | Standard        |       | Balanced processing               |

DICAS

- M + Auto ISO = 'wildlife triangle': lock aperture + speed, ISO floats

- Zone AF gives generous tracking area — no need for surgical framing

POR QUE ESTE MODO FUNCIONA

Manual + Auto ISO guarantees your two critical variables: f/2.8 for max light gathering, 1/1000s baseline for freezing motion. Raise to 1/2000+ if light allows. The camera just adjusts ISO. AFC + Animal Detection + Zone AF; camera recognizes animals, locks on, and tracks through the frame.