

DATACOM



DmOS MIB Reference

Version 12.4.0

Contacts

Technical Support

Datacom has available a support portal - DmSupport, to help the customers in use and config of our equipment.

Access to the DmSupport can be made through link: <https://supportcenter.datacom.com.br>

In this site the following are available: firmwares, technical datasheets, config guide, MIBs and manuals for download. In addition, it allows opening of calls for assistance with our technical team.

Telephone Number: **+55 51 3933-3122**

We would like to highlight that our assistance through telephone support is available from Monday through Friday from 08:00 AM through 05:30 PM.

Important: For support assistance 24x7, please request a quotation to our sales department.

General Information

For any other additional information, please visit the <https://www.datacom.com.br/en> or call:

DATACOM

Rua América, 1000

92990-000 - Eldorado do Sul - RS - Brazil

+55 51 3933-3000

Table of Contents

Contacts	2
1 DATACOM-GENERIC-DEVICE-TRAPS-MIB	26
1.1 mtGenDvInfInsertedDevTrap	26
1.2 mtGenDvInfRemovedDevTrap	26
1.3 mtGenDvStSnmpManagementStatusTrap	26
1.4 mtGenDvStLatchedPossibleNewCfgTrap	26
1.5 agFwRemDownTempMemTrap	26
1.6 agFwRemDownActionStTrap	27
1.7 mtGenDvInfNumPortsTrap	27
1.8 mtGenDvInfTempRangeTrap	27
1.9 mtGenDvInfFanFailTrap	27
1.10 mtGenDvInfInsertedPortTrap	27
1.11 mtGenDvInfRemovedPortTrap	27
1.12 mtGenDvInfPortConfigModeTrap	27
1.13 mtGenDvInfPowerStatusTrap	27
1.14 smtGenDvStLinkStatusTribE1PpiExcSlipTrap	28
1.15 smtGenDvStLinkStatusDigitalItfExcSlipTrap	28
1.16 smtGenDvStLinkStatusDslExcSlipTrap	28
1.17 smtGenDvStPhSlotStFailFanFailTrap	28
1.18 smtGenDvStPhSlotStFailFanMismatchTrap	28
1.19 smtGenDvStPhSlotStFailPwrSuppFailTrap	28
1.20 smtGenDvStPhSlotStFailPwrRedundancyFailTrap	28
1.21 smtGenDvStPhSlotStFailPwrOverloadTrap	28
1.22 smtGenDvStPhSlotStFailFuseFailTrap	29
1.23 smtGenDvEthernetOverloadTrap	29
1.24 smtGenDvStPhSlotStFailAggFailTrap	29
1.25 smtGenDvStPhSlotOperStAggPrevMaintReqTrap	29
1.26 smtGenDvStPhSlotStFailTribFailTrap	29
1.27 smtGenDvStPhSlotPresenceTrap	29
1.28 smtGenDvStCurrentDevCpuFWUpdateFailure	29
1.29 smtGenDvStCurrentDevCpuFWInvalidInactive	29
1.30 smtGenDvStCurrentDevCpuFWImageTemporary	30
1.31 smtGenDvStCurrentDevCpuFWUpdateBeginning	30
1.32 smtGenDvStPhSlotStFailCpuFailTrap	30
1.33 smtGenDvStPhSlotStFailCriticalTempTrap	30
1.34 smtsdhStCurrentDevCpuFWUpdateReady	30
1.35 smtsdhStCurrentDevFWVersionChanged	30

1.36 smtGenDvStPhSlotStCardRemovedTrap	30
1.37 smtGenDvStPhSlotStCardMismatchTrap	30
1.38 smtGenDvStPhSlotStCardDisabledTrap	31
1.39 smtGenDvStPhSlotStUnsupportedCardTrap	31
1.40 smtGenDvStPhSlotStCardConfigMismatch	31
1.41 smtGenDvStPhSlotStCardFail	31
1.42 smtGenDvStPhSlotStCardFwMismatch	31
1.43 smtGenDvStPhSlotStCardCriticalTemp	31
1.44 smtGenDvStPhSlotStCardHwConfigFail	31
1.45 smtGenDvStPhSlotStCardHwProtected	31
1.46 smtGenDvStPhSlotStCardVendorMismatch	32
1.47 smtGenDvStLastChangeTmTrap	32
1.48 smtGenDvStLastActivationTrap	32
1.49 smtGenDvStUserListChangedTrap	32
1.50 smtGenDvStCpuActiveTrap	32
1.51 smtGenDvStCpuColdStartTrap	32
1.52 smtGenDvStCpuWarmStartTrap	32
1.53 smtGenDvInfInsertedDevTrap	32
1.54 smtGenDvInfRemovedDevTrap	33
1.55 sFPmismatchAlarmTrap	33
1.56 sFPvendorMismatchAlarmTrap	33
1.57 configTemporaryAlarmTrap	33
1.58 edfaFailureAlarmTrap	33
1.59 edfaLowInputPowerFailureAlarmTrap	33
1.60 icad2Subdev1MismatchAlarmTrap	33
1.61 icad2Subdev2MismatchAlarmTrap	33
1.62 icad2Subdev1NotPresentAlarmTrap	34
1.63 icad2Subdev2NotPresentAlarmTrap	34
1.64 icad2Subdev1FailureAlarmTrap	34
1.65 icad2Subdev2FailureAlarmTrap	34
1.66 smtGenDvStLostComWithItfTrap	34
1.67 smtGenDvStLoSTrap	34
1.68 smtGenDvStAiSTrap	34
1.69 smtGenDvStLoFTrap	34
1.70 smtGenDvStRalmTrap	35
1.71 smtGenDvStMfaTrap	35
1.72 smtGenDvStLomTrap	35
1.73 smtGenDvStCpuLoadThresholdTrap	35
1.74 smtGenDvStDiskUseThresholdTrap	35

1.75 smtGenDvStMemoryUseThresholdTrap	35
1.76 stMacSpoofingTrap	35
1.77 tLoginFailTrap	35
1.78 tLoginSucessTrap	36
1.79 tTxFaultTrap	36
1.80 cpuFWMismatchAlarmTrap	36
1.81 cardFWMismatchAlarmTrap	36
1.82 fwLoadByTftpAlarmTrap	36
1.83 trapLicenseWillExpire	36
1.84 trapLicenseExpired	36
1.85 uBootUpdateAvailAlarmTrap	36
1.86 swNonHomologSfpTrap	37
1.87 genDvTrapsInfMibVersion	37
1.87.1 genDvTrapsInfLastTrDevNo	37
1.87.2 genDvTrapsInfLastTrDevLocalId	37
1.87.3 genDvTrapsInfLastTrSlotNo	37
1.87.4 genDvTrapsInfLastTrPortNo	38
1.87.5 genDvTrapsInfLastTrValue	38
1.87.6 genDvTrapsInfLastTrType	38
1.87.7 genDvTrapsInfLastTrTimeStamp	38
1.87.8 genDvTrapsInfLastTrDeviceProduct	38
1.87.9 genDvTrapsInfLastTrAlarmId	39
1.87.10 genDvTrapsInfLastTrAlarmVal	39
1.87.11 genDvTrapsInfLastTrUserName	39
1.87.12 genDvTrapsInfLastTrAlarmSeverityVal	39
1.87.13 genDvTrapsInfLastTrChannel	40
1.87.14 genDvTrapLicenseSN	40
1.87.15 genDvTrapLicenseExpire	40
1.87.16 genDvTrapsInfLastTrValueVlan	40
1.87.17 genDvTrapsInfLastTrStringMac	41
1.87.18 genDvTrapsInfTable	41
2 DATACOM-GPON-TRAPS-MIB	43
2.1 dmAdGponTrapsInfLastTrapOnuID	43
2.2 dmAdGponTrapsInfLastTrapSwdlInfo	43
2.3 dmAdGponTrapsInfLastTrapOnuSN	43
2.4 gPonLOSiAlarm	44
2.5 gPonLOFiAlarm	44
2.6 gPonDOWiAlarm	44

2.7 gPonSFIAAlarm	44
2.8 gPonSDIAAlarm	44
2.9 gPonLCDGiAlarm	44
2.10 gPonRDiAlarm	45
2.11 gPonTFAlarm	45
2.12 gPonSUFiAlarm	45
2.13 gPonDFiAlarm	45
2.14 gPonLOAiAlarm	45
2.15 gPonDGiAlarm	45
2.16 gPonLOAMiAlarm	46
2.17 gPonMISiAlarm	46
2.18 gPonPEEiAlarm	46
2.19 gPonOnuEquipmentFailureAlarm	46
2.20 gPonOnuPowerFailureAlarm	46
2.21 gPonOnuBatteryMissingAlarm	46
2.22 gPonOnuBatteryFailureAlarm	47
2.23 gPonOnuBatteryLowAlarm	47
2.24 gPonOnuPhysicalIntrusionAlarm	47
2.25 gPonOnuSelfTestFailureAlarm	47
2.26 gPonOnuVoltageRedAlarm	47
2.27 gPonOnuDiscoveredEvent	47
2.28 gPonOnuPasswordMismatchAlarm	48
2.29 gPonOnuSwdlInProgressEvent	48
2.30 gPonLOBiAlarm	48
2.31 gPonLOPCiAlarm	48
2.32 gPonLOOCiAlarm	48
2.33 gPonTIWiAlarm	48
3 DATACOM-PING-MIB	49
3.1 pingProbeFailed	49
3.2 pingTestFailed	49
3.3 pingTestCompleted	49
3.4 pingMaxConcurrentRequests	50
3.5 pingCtlTable	50
3.5.1 pingCtlOwnerIndex	50
3.5.2 pingCtlTestName	51
3.5.3 pingCtlTargetAddressType	51
3.5.4 pingCtlTargetAddress	51
3.5.5 pingCtlDataSize	51

3.5.6 pingCtlTimeOut	52
3.5.7 pingCtlProbeCount	52
3.5.8 pingCtlAdminStatus	52
3.5.9 pingCtlDataFill	53
3.5.10 pingCtlFrequency	53
3.5.11 pingCtlMaxRows	53
3.5.12 pingCtlStorageType	54
3.5.13 pingCtlTrapGeneration	54
3.5.14 pingCtlTrapProbeFailureFilter	54
3.5.15 pingCtlTrapTestFailureFilter	55
3.5.16 pingCtlType	55
3.5.17 pingCtlDescr	55
3.5.18 pingCtlSourceAddressType	55
3.5.19 pingCtlSourceAddress	56
3.5.20 pingCtlIfIndex	56
3.5.21 pingCtlByPassRouteTable	56
3.5.22 pingCtlDSField	57
3.5.23 pingCtlRowStatus	57
3.6 pingResultsTable	57
3.6.1 pingResultsOperStatus	58
3.6.2 pingResultsIpTargetAddressType	58
3.6.3 pingResultsIpTargetAddress	58
3.6.4 pingResultsMinRtt	59
3.6.5 pingResultsMaxRtt	59
3.6.6 pingResultsAverageRtt	59
3.6.7 pingResultsProbeResponses	59
3.6.8 pingResultsSentProbes	60
3.6.9 pingResultsRttSumOfSquares	60
3.6.10 pingResultsLastGoodProbe	60
3.7 pingProbeHistoryTable	60
3.7.1 pingProbeHistoryIndex	61
3.7.2 pingProbeHistoryResponse	61
3.7.3 pingProbeHistoryStatus	61
3.7.4 pingProbeHistoryLastRC	61
3.7.5 pingProbeHistoryTime	62
3.8 pingCompliance	62
3.9 pingFullCompliance	62
3.10 pingMinimumCompliance	62
3.11 pingGroup	63

3.12 pingTimeStampGroup	63
3.13 pingNotificationsGroup	63
3.14 pingMinimumGroup	63
3.15 pingCtlRowStatusGroup	63
3.16 pingHistoryGroup	63
4 DATACOM-ROUTER-B-MIB	64
4.1 rtbInfltGprsTable	64
4.1.1 rtbInfltGprsDevNo	64
4.1.2 rtbInfltGprsDevLocalId	65
4.1.3 rtbInfltGprsSlotNo	65
4.1.4 rtbInfltGprsPortNo	65
4.1.5 rtbInfltGprsTainf	65
4.1.6 rtbInfltGprsTaConf	65
4.1.7 rtbInfltGprsTaSerial	66
4.1.8 rtbInfltGprsTaRegistry	66
4.1.9 rtbInfltGprsSimCardInf	66
4.1.10 rtbInfltGprsCellConn	66
4.1.11 rtbInfltGprsCellsMon	67
4.1.12 rtbInfltGprsNetInf	67
4.2 rtbStlftGenTable	67
4.2.1 rtbStlftGenDevNo	67
4.2.2 rtbStlftGenDevLocalId	67
4.2.3 rtbStlftGenSlotNo	68
4.2.4 rtbStlftGenPortNo	68
4.2.5 rtbStlftGenLink	68
4.2.6 rtbStlftGenIndex	68
4.3 rtbStlftAddTable	69
4.3.1 rtbStlftAddDevNo	69
4.3.2 rtbStlftAddDevLocalId	69
4.3.3 rtbStlftAddSlotNo	69
4.3.4 rtbStlftAddPortNo	70
4.3.5 rtbStlftAddLocal	70
4.3.6 rtbStlftAddRemote	70
4.4 rtbPerfHwStCpu	70
4.5 rtbPerfHwStMemory	70
4.6 rtbPerflftTable	71
4.6.1 rtbPerflftIndex	71
4.6.2 rtbPerflftDescr	71

4.6.3 rtbPerfltfOctets	71
4.6.4 rtbPerfltfPkts	72
4.6.5 rtbPerfltfCollisions	72
4.6.6 rtbPerfltfUtilization	72
4.6.7 rtbPerfltfDrop	72
4.6.8 rtbPerfltfError	73
4.6.9 rtbPerfltfRxDataRate	73
4.6.10 rtbPerfltfTxDataRate	73
4.6.11 rtbPerfltfRxDropRate	73
4.6.12 rtbPerfltfTxDropRate	73
4.7 rtbPerfQoSQueueTable	74
4.7.1 rtbPerfQoSQueueIndex	74
4.7.2 rtbPerfQoSQueueIrfDescr	74
4.7.3 rtbPerfQoSQueueMark	74
4.7.4 rtbPerfQoSQueueTxDataRate	75
4.7.5 rtbPerfQoSQueueTxPktDropRate	75
4.7.6 rtbPerfQoSQueueTrafficDescr	75
4.7.7 rtbPerfQoSQueueClassName	75
4.7.8 rtbPerfQoSQueuePriority	75
4.7.9 rtbPerfQoSQueueMinRate	76
4.7.10 rtbPerfQoSQueueMaxRate	76
4.7.11 rtbPerfQoSQueueDroppedBytes	76
4.7.12 rtbPerfQoSQueueSentBytes	76
4.7.13 rtbPerfQoSQueueEnqueuedBytes	77
4.7.14 rtbPerfQoSQueueTxDataRateBits	77
4.7.15 rtbPerfQoSQueueDroppedPkts	77
4.7.16 rtbPerfQoSQueueSentPkts	77
4.8 rtbConfigCopyProtocol	77
4.9 rtbConfigCopyServerAddress	78
4.10 rtbConfigCopyFileName	78
4.11 rtbConfigCopyDestFileType	78
4.12 rtbConfigCopyInitTransfer	79
4.13 rtbConfigCopyStatus	79
4.14 rtbConfigCopySave	79
4.15 rtbConfigCopyApplyType	79
4.16 rtbConfigCopyFileFormat	80
4.17 rtbConfigCopyOpType	80
4.18 rtbConfigCopyUser	80
4.19 rtbConfigCopyPassword	81

4.20 rtbLTESignalStrength	81
4.21 rtbLTEChannel	81
4.22 rtbLTENeighborTable	81
4.22.1 rtbLTENeighborIndex	82
4.22.2 rtbLTENeighborIndexNeighbor	82
4.22.3 rtbLTENeighborDescr	82
4.22.4 rtbLTENeighborRFChannelNumber	82
4.23 rtbLTENeighborCellsTable	83
4.23.1 rtbLTENeighborCellsIndex	83
4.23.2 rtbLTENeighborCellsPhysicalCellID	83
4.23.3 rtbLTENeighborCellsRSRQ	83
4.23.4 rtbLTENeighborCellsRSRP	84
4.23.5 rtbLTENeighborCellsRSSI	84
4.23.6 rtbLTENeighborCellsCellSelectionRXLevel	84
4.24 rtbLTEConnectionStatus	84
5 DATACOM-SMI	85
6 DMOS-AUTHENTICATION-NOTIFICATIONS-MIB	86
6.1 loginFail	86
6.2 loginSuccess	86
7 DMOS-BGP4-MIB	87
7.1 bgpPrefixCountersTable	87
7.1.1 bgpPrefixCountersRemoteAddressType	87
7.1.2 bgpPrefixCountersRemoteAddress	87
7.1.3 bgpPrefixCountersFamilyAfi	87
7.1.4 bgpPrefixCountersFamilySafi	88
7.1.5 bgpPrefixCountersInPrefixes	88
7.1.6 bgpPrefixCountersInAcceptedPrefixes	88
7.1.7 bgpPrefixCountersInRejectedPrefixes	88
7.1.8 bgpPrefixCountersOutPrefixes	89
7.1.9 bgpPrefixCountersOutAdvertisedPrefixes	89
7.1.10 bgpPrefixCountersInActivePrefixes	89
7.1.11 bgpPrefixCountersInPrefixesDeniedByPol	89
8 DMOS-CARDMGR-NOTIFICATIONS-MIB	90
8.1 dmosCardmgrAlarmTrapsGroup	90
8.2 cardNotProvisionedAlarmTrap	90
8.3 cardNotPresentAlarmTrap	90

8.4 cardRemovedAlarmTrap	90
8.5 cardMismatchAlarmTrap	90
8.6 cardInsertedTrap	91
8.7 cardRemovedTrap	91
8.8 fanModuleNotPresentAlarmTrap	91
8.9 cardUpdatedTrap	91
8.10 psuUnsupportedAlarmTrap	91
8.11 cardUninitializedAlarmTrap	91
9 DMOS-CFM-MIB	92
9.1 cfmDelayMeasurementProbeTable	92
9.1.1 cfmDelayMeasurementProbeId	92
9.2 cfmDelayMeasurementProbeSessionTable	92
9.2.1 cfmDelayMeasurementProbeSessionId	92
9.2.2 cfmDelayMeasurementProbeSessionPcp	93
9.2.3 cfmDelayMeasurementProbeSessionLastAvgDelay	93
9.2.4 cfmDelayMeasurementProbeSessionLastMinDelay	93
9.2.5 cfmDelayMeasurementProbeSessionLastMaxDelay	93
9.2.6 cfmDelayMeasurementProbeSessionLastAvgJitter	93
9.2.7 cfmDelayMeasurementProbeSessionLastMinJitter	94
9.2.8 cfmDelayMeasurementProbeSessionLastMaxJitter	94
9.2.9 cfmDelayMeasurementProbeSessionLastLossRatio	94
9.2.10 cfmDelayMeasurementProbeSessionLastPcpMismatchRatio	94
9.2.11 cfmDelayMeasurementProbeSessionAllAvgDelay	94
9.2.12 cfmDelayMeasurementProbeSessionAllMinDelay	95
9.2.13 cfmDelayMeasurementProbeSessionAllMaxDelay	95
9.2.14 cfmDelayMeasurementProbeSessionAllAvgJitter	95
9.2.15 cfmDelayMeasurementProbeSessionAllMinJitter	95
9.2.16 cfmDelayMeasurementProbeSessionAllMaxJitter	95
9.2.17 cfmDelayMeasurementProbeSessionAllLossRatio	96
9.2.18 cfmDelayMeasurementProbeSessionAllPcpMismatchRatio	96
10 DMOS-CONFIG-NOTIFICATIONS-MIB	97
10.1 configCommit	97
11 DMOS-CPU-NOTIFICATIONS-MIB	98
11.1 dmosCpuNotificationThreshold	98
11.2 dmosCpuNotificationInterval	98
11.3 dmosCpuNotificationValue	98
11.4 dmosCpuNotificationCoreId	99

11.5 dmosCpuAlarmInfoGroup	99
11.6 dmosCpuAlarmTrapsGroup	99
11.7 cpuLoadHighTrap	99
11.8 cpuCoreHighTrap	99
12 DMOS-EAPS	100
12.1 eapsStateTable	100
12.1.1 eapsDomainID	100
12.1.2 eapsDomainName	100
12.1.3 eapsDomainState	101
12.1.4 eapsDomainMode	101
12.1.5 eapsDomainPrimaryPortState	101
12.1.6 eapsDomainSecondaryPortState	101
12.1.7 eapsDomainHealthCheckState	102
12.2 eapsConfigTable	102
12.2.1 eapsCfgDomainID	102
12.2.2 eapsCfgDomainPrimaryPort	102
12.2.3 eapsCfgDomainSecondaryPort	103
13 DMOS-EDFA-MIB	104
13.1 edfaTable	104
13.1.1 edfaInterfaceName	104
13.1.2 edfaDescription	104
13.1.3 edfaInputPower	105
13.1.4 edfaOutputPower	105
13.1.5 edfaSignalPower	105
13.1.6 edfaGain	105
13.1.7 edfaAmplifier	105
13.1.8 edfaLdCurrent	106
13.1.9 edfaLdEolCurrent	106
13.1.10 edfaTecCurrent	106
13.1.11 edfaTecVoltage	106
13.1.12 edfaSupplyVoltage	107
13.1.13 edfaLdTemperature	107
13.1.14 edfaCaseTemperature	107
13.2 ramanTable	107
13.2.1 ramanInterfaceName	107
13.2.2 ramanInputPower	108
13.2.3 ramanOutputPower	108
13.2.4 ramanSignalPower	108

13.2.5 ramanAsePower	108
13.2.6 ramanReflectionPower	109
13.2.7 ramanGain	109
13.2.8 ramanAmplifier	109
13.2.9 ramanCaseTemperature	109
13.2.10 ramanPumpPower	109
13.2.11 ramanLdCurrent	110
13.2.12 ramanLdEolCurrent	110
13.2.13 ramanTecCurrent	110
13.2.14 ramanTecVoltage	110
13.2.15 ramanLdTemperature	111
13.2.16 ramanPumpPower2	111
13.2.17 ramanLdCurrent2	111
13.2.18 ramanLdEolCurrent2	111
13.2.19 ramanTecCurrent2	111
13.2.20 ramanTecVoltage2	112
13.2.21 ramanLdTemperature2	112
14 DMOS-ERPS-MIB	113
14.1 erpsStateTable	113
14.1.1 erpsRingId	113
14.1.2 erpsRingControlVlan	113
14.1.3 erpsRingName	114
14.1.4 erpsRingType	114
14.1.5 erpsRingParentRing	114
14.1.6 erpsRingState	114
14.1.7 erpsRingPort0	115
14.1.8 erpsRingPort0RplRole	115
14.1.9 erpsRingPort0LocalFailure	115
14.1.10 erpsRingPort0State	115
14.1.11 erpsRingPort1	116
14.1.12 erpsRingPort1RplRole	116
14.1.13 erpsRingPort1LocalFailure	116
14.1.14 erpsRingPort1State	116
15 DMOS-EXPERIMENTAL-NOTIFICATIONS-MIB	117
16 DMOS-EXPERIMENTAL-TEST-NOTIFICATIONS-MIB	118
16.1 testParamUint32	118
16.2 testParamInt32	118

16.3 testParamStr	119
16.4 testParamFloat	119
17 DMOS-GPON-NOTIFICATIONS-MIB	120
17.1 dmosGponAlarmTrapsGroup	120
17.2 gPonOnuAutoProvAddFailTrap	120
18 DMOS-HW-MONITOR-MIB	121
18.1 environmentChassisTable	121
18.1.1 environmentChassisId	121
18.2 environmentSlotTable	121
18.2.1 environmentSlotId	122
18.3 temperatureSensorTable	122
18.3.1 temperatureSensorId	122
18.3.2 temperatureSensorDescription	122
18.3.3 temperatureSensorMaxTemperature	122
18.3.4 temperatureSensorMinTemperature	123
18.3.5 temperatureSensorHysteresis	123
18.3.6 temperatureSensorCurrentTemperature	123
18.3.7 temperatureSensorTemperatureReadError	123
18.3.8 temperatureSensorTemperatureStatus	124
18.4 fanTable	124
18.4.1 fanId	124
18.4.2 fanDescription	124
18.4.3 fanSpeed	124
18.4.4 fanSpeedReadError	125
18.4.5 fanSpeedStatus	125
18.5 psuTable	125
18.5.1 psuId	125
18.5.2 psuStatus	126
19 DMOS-HW-MONITOR-NOTIFICATIONS-MIB	127
19.1 dmosHwMonValue	127
19.2 dmosHwMonLimitValue	127
19.3 dmosHwMonAlarmInfoGroup	127
19.4 dmosFanAlarmTrapsGroup	127
19.5 dmosTempAlarmTrapsGroup	128
19.6 dmosPsuAlarmTrapsGroup	128
19.7 fanHighAlarmTrap	128
19.8 fanLowAlarmTrap	128

19.9 fanFailAlarmTrap	128
19.10 fanErrorAlarmTrap	128
19.11 tempHighAlarmTrap	129
19.12 tempLowAlarmTrap	129
19.13 tempErrorAlarmTrap	129
19.14 tempCriticalAlarmTrap	129
19.15 psuPowerInputFailureAlarmTrap	129
19.16 psuFuseFailureAlarmTrap	129
19.17 psuErrorAlarmTrap	130
20 DMOS-INVENTORY-FAILURE-MIB	131
20.1 inventoryErrorTrap	131
21 DMOS-INVENTORY-MIB	132
21.1 chassisTable	132
21.1.1 chassisChassisId	132
21.1.2 chassisProductName	132
21.1.3 chassisPartNumber	132
21.1.4 chassisSerialNumber	133
21.1.5 chassisVendor	133
21.1.6 chassisProductModel	133
21.1.7 chassisProductRevision	133
21.1.8 chassisPcbRevision	134
21.1.9 chassisHardwareVersion	134
21.1.10 chassisOperationTemperature	134
21.1.11 chassisSystemMacAddress	134
21.1.12 chassisFactoryStatus	134
21.1.13 chassisNumMaintenance	135
21.1.14 chassisItemsMaintenance	135
21.1.15 chassisDateLastMaintenance	135
21.1.16 chassisCardSpecific	135
21.1.17 chassisFirmwareRevision	136
21.1.18 chassisInventoryState	136
21.2 chassisSlotTable	136
21.2.1 chassisSlotSlotId	136
21.2.2 chassisSlotId	136
21.2.3 chassisSlotCardPartNumber	137
21.2.4 chassisSlotCardSerialNumber	137
21.2.5 chassisSlotCardVendor	137
21.2.6 chassisSlotCardProductModel	137

21.2.7 chassisSlotCardProductRevision	138
21.2.8 chassisSlotCardPcbRevision	138
21.2.9 chassisSlotCardHardwareVersion	138
21.2.10 chassisSlotCardOperationTemperature	138
21.2.11 chassisSlotCardSystemMacAddress	138
21.2.12 chassisSlotCardFactoryStatus	139
21.2.13 chassisSlotCardNumMaintenance	139
21.2.14 chassisSlotCardItemsMaintenance	139
21.2.15 chassisSlotCardDateLastMaintenance	139
21.2.16 chassisSlotCardCardSpecific	140
21.2.17 chassisSlotCardFirmwareRevision	140
21.2.18 chassisSlotCardInventoryState	140
21.3 transceiverInventoryTable	140
21.3.1 transceiverInventoryIfIndex	140
21.3.2 transceiverInventoryInfoType	141
21.3.3 transceiverInventoryInfoConnector	141
21.3.4 transceiverInventoryInfoEthernetStandards	141
21.3.5 transceiverInventoryInfoVendorName	141
21.3.6 transceiverInventoryInfoVendorSn	142
21.3.7 transceiverInventoryInfoVendorPn	142
21.3.8 transceiverInventoryInfoLaserWavelength	142
21.3.9 transceiverInventoryInfoDiagnostics	142
21.3.10 transceiverInventoryInfoTemperatureThresholdsAlarmLow	143
21.3.11 transceiverInventoryInfoTemperatureThresholdsAlarmHigh	143
21.3.12 transceiverInventoryInfoTemperatureThresholdsWarningLow	143
21.3.13 transceiverInventoryInfoTemperatureThresholdsWarningHigh	143
21.3.14 transceiverInventoryInfoRxPowerThresholdsAlarmLow	144
21.3.15 transceiverInventoryInfoRxPowerThresholdsAlarmHigh	144
21.3.16 transceiverInventoryInfoRxPowerThresholdsWarningLow	144
21.3.17 transceiverInventoryInfoRxPowerThresholdsWarningHigh	144
21.3.18 transceiverInventoryInfoTxPowerThresholdsAlarmLow	144
21.3.19 transceiverInventoryInfoTxPowerThresholdsAlarmHigh	145
21.3.20 transceiverInventoryInfoTxPowerThresholdsWarningLow	145
21.3.21 transceiverInventoryInfoTxPowerThresholdsWarningHigh	145
21.3.22 transceiverInventoryInfoVcc3v3ThresholdsAlarmLow	145
21.3.23 transceiverInventoryInfoVcc3v3ThresholdsAlarmHigh	146
21.3.24 transceiverInventoryInfoVcc3v3ThresholdsWarningLow	146
21.3.25 transceiverInventoryInfoVcc3v3ThresholdsWarningHigh	146
21.3.26 transceiverInventoryInfoTxBiasThresholdsAlarmLow	146

21.3.27 transceiverInventoryInfoTxBiasThresholdsAlarmHigh	146
21.3.28 transceiverInventoryInfoTxBiasThresholdsWarningLow	147
21.3.29 transceiverInventoryInfoTxBiasThresholdsWarningHigh	147
21.3.30 transceiverInventoryInfoPhysicalMedia	147
21.3.31 transceiverInventoryInfoReadOk	147
21.3.32 transceiverInventoryInfoFiberType	148
22 DMOS-LBD-NOTIFICATIONS-MIB	149
22.1 dmosLbdAlarmTrapsGroup	149
22.2 loopbackDetectedAlarmTrap	149
23 DMOS-LFD-NOTIFICATIONS-MIB	150
23.1 dmosLfdAlarmTrapsGroup	150
23.2 linkFlapDetectedAlarmTrap	150
24 DMOS-LINE-PROTECTION-MIB	151
24.1 lineProtectionTable	151
24.1.1 interfaceName	151
24.1.2 description	151
24.1.3 mode	151
24.1.4 activeLine	152
24.1.5 powerThresholdLine1	152
24.1.6 inputPowerLine1	152
24.1.7 powerThresholdLine2	152
24.1.8 inputPowerLine2	153
25 DMOS-MEM-NOTIFICATIONS-MIB	154
25.1 dmosMemNotificationThreshold	154
25.2 dmosMemNotificationInterval	154
25.3 dmosMemAlarmInfoGroup	154
25.4 dmosMemAlarmTrapsGroup	154
25.5 memAvailableLowTrap	155
26 DMOS-NOTIFICATIONS-MIB	156
26.1 notificationTime	156
26.2 notificationName	156
26.3 notificationSourceType	156
26.4 notificationSourceValue	157
26.5 notificationSeverity	157
26.6 notificationInfo	157
26.7 notificationAlarmState	157

26.8 infoNotificationGroup	157
26.9 alarmNotificationGroup	158
27 DMOS-ONU-COUNTING-MIB	159
27.1 ponIfGlobalTotalOnus	159
27.2 ponIfGlobalNonProvisionedOnus	159
27.3 ponIfGlobalUpOnus	159
27.4 ponIfGlobalDownOnus	160
27.5 ponIfTable	160
27.5.1 ponIfIndex	160
27.5.2 ponIfDescr	160
27.5.3 ponIfTotalOnus	161
27.5.4 ponIfNonProvisionedOnus	161
27.5.5 ponIfUpOnus	161
27.5.6 ponIfDownOnus	161
27.6 ponIfDiscoveredOnusTable	162
27.6.1 ponIfIndexDiscoveredOnus	162
27.6.2 id	162
27.6.3 onuSerialNumber	162
28 DMOS-POLICER-MIB	163
28.1 policerInstanceTable	163
28.1.1 policerInstanceInstanceld	163
28.1.2 policerInstanceProfile	163
28.1.3 policerInstanceMode	163
28.1.4 policerInstanceStage	164
28.1.5 policerInstanceCir	164
28.1.6 policerInstanceEir	164
28.1.7 policerInstancePir	164
28.1.8 policerInstanceForwarded	165
28.1.9 policerInstanceDropped	165
28.2 policerInstanceInterfaceTable	165
28.2.1 policerInstanceInterfaceIfIndex	165
28.2.2 policerInstanceInterfaceIfName	165
29 DMOS-REBOOT-MIB	167
29.1 rebootReason	167
30 DMOS-REDUNDANCY-NOTIFICATIONS-MIB	168
30.1 dmosRedundancyAlarmTrapsGroup	168

30.2 controllerRedundancyFailureAlarmTrap	168
31 DMOS-SYSMON-MIB	169
31.1 cpuChassisTable	169
31.1.1 cpuChassisId	169
31.2 cpuSlotTable	169
31.2.1 cpuSlotId	170
31.2.2 cpuLoadFiveSecondsActive	170
31.2.3 cpuLoadFiveSecondsIdle	170
31.2.4 cpuLoadOneMinuteActive	170
31.2.5 cpuLoadOneMinuteIdle	170
31.2.6 cpuLoadFiveMinutesActive	171
31.2.7 cpuLoadFiveMinutesIdle	171
31.3 cpuCoreTable	171
31.3.1 cpuCoreCoreId	171
31.3.2 cpuCoreFiveSecondsActive	172
31.3.3 cpuCoreFiveSecondsUser	172
31.3.4 cpuCoreFiveSecondsSystem	172
31.3.5 cpuCoreFiveSecondsNice	172
31.3.6 cpuCoreFiveSecondsIdle	172
31.3.7 cpuCoreFiveSecondsWait	173
31.3.8 cpuCoreFiveSecondsInterrupt	173
31.3.9 cpuCoreFiveSecondsSoftirq	173
31.3.10 cpuCoreOneMinuteActive	173
31.3.11 cpuCoreOneMinuteUser	174
31.3.12 cpuCoreOneMinuteSystem	174
31.3.13 cpuCoreOneMinuteNice	174
31.3.14 cpuCoreOneMinuteIdle	174
31.3.15 cpuCoreOneMinuteWait	174
31.3.16 cpuCoreOneMinuteInterrupt	175
31.3.17 cpuCoreOneMinuteSoftirq	175
31.3.18 cpuCoreFiveMinutesActive	175
31.3.19 cpuCoreFiveMinutesUser	175
31.3.20 cpuCoreFiveMinutesSystem	176
31.3.21 cpuCoreFiveMinutesNice	176
31.3.22 cpuCoreFiveMinutesIdle	176
31.3.23 cpuCoreFiveMinutesWait	176
31.3.24 cpuCoreFiveMinutesInterrupt	176
31.3.25 cpuCoreFiveMinutesSoftirq	177

31.4 cpuSysUptime	177
31.5 memoryChassisTable	177
31.5.1 memoryChassisId	177
31.6 memorySlotTable	178
31.6.1 memorySlotId	178
31.6.2 memoryFiveSecondsTotal	178
31.6.3 memoryFiveSecondsUsed	178
31.6.4 memoryFiveSecondsFree	178
31.6.5 memoryFiveSecondsBuffered	179
31.6.6 memoryFiveSecondsCached	179
31.6.7 memoryFiveSecondsAvailable	179
31.6.8 memoryFiveSecondsSlabRecl	179
31.6.9 memoryFiveSecondsSlabUnrecl	180
31.6.10 memoryFiveMinutesTotal	180
31.6.11 memoryFiveMinutesUsed	180
31.6.12 memoryFiveMinutesFree	180
31.6.13 memoryFiveMinutesBuffered	180
31.6.14 memoryFiveMinutesCached	181
31.6.15 memoryFiveMinutesAvailable	181
31.6.16 memoryFiveMinutesSlabRecl	181
31.6.17 memoryFiveMinutesSlabUnrecl	181
31.6.18 memoryThirtyMinutesTotal	182
31.6.19 memoryThirtyMinutesUsed	182
31.6.20 memoryThirtyMinutesFree	182
31.6.21 memoryThirtyMinutesBuffered	182
31.6.22 memoryThirtyMinutesCached	182
31.6.23 memoryThirtyMinutesAvailable	183
31.6.24 memoryThirtyMinutesSlabRecl	183
31.6.25 memoryThirtyMinutesSlabUnrecl	183
31.6.26 memoryOneMinuteTotal	183
31.6.27 memoryOneMinuteUsed	184
31.6.28 memoryOneMinuteFree	184
31.6.29 memoryOneMinuteBuffered	184
31.6.30 memoryOneMinuteCached	184
31.6.31 memoryOneMinuteAvailable	184
31.6.32 memoryOneMinuteSlabRecl	185
31.6.33 memoryOneMinuteSlabUnrecl	185
31.6.34 memoryFiveSecondsTotalKB	185
31.6.35 memoryFiveSecondsUsedKB	185

31.6.36 memoryFiveSecondsFreeKB	186
31.6.37 memoryFiveSecondsBufferedKB	186
31.6.38 memoryFiveSecondsCachedKB	186
31.6.39 memoryFiveSecondsAvailableKB	186
31.6.40 memoryFiveSecondsSlabReclKB	186
31.6.41 memoryFiveSecondsSlabUnreclKB	187
31.6.42 memoryFiveMinutesTotalKB	187
31.6.43 memoryFiveMinutesUsedKB	187
31.6.44 memoryFiveMinutesFreeKB	187
31.6.45 memoryFiveMinutesBufferedKB	188
31.6.46 memoryFiveMinutesCachedKB	188
31.6.47 memoryFiveMinutesAvailableKB	188
31.6.48 memoryFiveMinutesSlabReclKB	188
31.6.49 memoryFiveMinutesSlabUnreclKB	188
31.6.50 memoryThirtyMinutesTotalKB	189
31.6.51 memoryThirtyMinutesUsedKB	189
31.6.52 memoryThirtyMinutesFreeKB	189
31.6.53 memoryThirtyMinutesBufferedKB	189
31.6.54 memoryThirtyMinutesCachedKB	190
31.6.55 memoryThirtyMinutesAvailableKB	190
31.6.56 memoryThirtyMinutesSlabReclKB	190
31.6.57 memoryThirtyMinutesSlabUnreclKB	190
31.6.58 memoryOneMinuteTotalKB	190
31.6.59 memoryOneMinuteUsedKB	191
31.6.60 memoryOneMinuteFreeKB	191
31.6.61 memoryOneMinuteBufferedKB	191
31.6.62 memoryOneMinuteCachedKB	191
31.6.63 memoryOneMinuteAvailableKB	192
31.6.64 memoryOneMinuteSlabReclKB	192
31.6.65 memoryOneMinuteSlabUnreclKB	192

32 DMOS-TC-MIB 193

33 DMOS-TRANSCEIVER-MIB 194

33.1 transceiverTable	194
33.1.1 temperature	194
33.1.2 voltage	194
33.1.3 laneCount	195
33.1.4 osnr	195
33.1.5 prefec	195

33.1.6 ferc	195
33.1.7 qvalue	196
33.1.8 qfactor	196
33.1.9 chromaticDispersion	196
33.2 transceiverLaneTable	197
33.2.1 laneIndex	197
33.2.2 laneRxPower	197
33.2.3 laneTxPower	197
33.2.4 laneTxBias	197
34 DMOS-USER-DEFINED-COUNTERS	199
34.1 countersIngressTable	199
34.1.1 countersIngressId	199
34.1.2 countersIngressDescription	199
34.1.3 countersIngressValue	199
34.1.4 countersIngressType	200
34.2 countersEgressTable	200
34.2.1 countersEgressId	200
34.2.2 countersEgressDescription	200
34.2.3 countersEgressValue	201
34.2.4 countersEgressType	201
35 GPON-ONU-IF-MIB	202
35.1 onulfTable	202
35.1.1 onuifIndex	202
35.1.2 onuifDescr	202
35.1.3 onuifType	203
35.1.4 onuifName	204
35.1.5 onuifAdminStatus	204
35.1.6 onuifOperStatus	204
35.1.7 onulfStatisticsInOctets	205
35.1.8 onulfStatisticsInUcastPkts	205
35.1.9 onulfStatisticsInMulticastPkts	205
35.1.10 onulfStatisticsInBroadcastPkts	205
35.1.11 onulfStatisticsInDiscards	205
35.1.12 onulfStatisticsInErrors	206
35.1.13 onulfStatisticsInUnknownProtos	206
35.1.14 onulfStatisticsOutOctets	206
35.1.15 onulfStatisticsOutUcastPkts	206
35.1.16 onulfStatisticsOutMulticastPkts	207

35.1.17 onulfStatisticsOutBroadcastPkts	207
35.1.18 onulfStatisticsOutDiscards	207
35.1.19 onulfStatisticsOutErrors	207
35.1.20 onulfOnuPowerTx	207
35.1.21 onulfOnuPowerRx	208
35.1.22 onulfAlias	208
35.1.23 onulfStatisticsInBwUsage	208
35.1.24 onulfStatisticsOutBwUsage	208
35.1.25 onuSysUpTime	209
35.1.26 onuGemInOctets	209
35.1.27 onuGemInPackets	209
35.1.28 onuGemOutOctets	209
35.1.29 onuGemOutPackets	209
36 TWAMP-MIB	211
36.1 twampSessionTable	211
36.1.1 twampSessionId	211
36.1.2 twampSessionDuration	211
36.1.3 twampSessionInterval	212
36.1.4 twampSessionState	212
36.1.5 twampSessionSrcAddr	212
36.1.6 twampSessionDstAddr	212
36.1.7 twampSessionDstPort	213
36.1.8 twampSessionPktSize	213
36.1.9 twampSessionDSCP	213
36.1.10 twampSessionTotalTests	213
36.1.11 twampSessionTotalTxPkts	214
36.1.12 twampSessionTotalRxPkts	214
36.1.13 twampSessionDescription	214
36.2 twampTestTable	214
36.2.1 twampTestSessionId	215
36.2.2 twampTestIndex	215
36.2.3 twampTestId	215
36.2.4 twampTestDelayMin	215
36.2.5 twampTestDelayMax	216
36.2.6 twampTestDelayAvg	216
36.2.7 twampTestJitterMin	216
36.2.8 twampTestJitterMax	216
36.2.9 twampTestJitterAvg	216

36.2.10 twampTestTxPkts	217
36.2.11 twampTestRxPkts	217
36.2.12 twampTestLossRatio	217
36.2.13 twampTestConnectivity	217
36.2.14 twampTestRoundTripDelayMin	218
36.2.15 twampTestRoundTripDelayMax	218
36.2.16 twampTestRoundTripDelayAvg	218
36.2.17 twampTestState	218
36.2.18 twampTestDescription	218
36.3 twampFarEndTestTable	219
36.3.1 twampFarEndTestSessionId	219
36.3.2 twampFarEndTestIndex	219
36.3.3 twampFarEndTestId	219
36.3.4 twampFarEndTestDelayMin	220
36.3.5 twampFarEndTestDelayMax	220
36.3.6 twampFarEndTestDelayAvg	220
36.3.7 twampFarEndTestJitterMin	220
36.3.8 twampFarEndTestJitterMax	221
36.3.9 twampFarEndTestJitterAvg	221
36.3.10 twampFarEndTestTxPkts	221
36.3.11 twampFarEndTestRxPkts	221
36.3.12 twampFarEndTestLossRatio	221
36.3.13 twampFarEndTestConnectivity	222
36.4 twampNearEndTestTable	222
36.4.1 twampNearEndTestSessionId	222
36.4.2 twampNearEndTestIndex	222
36.4.3 twampNearEndTestId	223
36.4.4 twampNearEndTestDelayMin	223
36.4.5 twampNearEndTestDelayMax	223
36.4.6 twampNearEndTestDelayAvg	223
36.4.7 twampNearEndTestJitterMin	224
36.4.8 twampNearEndTestJitterMax	224
36.4.9 twampNearEndTestJitterAvg	224
36.4.10 twampNearEndTestTxPkts	224
36.4.11 twampNearEndTestRxPkts	224
36.4.12 twampNearEndTestLossRatio	225
36.4.13 twampNearEndTestConnectivity	225

Legal Note**226**

Warranty	226
-----------------	------------

1 DATACOM-GENERIC-DEVICE-TRAPS-MIB

MIB file: DATACOM-GENERIC-DEVICE-TRAPS-MIB.mib

This MIB file has the following root objects:

- **datacomGenDvTrapsMIBModule**
 - **OID:** 1.3.6.1.4.1.3709.1.1.24
- **dmGenDvTrapsMIB**
 - **OID:** 1.3.6.1.4.1.3709.2.4
 - **Object identities:**
 - dmGenDvTrapsInf (1.3.6.1.4.1.3709.2.4.1)

1.1 mtGenDvInfInsertedDevTrap

OID: 1.3.6.1.4.1.3709.2.4.0.1

Description: This trap is sent every time an remote device is inserted.

1.2 mtGenDvInfRemovedDevTrap

OID: 1.3.6.1.4.1.3709.2.4.0.2

Description: This trap is sent every time an remote device is removed.

1.3 mtGenDvStSnmppManagementStatusTrap

OID: 1.3.6.1.4.1.3709.2.4.0.51

Description: This trap is sent every time the genDvtSnmppManagementStatus object changes its state.

1.4 mtGenDvStLatchedPossibleNewCfgTrap

OID: 1.3.6.1.4.1.3709.2.4.0.52

Description: This trap is sent every time the genDvtLatchedPossibleNewCfg object changes its state. Values: 1 none 2 possibleNewConfig

1.5 agFwRemDownTempMemTrap

OID: 1.3.6.1.4.1.3709.2.4.0.61

Description: This trap is sent every time the dmAgFwRemDownTempMem object changes its state.

1.6 agFwRemDownActionStTrap

OID: 1.3.6.1.4.1.3709.2.4.0.62

Description: This trap is sent every time the dmAgFwRemDownActionSt object changes its state.

1.7 mtGenDvInfNumPortsTrap

OID: 1.3.6.1.4.1.3709.2.4.0.100

Description: This trap indicates device's port state 2 - fail interface on slot. 3 - unknown interface on slot.

1.8 mtGenDvInfTempRangeTrap

OID: 1.3.6.1.4.1.3709.2.4.0.601

Description: This trap is sent every time the temperature is out of range. Values: 1 Temperature inside range 2 Temperature above limit 3 Temperature below limit 4 Shutdown temperature

1.9 mtGenDvInfFanFailTrap

OID: 1.3.6.1.4.1.3709.2.4.0.611

Description: This trap is sent every time Fan fails. Values: 1 Fan working properly 2 Fan failure

1.10 mtGenDvInfInsertedPortTrap

OID: 1.3.6.1.4.1.3709.2.4.0.701

Description: This trap is sent every time an interface is inserted in device.

1.11 mtGenDvInfRemovedPortTrap

OID: 1.3.6.1.4.1.3709.2.4.0.702

Description: This trap is sent every time an interface is removed from device.

1.12 mtGenDvInfPortConfigModeTrap

OID: 1.3.6.1.4.1.3709.2.4.0.809

Description: This trap is sent every time there is a change at the interface config mode object.

1.13 mtGenDvInfPowerStatusTrap

OID: 1.3.6.1.4.1.3709.2.4.0.901

Description: This trap is sent every time Power Status change.

1.14 smtGenDvStLinkStatusTribE1PpiExcSlipTrap

OID: 1.3.6.1.4.1.3709.2.4.0.13018

Description: This trap is sent every time the link STATUS object changes its value.

1.15 smtGenDvStLinkStatusDigitalItfExcSlipTrap

OID: 1.3.6.1.4.1.3709.2.4.0.13204

Description: This trap is sent every time the link STATUS object changes its value.

1.16 smtGenDvStLinkStatusDslExcSlipTrap

OID: 1.3.6.1.4.1.3709.2.4.0.13304

Description: This trap is sent every time the link STATUS object changes its value.

1.17 smtGenDvStPhSlotStFailFanFailTrap

OID: 1.3.6.1.4.1.3709.2.4.0.16002

Description: This trap is sent every time the local status fail object changes its value.

1.18 smtGenDvStPhSlotStFailFanMismatchTrap

OID: 1.3.6.1.4.1.3709.2.4.0.16007

Description: This trap is sent every time the local status fail object changes its value.

1.19 smtGenDvStPhSlotStFailPwrSuppFailTrap

OID: 1.3.6.1.4.1.3709.2.4.0.16102

Description: This trap is sent every time the local status fail object changes its value.

1.20 smtGenDvStPhSlotStFailPwrRedundancyFailTrap

OID: 1.3.6.1.4.1.3709.2.4.0.16103

Description: This trap is sent every time the local status fail object changes its value.

1.21 smtGenDvStPhSlotStFailPwrOverloadTrap

OID: 1.3.6.1.4.1.3709.2.4.0.16104

Description: This trap is sent every time the local status fail object changes its value.

1.22 smtGenDvStPhSlotStFailFuseFailTrap

OID: 1.3.6.1.4.1.3709.2.4.0.16105

Description: This trap is sent every time the local status fail object changes its value.

1.23 smtGenDvEthernetOverloadTrap

OID: 1.3.6.1.4.1.3709.2.4.0.16111

Description: This trap is sent every time the local status fail object changes its value.

1.24 smtGenDvStPhSlotStFailAggFailTrap

OID: 1.3.6.1.4.1.3709.2.4.0.16122

Description: This trap is sent every time the local status fail object changes its value.

1.25 smtGenDvStPhSlotOperStAggPrevMaintReqTrap

OID: 1.3.6.1.4.1.3709.2.4.0.16126

Description: This trap is sent every time the local operational status object changes its value.

1.26 smtGenDvStPhSlotStFailTribFailTrap

OID: 1.3.6.1.4.1.3709.2.4.0.16132

Description: This trap is sent every time the local status fail object changes its value.

1.27 smtGenDvStPhSlotPresenceTrap

OID: 1.3.6.1.4.1.3709.2.4.0.17001

Description: This trap is sent every time the local presence object changes its value. Values are 1 : CardRemoved 2: CardInserted

1.28 smtGenDvStCurrentDevCpuFWUpdateFailure

OID: 1.3.6.1.4.1.3709.2.4.0.17007

Description: This trap is sent every time the local presence object changes its value.

1.29 smtGenDvStCurrentDevCpuFWInvalidInactive

OID: 1.3.6.1.4.1.3709.2.4.0.17009

Description: This trap is sent every time the local presence object changes its value. Values: 1 Firmware inactive valid 2 Firmware inactive invalid

1.30 smtGenDvStCurrentDevCpuFWImageTemporary

OID: 1.3.6.1.4.1.3709.2.4.0.17010

Description: This trap is sent every time the local presence object changes its value.

1.31 smtGenDvStCurrentDevCpuFWUpdateBeginning

OID: 1.3.6.1.4.1.3709.2.4.0.17011

Description: This trap is sent every time the local presence object changes its value.

1.32 smtGenDvStPhSlotStFailCpuFailTrap

OID: 1.3.6.1.4.1.3709.2.4.0.17012

Description: This trap is sent every time the local status fail object changes its value.

1.33 smtGenDvStPhSlotStFailCriticalTempTrap

OID: 1.3.6.1.4.1.3709.2.4.0.17013

Description: This trap is sent every time the local status fail object changes its value.

1.34 smtsdhStCurrentDevCpuFWUpdateReady

OID: 1.3.6.1.4.1.3709.2.4.0.17015

Description: This trap is sent every time the local presence object changes its value.

1.35 smtsdhStCurrentDevFWVersionChanged

OID: 1.3.6.1.4.1.3709.2.4.0.17020

Description: Firmware version changed. Values: genDvTrapsInfObjIntegerVal 2 = FW Version Changed

1.36 smtGenDvStPhSlotStCardRemovedTrap

OID: 1.3.6.1.4.1.3709.2.4.0.17022

Description: This trap is sent every time the local status object changes its value.

1.37 smtGenDvStPhSlotStCardMismatchTrap

OID: 1.3.6.1.4.1.3709.2.4.0.17023

Description: This trap is sent every time the local status object changes its value.

1.38 smtGenDvStPhSlotStCardDisabledTrap

OID: 1.3.6.1.4.1.3709.2.4.0.17024

Description: This trap is sent every time the local status object changes its value.

1.39 smtGenDvStPhSlotStUnsupportedCardTrap

OID: 1.3.6.1.4.1.3709.2.4.0.17025

Description: This trap is sent every time the local status object changes its value.

1.40 smtGenDvStPhSlotStCardConfigMismatch

OID: 1.3.6.1.4.1.3709.2.4.0.17026

Description: This trap is sent every time the local status object changes its value.

1.41 smtGenDvStPhSlotStCardFail

OID: 1.3.6.1.4.1.3709.2.4.0.17027

Description: This trap is sent every time the local status object changes its value.

1.42 smtGenDvStPhSlotStCardFwMismatch

OID: 1.3.6.1.4.1.3709.2.4.0.17028

Description: This trap is sent every time the local status object changes its value.

1.43 smtGenDvStPhSlotStCardCriticalTemp

OID: 1.3.6.1.4.1.3709.2.4.0.17029

Description: This trap is sent every time the local status object changes its value.

1.44 smtGenDvStPhSlotStCardHwConfigFail

OID: 1.3.6.1.4.1.3709.2.4.0.17030

Description: This trap is sent every time the local status object changes its value.

1.45 smtGenDvStPhSlotStCardHwProtected

OID: 1.3.6.1.4.1.3709.2.4.0.17031

Description: This trap is sent every time the local status object changes its value.

1.46 smtGenDvStPhSlotStCardVendorMismatch

OID: 1.3.6.1.4.1.3709.2.4.0.17032

Description: This trap is sent every time the local status object changes its value.

1.47 smtGenDvStLastChangeTmTrap

OID: 1.3.6.1.4.1.3709.2.4.0.17151

Description: This trap is sent every time the local equipment time change its value (configuration).

1.48 smtGenDvStLastActivationTrap

OID: 1.3.6.1.4.1.3709.2.4.0.17171

Description: This trap is sent every time the local up time of last configuration activated object changes its value.

1.49 smtGenDvStUserListChangedTrap

OID: 1.3.6.1.4.1.3709.2.4.0.17172

Description: This trap is sent every time an remote device is removed.

1.50 smtGenDvStCpuActiveTrap

OID: 1.3.6.1.4.1.3709.2.4.0.17191

Description: This trap is sent every time the cpu becomes active.

1.51 smtGenDvStCpuColdStartTrap

OID: 1.3.6.1.4.1.3709.2.4.0.17192

Description: This trap is sent every time the cpu starts up after a power-off state.

1.52 smtGenDvStCpuWarmStartTrap

OID: 1.3.6.1.4.1.3709.2.4.0.17193

Description: This trap is sent every time the cpu starts up after a software reset.

1.53 smtGenDvInInsertedDevTrap

OID: 1.3.6.1.4.1.3709.2.4.0.20001

Description: This trap is sent every time an remote device is inserted.

1.54 smtGenDvInfRemovedDevTrap

OID: 1.3.6.1.4.1.3709.2.4.0.20002

Description: This trap is sent every time an remote device is removed.

1.55 sFPmismatchAlarmTrap

OID: 1.3.6.1.4.1.3709.2.4.0.21003

Description: This trap is sent when an SFP is mismatched.

1.56 sFPvendorMismatchAlarmTrap

OID: 1.3.6.1.4.1.3709.2.4.0.21007

Description: This trap is sent when a not approved sfp is inserted in the equipment.

1.57 configTemporaryAlarmTrap

OID: 1.3.6.1.4.1.3709.2.4.0.21101

Description: This trap is sent when a temporary config alarm changes its value.

1.58 edfaFailureAlarmTrap

OID: 1.3.6.1.4.1.3709.2.4.0.22014

Description: This trap is sent when the EDFA alarm changes its value.

1.59 edfaLowInputPowerFailureAlarmTrap

OID: 1.3.6.1.4.1.3709.2.4.0.22015

Description: This trap is sent when the EDFA-Low_Input_Power alarm changes its value.

1.60 icad2Subdev1MismatchAlarmTrap

OID: 1.3.6.1.4.1.3709.2.4.0.22101

Description: This trap is sent when the Icad2-Subdev_1_Mismatch alarm changes its value.

1.61 icad2Subdev2MismatchAlarmTrap

OID: 1.3.6.1.4.1.3709.2.4.0.22102

Description: This trap is sent when the Icad2-Subdev_2_Mismatch alarm changes its value.

1.62 icad2Subdev1NotPresentAlarmTrap

OID: 1.3.6.1.4.1.3709.2.4.0.22103

Description: This trap is sent when the Icad2-Subdev_1_Not_Present alarm changes its value.

1.63 icad2Subdev2NotPresentAlarmTrap

OID: 1.3.6.1.4.1.3709.2.4.0.22104

Description: This trap is sent when the Icad2-Subdev_2_Not_Present alarm changes its value.

1.64 icad2Subdev1FailureAlarmTrap

OID: 1.3.6.1.4.1.3709.2.4.0.22105

Description: This trap is sent when the Icad2-Subdev_1_Failure alarm changes its value.

1.65 icad2Subdev2FailureAlarmTrap

OID: 1.3.6.1.4.1.3709.2.4.0.22106

Description: This trap is sent when the Icad2-Subdev_2_Failure alarm changes its value.

1.66 smtGenDvStLostComWithItfTrap

OID: 1.3.6.1.4.1.3709.2.4.0.30000

Description: This trap is sent every time the communication with interface module is lost.

1.67 smtGenDvStLoSTrap

OID: 1.3.6.1.4.1.3709.2.4.0.30001

Description: This trap is sent every time a loss of signal is detected.

1.68 smtGenDvStAiSTrap

OID: 1.3.6.1.4.1.3709.2.4.0.30002

Description: This trap is sent every time an alarm indication signal is raised.

1.69 smtGenDvStLofTrap

OID: 1.3.6.1.4.1.3709.2.4.0.30003

Description: This trap is sent every time a loss of frame alignment is detected.

1.70 smtGenDvStRalmTrap

OID: 1.3.6.1.4.1.3709.2.4.0.30004

Description: This trap is sent every time a remote alarm is raised.

1.71 smtGenDvStMfaTrap

OID: 1.3.6.1.4.1.3709.2.4.0.30005

Description: This trap is sent every time a no multiframe alignment found alarm is raised.

1.72 smtGenDvStLomTrap

OID: 1.3.6.1.4.1.3709.2.4.0.30006

Description: This trap is sent every time a loss of multiframe alignment alarm is raised.

1.73 smtGenDvStCpuLoadThresholdTrap

OID: 1.3.6.1.4.1.3709.2.4.0.30007

Description: This trap is sent every time a cpuload threshold is reached.

1.74 smtGenDvStDiskUseThresholdTrap

OID: 1.3.6.1.4.1.3709.2.4.0.30008

Description: This trap is sent every time a disk usage threshold is reached.

1.75 smtGenDvStMemoryUseThresholdTrap

OID: 1.3.6.1.4.1.3709.2.4.0.30009

Description: This trap is sent every time a memory use threshold is reached.

1.76 stMacSpoofingTrap

OID: 1.3.6.1.4.1.3709.2.4.0.30010

Description: This trap is sent when it is detected that the user over this port sent traffic containing source MAC address already in use by another user port, potentially a malicious use of the line

1.77 tLoginFailTrap

OID: 1.3.6.1.4.1.3709.2.4.0.40001

Description: This trap is sent when an user try logging with a incorrect username or password.

1.78 tLoginSucessTrap

OID: 1.3.6.1.4.1.3709.2.4.0.40002

Description: This trap is sent when an user get logging.

1.79 tTxFaultTrap

OID: 1.3.6.1.4.1.3709.2.4.0.40003

Description: This trap is sent every time a TX fault is detected.

1.80 cpuFWMismatchAlarmTrap

OID: 1.3.6.1.4.1.3709.2.4.0.40004

Description: This trap is sent when the current MPU FW is not the selected firmware.

1.81 cardFWMismatchAlarmTrap

OID: 1.3.6.1.4.1.3709.2.4.0.40005

Description: This trap is sent when the card FW is not the same as the active MPU.

1.82 fwLoadByTftpAlarmTrap

OID: 1.3.6.1.4.1.3709.2.4.0.40006

Description: This trap is sent when line card loaded firmware from tftp instead of flash.

1.83 trapLicenseWillExpire

OID: 1.3.6.1.4.1.3709.2.4.0.40007

Description: This trap is sent when the expiration of a license will occur in less than XXX hours.

1.84 trapLicenseExpired

OID: 1.3.6.1.4.1.3709.2.4.0.40008

Description: This trap is sent when a license is expired.

1.85 uBootUpdateAvailAlarmTrap

OID: 1.3.6.1.4.1.3709.2.4.0.40009

Description: This trap is sent when U-boot must be updated.

1.86 swNonHomologSfpTrap

OID: 1.3.6.1.4.1.3709.2.4.0.40010

Description: This trap is sent when a non-homologated SFP is placed.

1.87 genDvTrapsInfMibVersion

OID: 1.3.6.1.4.1.3709.2.4.1.1

Description: The genDvTraps MIB version supported by this agent software version.

Syntax: DisplayString

Access: read-only

Status: mandatory

1.87.1 genDvTrapsInfLastTrDevNo

OID: 1.3.6.1.4.1.3709.2.4.1.11

Description: Device number of the last trap.

Syntax: DmDevIndex

Access: read-only

Status: mandatory

1.87.2 genDvTrapsInfLastTrDevLocalId

OID: 1.3.6.1.4.1.3709.2.4.1.12

Description: Device local of the last trap.

Syntax: DmDevLocalIndex

Access: read-only

Status: mandatory

1.87.3 genDvTrapsInfLastTrSlotNo

OID: 1.3.6.1.4.1.3709.2.4.1.13

Description: Slot number of the last trap.

Syntax: DmSlotIndex

Access: read-only

Status: mandatory

1.87.4 genDvTrapsInfLastTrPortNo

OID: 1.3.6.1.4.1.3709.2.4.1.14

Description: Port number of the last trap.

Syntax: DmPortIndex

Access: read-only

Status: mandatory

1.87.5 genDvTrapsInfLastTrValue

OID: 1.3.6.1.4.1.3709.2.4.1.15

Description: New value of the object that changed.

Syntax: INTEGER

Access: read-only

Status: mandatory

1.87.6 genDvTrapsInfLastTrType

OID: 1.3.6.1.4.1.3709.2.4.1.16

Description: Type of the last trap.

Syntax: INTEGER

Access: read-only

Status: mandatory

1.87.7 genDvTrapsInfLastTrTimeStamp

OID: 1.3.6.1.4.1.3709.2.4.1.17

Description: Time stamp of the last trap.

Syntax: TimeTicks

Access: read-only

Status: mandatory

1.87.8 genDvTrapsInfLastTrDeviceProduct

OID: 1.3.6.1.4.1.3709.2.4.1.18

Description: The device product of the last trap.

Syntax: OBJECT IDENTIFIER

Access: read-only

Status: mandatory

1.87.9 genDvTrapsInfLastTrAlarmId

OID: 1.3.6.1.4.1.3709.2.4.1.19

Description: Alarm number of the last trap.

Syntax: INTEGER

Access: read-only

Status: mandatory

1.87.10 genDvTrapsInfLastTrAlarmVal

OID: 1.3.6.1.4.1.3709.2.4.1.20

Description: Alarm value of the last trap.

Syntax: INTEGER

Syntax details: (Enumeration) 'activated': 2, 'deactivated': 1, 'unstable': 3

Access: read-only

Status: mandatory

1.87.11 genDvTrapsInfLastTrUserName

OID: 1.3.6.1.4.1.3709.2.4.1.21

Description: User name of the last trap.

Syntax: DisplayString

Access: read-only

Status: mandatory

1.87.12 genDvTrapsInfLastTrAlarmSeverityVal

OID: 1.3.6.1.4.1.3709.2.4.1.22

Description: Severity value of a trap.

Syntax: INTEGER

Syntax details: (Enumeration) 'critical': 5, 'info': 1, 'major': 4, 'minor': 3, 'warning': 2

Access: read-only

Status: mandatory

1.87.13 genDvTrapsInfLastTrChannel

OID: 1.3.6.1.4.1.3709.2.4.1.23

Description: Channel of the last trap.

Syntax: INTEGER

Access: read-only

Status: mandatory

1.87.14 genDvTrapLicenseSN

OID: 1.3.6.1.4.1.3709.2.4.1.24

Description: The license with serial number.

Syntax: INTEGER

Access: read-only

Status: mandatory

1.87.15 genDvTrapLicenseExpire

OID: 1.3.6.1.4.1.3709.2.4.1.25

Description: Time to expire a License.

Syntax: INTEGER

Access: read-only

Status: mandatory

1.87.16 genDvTrapsInfLastTrValueVlan

OID: 1.3.6.1.4.1.3709.2.4.1.26

Description: Vlan's number.

Syntax: INTEGER

Syntax details: (Range) 1 - 4096

Access: read-only

Status: mandatory

1.87.17 genDvTrapsInfLastTrStringMac

OID: 1.3.6.1.4.1.3709.2.4.1.27

Description: String containing MAC address (format xx:xx:xx:xx:xx:xx).

Syntax: OCTET STRING

Access: read-only

Status: mandatory

1.87.18 genDvTrapsInfTable

OID: 1.3.6.1.4.1.3709.2.4.1.100

Description: Table with general trap information about the equipment managed by this MIB.

Syntax: SEQUENCE OF genDvTrapsInfEntry (OID: 1.3.6.1.4.1.3709.2.4.1.100.1)

Access: not-accessible

Status: mandatory

genDvTrapsInfIdxNo

OID: 1.3.6.1.4.1.3709.2.4.1.100.1.1

Description: Index number.

Syntax: DmTrapIndex

Access: read-only

Status: mandatory

genDvTrapsInfObjectOid

OID: 1.3.6.1.4.1.3709.2.4.1.100.1.2

Description: OID (Object Identifier) number.

Syntax: OBJECT IDENTIFIER

Access: read-only

Status: mandatory

genDvTrapsInfObjIntegerVal

OID: 1.3.6.1.4.1.3709.2.4.1.100.1.3

Description: Object value (Integer).

Syntax: INTEGER

Access: read-only

Status: mandatory

genDvTrapsInfObjTmTicksVal

OID: 1.3.6.1.4.1.3709.2.4.1.100.1.4

Description: Object value (TimeTicks).

Syntax: TimeTicks

Access: read-only

Status: mandatory

genDvTrapsInfObjStringVal

OID: 1.3.6.1.4.1.3709.2.4.1.100.1.5

Description: Object value (Octet String).

Syntax: OCTET STRING

Access: read-only

Status: mandatory

genDvTrapsInfObjCounterVal

OID: 1.3.6.1.4.1.3709.2.4.1.100.1.6

Description: Object value (Counter).

Syntax: Counter32

Access: read-only

Status: mandatory

genDvTrapsInfObjGaugeVal

OID: 1.3.6.1.4.1.3709.2.4.1.100.1.7

Description: Object value (Gauge).

Syntax: Gauge32

Access: read-only

Status: mandatory

2 DATACOM-GPON-TRAPS-MIB

MIB file: DATACOM-GPON-TRAPS-MIB.mib

This MIB file has the following root objects:

- **datacomGponTrapsMIBModule**
 - **OID:** 1.3.6.1.4.1.3709.1.1.5
 - **Description:** The MIB module for DATACOM GPON traps.
- **dmAdGponTrapsMIB**
 - **OID:** 1.3.6.1.4.1.3709.3.5.200
 - **Object identities:**
 - dmAdGponTrapsInf (1.3.6.1.4.1.3709.3.5.200.1)
 - dmAdGponTraps (1.3.6.1.4.1.3709.3.5.200.2)

2.1 dmAdGponTrapsInfLastTrapOnuID

OID: 1.3.6.1.4.1.3709.3.5.200.1.1

Description: ONU ID of the last trap.

Syntax: INTEGER

Access: read-only

Status: current

2.2 dmAdGponTrapsInfLastTrapSwdlInfo

OID: 1.3.6.1.4.1.3709.3.5.200.1.2

Description: ONU SWDL progress status.

Syntax: INTEGER

Syntax details: (Enumeration) 'aborted': 22, 'error': 24, 'invalid': 25, 'started': 21, 'successful': 23

Access: read-only

Status: current

2.3 dmAdGponTrapsInfLastTrapOnuSN

OID: 1.3.6.1.4.1.3709.3.5.200.1.3

Description: ONU Serial Number.

Syntax: OCTET STRING

Access: read-only

Status: current

2.4 gPonLOSiAlarm

OID: 1.3.6.1.4.1.3709.3.5.200.2.50001

Description: Loss of signal for ONU.

Status: current

2.5 gPonLOFiAlarm

OID: 1.3.6.1.4.1.3709.3.5.200.2.50002

Description: Loss of Frame of ONU.

Status: current

2.6 gPonDOWiAlarm

OID: 1.3.6.1.4.1.3709.3.5.200.2.50003

Description: Drift of Window of ONU.

Status: current

2.7 gPonSFiAlarm

OID: 1.3.6.1.4.1.3709.3.5.200.2.50004

Description: Signal Fail of ONU.

Status: current

2.8 gPonSDiAlarm

OID: 1.3.6.1.4.1.3709.3.5.200.2.50005

Description: Signal degrade of ONU.

Status: current

2.9 gPonLCDGiAlarm

OID: 1.3.6.1.4.1.3709.3.5.200.2.50006

Description: Loss of GEM channel delineation.

Status: current

2.10 gPonRDiAlarm

OID: 1.3.6.1.4.1.3709.3.5.200.2.50007

Description: Remote defect indication of ONU.

Status: current

2.11 gPonTFAlarm

OID: 1.3.6.1.4.1.3709.3.5.200.2.50008

Description: Transmitter failure on PON link.

Status: current

2.12 gPonSUFiAlarm

OID: 1.3.6.1.4.1.3709.3.5.200.2.50009

Description: Start-up Failure of ONU.

Status: current

2.13 gPonDFiAlarm

OID: 1.3.6.1.4.1.3709.3.5.200.2.50010

Description: ONU does not react correctly after three Deactivate_ONU-ID or three Disable_Serial_Number messages.

Status: current

2.14 gPonLOAiAlarm

OID: 1.3.6.1.4.1.3709.3.5.200.2.50011

Description: Loss of Ack with ONU.

Status: current

2.15 gPonDGiAlarm

OID: 1.3.6.1.4.1.3709.3.5.200.2.50012

Description: Receive Dying Gasp of ONU.

Status: current

2.16 gPonLOAMiAlarm

OID: 1.3.6.1.4.1.3709.3.5.200.2.50013

Description: Loss of PLOAM for ONU.

Status: current

2.17 gPonMISiAlarm

OID: 1.3.6.1.4.1.3709.3.5.200.2.50014

Description: Link Mismatch of ONU.

Status: current

2.18 gPonPEEiAlarm

OID: 1.3.6.1.4.1.3709.3.5.200.2.50015

Description: Physical Equipment error of ONU.

Status: current

2.19 gPonOnuEquipmentFailureAlarm

OID: 1.3.6.1.4.1.3709.3.5.200.2.50016

Description: ONU Equipment failure.

Status: current

2.20 gPonOnuPowerFailureAlarm

OID: 1.3.6.1.4.1.3709.3.5.200.2.50017

Description: ONU Power failure.

Status: current

2.21 gPonOnuBatteryMissingAlarm

OID: 1.3.6.1.4.1.3709.3.5.200.2.50018

Description: ONU Battery missing.

Status: current

2.22 gPonOnuBatteryFailureAlarm

OID: 1.3.6.1.4.1.3709.3.5.200.2.50019

Description: ONU Battery failure.

Status: current

2.23 gPonOnuBatteryLowAlarm

OID: 1.3.6.1.4.1.3709.3.5.200.2.50020

Description: ONU Battery low.

Status: current

2.24 gPonOnuPhysicalIntrusionAlarm

OID: 1.3.6.1.4.1.3709.3.5.200.2.50021

Description: ONU Physical intrusion.

Status: current

2.25 gPonOnuSelfTestFailureAlarm

OID: 1.3.6.1.4.1.3709.3.5.200.2.50022

Description: ONU Self testing failure.

Status: current

2.26 gPonOnuVoltageRedAlarm

OID: 1.3.6.1.4.1.3709.3.5.200.2.50023

Description: ONU Voltage red.

Status: current

2.27 gPonOnuDiscoveredEvent

OID: 1.3.6.1.4.1.3709.3.5.200.2.50024

Description: ONU discovered on PON link.

Status: current

2.28 gPonOnuPasswordMismatchAlarm

OID: 1.3.6.1.4.1.3709.3.5.200.2.50025

Description: ONU password mismatch.

Status: current

2.29 gPonOnuSwdlInProgressEvent

OID: 1.3.6.1.4.1.3709.3.5.200.2.50026

Description: ONU Software download in progress.

Status: current

2.30 gPonLOBiAlarm

OID: 1.3.6.1.4.1.3709.3.5.200.2.50027

Description: ONU Loss of burst (XGS).

Status: current

2.31 gPonLOPCiAlarm

OID: 1.3.6.1.4.1.3709.3.5.200.2.50028

Description: Loss of PLOAM for ONU (XGS).

Status: current

2.32 gPonLOOCiAlarm

OID: 1.3.6.1.4.1.3709.3.5.200.2.50029

Description: Loss of OMCC channel (XGS).

Status: current

2.33 gPonTIWiAlarm

OID: 1.3.6.1.4.1.3709.3.5.200.2.50030

Description: Transmission interference warning of ONU.

Status: current

3 DATACOM-PING-MIB

MIB file: DATACOM-PING-MIB.mib

This MIB file has the following root objects:

- **pingMIB**
 - **OID:** 1.3.6.1.4.1.3709.3.5.21.8
 - **Description:** The Ping MIB (DATACOM-PING-MIB) provides the capability of controlling the use of the ping function at a remote host. Copyright (C) The Internet Society (2006). This version of this MIB module is part of RFC 4560; see the RFC itself for full legal notices.
 - **Object identities:**
 - pingNotifications (1.3.6.1.4.1.3709.3.5.21.8.0)
 - pingObjects (1.3.6.1.4.1.3709.3.5.21.8.1)
 - pingConformance (1.3.6.1.4.1.3709.3.5.21.8.2)
 - pingImplementationTypeDomains (1.3.6.1.4.1.3709.3.5.21.8.3)

3.1 pingProbeFailed

OID: 1.3.6.1.4.1.3709.3.5.21.8.0.1

Description: Generated when a probe failure is detected, when the corresponding pingCtlTrapGeneration object is set to probeFailure(0), subject to the value of pingCtlTrapProbeFailureFilter. The object pingCtlTrapProbeFailureFilter can be used to specify the number of consecutive probe failures that are required before this notification can be generated.

Status: current

3.2 pingTestFailed

OID: 1.3.6.1.4.1.3709.3.5.21.8.0.2

Description: Generated when a ping test is determined to have failed, when the corresponding pingCtlTrapGeneration object is set to testFailure(1). In this instance, pingCtlTrapTestFailureFilter should specify the number of probes in a test required to have failed in order to consider the test failed.

Status: current

3.3 pingTestCompleted

OID: 1.3.6.1.4.1.3709.3.5.21.8.0.3

Description: Generated at the completion of a ping test when the corresponding pingCtlTrapGeneration object has the testCompletion(2) bit set.

Status: current

3.4 pingMaxConcurrentRequests

OID: 1.3.6.1.4.1.3709.3.5.21.8.1.1

Description: The maximum number of concurrent active ping requests that are allowed within an agent implementation. A value of 0 for this object implies that there is no limit for the number of concurrent active requests in effect. The limit applies only to new requests being activated. When a new value is set, the agent will continue processing all the requests already active, even if their number exceeds the limit just imposed.

Syntax: Unsigned32

Access: read-write

Status: current

3.5 pingCtlTable

OID: 1.3.6.1.4.1.3709.3.5.21.8.1.2

Description: Defines the ping Control Table for providing, via SNMP, the capability of performing ping operations at a remote host. The results of these operations are stored in the pingResultsTable and the pingProbeHistoryTable.

Syntax: SEQUENCE OF pingCtlEntry (OID: 1.3.6.1.4.1.3709.3.5.21.8.1.2.1)

Access: not-accessible

Status: current

3.5.1 pingCtlOwnerIndex

OID: 1.3.6.1.4.1.3709.3.5.21.8.1.2.1.1

Description: To facilitate the provisioning of access control by a security administrator using the View-Based Access Control Model (RFC 2575, VACM) for tables in which multiple users may need to create or modify entries independently, the initial index is used as an 'owner index'. Such an initial index has a syntax of SnmpAdminString and can thus be trivially mapped to a securityName or groupName defined in VACM, in accordance with a security policy. When used in conjunction with such a security policy, all entries in the table belonging to a particular user (or group) will have the same value for this initial index. For a given user's entries in a particular table, the object identifiers for the information in these entries will have the same subidentifiers (except for the 'column' subidentifier) up to the end of the encoded owner index. To configure VACM to permit access to this portion of the table, one would create vacmViewTreeFamilyTable entries with the value of vacmViewTreeFamilySubtree including the owner index portion, and vacmViewTreeFamilyMask 'wildcarding' the column subidentifier. More elaborate configurations are possible.

Syntax: SnmpAdminString

Syntax details: (Size) 0 - 32

Access: not-accessible

Status: current

3.5.2 pingCtlTestName

OID: 1.3.6.1.4.1.3709.3.5.21.8.1.2.1.2

Description: The name of the ping test. This is locally unique, within the scope of a pingCtlOwnerIndex.

Syntax: SnmpAdminString

Syntax details: (Size) 0 - 32

Access: not-accessible

Status: current

3.5.3 pingCtlTargetAddressType

OID: 1.3.6.1.4.1.3709.3.5.21.8.1.2.1.3

Description: Specifies the type of host address to be used at a remote host for performing a ping operation.

Syntax: InetAddressType

Access: read-create

Status: current

3.5.4 pingCtlTargetAddress

OID: 1.3.6.1.4.1.3709.3.5.21.8.1.2.1.4

Description: Specifies the host address to be used at a remote host for performing a ping operation. The host address type is determined by the value of the corresponding pingCtlTargetAddressType. A value for this object MUST be set prior to transitioning its corresponding pingCtlEntry to active(1) via pingCtlRowStatus.

Syntax: InetAddress

Access: read-create

Status: current

3.5.5 pingCtlDataSize

OID: 1.3.6.1.4.1.3709.3.5.21.8.1.2.1.5

Description: Specifies the size of the data portion to be transmitted in a ping operation, in octets. Whether this value can be applied depends on the selected implementation method for performing a ping operation, indicated by pingCtlType in the same conceptual row. If the method used allows applying the value contained in this object, then it MUST be applied. If the specified size is not appropriate for the chosen ping method, the implementation SHOULD use whatever size (appropriate to the method) is closest to the specified size. The maximum value for this object was computed by subtracting the smallest possible IP header size of 20 octets (IPv4 header with no options) and the UDP header size of 8 octets from the maximum IP packet size. An IP packet has a maximum size of 65535 octets (excluding IPv6 Jumbograms).

Syntax: Unsigned32

Syntax details: (Range) 0 - 65507

Access: read-create

Status: current

3.5.6 pingCtlTimeOut

OID: 1.3.6.1.4.1.3709.3.5.21.8.1.2.1.6

Description: Specifies the time-out value, in seconds, for a remote ping operation.

Syntax: Unsigned32

Syntax details: (Range) 1 - 60

Access: read-create

Status: current

3.5.7 pingCtlProbeCount

OID: 1.3.6.1.4.1.3709.3.5.21.8.1.2.1.7

Description: Specifies the number of times to perform a ping operation at a remote host as part of a single ping test.

Syntax: Unsigned32

Syntax details: (Range) 1 - 15

Access: read-create

Status: current

3.5.8 pingCtlAdminStatus

OID: 1.3.6.1.4.1.3709.3.5.21.8.1.2.1.8

Description: Reflects the desired state that a pingCtlEntry should be in: enabled(1) - Attempt to activate the test as defined by this pingCtlEntry. disabled(2) - Deactivate the test as defined by this pingCtlEntry. Refer to the corresponding pingResultsOperStatus to determine the operational state of the test defined by this entry.

Syntax: INTEGER

Syntax details: (Enumeration) 'disabled': 2, 'enabled': 1

Access: read-create

Status: current

3.5.9 pingCtlDataFill

OID: 1.3.6.1.4.1.3709.3.5.21.8.1.2.1.9

Description: The content of this object is used together with the corresponding pingCtlDataSize value to determine how to fill the data portion of a probe packet. The option of selecting a data fill pattern can be useful when links are compressed or have data pattern sensitivities. The contents of pingCtlDataFill should be repeated in a ping packet when the size of the data portion of the ping packet is greater than the size of pingCtlDataFill.

Syntax: OCTET STRING

Syntax details: (Size) 0 - 1024

Access: read-create

Status: current

3.5.10 pingCtlFrequency

OID: 1.3.6.1.4.1.3709.3.5.21.8.1.2.1.10

Description: The number of seconds to wait before repeating a ping test as defined by the value of the various objects in the corresponding row. A single ping test consists of a series of ping probes. The number of probes is determined by the value of the corresponding pingCtlProbeCount object. After a single test is completed the number of seconds as defined by the value of pingCtlFrequency MUST elapse before the next ping test is started. A value of 0 for this object implies that the test as defined by the corresponding entry will not be repeated.

Syntax: Unsigned32

Access: read-create

Status: current

3.5.11 pingCtlMaxRows

OID: 1.3.6.1.4.1.3709.3.5.21.8.1.2.1.11

Description: The maximum number of corresponding entries allowed in the pingProbeHistoryTable. An implementation of this MIB will remove the oldest corresponding entry in the pingProbeHistoryTable to allow the addition of a new entry once the number of corresponding rows in the pingProbeHistoryTable reaches this value. Old entries are not removed when a new test is started. Entries are added to the pingProbeHistoryTable until pingCtlMaxRows is reached before entries begin to be removed. A value of 0 for this object disables creation of pingProbeHistoryTable entries.

Syntax: Unsigned32

Access: read-create

Status: current

3.5.12 pingCtlStorageType

OID: 1.3.6.1.4.1.3709.3.5.21.8.1.2.1.12

Description: The storage type for this conceptual row. Conceptual rows having the value 'permanent' need not allow write-access to any columnar objects in the row.

Syntax: StorageType

Access: read-create

Status: current

3.5.13 pingCtlTrapGeneration

OID: 1.3.6.1.4.1.3709.3.5.21.8.1.2.1.13

Description: The value of this object determines when and whether to generate a notification for this entry: probeFailure(0) - Generate a pingProbeFailed notification subject to the value of pingCtlTrapProbeFailureFilter. The object pingCtlTrapProbeFailureFilter can be used to specify the number of consecutive probe failures that are required before a pingProbeFailed notification can be generated. testFailure(1) - Generate a pingTestFailed notification. In this instance the object pingCtlTrapTestFailureFilter can be used to determine the number of probe failures that signal when a test fails. testCompletion(2) - Generate a pingTestCompleted notification. By default, no bits are set, indicating that none of the above options is selected.

Syntax: Bits

Access: read-create

Status: current

3.5.14 pingCtlTrapProbeFailureFilter

OID: 1.3.6.1.4.1.3709.3.5.21.8.1.2.1.14

Description: The value of this object is used to determine when to generate a pingProbeFailed NOTIFICATION. Setting BIT probeFailure(0) of object pingCtlTrapGeneration to '1' implies that a pingProbeFailed NOTIFICATION is generated only when a number of consecutive ping probes equal to the value of pingCtlTrapProbeFailureFilter fail within a given ping test. After triggering the notification, the probe failure counter is reset to zero.

Syntax: Unsigned32

Syntax details: (Range) 0 - 15

Access: read-create

Status: current

3.5.15 pingCtlTrapTestFailureFilter

OID: 1.3.6.1.4.1.3709.3.5.21.8.1.2.1.15

Description: The value of this object is used to determine when to generate a pingTestFailed NOTIFICATION. Setting BIT testFailure(1) of object pingCtlTrapGeneration to '1' implies that a pingTestFailed NOTIFICATION is generated only when a number of consecutive ping tests equal to the value of pingCtlTrapProbeFailureFilter fail. After triggering the notification, the test failure counter is reset to zero.

Syntax: Unsigned32

Syntax details: (Range) 0 - 15

Access: read-create

Status: current

3.5.16 pingCtlType

OID: 1.3.6.1.4.1.3709.3.5.21.8.1.2.1.16

Description: The value of this object is used either to report or to select the implementation method to be used for calculating a ping response time. The value of this object MAY be selected from pingImplementationTypeDomains. Additional implementation types SHOULD be allocated as required by implementers of the DATACOM-PING-MIB under their enterprise-specific registration point and not beneath pingImplementationTypeDomains.

Syntax: OBJECT IDENTIFIER

Access: read-create

Status: current

3.5.17 pingCtlDescr

OID: 1.3.6.1.4.1.3709.3.5.21.8.1.2.1.17

Description: The purpose of this object is to provide a descriptive name of the remote ping test.

Syntax: SnmpAdminString

Access: read-create

Status: current

3.5.18 pingCtlSourceAddressType

OID: 1.3.6.1.4.1.3709.3.5.21.8.1.2.1.18

Description: Specifies the type of the source address, pingCtlSourceAddress, to be used at a remote host when a ping operation is performed.

Syntax: InetAddressType

Access: read-create

Status: current

3.5.19 pingCtlSourceAddress

OID: 1.3.6.1.4.1.3709.3.5.21.8.1.2.1.19

Description: Use the specified IP address (which must be given in numeric form, not as a hostname) as the source address in outgoing probe packets. On hosts with more than one IP address, this option can be used to select the address to be used. If the IP address is not one of this machine's interface addresses, an error is returned and nothing is sent. A zero-length octet string value for this object disables source address specification. The address type (InetAddressType) that relates to this object is specified by the corresponding value of pingCtlSourceAddressType.

Syntax: InetAddress

Access: read-create

Status: current

3.5.20 pingCtlIfIndex

OID: 1.3.6.1.4.1.3709.3.5.21.8.1.2.1.20

Description: Setting this object to an interface's ifIndex prior to starting a remote ping operation directs the ping probes to be transmitted over the specified interface. A value of zero for this object means that this option is not enabled.

Syntax: InterfaceIndexOrZero

Access: read-create

Status: current

3.5.21 pingCtlByPassRouteTable

OID: 1.3.6.1.4.1.3709.3.5.21.8.1.2.1.21

Description: The purpose of this object is to enable optional bypassing the route table. If enabled, the remote host will bypass the normal routing tables and send directly to a host on an attached network. If the host is not on a directly attached network, an error is returned. This option can be used to perform the ping operation to a local host through an interface that has no route defined (e.g., after the interface was dropped by the routing daemon at the host).

Syntax: TruthValue

Access: read-create

Status: current

3.5.22 pingCtlDSField

OID: 1.3.6.1.4.1.3709.3.5.21.8.1.2.1.22

Description: Specifies the value to store in the Type of Service (TOS) octet in the IPv4 header or in the Traffic Class octet in the IPv6 header, respectively, of the IP packet used to encapsulate the ping probe. The octet to be set in the IP header contains the Differentiated Services (DS) Field in the six most significant bits. This option can be used to determine what effect an explicit DS Field setting has on a ping response. Not all values are legal or meaningful. A value of 0 means that the function represented by this option is not supported. DS Field usage is often not supported by IP implementations, and not all values are supported. Refer to RFC 2474 and RFC 3260 for guidance on usage of this field.

Syntax: Unsigned32

Syntax details: (Range) 0 - 255

Access: read-create

Status: current

3.5.23 pingCtlRowStatus

OID: 1.3.6.1.4.1.3709.3.5.21.8.1.2.1.23

Description: This object allows entries to be created and deleted in the pingCtlTable. Deletion of an entry in this table results in the deletion of all corresponding (same pingCtlOwnerIndex and pingCtlTestName index values) pingResultsTable and pingProbeHistoryTable entries. A value MUST be specified for pingCtlTargetAddress prior to acceptance of a transition to active(1) state. When a value for pingCtlTargetAddress is set, the value of object pingCtlRowStatus changes from notReady(3) to notInService(2). Activation of a remote ping operation is controlled via pingCtlAdminStatus, not by changing this object's value to active(1). Transitions in and out of active(1) state are not allowed while an entry's pingResultsOperStatus is active(1), with the exception that deletion of an entry in this table by setting its RowStatus object to destroy(6) will stop an active ping operation. The operational state of a ping operation can be determined by examination of its pingResultsOperStatus object.

Syntax: RowStatus

Access: read-create

Status: current

3.6 pingResultsTable

OID: 1.3.6.1.4.1.3709.3.5.21.8.1.3

Description: Defines the Ping Results Table for providing the capability of performing ping operations at a remote host. The results of these operations are stored in the pingResultsTable and the pingProbeHistoryTable. An entry is added to the pingResultsTable when an pingCtlEntry is started by successful transition of its pingCtlAdminStatus object to enabled(1). If the object pingCtlAdminStatus already has the value enabled(1), and if the corresponding pingResultsOperStatus object has the value completed(3), then successfully writing enabled(1) to object pingCtlAdminStatus re-initializes the already

existing entry in the pingResultsTable. The values of objects in the re-initialized entry are the same as the values of objects in a new entry would be. An entry is removed from the pingResultsTable when its corresponding pingCtlEntry is deleted.

Syntax: SEQUENCE OF pingResultsEntry (OID: 1.3.6.1.4.1.3709.3.5.21.8.1.3.1)

Access: not-accessible

Status: current

3.6.1 pingResultsOperStatus

OID: 1.3.6.1.4.1.3709.3.5.21.8.1.3.1.1

Description: Reflects the operational state of a pingCtlEntry: enabled(1) - Test is active. disabled(2) - Test has stopped. completed(3) - Test is completed.

Syntax: INTEGER

Syntax details: (Enumeration) 'completed': 3, 'disabled': 2, 'enabled': 1

Access: read-only

Status: current

3.6.2 pingResultsIpTargetAddressType

OID: 1.3.6.1.4.1.3709.3.5.21.8.1.3.1.2

Description: This object indicates the type of address stored in the corresponding pingResultsIpTargetAddress object.

Syntax: InetAddressType

Access: read-only

Status: current

3.6.3 pingResultsIpTargetAddress

OID: 1.3.6.1.4.1.3709.3.5.21.8.1.3.1.3

Description: This object reports the IP address associated with a pingCtlTargetAddress value when the destination address is specified as a DNS name. The value of this object should be a zero-length octet string when a DNS name is not specified or when a specified DNS name fails to resolve. The address type (InetAddressType) that relates to this object is specified by the corresponding value of pingResultsIpTargetAddressType.

Syntax: InetAddress

Access: read-only

Status: current

3.6.4 pingResultsMinRtt

OID: 1.3.6.1.4.1.3709.3.5.21.8.1.3.1.4

Description: The minimum ping round-trip-time (RTT) received. A value of 0 for this object implies that no RTT has been received.

Syntax: Unsigned32

Access: read-only

Status: current

3.6.5 pingResultsMaxRtt

OID: 1.3.6.1.4.1.3709.3.5.21.8.1.3.1.5

Description: The maximum ping round-trip-time (RTT) received. A value of 0 for this object implies that no RTT has been received.

Syntax: Unsigned32

Access: read-only

Status: current

3.6.6 pingResultsAverageRtt

OID: 1.3.6.1.4.1.3709.3.5.21.8.1.3.1.6

Description: The current average ping round-trip-time (RTT).

Syntax: Unsigned32

Access: read-only

Status: current

3.6.7 pingResultsProbeResponses

OID: 1.3.6.1.4.1.3709.3.5.21.8.1.3.1.7

Description: Number of responses received for the corresponding pingCtlEntry and pingResultsEntry. The value of this object MUST be reported as 0 when no probe responses have been received.

Syntax: Gauge32

Access: read-only

Status: current

3.6.8 pingResultsSentProbes

OID: 1.3.6.1.4.1.3709.3.5.21.8.1.3.1.8

Description: The value of this object reflects the number of probes sent for the corresponding pingCtlEntry and pingResultsEntry. The value of this object MUST be reported as 0 when no probes have been sent.

Syntax: Gauge32

Access: read-only

Status: current

3.6.9 pingResultsRttSumOfSquares

OID: 1.3.6.1.4.1.3709.3.5.21.8.1.3.1.9

Description: This object contains the sum of the squares for all ping responses received. Its purpose is to enable standard deviation calculation. The value of this object MUST be reported as 0 when no ping responses have been received.

Syntax: Unsigned32

Access: read-only

Status: current

3.6.10 pingResultsLastGoodProbe

OID: 1.3.6.1.4.1.3709.3.5.21.8.1.3.1.10

Description: Date and time when the last response was received for a probe.

Syntax: DateAndTime

Access: read-only

Status: current

3.7 pingProbeHistoryTable

OID: 1.3.6.1.4.1.3709.3.5.21.8.1.4

Description: Defines a table for storing the results of ping operations. The number of entries in this table is limited per entry in the pingCtlTable by the value of the corresponding pingCtlMaxRows object. An entry in this table is created when the result of a ping probe is determined. The initial 2 instance identifier index values identify the pingCtlEntry that a probe result (pingProbeHistoryEntry) belongs to. An entry is removed from this table when its corresponding pingCtlEntry is deleted. An implementation of this MIB will remove the oldest entry in the pingProbeHistoryTable of the corresponding entry in the pingCtlTable to allow the addition of a new entry once the number of rows in the pingProbeHistoryTable reaches the value specified by pingCtlMaxRows for the corresponding entry in the pingCtlTable.

Syntax: SEQUENCE OF pingProbeHistoryEntry (OID: 1.3.6.1.4.1.3709.3.5.21.8.1.4.1)

Access: not-accessible

Status: current

3.7.1 pingProbeHistoryIndex

OID: 1.3.6.1.4.1.3709.3.5.21.8.1.4.1.1

Description: An entry in this table is created when the result of a ping probe is determined. The initial 2 instance identifier index values identify the pingCtlEntry that a probe result (pingProbeHistoryEntry) belongs to. An implementation **MUST** start assigning pingProbeHistoryIndex values at 1 and wrap after exceeding the maximum possible value as defined by the limit of this object ('ffffffff'h).

Syntax: Unsigned32

Syntax details: (Range) 1 - 4294967295

Access: not-accessible

Status: current

3.7.2 pingProbeHistoryResponse

OID: 1.3.6.1.4.1.3709.3.5.21.8.1.4.1.2

Description: The amount of time measured in milliseconds from when a probe was sent to when its response was received or when it timed out. The value of this object is reported as 0 when it is not possible to transmit a probe.

Syntax: Unsigned32

Access: read-only

Status: current

3.7.3 pingProbeHistoryStatus

OID: 1.3.6.1.4.1.3709.3.5.21.8.1.4.1.3

Description: The result of a particular probe done by a remote host.

Syntax: OperationResponseStatus

Access: read-only

Status: current

3.7.4 pingProbeHistoryLastRC

OID: 1.3.6.1.4.1.3709.3.5.21.8.1.4.1.4

Description: The last implementation-method-specific reply code received. If the ICMP Echo capability is being used, then a successful probe ends when an ICMP response is received that contains the code ICMP_ECHOREPLY(0). The ICMP codes

are maintained by IANA. Standardized ICMP codes are listed at <http://www.iana.org/assignments/icmp-parameters>. The ICMPv6 codes are listed at <http://www.iana.org/assignments/icmpv6-parameters>.

Syntax: Integer32

Access: read-only

Status: current

3.7.5 pingProbeHistoryTime

OID: 1.3.6.1.4.1.3709.3.5.21.8.1.4.1.5

Description: Timestamp for when this probe result was determined.

Syntax: DateAndTime

Access: read-only

Status: current

3.8 pingCompliance

OID: 1.3.6.1.4.1.3709.3.5.21.8.2.1.1

Description: The compliance statement for the DATACOM-PING-MIB. This compliance statement has been deprecated because the group pingGroup and the pingTimeStampGroup have been split and deprecated. The pingFullCompliance statement is semantically identical to the deprecated pingCompliance statement.

Status: deprecated

3.9 pingFullCompliance

OID: 1.3.6.1.4.1.3709.3.5.21.8.2.1.2

Description: The compliance statement for SNMP entities that fully implement the DATACOM-PING-MIB.

Status: current

3.10 pingMinimumCompliance

OID: 1.3.6.1.4.1.3709.3.5.21.8.2.1.3

Description: The minimum compliance statement for SNMP entities that implement the minimal subset of the DATACOM-PING-MIB. Implementors might choose this subset for small devices with limited resources.

Status: current

3.11 pingGroup

OID: 1.3.6.1.4.1.3709.3.5.21.8.2.2.1

Description: The group of objects that constitute the remote ping capability.

Status: deprecated

3.12 pingTimeStampGroup

OID: 1.3.6.1.4.1.3709.3.5.21.8.2.2.2

Description: The group of DateAndTime objects.

Status: deprecated

3.13 pingNotificationsGroup

OID: 1.3.6.1.4.1.3709.3.5.21.8.2.2.3

Description: The notification that are required to be supported by implementations of this MIB.

Status: current

3.14 pingMinimumGroup

OID: 1.3.6.1.4.1.3709.3.5.21.8.2.2.4

Description: The group of objects that constitute the remote ping capability.

Status: current

3.15 pingCtlRowStatusGroup

OID: 1.3.6.1.4.1.3709.3.5.21.8.2.2.5

Description: The RowStatus object of the pingCtlTable.

Status: current

3.16 pingHistoryGroup

OID: 1.3.6.1.4.1.3709.3.5.21.8.2.2.6

Description: The group of objects that constitute the history capability.

Status: current

4 DATACOM-ROUTER-B-MIB

MIB file: DATACOM-ROUTER-B-MIB.mib

This MIB file has the following root objects:

- **datacomRouterBMIBModule**
 - **OID:** 1.3.6.1.4.1.3709.1.1.3521
 - **Description:** The MIB module for Datacom router type B.
- **dmAdRouterBMIB**
 - **OID:** 1.3.6.1.4.1.3709.3.5.21
 - **Object identities:**
 - dmAdRtbInf (1.3.6.1.4.1.3709.3.5.21.1)
 - dmAdRtbStatus (1.3.6.1.4.1.3709.3.5.21.2)
 - dmAdRtbPerformance (1.3.6.1.4.1.3709.3.5.21.5)
 - dmAdRtbConfigCopy (1.3.6.1.4.1.3709.3.5.21.6)
 - dmAdRtbLTE (1.3.6.1.4.1.3709.3.5.21.7)

4.1 rtbInfltGprsTable

OID: 1.3.6.1.4.1.3709.3.5.21.1.15

Description: Table with router B information about the router managed by this MIB.

Syntax: SEQUENCE OF rtbInfltGprsEntry (OID: 1.3.6.1.4.1.3709.3.5.21.1.15.1)

Access: not-accessible

Status: current

4.1.1 rtbInfltGprsDevNo

OID: 1.3.6.1.4.1.3709.3.5.21.1.15.1.1

Description: Device number.

Syntax: DmDevIndex

Access: read-only

Status: current

4.1.2 rtbInfltGprsDevLocalId

OID: 1.3.6.1.4.1.3709.3.5.21.1.15.1.2

Description: Device local or remote.

Syntax: DmDevLocalIndex

Access: read-only

Status: current

4.1.3 rtbInfltGprsSlotNo

OID: 1.3.6.1.4.1.3709.3.5.21.1.15.1.3

Description: Slot number.

Syntax: DmSlotIndex

Access: read-only

Status: current

4.1.4 rtbInfltGprsPortNo

OID: 1.3.6.1.4.1.3709.3.5.21.1.15.1.4

Description: Port number.

Syntax: DmPortIndex

Access: read-only

Status: current

4.1.5 rtbInfltGprsTaInf

OID: 1.3.6.1.4.1.3709.3.5.21.1.15.1.5

Description: ta_info.

Syntax: DisplayString

Access: read-only

Status: current

4.1.6 rtbInfltGprsTaConf

OID: 1.3.6.1.4.1.3709.3.5.21.1.15.1.6

Description: ta_conf.

Syntax: DisplayString

Access: read-only

Status: current

4.1.7 rtbInfltGprsTaSerial

OID: 1.3.6.1.4.1.3709.3.5.21.1.15.1.7

Description: ta_serial.

Syntax: DisplayString

Access: read-only

Status: current

4.1.8 rtbInfltGprsTaRegistry

OID: 1.3.6.1.4.1.3709.3.5.21.1.15.1.8

Description: ta_registry.

Syntax: DisplayString

Access: read-only

Status: current

4.1.9 rtbInfltGprsSimCardInf

OID: 1.3.6.1.4.1.3709.3.5.21.1.15.1.9

Description: simcard_info.

Syntax: DisplayString

Access: read-only

Status: current

4.1.10 rtbInfltGprsCellConn

OID: 1.3.6.1.4.1.3709.3.5.21.1.15.1.10

Description: cell_conn.

Syntax: DisplayString

Access: read-only

Status: current

4.1.11 rtbInfltGprsCellsMon

OID: 1.3.6.1.4.1.3709.3.5.21.1.15.1.11

Description: cells_mon.

Syntax: DisplayString

Access: read-only

Status: current

4.1.12 rtbInfltGprsNetInf

OID: 1.3.6.1.4.1.3709.3.5.21.1.15.1.12

Description: gprs_info.

Syntax: DisplayString

Access: read-only

Status: current

4.2 rtbStltfGenTable

OID: 1.3.6.1.4.1.3709.3.5.21.2.12

Description: Table with router B link status about the router managed by this MIB.

Syntax: SEQUENCE OF rtbStltfGenEntry (OID: 1.3.6.1.4.1.3709.3.5.21.2.12.1)

Access: not-accessible

Status: current

4.2.1 rtbStltfGenDevNo

OID: 1.3.6.1.4.1.3709.3.5.21.2.12.1.1

Description: Device number.

Syntax: DmDevIndex

Access: read-only

Status: current

4.2.2 rtbStltfGenDevLocalId

OID: 1.3.6.1.4.1.3709.3.5.21.2.12.1.2

Description: Device local or remote.

Syntax: DmDevLocalIndex

Access: read-only

Status: current

4.2.3 rtbStItfGenSlotNo

OID: 1.3.6.1.4.1.3709.3.5.21.2.12.1.3

Description: Slot number.

Syntax: DmSlotIndex

Access: read-only

Status: current

4.2.4 rtbStItfGenPortNo

OID: 1.3.6.1.4.1.3709.3.5.21.2.12.1.4

Description: Port number.

Syntax: DmPortIndex

Access: read-only

Status: current

4.2.5 rtbStItfGenLink

OID: 1.3.6.1.4.1.3709.3.5.21.2.12.1.5

Description: The current operational state of the interface.

Syntax: INTEGER

Syntax details: (Enumeration) 'down': 2, 'infNotAvailable': 255, 'up': 1

Access: read-only

Status: current

4.2.6 rtbStItfGenIndex

OID: 1.3.6.1.4.1.3709.3.5.21.2.12.1.6

Description: Interface index in mib-2.interfaces (.1.3.6.1.2.1.2). When the interface is not available (link down) the value is 255.

Syntax: INTEGER

Syntax details: (Range) 1 - 100

Access: read-only

Status: current

4.3 rtbStItfAddTable

OID: 1.3.6.1.4.1.3709.3.5.21.2.15

Description: Table with router B IP address status about the router managed by this MIB.

Syntax: SEQUENCE OF rtbStItfAddEntry (OID: 1.3.6.1.4.1.3709.3.5.21.2.15.1)

Access: not-accessible

Status: current

4.3.1 rtbStItfAddDevNo

OID: 1.3.6.1.4.1.3709.3.5.21.2.15.1.1

Description: Device number.

Syntax: DmDevIndex

Access: read-only

Status: current

4.3.2 rtbStItfAddDevLocalId

OID: 1.3.6.1.4.1.3709.3.5.21.2.15.1.2

Description: Device local or remote.

Syntax: DmDevLocalIndex

Access: read-only

Status: current

4.3.3 rtbStItfAddSlotNo

OID: 1.3.6.1.4.1.3709.3.5.21.2.15.1.3

Description: Slot number.

Syntax: DmSlotIndex

Access: read-only

Status: current

4.3.4 rtbStItfAddPortNo

OID: 1.3.6.1.4.1.3709.3.5.21.2.15.1.4

Description: Port number.

Syntax: DmPortIndex

Access: read-only

Status: current

4.3.5 rtbStItfAddLocal

OID: 1.3.6.1.4.1.3709.3.5.21.2.15.1.5

Description: Local Address.

Syntax: IpAddress

Access: read-only

Status: current

4.3.6 rtbStItfAddRemote

OID: 1.3.6.1.4.1.3709.3.5.21.2.15.1.6

Description: Remote Address.

Syntax: IpAddress

Access: read-only

Status: current

4.4 rtbPerfHwStCpu

OID: 1.3.6.1.4.1.3709.3.5.21.5.1

Description: CPU performance in percent.

Syntax: INTEGER

Syntax details: (Range) 0 - 255

Access: read-only

Status: current

4.5 rtbPerfHwStMemory

OID: 1.3.6.1.4.1.3709.3.5.21.5.2

Description: Memory performance in percent.

Syntax: INTEGER

Syntax details: (Range) 0 - 255

Access: read-only

Status: current

4.6 rtbPerfltTable

OID: 1.3.6.1.4.1.3709.3.5.21.5.15

Description: Interface performance.

Syntax: SEQUENCE OF rtbPerfltEntry (OID: 1.3.6.1.4.1.3709.3.5.21.5.15.1)

Access: not-accessible

Status: current

4.6.1 rtbPerfltIndex

OID: 1.3.6.1.4.1.3709.3.5.21.5.15.1.1

Description: Interface index in mib-2.interfaces (.1.3.6.1.2.1.2).

Syntax: INTEGER

Syntax details: (Range) 1 - 100

Access: read-only

Status: current

4.6.2 rtbPerfltDescr

OID: 1.3.6.1.4.1.3709.3.5.21.5.15.1.2

Description: Interface name.

Syntax: DisplayString

Access: read-only

Status: current

4.6.3 rtbPerfltOctets

OID: 1.3.6.1.4.1.3709.3.5.21.5.15.1.3

Description: Octets received in this interface.

Syntax: Counter32

Access: read-only

Status: current

4.6.4 rtbPerfltPkts

OID: 1.3.6.1.4.1.3709.3.5.21.5.15.1.4

Description: Packets received in this interface.

Syntax: Counter32

Access: read-only

Status: current

4.6.5 rtbPerfltCollisions

OID: 1.3.6.1.4.1.3709.3.5.21.5.15.1.5

Description: Collisions number in this interface.

Syntax: Counter32

Access: read-only

Status: current

4.6.6 rtbPerfltUtilization

OID: 1.3.6.1.4.1.3709.3.5.21.5.15.1.6

Description: Data rate received in this interface (bits/second).

Syntax: Counter32

Access: read-only

Status: current

4.6.7 rtbPerfltDrop

OID: 1.3.6.1.4.1.3709.3.5.21.5.15.1.7

Description: Packets per second dropped in this interface (packets/second).

Syntax: Counter32

Access: read-only

Status: current

4.6.8 rtbPerfltfError

OID: 1.3.6.1.4.1.3709.3.5.21.5.15.1.8

Description: Packets per second errored in this interface (packets/second).

Syntax: Counter32

Access: read-only

Status: current

4.6.9 rtbPerfltfRxDataRate

OID: 1.3.6.1.4.1.3709.3.5.21.5.15.1.9

Description: Data rate received in this interface (kbits/second).

Syntax: Counter32

Access: read-only

Status: current

4.6.10 rtbPerfltfTxDataRate

OID: 1.3.6.1.4.1.3709.3.5.21.5.15.1.10

Description: Data rate transmitted in this interface (kbits/second).

Syntax: Counter32

Access: read-only

Status: current

4.6.11 rtbPerfltfRxDropRate

OID: 1.3.6.1.4.1.3709.3.5.21.5.15.1.11

Description: Data rate dropped in reception of this interface (kbits/second).

Syntax: Counter32

Access: read-only

Status: current

4.6.12 rtbPerfltfTxDropRate

OID: 1.3.6.1.4.1.3709.3.5.21.5.15.1.12

Description: Data rate dropped in transmission of this interface (kbits/second).

Syntax: Counter32

Access: read-only

Status: current

4.7 rtbPerfQoSQueueTable

OID: 1.3.6.1.4.1.3709.3.5.21.5.20

Description: Interface performance.

Syntax: SEQUENCE OF rtbPerfQoSQueueEntry (OID: 1.3.6.1.4.1.3709.3.5.21.5.20.1)

Access: not-accessible

Status: current

4.7.1 rtbPerfQoSQueueIndex

OID: 1.3.6.1.4.1.3709.3.5.21.5.20.1.1

Description: Queue number.

Syntax: INTEGER

Syntax details: (Range) 1 - 2000000253

Access: read-only

Status: current

4.7.2 rtbPerfQoSQueueIrfDescr

OID: 1.3.6.1.4.1.3709.3.5.21.5.20.1.2

Description: Interface name for this queue.

Syntax: DisplayString

Access: read-only

Status: current

4.7.3 rtbPerfQoSQueueMark

OID: 1.3.6.1.4.1.3709.3.5.21.5.20.1.3

Description: Mark used in this queue.

Syntax: INTEGER

Syntax details: (Range) 1 - 2000000253

Access: read-only

Status: current

4.7.4 rtbPerfQoSQueueTxDataRate

OID: 1.3.6.1.4.1.3709.3.5.21.5.20.1.4

Description: Data rate transmitted in this queue (kbits/second).

Syntax: Counter32

Access: read-only

Status: current

4.7.5 rtbPerfQoSQueueTxPktDropRate

OID: 1.3.6.1.4.1.3709.3.5.21.5.20.1.5

Description: Packets drop rate in this queue (packets/second).

Syntax: Counter32

Access: read-only

Status: current

4.7.6 rtbPerfQoSQueueTrafficDescr

OID: 1.3.6.1.4.1.3709.3.5.21.5.20.1.6

Description: Description of the filters used in input for the traffic of this class (mark rules).

Syntax: DisplayString

Access: read-only

Status: current

4.7.7 rtbPerfQoSQueueClassName

OID: 1.3.6.1.4.1.3709.3.5.21.5.20.1.7

Description: A configured name for the class.

Syntax: DisplayString

Access: read-only

Status: current

4.7.8 rtbPerfQoSQueuePriority

OID: 1.3.6.1.4.1.3709.3.5.21.5.20.1.8

Description: Priority of the class.

Syntax: INTEGER

Syntax details: (Range) 1 - 1023

Access: read-only

Status: current

4.7.9 rtbPerfQoSQueueMinRate

OID: 1.3.6.1.4.1.3709.3.5.21.5.20.1.9

Description: Reserved bandwidth for the class (bps).

Syntax: INTEGER

Access: read-only

Status: current

4.7.10 rtbPerfQoSQueueMaxRate

OID: 1.3.6.1.4.1.3709.3.5.21.5.20.1.10

Description: Maximum bandwidth that this class can use (bps).

Syntax: INTEGER

Access: read-only

Status: current

4.7.11 rtbPerfQoSQueueDroppedBytes

OID: 1.3.6.1.4.1.3709.3.5.21.5.20.1.11

Description: The total of bytes dropped in this class.

Syntax: Counter64

Access: read-only

Status: current

4.7.12 rtbPerfQoSQueueSentBytes

OID: 1.3.6.1.4.1.3709.3.5.21.5.20.1.12

Description: The total of bytes sent in this class.

Syntax: Counter64

Access: read-only

Status: current

4.7.13 rtbPerfQoSQueueEnqueuedBytes

OID: 1.3.6.1.4.1.3709.3.5.21.5.20.1.13

Description: Number of bytes in the queue.

Syntax: Counter32

Access: read-only

Status: current

4.7.14 rtbPerfQoSQueueTxDataRateBits

OID: 1.3.6.1.4.1.3709.3.5.21.5.20.1.14

Description: Data rate transmission in the class (bps).

Syntax: Counter32

Access: read-only

Status: current

4.7.15 rtbPerfQoSQueueDroppedPkts

OID: 1.3.6.1.4.1.3709.3.5.21.5.20.1.15

Description: The total of packets dropped in this class.

Syntax: Counter64

Access: read-only

Status: current

4.7.16 rtbPerfQoSQueueSentPkts

OID: 1.3.6.1.4.1.3709.3.5.21.5.20.1.16

Description: The total of packets sent in this class.

Syntax: Counter64

Access: read-only

Status: current

4.8 rtbConfigCopyProtocol

OID: 1.3.6.1.4.1.3709.3.5.21.6.1

Description: Selects the network protocol to be used on the file rtbConfigCopyFileName transfer from the rtbConfigCopyServerAddress to apply the config rtbConfigCopyDestFileType onto the device or export it. Default value is: tftp(1)

Syntax: INTEGER

Syntax details: (Enumeration) 'ftp': 2, 'sftp': 3, 'tftp': 1

Access: read-write

Status: current

4.9 rtbConfigCopyServerAddress

OID: 1.3.6.1.4.1.3709.3.5.21.6.2

Description: IP address of file server.

Syntax: IpAddress

Access: read-write

Status: current

4.10 rtbConfigCopyFileName

OID: 1.3.6.1.4.1.3709.3.5.21.6.3

Description: Name of the file to download or upload according to rtbConfigCopyOpType, it can be a path inside the server.

Syntax: DisplayString

Syntax details: (Size) 0 - 255

Access: read-write

Status: current

4.11 rtbConfigCopyDestFileType

OID: 1.3.6.1.4.1.3709.3.5.21.6.4

Description: Selects on which the file copied from the rtbConfigCopyServerAddress will be applied: runningConfig(1) or startupConfig(2). If on runningConfig(1), the current device configuration will be changed, else on startupConfig(2), then the current config wont be changed and only will take effect after a reboot. Default value is: runningConfig(1)

Syntax: INTEGER

Syntax details: (Enumeration) 'runningConfig': 1, 'startupConfig': 2

Access: read-write

Status: current

4.12 rtbConfigCopyInitTransfer

OID: 1.3.6.1.4.1.3709.3.5.21.6.5

Description: If the rtbConfigCopyOpType is set to apply (1) then start the process of downloading the rtbConfigCopyFileName from rtbConfigCopyServerAddress and apply on the rtbConfigCopyDestFileType device configuration. Otherwise, if rtbConfigCopyOpType is export (2), then upload the startup-config named as rtbConfigCopyFileName to rtbConfigCopyServerAddress. After the process is finished, the status will be available in the rtbConfigCopyStatus object. Default value is: inactive(1).

Syntax: INTEGER

Syntax details: (Enumeration) 'active': 2, 'inactive': 1

Access: read-write

Status: current

4.13 rtbConfigCopyStatus

OID: 1.3.6.1.4.1.3709.3.5.21.6.6

Description: Status of requested process in rtbConfigCopyInitTransfer. Default value is: successful(1).

Syntax: INTEGER

Syntax details: (Enumeration) 'failed': 3, 'running': 2, 'successful': 1

Access: read-only

Status: current

4.14 rtbConfigCopySave

OID: 1.3.6.1.4.1.3709.3.5.21.6.7

Description: Start the process of saving active configuration to flash. This process requires some seconds to finish. Default value is: inactive(1).

Syntax: INTEGER

Syntax details: (Enumeration) 'active': 2, 'inactive': 1

Access: read-write

Status: current

4.15 rtbConfigCopyApplyType

OID: 1.3.6.1.4.1.3709.3.5.21.6.8

Description: Type of apply that will be performed. A total replace of the configuration or a merge with the existing config. Default value is: replace(2).

Syntax: INTEGER

Syntax details: (Enumeration) 'merge': 1, 'replace': 2

Access: read-write

Status: current

4.16 rtbConfigCopyFileFormat

OID: 1.3.6.1.4.1.3709.3.5.21.6.9

Description: Type of the configuration apply file format that will be sent. It might have a set of commands or have a tree scheme. By default, the file format is auto detected. Default value is: auto-detect(1).

Syntax: INTEGER

Syntax details: (Enumeration) 'auto-detect': 1, 'cmd-sets': 3, 'file-tree': 2

Access: read-write

Status: current

4.17 rtbConfigCopyOpType

OID: 1.3.6.1.4.1.3709.3.5.21.6.10

Description: Selects which type of operation will be performed, if applying the configuration to the equipment from a TFTP server is desired, select apply(1), otherwise select export(2), which will copy the configuration from the equipment to a TFTP server.

Syntax: INTEGER

Syntax details: (Enumeration) 'apply': 1, 'export': 2

Access: read-write

Status: current

4.18 rtbConfigCopyUser

OID: 1.3.6.1.4.1.3709.3.5.21.6.11

Description: Username for FTP and SFTP.

Syntax: DisplayString

Syntax details: (Size) 0 - 255

Access: read-write

Status: current

4.19 rtbConfigCopyPassword

OID: 1.3.6.1.4.1.3709.3.5.21.6.12

Description: Password for FTP and SFTP.

Syntax: DisplayString

Syntax details: (Size) 0 - 255

Access: read-write

Status: current

4.20 rtbLTESignalStrength

OID: 1.3.6.1.4.1.3709.3.5.21.7.1

Description: LTE signal strength in dBm.

Syntax: DisplayString

Syntax details: (Size) 0 - 255

Access: read-only

Status: current

4.21 rtbLTEChannel

OID: 1.3.6.1.4.1.3709.3.5.21.7.2

Description: Current LTE Channel in use.

Syntax: INTEGER

Syntax details: (Range) 1 - 2000000253

Access: read-only

Status: current

4.22 rtbLTENeighborTable

OID: 1.3.6.1.4.1.3709.3.5.21.7.3

Description: LTE Neighbor information.

Syntax: SEQUENCE OF rtbLTENeighborEntry (OID: 1.3.6.1.4.1.3709.3.5.21.7.3.1)

Access: not-accessible

Status: current

4.22.1 rtbLTENeighborIndex

OID: 1.3.6.1.4.1.3709.3.5.21.7.3.1.1

Description: Index of Neighbor row.

Syntax: INTEGER

Syntax details: (Range) 1 - 2000000253

Access: read-only

Status: current

4.22.2 rtbLTENeighborIndexNeighbor

OID: 1.3.6.1.4.1.3709.3.5.21.7.3.1.2

Description: Neighbor number.

Syntax: INTEGER

Syntax details: (Range) 1 - 2000000253

Access: read-only

Status: current

4.22.3 rtbLTENeighborDescr

OID: 1.3.6.1.4.1.3709.3.5.21.7.3.1.3

Description: Neighbor description.

Syntax: DisplayString

Access: read-only

Status: current

4.22.4 rtbLTENeighborRFChannelNumber

OID: 1.3.6.1.4.1.3709.3.5.21.7.3.1.4

Description: Neighbor channel number.

Syntax: DisplayString

Access: read-only

Status: current

4.23 rtbLTENeighborCellsTable

OID: 1.3.6.1.4.1.3709.3.5.21.7.4

Description: LTE Neighbor Cells information.

Syntax: SEQUENCE OF rtbLTENeighborCellsEntry (OID: 1.3.6.1.4.1.3709.3.5.21.7.4.1)

Access: not-accessible

Status: current

4.23.1 rtbLTENeighborCellsIndex

OID: 1.3.6.1.4.1.3709.3.5.21.7.4.1.1

Description: Index of Neighbor Cell row.

Syntax: INTEGER

Syntax details: (Range) 1 - 2000000253

Access: read-only

Status: current

4.23.2 rtbLTENeighborCellsPhysicalCellID

OID: 1.3.6.1.4.1.3709.3.5.21.7.4.1.2

Description: Physical Cell ID.

Syntax: INTEGER

Syntax details: (Range) 1 - 2000000253

Access: read-only

Status: current

4.23.3 rtbLTENeighborCellsRSRQ

OID: 1.3.6.1.4.1.3709.3.5.21.7.4.1.3

Description: RSRQ.

Syntax: DisplayString

Access: read-only

Status: current

4.23.4 rtbLTENeighborCellsRSRP

OID: 1.3.6.1.4.1.3709.3.5.21.7.4.1.4

Description: RSRP.

Syntax: DisplayString

Access: read-only

Status: current

4.23.5 rtbLTENeighborCellsRSSI

OID: 1.3.6.1.4.1.3709.3.5.21.7.4.1.5

Description: RSSI.

Syntax: DisplayString

Access: read-only

Status: current

4.23.6 rtbLTENeighborCellsCellSelectionRXLevel

OID: 1.3.6.1.4.1.3709.3.5.21.7.4.1.6

Description: Cell Selection RX Level.

Syntax: INTEGER

Syntax details: (Range) 1 - 2000000253

Access: read-only

Status: current

4.24 rtbLTEConnectionStatus

OID: 1.3.6.1.4.1.3709.3.5.21.7.5

Description: Identify whether LTE interface is connected to a network.

Syntax: INTEGER

Syntax details: (Enumeration) 'connected': 1, 'disconnected': 0

Access: read-only

Status: current

5 DATACOM-SMI

MIB file: DATACOM-SMI.mib

This MIB file has the following root objects:

- **datacom**
 - **OID:** 1.3.6.1.4.1.3709
 - **Object identities:**
 - datacomRegistrations (1.3.6.1.4.1.3709.1)
 - datacomGenericMIBs (1.3.6.1.4.1.3709.2)
 - datacomProductsMIBs (1.3.6.1.4.1.3709.3)
 - datacomExperimental (1.3.6.1.4.1.3709.4)

6 DMOS-AUTHENTICATION-NOTIFICATIONS-MIB

MIB file: DMOS-AUTHENTICATION-NOTIFICATIONS-MIB.mib

This MIB file has the following root objects:

- **dmosAuthenticationNotificationsMIB**
 - **OID:** 1.3.6.1.4.1.3709.3.6.3.3.7
 - **Description:** DmOS MIB module for authentication notifications.
 - **Object identities:**
 - dmosAuthenticationNotificationGroups (1.3.6.1.4.1.3709.3.6.3.3.7.1)

6.1 loginFail

OID: 1.3.6.1.4.1.3709.3.6.3.3.7.2

Description: Login failure trap.

Status: current

6.2 loginSuccess

OID: 1.3.6.1.4.1.3709.3.6.3.3.7.3

Description: Login success trap.

Status: current

7 DMOS-BGP4-MIB

MIB file: DMOS-BGP4-MIB.mib

This MIB file has the following root objects:

- **dmosBgpCountersMIB**
 - **OID:** 1.3.6.1.4.1.3709.3.6.13
 - **Description:** The DmOS MIB module for the BGP-4 protocol.

7.1 bgpPrefixCountersTable

OID: 1.3.6.1.4.1.3709.3.6.13.1

Description: BGP prefix counter table. This table contains the prefix counters for each peer.

Syntax: SEQUENCE OF bgpPrefixCountersEntry (OID: 1.3.6.1.4.1.3709.3.6.13.1.1)

Access: not-accessible

Status: current

7.1.1 bgpPrefixCountersRemoteAddressType

OID: 1.3.6.1.4.1.3709.3.6.13.1.1.1

Description: The type of the remote address.

Syntax: InetAddressType

Access: not-accessible

Status: current

7.1.2 bgpPrefixCountersRemoteAddress

OID: 1.3.6.1.4.1.3709.3.6.13.1.1.2

Description: The peer IP address.

Syntax: InetAddress

Access: not-accessible

Status: current

7.1.3 bgpPrefixCountersFamilyAfi

OID: 1.3.6.1.4.1.3709.3.6.13.1.1.3

Description: The Address Family Identifier.

Syntax: INTEGER

Syntax details: (Enumeration) 'dns': 16, 'ipv4': 1, 'ipv4z': 3, 'ipv6': 2, 'ipv6z': 4, 'unknown': 0

Access: not-accessible

Status: current

7.1.4 bgpPrefixCountersFamilySafi

OID: 1.3.6.1.4.1.3709.3.6.13.1.1.4

Description: The Subsequent Address Family Identifiers.

Syntax: BgpSafi

Access: not-accessible

Status: current

7.1.5 bgpPrefixCountersInPrefixes

OID: 1.3.6.1.4.1.3709.3.6.13.1.1.5

Description: The number of prefixes received from a peer and are stored in the Adj-Ribs-In for that peer.

Syntax: Gauge32

Access: read-only

Status: current

7.1.6 bgpPrefixCountersInAcceptedPrefixes

OID: 1.3.6.1.4.1.3709.3.6.13.1.1.6

Description: The number of prefixes for a peer that are installed in the Adj-Ribs-In and are eligible to become active in the Loc-Rib.

Syntax: Gauge32

Access: read-only

Status: current

7.1.7 bgpPrefixCountersInRejectedPrefixes

OID: 1.3.6.1.4.1.3709.3.6.13.1.1.7

Description: The number of prefixes for a peer that are installed in the Adj-Ribs-In and are NOT eligible to become active in the Loc-Rib.

Syntax: Gauge32

Access: read-only

Status: current

7.1.8 bgpPrefixCountersOutPrefixes

OID: 1.3.6.1.4.1.3709.3.6.13.1.1.8

Description: The number of prefixes for a peer that are installed in that peer's Adj-Ribs-Out.

Syntax: Gauge32

Access: read-only

Status: current

7.1.9 bgpPrefixCountersOutAdvertisedPrefixes

OID: 1.3.6.1.4.1.3709.3.6.13.1.1.9

Description: The number of advertised prefixes currently associated with the peer.

Syntax: Gauge32

Access: read-only

Status: current

7.1.10 bgpPrefixCountersInActivePrefixes

OID: 1.3.6.1.4.1.3709.3.6.13.1.1.10

Description: The number of prefixes for a peer that are installed in the Adj-RIB-In and are marked as 'active' in the Loc-Rib.

Syntax: Gauge32

Access: read-only

Status: current

7.1.11 bgpPrefixCountersInPrefixesDeniedByPol

OID: 1.3.6.1.4.1.3709.3.6.13.1.1.11

Description: The number of times a received prefix has been denied, and therefore not installed in the Adj-RIB-In, because of local filter policy.

Syntax: Gauge32

Access: read-only

Status: current

8 DMOS-CARDMGR-NOTIFICATIONS-MIB

MIB file: DMOS-CARDMGR-NOTIFICATIONS-MIB.mib

This MIB file has the following root objects:

- **dmosCardmgrNotificationsMIB**
 - **OID:** 1.3.6.1.4.1.3709.3.6.3.3.3
 - **Description:** DmOS notifications related to card manager events.
 - **Object identities:**
 - dmosCardmgrNotificationGroups (1.3.6.1.4.1.3709.3.6.3.3.3.1)

8.1 dmosCardmgrAlarmTrapsGroup

OID: 1.3.6.1.4.1.3709.3.6.3.3.3.1.1

Description: Traps generated by card manager alarms.

Status: current

8.2 cardNotProvisionedAlarmTrap

OID: 1.3.6.1.4.1.3709.3.6.3.3.3.2

Description: Card not provisioned alarm trap.

Status: current

8.3 cardNotPresentAlarmTrap

OID: 1.3.6.1.4.1.3709.3.6.3.3.3.3

Description: Card not present alarm trap.

Status: current

8.4 cardRemovedAlarmTrap

OID: 1.3.6.1.4.1.3709.3.6.3.3.3.4

Description: Card removed alarm trap.

Status: current

8.5 cardMismatchAlarmTrap

OID: 1.3.6.1.4.1.3709.3.6.3.3.3.5

Description: Card mismatch alarm trap.

Status: current

8.6 cardInsertedTrap

OID: 1.3.6.1.4.1.3709.3.6.3.3.3.6

Description: Card inserted trap.

Status: current

8.7 cardRemovedTrap

OID: 1.3.6.1.4.1.3709.3.6.3.3.3.7

Description: Card removed trap.

Status: current

8.8 fanModuleNotPresentAlarmTrap

OID: 1.3.6.1.4.1.3709.3.6.3.3.3.8

Description: Fan module not present alarm trap.

Status: current

8.9 cardUpdatedTrap

OID: 1.3.6.1.4.1.3709.3.6.3.3.3.9

Description: Card updated trap.

Status: current

8.10 psuUnsupportedAlarmTrap

OID: 1.3.6.1.4.1.3709.3.6.3.3.3.10

Description: PSU not supported in this product.

Status: current

8.11 cardUninitializedAlarmTrap

OID: 1.3.6.1.4.1.3709.3.6.3.3.3.11

Description: Card could not be correctly initialized.

Status: current

9 DMOS-CFM-MIB

MIB file: DMOS-CFM-MIB.mib

This MIB file has the following root objects:

- **dmosCfmMIB**
 - **OID:** 1.3.6.1.4.1.3709.3.6.14
 - **Description:** The DmOS MIB module for the CFM protocol
 - **Object identities:**
 - cfmDelayMeasurement (1.3.6.1.4.1.3709.3.6.14.1)

9.1 cfmDelayMeasurementProbeTable

OID: 1.3.6.1.4.1.3709.3.6.14.1.1

Description: Display CFM Delay Measurement Probes List

Syntax: SEQUENCE OF cfmDelayMeasurementProbeEntry (OID: 1.3.6.1.4.1.3709.3.6.14.1.1.1)

Access: not-accessible

Status: current

9.1.1 cfmDelayMeasurementProbeId

OID: 1.3.6.1.4.1.3709.3.6.14.1.1.1.1

Syntax: UnsignedShort

Access: read-only

Status: current

9.2 cfmDelayMeasurementProbeSessionTable

OID: 1.3.6.1.4.1.3709.3.6.14.1.2

Description: Display CFM Delay Measurement Sessions

Syntax: SEQUENCE OF cfmDelayMeasurementProbeSessionEntry (OID: 1.3.6.1.4.1.3709.3.6.14.1.2.1)

Access: not-accessible

Status: current

9.2.1 cfmDelayMeasurementProbeSessionId

OID: 1.3.6.1.4.1.3709.3.6.14.1.2.1.1

Syntax: UnsignedShort

Access: read-only

Status: current

9.2.2 cfmDelayMeasurementProbeSessionPcp

OID: 1.3.6.1.4.1.3709.3.6.14.1.2.1.2

Description: Display data of a session with a specific PCP

Syntax: Integer32

Access: read-only

Status: current

9.2.3 cfmDelayMeasurementProbeSessionLastAvgDelay

OID: 1.3.6.1.4.1.3709.3.6.14.1.2.1.3

Syntax: Integer32

Access: read-only

Status: current

9.2.4 cfmDelayMeasurementProbeSessionLastMinDelay

OID: 1.3.6.1.4.1.3709.3.6.14.1.2.1.4

Syntax: Integer32

Access: read-only

Status: current

9.2.5 cfmDelayMeasurementProbeSessionLastMaxDelay

OID: 1.3.6.1.4.1.3709.3.6.14.1.2.1.5

Syntax: Integer32

Access: read-only

Status: current

9.2.6 cfmDelayMeasurementProbeSessionLastAvgJitter

OID: 1.3.6.1.4.1.3709.3.6.14.1.2.1.6

Syntax: Integer32

Access: read-only

Status: current

9.2.7 cfmDelayMeasurementProbeSessionLastMinJitter

OID: 1.3.6.1.4.1.3709.3.6.14.1.2.1.7

Syntax: Integer32

Access: read-only

Status: current

9.2.8 cfmDelayMeasurementProbeSessionLastMaxJitter

OID: 1.3.6.1.4.1.3709.3.6.14.1.2.1.8

Syntax: Integer32

Access: read-only

Status: current

9.2.9 cfmDelayMeasurementProbeSessionLastLossRatio

OID: 1.3.6.1.4.1.3709.3.6.14.1.2.1.9

Syntax: Integer32

Access: read-only

Status: current

9.2.10 cfmDelayMeasurementProbeSessionLastPcpMismatchRatio

OID: 1.3.6.1.4.1.3709.3.6.14.1.2.1.10

Syntax: Integer32

Access: read-only

Status: current

9.2.11 cfmDelayMeasurementProbeSessionAllAvgDelay

OID: 1.3.6.1.4.1.3709.3.6.14.1.2.1.11

Syntax: Integer32

Access: read-only

Status: current

9.2.12 cfmDelayMeasurementProbeSessionAllMinDelay

OID: 1.3.6.1.4.1.3709.3.6.14.1.2.1.12

Syntax: Integer32

Access: read-only

Status: current

9.2.13 cfmDelayMeasurementProbeSessionAllMaxDelay

OID: 1.3.6.1.4.1.3709.3.6.14.1.2.1.13

Syntax: Integer32

Access: read-only

Status: current

9.2.14 cfmDelayMeasurementProbeSessionAllAvgJitter

OID: 1.3.6.1.4.1.3709.3.6.14.1.2.1.14

Syntax: Integer32

Access: read-only

Status: current

9.2.15 cfmDelayMeasurementProbeSessionAllMinJitter

OID: 1.3.6.1.4.1.3709.3.6.14.1.2.1.15

Syntax: Integer32

Access: read-only

Status: current

9.2.16 cfmDelayMeasurementProbeSessionAllMaxJitter

OID: 1.3.6.1.4.1.3709.3.6.14.1.2.1.16

Syntax: Integer32

Access: read-only

Status: current

9.2.17 cfmDelayMeasurementProbeSessionAllLossRatio

OID: 1.3.6.1.4.1.3709.3.6.14.1.2.1.17

Syntax: Integer32

Access: read-only

Status: current

9.2.18 cfmDelayMeasurementProbeSessionAllPcpMismatchRatio

OID: 1.3.6.1.4.1.3709.3.6.14.1.2.1.18

Syntax: Integer32

Access: read-only

Status: current

10 DMOS-CONFIG-NOTIFICATIONS-MIB

MIB file: DMOS-CONFIG-NOTIFICATIONS-MIB.mib

This MIB file has the following root objects:

- **dmosConfigNotificationsMIB**
 - **OID:** 1.3.6.1.4.1.3709.3.6.3.3.8
 - **Description:** DmOS MIB module for configuration notifications.
 - **Object identities:**
 - dmosConfigNotificationGroups (1.3.6.1.4.1.3709.3.6.3.3.8.1)

10.1 configCommit

OID: 1.3.6.1.4.1.3709.3.6.3.3.8.2

Description: Configuration commit trap.

Status: current

11 DMOS-CPU-NOTIFICATIONS-MIB

MIB file: DMOS-CPU-NOTIFICATIONS-MIB.mib

This MIB file has the following root objects:

- **dmosCpuNotificationsMIB**
 - **OID:** 1.3.6.1.4.1.3709.3.6.3.3.0
 - **Description:** The CPU notifications designed to be used by notification manager
 - **Object identities:**
 - dmosCpuNotificationObjects (1.3.6.1.4.1.3709.3.6.3.3.0.1)
 - dmosCpuNotificationGroups (1.3.6.1.4.1.3709.3.6.3.3.0.2)

11.1 dmosCpuNotificationThreshold

OID: 1.3.6.1.4.1.3709.3.6.3.3.0.1.1

Description: CPU alarm threshold percentage.

Syntax: UnsignedPercent

Access: accessible-for-notify

Status: current

11.2 dmosCpuNotificationInterval

OID: 1.3.6.1.4.1.3709.3.6.3.3.0.1.2

Description: Time interval that generated the alarm value.

Syntax: Gauge32

Access: accessible-for-notify

Status: current

11.3 dmosCpuNotificationValue

OID: 1.3.6.1.4.1.3709.3.6.3.3.0.1.3

Description: CPU load value that generated the alarm.

Syntax: UnsignedPercent

Access: accessible-for-notify

Status: current

11.4 dmosCpuNotificationCoreId

OID: 1.3.6.1.4.1.3709.3.6.3.3.0.1.4

Description: Identifier of CPU core that generated the alarm

Syntax: Gauge32

Access: accessible-for-notify

Status: current

11.5 dmosCpuAlarmInfoGroup

OID: 1.3.6.1.4.1.3709.3.6.3.3.0.2.1

Description: A set of objects that provides more information about CPU alarms.

Status: current

11.6 dmosCpuAlarmTrapsGroup

OID: 1.3.6.1.4.1.3709.3.6.3.3.0.2.2

Description: Traps generated by CPU alarms.

Status: current

11.7 cpuLoadHighTrap

OID: 1.3.6.1.4.1.3709.3.6.3.3.0.3

Description: Alarm trap for high CPU load.

Status: current

11.8 cpuCoreHighTrap

OID: 1.3.6.1.4.1.3709.3.6.3.3.0.4

Description: Alarm trap for high CPU core load.

Status: current

12 DMOS-EAPS

MIB file: DMOS-EAPS.mib

This MIB file has the following root objects:

- **dmosEapsMIB**
 - **OID:** 1.3.6.1.4.1.3709.3.6.17
 - **Description:** This module contains the YANG definitions for EAPS protocol.

12.1 eapsStateTable

OID: 1.3.6.1.4.1.3709.3.6.17.1

Description: This table holds all EAPS domain entries with status and current config information.

Syntax: SEQUENCE OF eapsStateEntry (OID: 1.3.6.1.4.1.3709.3.6.17.1.1)

Access: not-accessible

Status: current

12.1.1 eapsDomainID

OID: 1.3.6.1.4.1.3709.3.6.17.1.1.1

Description: EAPS configured domain.

Syntax: UnsignedByte

Syntax details: (Range) 0 - 63

Access: read-only

Status: current

12.1.2 eapsDomainName

OID: 1.3.6.1.4.1.3709.3.6.17.1.1.2

Description: Current text name configured for EAPS domain. If not configured, this OID will return 'No such instance currently exists at this OID'.

Syntax: String

Syntax details: (Size) 1 - 48

Access: read-only

Status: current

12.1.3 eapsDomainState

OID: 1.3.6.1.4.1.3709.3.6.17.1.1.3

Description: The current state of the EAPS domain. The possible states are Idle, Init, Complete, Failed, Pre Forwarding, Links Up and Link Down.

Syntax: INTEGER

Syntax details: (Enumeration) 'complete': 2, 'failed': 3, 'idle': 0, 'init': 1, 'link-down': 6, 'links-up': 5, 'pre-forwarding': 4

Access: read-only

Status: current

12.1.4 eapsDomainMode

OID: 1.3.6.1.4.1.3709.3.6.17.1.1.4

Description: Domain mode current configuration. A ring is allowed to have a single Master(0) node and multiple Transit(1) nodes.

Syntax: Node_mode

Access: read-only

Status: current

12.1.5 eapsDomainPrimaryPortState

OID: 1.3.6.1.4.1.3709.3.6.17.1.1.5

Description: The state of the domain primary port, where Up and Down refer to port link status and Enable and Blocked refer to the port traffic block state.

Syntax: Port_state

Access: read-only

Status: current

12.1.6 eapsDomainSecondaryPortState

OID: 1.3.6.1.4.1.3709.3.6.17.1.1.6

Description: The state of the domain secondary port, where Up and Down refer to port link status and Enable and Blocked refer to the port traffic block state.

Syntax: Port_state

Access: read-only

Status: current

12.1.7 eapsDomainHealthCheckState

OID: 1.3.6.1.4.1.3709.3.6.17.1.1.7

Description: Holds the health check state of the domain, wich can be OK or Failed. It'll return 'No such instance currently exists at this OID' until it assumes Ok or Failed state

Syntax: INTEGER

Syntax details: (Enumeration) 'failed': 1, 'ok': 0

Access: read-only

Status: current

12.2 eapsConfigTable

OID: 1.3.6.1.4.1.3709.3.6.17.2

Description: Table that holds all entries for reading current configuration of EAPS domains.

Syntax: SEQUENCE OF eapsConfigEntry (OID: 1.3.6.1.4.1.3709.3.6.17.2.1)

Access: not-accessible

Status: current

12.2.1 eapsCfgDomainID

OID: 1.3.6.1.4.1.3709.3.6.17.2.1.1

Description: EAPS configured domain.

Syntax: UnsignedByte

Syntax details: (Range) 0 - 63

Access: read-only

Status: current

12.2.2 eapsCfgDomainPrimaryPort

OID: 1.3.6.1.4.1.3709.3.6.17.2.1.2

Description: The primary port configured in the domain.

Syntax: String

Access: read-only

Status: current

12.2.3 eapsCfgDomainSecondaryPort

OID: 1.3.6.1.4.1.3709.3.6.17.2.1.3

Description: The secondary port configured in the domain.

Syntax: String

Access: read-only

Status: current

13 DMOS-EDFA-MIB

MIB file: DMOS-EDFA-MIB.mib

This MIB file has the following root objects:

- **dmosEdfaMIB**
 - **OID:** 1.3.6.1.4.1.3709.3.6.25
 - **Description:** This module contains DmOS EDFA status monitoring objects.
 - **Object identities:**
 - edfa (1.3.6.1.4.1.3709.3.6.25.1)
 - raman (1.3.6.1.4.1.3709.3.6.25.2)

13.1 edfaTable

OID: 1.3.6.1.4.1.3709.3.6.25.1.1

Description: Table containing EDFA entries.

Syntax: SEQUENCE OF edfaEntry (OID: 1.3.6.1.4.1.3709.3.6.25.1.1.1)

Access: not-accessible

Status: current

13.1.1 edfaInterfaceName

OID: 1.3.6.1.4.1.3709.3.6.25.1.1.1.2

Description: Name of the EDFA interface.

Syntax: DisplayString

Access: read-only

Status: current

13.1.2 edfaDescription

OID: 1.3.6.1.4.1.3709.3.6.25.1.1.1.3

Description: Configured description.

Syntax: Description

Access: read-only

Status: current

13.1.3 edfaInputPower

OID: 1.3.6.1.4.1.3709.3.6.25.1.1.1.4

Description: Current input power.

Syntax: OpticalPower

Access: read-only

Status: current

13.1.4 edfaOutputPower

OID: 1.3.6.1.4.1.3709.3.6.25.1.1.1.5

Description: Current output power.

Syntax: OpticalPower

Access: read-only

Status: current

13.1.5 edfaSignalPower

OID: 1.3.6.1.4.1.3709.3.6.25.1.1.1.6

Description: Current signal power.

Syntax: OpticalPower

Access: read-only

Status: current

13.1.6 edfaGain

OID: 1.3.6.1.4.1.3709.3.6.25.1.1.1.7

Description: Current gain.

Syntax: OpticalGain

Access: read-only

Status: current

13.1.7 edfaAmplifier

OID: 1.3.6.1.4.1.3709.3.6.25.1.1.1.8

Description: Current amplifier state.

Syntax: DisplayString

Access: read-only

Status: current

13.1.8 edfaLdCurrent

OID: 1.3.6.1.4.1.3709.3.6.25.1.1.1.9

Description: Current EDFA LD current.

Syntax: Current

Access: read-only

Status: current

13.1.9 edfaLdEolCurrent

OID: 1.3.6.1.4.1.3709.3.6.25.1.1.1.10

Description: Current EDFA LD EOL current.

Syntax: Current

Access: read-only

Status: current

13.1.10 edfaTecCurrent

OID: 1.3.6.1.4.1.3709.3.6.25.1.1.1.11

Description: Current EDFA TEC current.

Syntax: Current

Access: read-only

Status: current

13.1.11 edfaTecVoltage

OID: 1.3.6.1.4.1.3709.3.6.25.1.1.1.12

Description: Current EDFA TEC voltage.

Syntax: Voltage

Access: read-only

Status: current

13.1.12 edfaSupplyVoltage

OID: 1.3.6.1.4.1.3709.3.6.25.1.1.1.13

Description: Current EDFA supply voltage.

Syntax: Voltage

Access: read-only

Status: current

13.1.13 edfaLdTemperature

OID: 1.3.6.1.4.1.3709.3.6.25.1.1.1.14

Description: Current LD temperature.

Syntax: Temperature

Access: read-only

Status: current

13.1.14 edfaCaseTemperature

OID: 1.3.6.1.4.1.3709.3.6.25.1.1.1.15

Description: Current case temperature.

Syntax: Temperature

Access: read-only

Status: current

13.2 ramanTable

OID: 1.3.6.1.4.1.3709.3.6.25.2.1

Description: Table containing Raman entries.

Syntax: SEQUENCE OF ramanEntry (OID: 1.3.6.1.4.1.3709.3.6.25.2.1.1)

Access: not-accessible

Status: current

13.2.1 ramanInterfaceName

OID: 1.3.6.1.4.1.3709.3.6.25.2.1.1.2

Description: Name of the Raman interface.

Syntax: DisplayString

Access: read-only

Status: current

13.2.2 ramanInputPower

OID: 1.3.6.1.4.1.3709.3.6.25.2.1.1.3

Description: Current Raman signal power.

Syntax: OpticalPower

Access: read-only

Status: current

13.2.3 ramanOutputPower

OID: 1.3.6.1.4.1.3709.3.6.25.2.1.1.4

Description: Current Raman output power.

Syntax: OpticalPower

Access: read-only

Status: current

13.2.4 ramanSignalPower

OID: 1.3.6.1.4.1.3709.3.6.25.2.1.1.5

Description: Current Raman signal power.

Syntax: OpticalPower

Access: read-only

Status: current

13.2.5 ramanAsePower

OID: 1.3.6.1.4.1.3709.3.6.25.2.1.1.6

Description: Current Raman ASE power.

Syntax: OpticalPower

Access: read-only

Status: current

13.2.6 ramanReflectionPower

OID: 1.3.6.1.4.1.3709.3.6.25.2.1.1.7

Description: Current Raman reflection power.

Syntax: OpticalPower

Access: read-only

Status: current

13.2.7 ramanGain

OID: 1.3.6.1.4.1.3709.3.6.25.2.1.1.8

Description: Current Raman gain.

Syntax: OpticalGain

Access: read-only

Status: current

13.2.8 ramanAmplifier

OID: 1.3.6.1.4.1.3709.3.6.25.2.1.1.9

Description: Current Raman amplifier state.

Syntax: DisplayString

Access: read-only

Status: current

13.2.9 ramanCaseTemperature

OID: 1.3.6.1.4.1.3709.3.6.25.2.1.1.10

Description: Current Raman case temperature.

Syntax: Temperature

Access: read-only

Status: current

13.2.10 ramanPumpPower

OID: 1.3.6.1.4.1.3709.3.6.25.2.1.1.11

Description: Current Raman pump 1 power.

Syntax: PumpPower

Access: read-only

Status: current

13.2.11 ramanLdCurrent

OID: 1.3.6.1.4.1.3709.3.6.25.2.1.1.12

Description: Current Raman pump 1 LD current.

Syntax: Current

Access: read-only

Status: current

13.2.12 ramanLdEolCurrent

OID: 1.3.6.1.4.1.3709.3.6.25.2.1.1.13

Description: Current Raman pump 1 LD EOL current.

Syntax: Current

Access: read-only

Status: current

13.2.13 ramanTecCurrent

OID: 1.3.6.1.4.1.3709.3.6.25.2.1.1.14

Description: Current Raman pump 1 LD TEC current.

Syntax: Current

Access: read-only

Status: current

13.2.14 ramanTecVoltage

OID: 1.3.6.1.4.1.3709.3.6.25.2.1.1.15

Description: Current Raman pump 1 TEC voltage.

Syntax: Voltage

Access: read-only

Status: current

13.2.15 ramanLdTemperature

OID: 1.3.6.1.4.1.3709.3.6.25.2.1.1.16

Description: Current Raman pump 1 LD temperature.

Syntax: Temperature

Access: read-only

Status: current

13.2.16 ramanPumpPower2

OID: 1.3.6.1.4.1.3709.3.6.25.2.1.1.17

Description: Current Raman pump 2 power.

Syntax: PumpPower

Access: read-only

Status: current

13.2.17 ramanLdCurrent2

OID: 1.3.6.1.4.1.3709.3.6.25.2.1.1.18

Description: Current Raman pump 2 LD current.

Syntax: Current

Access: read-only

Status: current

13.2.18 ramanLdEolCurrent2

OID: 1.3.6.1.4.1.3709.3.6.25.2.1.1.19

Description: Current Raman pump 2 LD EOL current.

Syntax: Current

Access: read-only

Status: current

13.2.19 ramanTecCurrent2

OID: 1.3.6.1.4.1.3709.3.6.25.2.1.1.20

Description: Current Raman pump 2 LD TEC current.

Syntax: Current

Access: read-only

Status: current

13.2.20 ramanTecVoltage2

OID: 1.3.6.1.4.1.3709.3.6.25.2.1.1.21

Description: Current Raman pump 2 TEC voltage.

Syntax: Voltage

Access: read-only

Status: current

13.2.21 ramanLdTemperature2

OID: 1.3.6.1.4.1.3709.3.6.25.2.1.1.22

Description: Current Raman pump 2 LD temperature.

Syntax: Temperature

Access: read-only

Status: current

14 DMOS-ERPS-MIB

MIB file: DMOS-ERPS-MIB.mib

This MIB file has the following root objects:

- **dmosErpsMIB**
 - **OID:** 1.3.6.1.4.1.3709.3.6.16
 - **Description:** This module contains the YANG definitions for ERPS protocol status.

14.1 erpsStateTable

OID: 1.3.6.1.4.1.3709.3.6.16.1

Description: Display ERPS rings information.

Syntax: SEQUENCE OF erpsStateEntry (OID: 1.3.6.1.4.1.3709.3.6.16.1.1)

Access: not-accessible

Status: current

14.1.1 erpsRingId

OID: 1.3.6.1.4.1.3709.3.6.16.1.1.1

Description: The ERPS ring identifier

Syntax: Integer32

Syntax details: (Range) 1 - 239

Access: read-only

Status: current

14.1.2 erpsRingControlVlan

OID: 1.3.6.1.4.1.3709.3.6.16.1.1.2

Description: The VLAN ID used for ERPS control packets, in this ring instance.

Syntax: Unsigned32

Syntax details: (Range) 1 - 4094

Access: read-only

Status: current

14.1.3 erpsRingName

OID: 1.3.6.1.4.1.3709.3.6.16.1.1.3

Description: The textual name for this ERPS ring instance, according to the network manager's choice

Syntax: String

Syntax details: (Size) 1 - 48

Access: read-only

Status: current

14.1.4 erpsRingType

OID: 1.3.6.1.4.1.3709.3.6.16.1.1.4

Description: Ring Type of this instance. Possible types are Major-ring and Sub-ring.

Syntax: INTEGER

Syntax details: (Enumeration) 'major-ring': 0, 'sub-ring': 1

Access: read-only

Status: current

14.1.5 erpsRingParentRing

OID: 1.3.6.1.4.1.3709.3.6.16.1.1.5

Description: The parent-ring name for this ring instance. This information is available only when ring-type parameter is set to sub-ring. In major-rings it'll return 'No such instance currently exists at this OID'.

Syntax: String

Syntax details: (Size) 1 - 48

Access: read-only

Status: current

14.1.6 erpsRingState

OID: 1.3.6.1.4.1.3709.3.6.16.1.1.6

Description: The current state of the ring instance. The possible states are Init(0), Idle(1), Protection(2), ManualSwitch(3), ForcedSwitch(4), Pending(5) and Unknown(6).

Syntax: Erps_ring_status

Access: read-only

Status: current

14.1.7 erpsRingPort0

OID: 1.3.6.1.4.1.3709.3.6.16.1.1.7

Description: The first ring instance's port.

Syntax: String

Access: read-only

Status: current

14.1.8 erpsRingPort0RplRole

OID: 1.3.6.1.4.1.3709.3.6.16.1.1.8

Description: The RPL role of the first ring instance's port. Possible values are none, owner and neighbor.

Syntax: INTEGER

Syntax details: (Enumeration) 'neighbor': 2, 'none': 0, 'owner': 1

Access: read-only

Status: current

14.1.9 erpsRingPort0LocalFailure

OID: 1.3.6.1.4.1.3709.3.6.16.1.1.9

Description: Inform if the first port has a local failure. Possible values are Yes(0) and No(1).

Syntax: Erps_yes_or_no

Access: read-only

Status: current

14.1.10 erpsRingPort0State

OID: 1.3.6.1.4.1.3709.3.6.16.1.1.10

Description: The state of the first port. Possible values are Unknown(0), Forward(1), Blocked(2), Data-Blocked(3) and Control-Channel-Blocked(4).

Syntax: Erps_port_state

Access: read-only

Status: current

14.1.11 erpsRingPort1

OID: 1.3.6.1.4.1.3709.3.6.16.1.1.11

Description: The second ring instance's port.

Syntax: String

Access: read-only

Status: current

14.1.12 erpsRingPort1RplRole

OID: 1.3.6.1.4.1.3709.3.6.16.1.1.12

Description: The RPL role of the second ring instance's port. Possible values are owner, neighbor, and none. It'll return 'No such instance currently exists at this OID' on sub-rings interconnection nodes with virtual-channel configuration.

Syntax: INTEGER

Syntax details: (Enumeration) 'neighbor': 2, 'none': 0, 'owner': 1

Access: read-only

Status: current

14.1.13 erpsRingPort1LocalFailure

OID: 1.3.6.1.4.1.3709.3.6.16.1.1.13

Description: Inform if the second port has a local failure. Possible values are Yes(0) and No(1). It'll return 'No such instance currently exists at this OID' on sub-rings interconnection nodes with virtual-channel configuration.

Syntax: Erps_yes_or_no

Access: read-only

Status: current

14.1.14 erpsRingPort1State

OID: 1.3.6.1.4.1.3709.3.6.16.1.1.14

Description: The state of the second port. Possible values are Unknown(0), Forward(1), Blocked(2), Data-Blocked(3) and Control-Channel-Blocked(4). It'll return 'No such instance currently exists at this OID' on sub-rings interconnection nodes with virtual-channel configuration.

Syntax: Erps_port_state

Access: read-only

Status: current

15 DMOS-EXPERIMENTAL-NOTIFICATIONS-MIB

MIB file: DMOS-EXPERIMENTAL-NOTIFICATIONS-MIB.mib

This MIB file has the following root objects:

- **experimentalDmosNotifications**
 - **OID:** 1.3.6.1.4.1.3709.3.6.3.3.4294967294
- **dmosExperimentalNotificationsMIB**
 - **OID:** 1.3.6.1.4.1.3709.3.6.3.3.4294967294
 - **Description:** This module contains experimental DmOS notifications and related objects for internal use and can change without notice
 - **Object identities:**
 - experimentalNotificationObjects (1.3.6.1.4.1.3709.3.6.3.3.4294967294.1)
 - experimentalCustomNotifications (1.3.6.1.4.1.3709.3.6.3.3.4294967294.2)

16 DMOS-EXPERIMENTAL-TEST-NOTIFICATIONS-MIB

MIB file: DMOS-EXPERIMENTAL-TEST-NOTIFICATIONS-MIB.mib

This MIB file has the following root objects:

- **alarmTrap**
 - **OID:** 1.3.6.1.4.1.3709.3.6.3.4294967294.1
 - **Description:** Example trap.
- **dmosExperimentalTestNotificationsMIB**
 - **OID:** 1.3.6.1.4.1.3709.3.6.3.4294967294.1.2
 - **Description:** The notifications designed to be used in the tests of the notification manager
- **notificationTrap**
 - **OID:** 1.3.6.1.4.1.3709.3.6.3.4294967294.2.1
 - **Description:** A trap without binds.
- **eventTrap**
 - **OID:** 1.3.6.1.4.1.3709.3.6.3.4294967294.2.2
 - **Description:** A test trap.

16.1 testParamUint32

OID: 1.3.6.1.4.1.3709.3.6.3.4294967294.1.2.1

Description: An unsigned 32-bit integer for testing.

Syntax: Gauge32

Access: read-only

Status: current

16.2 testParamInt32

OID: 1.3.6.1.4.1.3709.3.6.3.4294967294.1.2.2

Description: A signed 32-bit integer for testing.

Syntax: Integer32

Access: read-only

Status: current

16.3 testParamStr

OID: 1.3.6.1.4.1.3709.3.6.3.4294967294.1.2.3

Description: A string for testing.

Syntax: DisplayString

Access: read-only

Status: current

16.4 testParamFloat

OID: 1.3.6.1.4.1.3709.3.6.3.4294967294.1.2.4

Description: A signed 32-bit integer for testing.

Syntax: FixedPoint2Dec

Access: read-only

Status: current

17 DMOS-GPON-NOTIFICATIONS-MIB

MIB file: DMOS-GPON-NOTIFICATIONS-MIB.mib

This MIB file has the following root objects:

- **dmosGponNotificationsMIB**
 - **OID:** 1.3.6.1.4.1.3709.3.6.3.3.4
 - **Description:** DmOS notifications related to GPON events.
 - **Object identities:**
 - dmosGponNotificationGroups (1.3.6.1.4.1.3709.3.6.3.3.4.1)

17.1 dmosGponAlarmTrapsGroup

OID: 1.3.6.1.4.1.3709.3.6.3.3.4.1.1

Description: Traps generated by GPON alarms.

Status: current

17.2 gPonOnuAutoProvAddFailTrap

OID: 1.3.6.1.4.1.3709.3.6.3.3.4.2

Description: Failure adding ONU during auto provisioning on PON link.

Status: current

18 DMOS-HW-MONITOR-MIB

MIB file: DMOS-HW-MONITOR-MIB.mib

This MIB file has the following root objects:

- **dmosHwMonitorMIB**
 - **OID:** 1.3.6.1.4.1.3709.3.6.6
 - **Description:** This module contains DmOS thermal information and status monitoring objects.
 - **Object identities:**
 - environment (1.3.6.1.4.1.3709.3.6.6.1)

18.1 environmentChassisTable

OID: 1.3.6.1.4.1.3709.3.6.6.1.1

Description: List of chassis for which thermal management information is available

Syntax: SEQUENCE OF environmentChassisEntry (OID: 1.3.6.1.4.1.3709.3.6.6.1.1.1)

Access: not-accessible

Status: current

18.1.1 environmentChassisId

OID: 1.3.6.1.4.1.3709.3.6.6.1.1.1.1

Description: Chassis identifier

Syntax: Unsigned32

Access: read-only

Status: current

18.2 environmentSlotTable

OID: 1.3.6.1.4.1.3709.3.6.6.1.2

Description: List of slots for which thermal management information is available

Syntax: SEQUENCE OF environmentSlotEntry (OID: 1.3.6.1.4.1.3709.3.6.6.1.2.1)

Access: not-accessible

Status: current

18.2.1 environmentSlotId

OID: 1.3.6.1.4.1.3709.3.6.6.1.2.1.1

Description: Slot identifier

Syntax: DisplayString

Access: read-only

Status: current

18.3 temperatureSensorTable

OID: 1.3.6.1.4.1.3709.3.6.6.1.3

Description: List of temperature sensors present on a given slot and chassis

Syntax: SEQUENCE OF temperatureSensorEntry (OID: 1.3.6.1.4.1.3709.3.6.6.1.3.1)

Access: not-accessible

Status: current

18.3.1 temperatureSensorId

OID: 1.3.6.1.4.1.3709.3.6.6.1.3.1.1

Description: Temperature sensor identifier

Syntax: DisplayString

Access: not-accessible

Status: current

18.3.2 temperatureSensorDescription

OID: 1.3.6.1.4.1.3709.3.6.6.1.3.1.2

Description: Temperature sensor description

Syntax: DisplayString

Access: read-only

Status: current

18.3.3 temperatureSensorMaxTemperature

OID: 1.3.6.1.4.1.3709.3.6.6.1.3.1.3

Description: High temperature alarm threshold

Syntax: EnvironmentSensorTemperature

Access: read-only

Status: current

18.3.4 temperatureSensorMinTemperature

OID: 1.3.6.1.4.1.3709.3.6.6.1.3.1.4

Description: Low temperature alarm threshold

Syntax: EnvironmentSensorTemperature

Access: read-only

Status: current

18.3.5 temperatureSensorHysteresis

OID: 1.3.6.1.4.1.3709.3.6.6.1.3.1.5

Description: Hysteresis value for both high and low temperature alarms

Syntax: EnvironmentSensorTemperature

Access: read-only

Status: current

18.3.6 temperatureSensorCurrentTemperature

OID: 1.3.6.1.4.1.3709.3.6.6.1.3.1.6

Description: Current temperature value being read by the sensor

Syntax: EnvironmentSensorTemperature

Access: read-only

Status: current

18.3.7 temperatureSensorTemperatureReadError

OID: 1.3.6.1.4.1.3709.3.6.6.1.3.1.7

Description: Indicates if an error occurred while trying to read from the sensor

Syntax: TruthValue

Access: read-only

Status: current

18.3.8 temperatureSensorTemperatureStatus

OID: 1.3.6.1.4.1.3709.3.6.6.1.3.1.8

Description: Temperature status based on minimum and maximum thresholds

Syntax: EnvironmentSensorStatus

Access: read-only

Status: current

18.4 fanTable

OID: 1.3.6.1.4.1.3709.3.6.6.1.4

Description: List of individual fans manageable on a given fan module/slot

Syntax: SEQUENCE OF fanEntry (OID: 1.3.6.1.4.1.3709.3.6.6.1.4.1)

Access: not-accessible

Status: current

18.4.1 fanId

OID: 1.3.6.1.4.1.3709.3.6.6.1.4.1.1

Description: Fan identifier

Syntax: DisplayString

Access: not-accessible

Status: current

18.4.2 fanDescription

OID: 1.3.6.1.4.1.3709.3.6.6.1.4.1.2

Description: Fan description

Syntax: DisplayString

Access: read-only

Status: current

18.4.3 fanSpeed

OID: 1.3.6.1.4.1.3709.3.6.6.1.4.1.4

Description: Current speed of the fan

Syntax: Unsigned32

Access: read-only

Status: current

18.4.4 fanSpeedReadError

OID: 1.3.6.1.4.1.3709.3.6.6.1.4.1.5

Description: Indicates if an error occurred while trying to read from the sensor

Syntax: TruthValue

Access: read-only

Status: current

18.4.5 fanSpeedStatus

OID: 1.3.6.1.4.1.3709.3.6.6.1.4.1.6

Description: Indicates the current state of the fan based on its speed

Syntax: EnvironmentSensorStatus

Access: read-only

Status: current

18.5 psuTable

OID: 1.3.6.1.4.1.3709.3.6.6.1.5

Description: List of Power Supply Units

Syntax: SEQUENCE OF psuEntry (OID: 1.3.6.1.4.1.3709.3.6.6.1.5.1)

Access: not-accessible

Status: current

18.5.1 psuld

OID: 1.3.6.1.4.1.3709.3.6.6.1.5.1.1

Description: Power Supply Unit identifier

Syntax: DisplayString

Access: not-accessible

Status: current

18.5.2 psuStatus

OID: 1.3.6.1.4.1.3709.3.6.6.1.5.1.2

Description: Indicates the current state of the PSU

Syntax: INTEGER

Syntax details: (Enumeration) 'error': 3, 'fuseFailure': 2, 'ok': 0, 'powerInputFailure': 1

Access: read-only

Status: current

19 DMOS-HW-MONITOR-NOTIFICATIONS-MIB

MIB file: DMOS-HW-MONITOR-NOTIFICATIONS-MIB.mib

This MIB file has the following root objects:

- **dmosHwMonNotificationsMIB**
 - **OID:** 1.3.6.1.4.1.3709.3.6.3.3.2
 - **Description:** This MIB file contains the definition of DmOS notifications related to the hardware monitoring.
 - **Object identities:**
 - dmosHwMonNotificationObjects (1.3.6.1.4.1.3709.3.6.3.3.2.1)
 - dmosHwMonNotificationGroups (1.3.6.1.4.1.3709.3.6.3.3.2.2)

19.1 dmosHwMonValue

OID: 1.3.6.1.4.1.3709.3.6.3.3.2.1.1

Description: Current value that triggered the notification.

Syntax: Integer32

Access: accessible-for-notify

Status: current

19.2 dmosHwMonLimitValue

OID: 1.3.6.1.4.1.3709.3.6.3.3.2.1.2

Description: Current limit that was overflow and that triggered the notification.

Syntax: Integer32

Access: accessible-for-notify

Status: current

19.3 dmosHwMonAlarmInfoGroup

OID: 1.3.6.1.4.1.3709.3.6.3.3.2.2.1

Description: A set of objects that provides more information about hardware monitoring alarms.

Status: current

19.4 dmosFanAlarmTrapsGroup

OID: 1.3.6.1.4.1.3709.3.6.3.3.2.2.2

Description: Traps generated by fan alarms.

Status: current

19.5 dmosTempAlarmTrapsGroup

OID: 1.3.6.1.4.1.3709.3.6.3.3.2.2.3

Description: Traps generated by temperature alarms.

Status: current

19.6 dmosPsuAlarmTrapsGroup

OID: 1.3.6.1.4.1.3709.3.6.3.3.2.2.4

Description: Traps generated by PSU alarms.

Status: current

19.7 fanHighAlarmTrap

OID: 1.3.6.1.4.1.3709.3.6.3.3.2.3

Description: Alarm for fan speed above the safe rpm speed.

Status: current

19.8 fanLowAlarmTrap

OID: 1.3.6.1.4.1.3709.3.6.3.3.2.4

Description: Alarm for fan speed below the safe rpm speed.

Status: current

19.9 fanFailAlarmTrap

OID: 1.3.6.1.4.1.3709.3.6.3.3.2.5

Description: Alarm for fan in a fail condition. The fan must be checked.

Status: current

19.10 fanErrorAlarmTrap

OID: 1.3.6.1.4.1.3709.3.6.3.3.2.6

Description: Alarm to report that an error happened on fan status reading.

Status: current

19.11 tempHighAlarmTrap

OID: 1.3.6.1.4.1.3709.3.6.3.3.2.7

Description: Alarm for high temperature of the device.

Status: current

19.12 tempLowAlarmTrap

OID: 1.3.6.1.4.1.3709.3.6.3.3.2.8

Description: Alarm for low temperature of the device.

Status: current

19.13 tempErrorAlarmTrap

OID: 1.3.6.1.4.1.3709.3.6.3.3.2.9

Description: It was not possible to read the temperature sensor.

Status: current

19.14 tempCriticalAlarmTrap

OID: 1.3.6.1.4.1.3709.3.6.3.3.2.10

Description: Alarm for critical temperature of the device.

Status: current

19.15 psuPowerInputFailureAlarmTrap

OID: 1.3.6.1.4.1.3709.3.6.3.3.2.11

Description: Alarm for PSU power input failure.

Status: current

19.16 psuFuseFailureAlarmTrap

OID: 1.3.6.1.4.1.3709.3.6.3.3.2.12

Description: Alarm for PSU fuse failure.

Status: current

19.17 psuErrorAlarmTrap

OID: 1.3.6.1.4.1.3709.3.6.3.3.2.13

Description: Alarm for PSU status check error.

Status: current

20 DMOS-INVENTORY-FAILURE-MIB

MIB file: DMOS-INVENTORY-FAILURE-MIB.mib

This MIB file has the following root objects:

- **dmosInventoryFailureMIB**
 - **OID:** 1.3.6.1.4.1.3709.3.6.3.3.10
 - **Description:** DmOS MIB for inventory failure trap.
 - **Object identities:**
 - dmosInventoryFailureGroups (1.3.6.1.4.1.3709.3.6.3.3.10.1)

20.1 inventoryErrorTrap

OID: 1.3.6.1.4.1.3709.3.6.3.3.10.2

Description: Failure to access the inventory trap.

Status: current

21 DMOS-INVENTORY-MIB

MIB file: DMOS-INVENTORY-MIB.mib

This MIB file has the following root objects:

- **dmosInventoryMIB**
 - **OID:** 1.3.6.1.4.1.3709.3.6.11

21.1 chassisTable

OID: 1.3.6.1.4.1.3709.3.6.11.1

Description: List of Chassis inventory information

Syntax: SEQUENCE OF chassisEntry (OID: 1.3.6.1.4.1.3709.3.6.11.1.1)

Access: not-accessible

Status: current

21.1.1 chassisChassisId

OID: 1.3.6.1.4.1.3709.3.6.11.1.1.1

Description: Chassis identification

Syntax: Unsigned32

Access: not-accessible

Status: current

21.1.2 chassisProductName

OID: 1.3.6.1.4.1.3709.3.6.11.1.1.2

Description: Name of product

Syntax: String

Access: read-only

Status: current

21.1.3 chassisPartNumber

OID: 1.3.6.1.4.1.3709.3.6.11.1.1.3

Description: Product part number

Syntax: String

Access: read-only

Status: current

21.1.4 chassisSerialNumber

OID: 1.3.6.1.4.1.3709.3.6.11.1.1.4

Description: Product serial number

Syntax: String

Access: read-only

Status: current

21.1.5 chassisVendor

OID: 1.3.6.1.4.1.3709.3.6.11.1.1.5

Description: Product vendor

Syntax: String

Access: read-only

Status: current

21.1.6 chassisProductModel

OID: 1.3.6.1.4.1.3709.3.6.11.1.1.6

Description: Hardware model of the product

Syntax: String

Access: read-only

Status: current

21.1.7 chassisProductRevision

OID: 1.3.6.1.4.1.3709.3.6.11.1.1.7

Description: Product revision

Syntax: UnsignedShort

Access: read-only

Status: current

21.1.8 chassisPcbRevision

OID: 1.3.6.1.4.1.3709.3.6.11.1.1.8

Description: PCB revision

Syntax: UnsignedShort

Access: read-only

Status: current

21.1.9 chassisHardwareVersion

OID: 1.3.6.1.4.1.3709.3.6.11.1.1.9

Description: Hardware version

Syntax: UnsignedByte

Access: read-only

Status: current

21.1.10 chassisOperationTemperature

OID: 1.3.6.1.4.1.3709.3.6.11.1.1.10

Description: Range of operating temperature

Syntax: String

Access: read-only

Status: current

21.1.11 chassisSystemMacAddress

OID: 1.3.6.1.4.1.3709.3.6.11.1.1.11

Description: Product MAC address

Syntax: HexList

Syntax details: (Size) 6 - 6

Access: read-only

Status: current

21.1.12 chassisFactoryStatus

OID: 1.3.6.1.4.1.3709.3.6.11.1.1.12

Description: Factory status of Product

Syntax: UnsignedByte

Access: read-only

Status: current

21.1.13 chassisNumMaintenance

OID: 1.3.6.1.4.1.3709.3.6.11.1.1.13

Description: Number of maintenances of Product

Syntax: UnsignedByte

Access: read-only

Status: current

21.1.14 chassisItemsMaintenance

OID: 1.3.6.1.4.1.3709.3.6.11.1.1.14

Description: Maintenance items of Product

Syntax: Unsigned32

Access: read-only

Status: current

21.1.15 chassisDateLastMaintenance

OID: 1.3.6.1.4.1.3709.3.6.11.1.1.15

Description: Date of last maintenance of Product

Syntax: String

Access: read-only

Status: current

21.1.16 chassisCardSpecific

OID: 1.3.6.1.4.1.3709.3.6.11.1.1.16

Description: Card specific info

Syntax: String

Access: read-only

Status: current

21.1.17 chassisFirmwareRevision

OID: 1.3.6.1.4.1.3709.3.6.11.1.17

Description: Firmware revision of Product

Syntax: String

Access: read-only

Status: current

21.1.18 chassisInventoryState

OID: 1.3.6.1.4.1.3709.3.6.11.1.18

Description: State of inventory

Syntax: INTEGER

Syntax details: (Enumeration) 'deferred-inventory': 4, 'invalid-inventory': 3, 'no-inventory': 2, 'valid-inventory': 1

Access: read-only

Status: current

21.2 chassisSlotTable

OID: 1.3.6.1.4.1.3709.3.6.11.2

Description: List of Slot inventory information

Syntax: SEQUENCE OF chassisSlotEntry (OID: 1.3.6.1.4.1.3709.3.6.11.2.1)

Access: not-accessible

Status: current

21.2.1 chassisSlotSlotId

OID: 1.3.6.1.4.1.3709.3.6.11.2.1.1

Description: Slot identification

Syntax: SlotIdTypeRestricted

Access: not-accessible

Status: current

21.2.2 chassisSlotId

OID: 1.3.6.1.4.1.3709.3.6.11.2.1.2

Description: Slot identification field in format chassis/slot

Syntax: String

Access: read-only

Status: current

21.2.3 chassisSlotCardPartNumber

OID: 1.3.6.1.4.1.3709.3.6.11.2.1.3

Description: Product part number

Syntax: String

Access: read-only

Status: current

21.2.4 chassisSlotCardSerialNumber

OID: 1.3.6.1.4.1.3709.3.6.11.2.1.4

Description: Product serial number

Syntax: String

Access: read-only

Status: current

21.2.5 chassisSlotCardVendor

OID: 1.3.6.1.4.1.3709.3.6.11.2.1.5

Description: Product vendor

Syntax: String

Access: read-only

Status: current

21.2.6 chassisSlotCardProductModel

OID: 1.3.6.1.4.1.3709.3.6.11.2.1.6

Description: Hardware model of the product

Syntax: String

Access: read-only

Status: current

21.2.7 chassisSlotCardProductRevision

OID: 1.3.6.1.4.1.3709.3.6.11.2.1.7

Description: Product revision

Syntax: UnsignedShort

Access: read-only

Status: current

21.2.8 chassisSlotCardPcbRevision

OID: 1.3.6.1.4.1.3709.3.6.11.2.1.8

Description: PCB revision

Syntax: UnsignedShort

Access: read-only

Status: current

21.2.9 chassisSlotCardHardwareVersion

OID: 1.3.6.1.4.1.3709.3.6.11.2.1.9

Description: Hardware version

Syntax: UnsignedByte

Access: read-only

Status: current

21.2.10 chassisSlotCardOperationTemperature

OID: 1.3.6.1.4.1.3709.3.6.11.2.1.10

Description: Range of operating temperature

Syntax: String

Access: read-only

Status: current

21.2.11 chassisSlotCardSystemMacAddress

OID: 1.3.6.1.4.1.3709.3.6.11.2.1.11

Description: Product MAC address

Syntax: HexList

Syntax details: (Size) 6 - 6

Access: read-only

Status: current

21.2.12 chassisSlotCardFactoryStatus

OID: 1.3.6.1.4.1.3709.3.6.11.2.1.12

Description: Factory status of Product

Syntax: UnsignedByte

Access: read-only

Status: current

21.2.13 chassisSlotCardNumMaintenance

OID: 1.3.6.1.4.1.3709.3.6.11.2.1.13

Description: Number of maintenances of Product

Syntax: UnsignedByte

Access: read-only

Status: current

21.2.14 chassisSlotCardItemsMaintenance

OID: 1.3.6.1.4.1.3709.3.6.11.2.1.14

Description: Maintenance items of Product

Syntax: Unsigned32

Access: read-only

Status: current

21.2.15 chassisSlotCardDateLastMaintenance

OID: 1.3.6.1.4.1.3709.3.6.11.2.1.15

Description: Date of last maintenance of Product

Syntax: String

Access: read-only

Status: current

21.2.16 chassisSlotCardCardSpecific

OID: 1.3.6.1.4.1.3709.3.6.11.2.1.16

Description: Card specific info

Syntax: String

Access: read-only

Status: current

21.2.17 chassisSlotCardFirmwareRevision

OID: 1.3.6.1.4.1.3709.3.6.11.2.1.17

Description: Firmware revision of Product

Syntax: String

Access: read-only

Status: current

21.2.18 chassisSlotCardInventoryState

OID: 1.3.6.1.4.1.3709.3.6.11.2.1.18

Description: State of inventory

Syntax: INTEGER

Syntax details: (Enumeration) 'deferred-inventory': 4, 'invalid-inventory': 3, 'no-inventory': 2, 'valid-inventory': 1

Access: read-only

Status: current

21.3 transceiverInventoryTable

OID: 1.3.6.1.4.1.3709.3.6.11.3

Description: List of transceiver inventory information

Syntax: SEQUENCE OF transceiverInventoryEntry (OID: 1.3.6.1.4.1.3709.3.6.11.3.1)

Access: not-accessible

Status: current

21.3.1 transceiverInventoryIfIndex

OID: 1.3.6.1.4.1.3709.3.6.11.3.1.1

Description: Interface index

Syntax: Unsigned32

Access: not-accessible

Status: current

21.3.2 transceiverInventoryInfoType

OID: 1.3.6.1.4.1.3709.3.6.11.3.1.2

Description: Transceiver type

Syntax: INTEGER

Syntax details: (Enumeration) 'dwdm-sfp': 11, 'gbic': 1, 'qsfp': 12, 'qsfp-dd': 24, 'qsfp-plus': 13, 'qsfp-plus-cmis': 30, 'qsfp28': 17, 'sfp': 3, 'soldered-on-mobo': 2, 'unknown': 0, 'x2': 10, 'xbi-300-pin': 4, 'xenpak': 5, 'xff': 7, 'xfp': 6, 'xfp-e': 8, 'xpak': 9

Access: read-only

Status: current

21.3.3 transceiverInventoryInfoConnector

OID: 1.3.6.1.4.1.3709.3.6.11.3.1.3

Description: Transceiver connector

Syntax: INTEGER

Syntax details: (Enumeration) 'bnc-tnc': 4, 'coaxial-headers': 5, 'copper-pigtail': 33, 'fiber-jack': 6, 'hssdc-ii': 32, 'lc': 7, 'mpo-parallel-optic': 12, 'mt-rj': 8, 'mu': 9, 'not-separable-connector': 35, 'optical-pigtail': 11, 'rj45': 34, 'sc': 1, 'sg': 10, 'style-1-copper': 2, 'style-2-copper': 3, 'unknown': 0

Access: read-only

Status: current

21.3.4 transceiverInventoryInfoEthernetStandards

OID: 1.3.6.1.4.1.3709.3.6.11.3.1.4

Description: Ethernet standards supported by the transceiver

Syntax: ConfdString

Access: read-only

Status: current

21.3.5 transceiverInventoryInfoVendorName

OID: 1.3.6.1.4.1.3709.3.6.11.3.1.5

Description: Transceiver vendor name

Syntax: String

Syntax details: (Size) 0 - 16

Access: read-only

Status: current

21.3.6 transceiverInventoryInfoVendorSn

OID: 1.3.6.1.4.1.3709.3.6.11.3.1.6

Description: Transceiver serial number

Syntax: String

Syntax details: (Size) 0 - 16

Access: read-only

Status: current

21.3.7 transceiverInventoryInfoVendorPn

OID: 1.3.6.1.4.1.3709.3.6.11.3.1.7

Description: Transceiver part number

Syntax: String

Syntax details: (Size) 0 - 16

Access: read-only

Status: current

21.3.8 transceiverInventoryInfoLaserWavelength

OID: 1.3.6.1.4.1.3709.3.6.11.3.1.8

Description: Transceiver laser wavelength

Syntax: String

Syntax details: (Size) 0 - 16

Access: read-only

Status: current

21.3.9 transceiverInventoryInfoDiagnostics

OID: 1.3.6.1.4.1.3709.3.6.11.3.1.9

Description: Transceiver digital diagnostics type

Syntax: INTEGER

Syntax details: (Enumeration) 'externally-calibrated': 2, 'internally-calibrated': 1, 'unavailable': 0

Access: read-only

Status: current

21.3.10 transceiverInventoryInfoTemperatureThresholdsAlarmLow

OID: 1.3.6.1.4.1.3709.3.6.11.3.1.10

Description: Low alarm threshold

Syntax: ConfdString

Access: read-only

Status: current

21.3.11 transceiverInventoryInfoTemperatureThresholdsAlarmHigh

OID: 1.3.6.1.4.1.3709.3.6.11.3.1.11

Description: High alarm threshold

Syntax: ConfdString

Access: read-only

Status: current

21.3.12 transceiverInventoryInfoTemperatureThresholdsWarningLow

OID: 1.3.6.1.4.1.3709.3.6.11.3.1.12

Description: Low warning threshold

Syntax: ConfdString

Access: read-only

Status: current

21.3.13 transceiverInventoryInfoTemperatureThresholdsWarningHigh

OID: 1.3.6.1.4.1.3709.3.6.11.3.1.13

Description: High warning threshold

Syntax: ConfdString

Access: read-only

Status: current

21.3.14 transceiverInventoryInfoRxPowerThresholdsAlarmLow

OID: 1.3.6.1.4.1.3709.3.6.11.3.1.14

Description: Low alarm threshold

Syntax: ConfdString

Access: read-only

Status: current

21.3.15 transceiverInventoryInfoRxPowerThresholdsAlarmHigh

OID: 1.3.6.1.4.1.3709.3.6.11.3.1.15

Description: High alarm threshold

Syntax: ConfdString

Access: read-only

Status: current

21.3.16 transceiverInventoryInfoRxPowerThresholdsWarningLow

OID: 1.3.6.1.4.1.3709.3.6.11.3.1.16

Description: Low warning threshold

Syntax: ConfdString

Access: read-only

Status: current

21.3.17 transceiverInventoryInfoRxPowerThresholdsWarningHigh

OID: 1.3.6.1.4.1.3709.3.6.11.3.1.17

Description: High warning threshold

Syntax: ConfdString

Access: read-only

Status: current

21.3.18 transceiverInventoryInfoTxPowerThresholdsAlarmLow

OID: 1.3.6.1.4.1.3709.3.6.11.3.1.18

Description: Low alarm threshold

Syntax: ConfdString

Access: read-only

Status: current

21.3.19 transceiverInventoryInfoTxPowerThresholdsAlarmHigh

OID: 1.3.6.1.4.1.3709.3.6.11.3.1.19

Description: High alarm threshold

Syntax: ConfdString

Access: read-only

Status: current

21.3.20 transceiverInventoryInfoTxPowerThresholdsWarningLow

OID: 1.3.6.1.4.1.3709.3.6.11.3.1.20

Description: Low warning threshold

Syntax: ConfdString

Access: read-only

Status: current

21.3.21 transceiverInventoryInfoTxPowerThresholdsWarningHigh

OID: 1.3.6.1.4.1.3709.3.6.11.3.1.21

Description: High warning threshold

Syntax: ConfdString

Access: read-only

Status: current

21.3.22 transceiverInventoryInfoVcc3v3ThresholdsAlarmLow

OID: 1.3.6.1.4.1.3709.3.6.11.3.1.22

Description: Low alarm threshold

Syntax: ConfdString

Access: read-only

Status: current

21.3.23 transceiverInventoryInfoVcc3v3ThresholdsAlarmHigh

OID: 1.3.6.1.4.1.3709.3.6.11.3.1.23

Description: High alarm threshold

Syntax: ConfdString

Access: read-only

Status: current

21.3.24 transceiverInventoryInfoVcc3v3ThresholdsWarningLow

OID: 1.3.6.1.4.1.3709.3.6.11.3.1.24

Description: Low warning threshold

Syntax: ConfdString

Access: read-only

Status: current

21.3.25 transceiverInventoryInfoVcc3v3ThresholdsWarningHigh

OID: 1.3.6.1.4.1.3709.3.6.11.3.1.25

Description: High warning threshold

Syntax: ConfdString

Access: read-only

Status: current

21.3.26 transceiverInventoryInfoTxBiasThresholdsAlarmLow

OID: 1.3.6.1.4.1.3709.3.6.11.3.1.26

Description: Low alarm threshold

Syntax: ConfdString

Access: read-only

Status: current

21.3.27 transceiverInventoryInfoTxBiasThresholdsAlarmHigh

OID: 1.3.6.1.4.1.3709.3.6.11.3.1.27

Description: High alarm threshold

Syntax: ConfdString

Access: read-only

Status: current

21.3.28 transceiverInventoryInfoTxBiasThresholdsWarningLow

OID: 1.3.6.1.4.1.3709.3.6.11.3.1.28

Description: Low warning threshold

Syntax: ConfdString

Access: read-only

Status: current

21.3.29 transceiverInventoryInfoTxBiasThresholdsWarningHigh

OID: 1.3.6.1.4.1.3709.3.6.11.3.1.29

Description: High warning threshold

Syntax: ConfdString

Access: read-only

Status: current

21.3.30 transceiverInventoryInfoPhysicalMedia

OID: 1.3.6.1.4.1.3709.3.6.11.3.1.30

Description: Transceiver physical media

Syntax: INTEGER

Syntax details: (Enumeration) 'electrical': 1, 'optical': 2, 'unknown': 0

Access: read-only

Status: current

21.3.31 transceiverInventoryInfoReadOk

OID: 1.3.6.1.4.1.3709.3.6.11.3.1.31

Description: Transceiver information valid

Syntax: TruthValue

Access: read-only

Status: current

21.3.32 transceiverInventoryInfoFiberType

OID: 1.3.6.1.4.1.3709.3.6.11.3.1.32

Description: Transceiver supported fiber type

Syntax: INTEGER

Syntax details: (Enumeration) 'multimode': 3, 'single-mode': 2, 'unavailable': 1, 'unknown': 0

Access: read-only

Status: current

22 DMOS-LBD-NOTIFICATIONS-MIB

MIB file: DMOS-LBD-NOTIFICATIONS-MIB.mib

This MIB file has the following root objects:

- **dmosLbdNotificationsMIB**
 - **OID:** 1.3.6.1.4.1.3709.3.6.3.3.6
 - **Description:** DmOS notifications related to loopback detection events.
 - **Object identities:**
 - dmosLbdNotificationGroups (1.3.6.1.4.1.3709.3.6.3.3.6.1)

22.1 dmosLbdAlarmTrapsGroup

OID: 1.3.6.1.4.1.3709.3.6.3.3.6.1.1

Description: Traps generated by loopback detection alarms.

Status: current

22.2 loopbackDetectedAlarmTrap

OID: 1.3.6.1.4.1.3709.3.6.3.3.6.2

Description: Loopback detected alarm trap.

Status: current

23 DMOS-LFD-NOTIFICATIONS-MIB

MIB file: DMOS-LFD-NOTIFICATIONS-MIB.mib

This MIB file has the following root objects:

- **dmosLfdNotificationsMIB**
 - **OID:** 1.3.6.1.4.1.3709.3.6.3.3.7
 - **Description:** DmOS notifications related to link flap detection events.
 - **Object identities:**
 - dmosLfdNotificationGroups (1.3.6.1.4.1.3709.3.6.3.3.7.1)

23.1 dmosLfdAlarmTrapsGroup

OID: 1.3.6.1.4.1.3709.3.6.3.3.7.1.1

Description: Traps generated by link flap detection alarms.

Status: current

23.2 linkFlapDetectedAlarmTrap

OID: 1.3.6.1.4.1.3709.3.6.3.3.7.2

Description: Link flap detected alarm trap.

Status: current

24 DMOS-LINE-PROTECTION-MIB

MIB file: DMOS-LINE-PROTECTION-MIB.mib

This MIB file has the following root objects:

- **dmosLineProtectionMIB**
 - **OID:** 1.3.6.1.4.1.3709.3.6.24
 - **Description:** This module contains DmOS Line-Protection status monitoring objects.

24.1 lineProtectionTable

OID: 1.3.6.1.4.1.3709.3.6.24.1

Description: Table containing Line-Protections.

Syntax: SEQUENCE OF lineProtectionEntry (OID: 1.3.6.1.4.1.3709.3.6.24.1.1)

Access: not-accessible

Status: current

24.1.1 interfaceName

OID: 1.3.6.1.4.1.3709.3.6.24.1.1.2

Description: Name of the Line-Protection interface.

Syntax: DisplayString

Access: read-only

Status: current

24.1.2 description

OID: 1.3.6.1.4.1.3709.3.6.24.1.1.3

Description: Configured description.

Syntax: Description

Access: read-only

Status: current

24.1.3 mode

OID: 1.3.6.1.4.1.3709.3.6.24.1.1.4

Description: Configured protection mode.

Syntax: ProtectionMode

Access: read-only

Status: current

24.1.4 activeLine

OID: 1.3.6.1.4.1.3709.3.6.24.1.1.5

Description: Current active line.

Syntax: ActiveLine

Access: read-only

Status: current

24.1.5 powerThresholdLine1

OID: 1.3.6.1.4.1.3709.3.6.24.1.1.6

Description: Configured Line-1 power threshold.

Syntax: OpticalPower

Access: read-only

Status: current

24.1.6 inputPowerLine1

OID: 1.3.6.1.4.1.3709.3.6.24.1.1.7

Description: Current input power of the Line-1.

Syntax: OpticalPower

Access: read-only

Status: current

24.1.7 powerThresholdLine2

OID: 1.3.6.1.4.1.3709.3.6.24.1.1.8

Description: Configured Line-2 power threshold.

Syntax: OpticalPower

Access: read-only

Status: current

24.1.8 inputPowerLine2

OID: 1.3.6.1.4.1.3709.3.6.24.1.1.9

Description: Current input power of the Line-2.

Syntax: OpticalPower

Access: read-only

Status: current

25 DMOS-MEM-NOTIFICATIONS-MIB

MIB file: DMOS-MEM-NOTIFICATIONS-MIB.mib

This MIB file has the following root objects:

- **dmosMemNotificationsMIB**
 - **OID:** 1.3.6.1.4.1.3709.3.6.3.3.1
 - **Description:** The memory notifications designed to be used by notification manager
 - **Object identities:**
 - dmosMemNotificationObjects (1.3.6.1.4.1.3709.3.6.3.3.1.1)
 - dmosMemNotificationGroups (1.3.6.1.4.1.3709.3.6.3.3.1.2)

25.1 dmosMemNotificationThreshold

OID: 1.3.6.1.4.1.3709.3.6.3.3.1.1.1

Description: Memory alarm threshold.

Syntax: Gauge32

Access: accessible-for-notify

Status: current

25.2 dmosMemNotificationInterval

OID: 1.3.6.1.4.1.3709.3.6.3.3.1.1.2

Description: Time interval during which the memory value was above/below the threshold.

Syntax: Gauge32

Access: accessible-for-notify

Status: current

25.3 dmosMemAlarmInfoGroup

OID: 1.3.6.1.4.1.3709.3.6.3.3.1.2.1

Description: A set of objects that provides more information about memory alarms.

Status: current

25.4 dmosMemAlarmTrapsGroup

OID: 1.3.6.1.4.1.3709.3.6.3.3.1.2.2

Description: Traps generated by memory alarms.

Status: current

25.5 memAvailableLowTrap

OID: 1.3.6.1.4.1.3709.3.6.3.3.1.3

Description: Alarm trap for low memory available.

Status: current

26 DMOS-NOTIFICATIONS-MIB

MIB file: DMOS-NOTIFICATIONS-MIB.mib

This MIB file has the following root objects:

- **dmosNotificationsMIB**
 - **OID:** 1.3.6.1.4.1.3709.3.6.3
 - **Description:** This module contains DmOS notifications data for SNMP
 - **Object identities:**
 - notificationObjects (1.3.6.1.4.1.3709.3.6.3.1)
 - notificationGroups (1.3.6.1.4.1.3709.3.6.3.2)
 - dmosNotifications (1.3.6.1.4.1.3709.3.6.3.3)

26.1 notificationTime

OID: 1.3.6.1.4.1.3709.3.6.3.1.1

Description: Date and Time when notification was generated

Syntax: DateAndTime

Access: accessible-for-notify

Status: current

26.2 notificationName

OID: 1.3.6.1.4.1.3709.3.6.3.1.2

Description: Name of notification

Syntax: DisplayString

Access: accessible-for-notify

Status: current

26.3 notificationSourceType

OID: 1.3.6.1.4.1.3709.3.6.3.1.3

Description: Type of source

Syntax: DisplayString

Access: accessible-for-notify

Status: current

26.4 notificationSourceValue

OID: 1.3.6.1.4.1.3709.3.6.3.1.4

Description: Source identification

Syntax: DisplayString

Access: accessible-for-notify

Status: current

26.5 notificationSeverity

OID: 1.3.6.1.4.1.3709.3.6.3.1.5

Description: Notification severity

Syntax: DisplayString

Access: accessible-for-notify

Status: current

26.6 notificationInfo

OID: 1.3.6.1.4.1.3709.3.6.3.1.6

Description: Summarized information of the notification

Syntax: DisplayString

Access: accessible-for-notify

Status: current

26.7 notificationAlarmState

OID: 1.3.6.1.4.1.3709.3.6.3.1.7

Description: Alarm state

Syntax: INTEGER

Syntax details: (Enumeration) 'clear': 1, 'set': 2, 'unstable': 3

Access: accessible-for-notify

Status: current

26.8 infoNotificationGroup

OID: 1.3.6.1.4.1.3709.3.6.3.2.1

Description: A set of objects that describes an occurrence informed by a notification not related to any alarm

Status: current

26.9 alarmNotificationGroup

OID: 1.3.6.1.4.1.3709.3.6.3.2.2

Description: The notifications that inform an alarm state transition contain all object members of this group in addition to infoNotificationGroup members

Status: current

27 DMOS-ONU-COUNTING-MIB

MIB file: DMOS-ONU-COUNTING-MIB.mib

This MIB file has the following root objects:

- **onuCountingIfMIB**
 - **OID:** 1.3.6.1.4.1.3709.3.6.18
 - **Description:** The DATACOM MIB module for ONUs counting by ponlink and total.
 - **Object identities:**
 - ponGlobalOnuCount (1.3.6.1.4.1.3709.3.6.18.1)

27.1 ponIfGlobalTotalOnus

OID: 1.3.6.1.4.1.3709.3.6.18.1.1

Description: Number of ONUs on all PON, including all states (provisioned up/down and not provisioned)

Syntax: Unsigned32

Syntax details: (Range) 0 - 2147483647

Access: read-only

Status: current

27.2 ponIfGlobalNonProvisionedOnus

OID: 1.3.6.1.4.1.3709.3.6.18.1.2

Description: Number of non provisioned ONUs on all interfaces

Syntax: Unsigned32

Syntax details: (Range) 0 - 2147483647

Access: read-only

Status: current

27.3 ponIfGlobalUpOnus

OID: 1.3.6.1.4.1.3709.3.6.18.1.3

Description: Number of ONUs provisioned and up on all interfaces

Syntax: Unsigned32

Syntax details: (Range) 0 - 2147483647

Access: read-only

Status: current

27.4 ponIfGlobalDownOnus

OID: 1.3.6.1.4.1.3709.3.6.18.1.4

Description: Number of ONUs provisioned and down on all interfaces

Syntax: Unsigned32

Syntax details: (Range) 0 - 2147483647

Access: read-only

Status: current

27.5 ponIfTable

OID: 1.3.6.1.4.1.3709.3.6.18.2

Description: This table represents the ONU counting per PON interface

Syntax: SEQUENCE OF ponIfEntry (OID: 1.3.6.1.4.1.3709.3.6.18.2.1)

Access: not-accessible

Status: current

27.5.1 ponIfIndex

OID: 1.3.6.1.4.1.3709.3.6.18.2.1.1

Description: Table index

Syntax: Unsigned32

Syntax details: (Range) 1 - 2147483647

Access: read-only

Status: current

27.5.2 ponIfDescr

OID: 1.3.6.1.4.1.3709.3.6.18.2.1.2

Description: Interface description

Syntax: String

Syntax details: (Size) 0 - 255

Access: read-only

Status: current

27.5.3 ponIfTotalOnus

OID: 1.3.6.1.4.1.3709.3.6.18.2.1.3

Description: Number of ONUs on PON link, including all states (provisioned up/down and not provisioned)

Syntax: Unsigned32

Syntax details: (Range) 0 - 2147483647

Access: read-only

Status: current

27.5.4 ponIfNonProvisionedOnus

OID: 1.3.6.1.4.1.3709.3.6.18.2.1.4

Description: Number of non provisioned ONUs on PON link

Syntax: Unsigned32

Syntax details: (Range) 0 - 2147483647

Access: read-only

Status: current

27.5.5 ponIfUpOnus

OID: 1.3.6.1.4.1.3709.3.6.18.2.1.5

Description: Number of ONUs provisioned and up on PON link

Syntax: Unsigned32

Syntax details: (Range) 0 - 2147483647

Access: read-only

Status: current

27.5.6 ponIfDownOnus

OID: 1.3.6.1.4.1.3709.3.6.18.2.1.6

Description: Number of ONUs provisioned and down on PON link

Syntax: Unsigned32

Syntax details: (Range) 0 - 2147483647

Access: read-only

Status: current

27.6 ponIfDiscoveredOnusTable

OID: 1.3.6.1.4.1.3709.3.6.18.3

Description: This table represents the list of discovered ONUs by pon link

Syntax: SEQUENCE OF ponIfDiscoveredOnusEntry (OID: 1.3.6.1.4.1.3709.3.6.18.3.1)

Access: not-accessible

Status: current

27.6.1 ponIfIndexDiscoveredOnus

OID: 1.3.6.1.4.1.3709.3.6.18.3.1.1

Description: If-index of pon link

Syntax: Unsigned32

Syntax details: (Range) 1 - 2147483647

Access: not-accessible

Status: current

27.6.2 id

OID: 1.3.6.1.4.1.3709.3.6.18.3.1.2

Description: Sequential ID of discovered onu

Syntax: Unsigned32

Syntax details: (Range) 0 - 127

Access: not-accessible

Status: current

27.6.3 onuSerialNumber

OID: 1.3.6.1.4.1.3709.3.6.18.3.1.3

Description: ONU serial number

Syntax: String

Access: read-only

Status: current

28 DMOS-POLICER-MIB

MIB file: DMOS-POLICER-MIB.mib

This MIB file has the following root objects:

- **dmosPolicerMIB**
 - **OID:** 1.3.6.1.4.1.3709.3.6.12
 - **Description:** The module for managing QoS traffic policing.

28.1 policerInstanceTable

OID: 1.3.6.1.4.1.3709.3.6.12.1

Syntax: SEQUENCE OF policerInstanceEntry (OID: 1.3.6.1.4.1.3709.3.6.12.1.1)

Access: not-accessible

Status: current

28.1.1 policerInstanceInstanceld

OID: 1.3.6.1.4.1.3709.3.6.12.1.1.1

Description: Instance ID

Syntax: UnsignedShort

Access: read-only

Status: current

28.1.2 policerInstanceProfile

OID: 1.3.6.1.4.1.3709.3.6.12.1.1.2

Description: Profile name

Syntax: String

Syntax details: (Size) 1 - 48

Access: read-only

Status: current

28.1.3 policerInstanceMode

OID: 1.3.6.1.4.1.3709.3.6.12.1.1.3

Description: Policer mode

Syntax: PolicerMode

Access: read-only

Status: current

28.1.4 policerInstanceStage

OID: 1.3.6.1.4.1.3709.3.6.12.1.1.4

Description: Policer stage

Syntax: PolicerStageExtended

Access: read-only

Status: current

28.1.5 policerInstanceCir

OID: 1.3.6.1.4.1.3709.3.6.12.1.1.5

Description: Committed information rate (kbits/s)

Syntax: Unsigned32

Access: read-only

Status: current

28.1.6 policerInstanceEir

OID: 1.3.6.1.4.1.3709.3.6.12.1.1.6

Description: Excess information rate (kbits/s)

Syntax: Unsigned32

Access: read-only

Status: current

28.1.7 policerInstancePir

OID: 1.3.6.1.4.1.3709.3.6.12.1.1.7

Description: Peak information rate (kbits/s)

Syntax: Unsigned32

Access: read-only

Status: current

28.1.8 policerInstanceForwarded

OID: 1.3.6.1.4.1.3709.3.6.12.1.1.8

Description: Number of forwarded bytes

Syntax: Counter64

Access: read-only

Status: current

28.1.9 policerInstanceDropped

OID: 1.3.6.1.4.1.3709.3.6.12.1.1.9

Description: Number of dropped bytes

Syntax: Counter64

Access: read-only

Status: current

28.2 policerInstanceInterfaceTable

OID: 1.3.6.1.4.1.3709.3.6.12.10

Syntax: SEQUENCE OF policerInstanceInterfaceEntry (OID: 1.3.6.1.4.1.3709.3.6.12.10.1)

Access: not-accessible

Status: current

28.2.1 policerInstanceInterfaceIndex

OID: 1.3.6.1.4.1.3709.3.6.12.10.1.1

Description: Interface index

Syntax: Integer32

Syntax details: (Range) 1 - 2147483647

Access: read-only

Status: current

28.2.2 policerInstanceInterfaceName

OID: 1.3.6.1.4.1.3709.3.6.12.10.1.2

Description: Interface name

Syntax: String

Syntax details: (Size) 0 - 64

Access: read-only

Status: current

29 DMOS-REBOOT-MIB

MIB file: DMOS-REBOOT-MIB.mib

This MIB file has the following root objects:

- **dmosRebootMIB**
 - **OID:** 1.3.6.1.4.1.3709.3.6.10
 - **Description:** Reboot execution.

29.1 rebootReason

OID: 1.3.6.1.4.1.3709.3.6.10.1

Syntax: String

Access: read-only

Status: current

30 DMOS-REDUNDANCY-NOTIFICATIONS-MIB

MIB file: DMOS-REDUNDANCY-NOTIFICATIONS-MIB.mib

This MIB file has the following root objects:

- **dmosRedundancyNotificationsMIB**
 - **OID:** 1.3.6.1.4.1.3709.3.6.3.3.5
 - **Description:** This MIB file contains the definition of DmOS notifications related to redundancy.
 - **Object identities:**
 - dmosRedundancyNotificationGroups (1.3.6.1.4.1.3709.3.6.3.3.5.1)

30.1 dmosRedundancyAlarmTrapsGroup

OID: 1.3.6.1.4.1.3709.3.6.3.3.5.1.1

Description: Traps generated by redundancy alarms.

Status: current

30.2 controllerRedundancyFailureAlarmTrap

OID: 1.3.6.1.4.1.3709.3.6.3.3.5.2

Description: Alarm indicating there is not a fully redundant controller available.

Status: current

31 DMOS-SYSMON-MIB

MIB file: DMOS-SYSMON-MIB.mib

This MIB file has the following root objects:

- **dmosSysmonMIB**
 - **OID:** 1.3.6.1.4.1.3709.3.6.4
 - **Description:** This module contains DmOS CPU and memory usage monitoring objects.
 - **Object identities:**
 - cpu (1.3.6.1.4.1.3709.3.6.4.1)
 - memory (1.3.6.1.4.1.3709.3.6.4.2)

31.1 cpuChassisTable

OID: 1.3.6.1.4.1.3709.3.6.4.1.1

Description: List of chassis for which CPU usage information is available

Syntax: SEQUENCE OF cpuChassisEntry (OID: 1.3.6.1.4.1.3709.3.6.4.1.1.1)

Access: not-accessible

Status: current

31.1.1 cpuChassisId

OID: 1.3.6.1.4.1.3709.3.6.4.1.1.1.1

Description: Chassis identifier

Syntax: Unsigned32

Access: read-only

Status: current

31.2 cpuSlotTable

OID: 1.3.6.1.4.1.3709.3.6.4.1.2

Description: List of slots for which CPU usage information is available

Syntax: SEQUENCE OF cpuSlotEntry (OID: 1.3.6.1.4.1.3709.3.6.4.1.2.1)

Access: not-accessible

Status: current

31.2.1 cpuSlotId

OID: 1.3.6.1.4.1.3709.3.6.4.1.2.1.1

Description: Slot identifier

Syntax: DisplayString

Access: not-accessible

Status: current

31.2.2 cpuLoadFiveSecondsActive

OID: 1.3.6.1.4.1.3709.3.6.4.1.2.1.2

Description: Average active CPU load over the last five seconds

Syntax: UnsignedPercent

Access: read-only

Status: current

31.2.3 cpuLoadFiveSecondsIdle

OID: 1.3.6.1.4.1.3709.3.6.4.1.2.1.3

Description: Average idle CPU load over the last five seconds

Syntax: UnsignedPercent

Access: read-only

Status: current

31.2.4 cpuLoadOneMinuteActive

OID: 1.3.6.1.4.1.3709.3.6.4.1.2.1.4

Description: Average active CPU load over the last minute

Syntax: UnsignedPercent

Access: read-only

Status: current

31.2.5 cpuLoadOneMinuteIdle

OID: 1.3.6.1.4.1.3709.3.6.4.1.2.1.5

Description: Average idle CPU load over the last minute

Syntax: UnsignedPercent

Access: read-only

Status: current

31.2.6 cpuLoadFiveMinutesActive

OID: 1.3.6.1.4.1.3709.3.6.4.1.2.1.6

Description: Average active CPU load of the last five minutes

Syntax: UnsignedPercent

Access: read-only

Status: current

31.2.7 cpuLoadFiveMinutesIdle

OID: 1.3.6.1.4.1.3709.3.6.4.1.2.1.7

Description: Average idle CPU load over the last five minutes

Syntax: UnsignedPercent

Access: read-only

Status: current

31.3 cpuCoreTable

OID: 1.3.6.1.4.1.3709.3.6.4.1.3

Description: Detailed information per CPU core

Syntax: SEQUENCE OF cpuCoreEntry (OID: 1.3.6.1.4.1.3709.3.6.4.1.3.1)

Access: not-accessible

Status: current

31.3.1 cpuCoreCoreId

OID: 1.3.6.1.4.1.3709.3.6.4.1.3.1.1

Description: CPU core identifier

Syntax: Unsigned32

Access: not-accessible

Status: current

31.3.2 cpuCoreFiveSecondsActive

OID: 1.3.6.1.4.1.3709.3.6.4.1.3.1.2

Description: Average active CPU core load over the last five seconds

Syntax: UnsignedPercent

Access: read-only

Status: current

31.3.3 cpuCoreFiveSecondsUser

OID: 1.3.6.1.4.1.3709.3.6.4.1.3.1.3

Description: Average user space CPU core load over the last five seconds

Syntax: UnsignedPercent

Access: read-only

Status: current

31.3.4 cpuCoreFiveSecondsSystem

OID: 1.3.6.1.4.1.3709.3.6.4.1.3.1.4

Description: Average kernel space CPU core load over the last five seconds

Syntax: UnsignedPercent

Access: read-only

Status: current

31.3.5 cpuCoreFiveSecondsNice

OID: 1.3.6.1.4.1.3709.3.6.4.1.3.1.5

Description: Average CPU core load spent on niced processes over the last five seconds

Syntax: UnsignedPercent

Access: read-only

Status: current

31.3.6 cpuCoreFiveSecondsIdle

OID: 1.3.6.1.4.1.3709.3.6.4.1.3.1.6

Description: Average idle CPU core load over the last five seconds

Syntax: UnsignedPercent

Access: read-only

Status: current

31.3.7 cpuCoreFiveSecondsWait

OID: 1.3.6.1.4.1.3709.3.6.4.1.3.1.7

Description: Average CPU core load spent waiting for I/O over the last five seconds

Syntax: UnsignedPercent

Access: read-only

Status: current

31.3.8 cpuCoreFiveSecondsInterrupt

OID: 1.3.6.1.4.1.3709.3.6.4.1.3.1.8

Description: Average CPU core load spent handling hardware interrupts over the last five seconds

Syntax: UnsignedPercent

Access: read-only

Status: current

31.3.9 cpuCoreFiveSecondsSoftirq

OID: 1.3.6.1.4.1.3709.3.6.4.1.3.1.9

Description: Average CPU core load spent handling software interrupts over the last five seconds

Syntax: UnsignedPercent

Access: read-only

Status: current

31.3.10 cpuCoreOneMinuteActive

OID: 1.3.6.1.4.1.3709.3.6.4.1.3.1.10

Description: Average active CPU core load over the last minute

Syntax: UnsignedPercent

Access: read-only

Status: current

31.3.11 cpuCoreOneMinuteUser

OID: 1.3.6.1.4.1.3709.3.6.4.1.3.1.11

Description: Average user space CPU core load over the last minute

Syntax: UnsignedPercent

Access: read-only

Status: current

31.3.12 cpuCoreOneMinuteSystem

OID: 1.3.6.1.4.1.3709.3.6.4.1.3.1.12

Description: Average kernel space CPU core load over the last minute

Syntax: UnsignedPercent

Access: read-only

Status: current

31.3.13 cpuCoreOneMinuteNice

OID: 1.3.6.1.4.1.3709.3.6.4.1.3.1.13

Description: Average CPU core load spent on niced processes over the last minute

Syntax: UnsignedPercent

Access: read-only

Status: current

31.3.14 cpuCoreOneMinuteIdle

OID: 1.3.6.1.4.1.3709.3.6.4.1.3.1.14

Description: Average idle CPU core load over the last minute

Syntax: UnsignedPercent

Access: read-only

Status: current

31.3.15 cpuCoreOneMinuteWait

OID: 1.3.6.1.4.1.3709.3.6.4.1.3.1.15

Description: Average CPU core load spent waiting for I/O over the last minute

Syntax: UnsignedPercent

Access: read-only

Status: current

31.3.16 cpuCoreOneMinuteInterrupt

OID: 1.3.6.1.4.1.3709.3.6.4.1.3.1.16

Description: Average CPU core load spent handling hardware interrupts over the last minute

Syntax: UnsignedPercent

Access: read-only

Status: current

31.3.17 cpuCoreOneMinuteSoftirq

OID: 1.3.6.1.4.1.3709.3.6.4.1.3.1.17

Description: Average CPU core load spent handling hardware interrupts over the last minute

Syntax: UnsignedPercent

Access: read-only

Status: current

31.3.18 cpuCoreFiveMinutesActive

OID: 1.3.6.1.4.1.3709.3.6.4.1.3.1.18

Description: Average active CPU core load over the last five minutes

Syntax: UnsignedPercent

Access: read-only

Status: current

31.3.19 cpuCoreFiveMinutesUser

OID: 1.3.6.1.4.1.3709.3.6.4.1.3.1.19

Description: Average user space CPU core load over the last five minutes

Syntax: UnsignedPercent

Access: read-only

Status: current

31.3.20 cpuCoreFiveMinutesSystem

OID: 1.3.6.1.4.1.3709.3.6.4.1.3.1.20

Description: Average kernel space CPU core load over the last five minutes

Syntax: UnsignedPercent

Access: read-only

Status: current

31.3.21 cpuCoreFiveMinutesNice

OID: 1.3.6.1.4.1.3709.3.6.4.1.3.1.21

Description: Average CPU core load spent on niced processes over the last five minutes

Syntax: UnsignedPercent

Access: read-only

Status: current

31.3.22 cpuCoreFiveMinutesIdle

OID: 1.3.6.1.4.1.3709.3.6.4.1.3.1.22

Description: Average idle CPU core load over the last five minutes

Syntax: UnsignedPercent

Access: read-only

Status: current

31.3.23 cpuCoreFiveMinutesWait

OID: 1.3.6.1.4.1.3709.3.6.4.1.3.1.23

Description: Average CPU core load spent waiting for I/O over the last five minutes

Syntax: UnsignedPercent

Access: read-only

Status: current

31.3.24 cpuCoreFiveMinutesInterrupt

OID: 1.3.6.1.4.1.3709.3.6.4.1.3.1.24

Description: Average CPU core load spent handling hardware interrupts over the last five minutes

Syntax: UnsignedPercent

Access: read-only

Status: current

31.3.25 cpuCoreFiveMinutesSoftirq

OID: 1.3.6.1.4.1.3709.3.6.4.1.3.1.25

Description: Average CPU core load spent handling hardware interrupts over the last five minutes

Syntax: UnsignedPercent

Access: read-only

Status: current

31.4 cpuSysUptime

OID: 1.3.6.1.4.1.3709.3.6.4.1.4

Description: The amount of time in seconds (64 bits resolution) since this host was last initialized. Note that this is different from sysUpTime and hrSystemUptime because both are represented in TimeTicks (in hundredths of a second) with a resolution of 32 bits (497 days approximately).

Syntax: Counter64

Access: read-only

Status: current

31.5 memoryChassisTable

OID: 1.3.6.1.4.1.3709.3.6.4.2.1

Description: List of chassis for which memory usage information is available

Syntax: SEQUENCE OF memoryChassisEntry (OID: 1.3.6.1.4.1.3709.3.6.4.2.1.1)

Access: not-accessible

Status: current

31.5.1 memoryChassisId

OID: 1.3.6.1.4.1.3709.3.6.4.2.1.1.1

Description: Chassis identifier

Syntax: Unsigned32

Access: read-only

Status: current

31.6 memorySlotTable

OID: 1.3.6.1.4.1.3709.3.6.4.2.2

Description: List of slots for which memory usage information is available

Syntax: SEQUENCE OF memorySlotEntry (OID: 1.3.6.1.4.1.3709.3.6.4.2.2.1)

Access: not-accessible

Status: current

31.6.1 memorySlotId

OID: 1.3.6.1.4.1.3709.3.6.4.2.2.1.1

Description: Slot identifier

Syntax: DisplayString

Access: not-accessible

Status: current

31.6.2 memoryFiveSecondsTotal

OID: 1.3.6.1.4.1.3709.3.6.4.2.2.1.2

Description: Average amount of total memory over the last five seconds

Syntax: Unsigned32

Access: read-only

Status: deprecated

31.6.3 memoryFiveSecondsUsed

OID: 1.3.6.1.4.1.3709.3.6.4.2.2.1.3

Description: Average amount of used memory over the last five seconds

Syntax: Unsigned32

Access: read-only

Status: deprecated

31.6.4 memoryFiveSecondsFree

OID: 1.3.6.1.4.1.3709.3.6.4.2.2.1.4

Description: Average amount of free memory over the last five seconds

Syntax: Unsigned32

Access: read-only

Status: deprecated

31.6.5 memoryFiveSecondsBuffered

OID: 1.3.6.1.4.1.3709.3.6.4.2.2.1.5

Description: Average amount of buffered memory over the last five seconds

Syntax: Unsigned32

Access: read-only

Status: deprecated

31.6.6 memoryFiveSecondsCached

OID: 1.3.6.1.4.1.3709.3.6.4.2.2.1.6

Description: Average amount of cached memory over the last five seconds

Syntax: Unsigned32

Access: read-only

Status: deprecated

31.6.7 memoryFiveSecondsAvailable

OID: 1.3.6.1.4.1.3709.3.6.4.2.2.1.7

Description: Average amount of available memory over the last five seconds

Syntax: Unsigned32

Access: read-only

Status: deprecated

31.6.8 memoryFiveSecondsSlabRecl

OID: 1.3.6.1.4.1.3709.3.6.4.2.2.1.8

Description: Average amount of reclaimable slab memory over the last five seconds

Syntax: Unsigned32

Access: read-only

Status: deprecated

31.6.9 memoryFiveSecondsSlabUnrecl

OID: 1.3.6.1.4.1.3709.3.6.4.2.2.1.9

Description: Average amount of unreclaimable slab memory over the last five seconds

Syntax: Unsigned32

Access: read-only

Status: deprecated

31.6.10 memoryFiveMinutesTotal

OID: 1.3.6.1.4.1.3709.3.6.4.2.2.1.10

Description: Average amount of total memory over the last five minutes

Syntax: Unsigned32

Access: read-only

Status: deprecated

31.6.11 memoryFiveMinutesUsed

OID: 1.3.6.1.4.1.3709.3.6.4.2.2.1.11

Description: Average amount of used memory over the last five minutes

Syntax: Unsigned32

Access: read-only

Status: deprecated

31.6.12 memoryFiveMinutesFree

OID: 1.3.6.1.4.1.3709.3.6.4.2.2.1.12

Description: Average amount of free memory over the last five minutes

Syntax: Unsigned32

Access: read-only

Status: deprecated

31.6.13 memoryFiveMinutesBuffered

OID: 1.3.6.1.4.1.3709.3.6.4.2.2.1.13

Description: Average amount of buffered memory over the last five minutes

Syntax: Unsigned32

Access: read-only

Status: deprecated

31.6.14 memoryFiveMinutesCached

OID: 1.3.6.1.4.1.3709.3.6.4.2.2.1.14

Description: Average amount of cached memory over the last five minutes

Syntax: Unsigned32

Access: read-only

Status: deprecated

31.6.15 memoryFiveMinutesAvailable

OID: 1.3.6.1.4.1.3709.3.6.4.2.2.1.15

Description: Average amount of available memory over the last five minutes

Syntax: Unsigned32

Access: read-only

Status: deprecated

31.6.16 memoryFiveMinutesSlabRecl

OID: 1.3.6.1.4.1.3709.3.6.4.2.2.1.16

Description: Average amount of reclaimable slab memory over the last five minutes

Syntax: Unsigned32

Access: read-only

Status: deprecated

31.6.17 memoryFiveMinutesSlabUnrecl

OID: 1.3.6.1.4.1.3709.3.6.4.2.2.1.17

Description: Average amount of unreclaimable slab memory over the last five minutes

Syntax: Unsigned32

Access: read-only

Status: deprecated

31.6.18 memoryThirtyMinutesTotal

OID: 1.3.6.1.4.1.3709.3.6.4.2.2.1.18

Description: Average amount of total memory over the last thirty minutes

Syntax: Unsigned32

Access: read-only

Status: deprecated

31.6.19 memoryThirtyMinutesUsed

OID: 1.3.6.1.4.1.3709.3.6.4.2.2.1.19

Description: Average amount of used memory over the last thirty minutes

Syntax: Unsigned32

Access: read-only

Status: deprecated

31.6.20 memoryThirtyMinutesFree

OID: 1.3.6.1.4.1.3709.3.6.4.2.2.1.20

Description: Average amount of free memory over the last thirty minutes

Syntax: Unsigned32

Access: read-only

Status: deprecated

31.6.21 memoryThirtyMinutesBuffered

OID: 1.3.6.1.4.1.3709.3.6.4.2.2.1.21

Description: Average amount of buffered memory over the last thirty minutes

Syntax: Unsigned32

Access: read-only

Status: deprecated

31.6.22 memoryThirtyMinutesCached

OID: 1.3.6.1.4.1.3709.3.6.4.2.2.1.22

Description: Average amount of cached memory over the last thirty minutes

Syntax: Unsigned32

Access: read-only

Status: deprecated

31.6.23 memoryThirtyMinutesAvailable

OID: 1.3.6.1.4.1.3709.3.6.4.2.2.1.23

Description: Average amount of available memory over the last thirty minutes

Syntax: Unsigned32

Access: read-only

Status: deprecated

31.6.24 memoryThirtyMinutesSlabRecl

OID: 1.3.6.1.4.1.3709.3.6.4.2.2.1.24

Description: Average amount of reclaimable slab memory over the last thirty minutes

Syntax: Unsigned32

Access: read-only

Status: deprecated

31.6.25 memoryThirtyMinutesSlabUnrecl

OID: 1.3.6.1.4.1.3709.3.6.4.2.2.1.25

Description: Average amount of unreclaimable slab memory over the last thirty minutes

Syntax: Unsigned32

Access: read-only

Status: deprecated

31.6.26 memoryOneMinuteTotal

OID: 1.3.6.1.4.1.3709.3.6.4.2.2.1.26

Description: Average amount of total memory over the last minute

Syntax: Unsigned32

Access: read-only

Status: deprecated

31.6.27 memoryOneMinuteUsed

OID: 1.3.6.1.4.1.3709.3.6.4.2.2.1.27

Description: Average amount of used memory over the last minute

Syntax: Unsigned32

Access: read-only

Status: deprecated

31.6.28 memoryOneMinuteFree

OID: 1.3.6.1.4.1.3709.3.6.4.2.2.1.28

Description: Average amount of free memory over the last minute

Syntax: Unsigned32

Access: read-only

Status: deprecated

31.6.29 memoryOneMinuteBuffered

OID: 1.3.6.1.4.1.3709.3.6.4.2.2.1.29

Description: Average amount of buffered memory over the last minute

Syntax: Unsigned32

Access: read-only

Status: deprecated

31.6.30 memoryOneMinuteCached

OID: 1.3.6.1.4.1.3709.3.6.4.2.2.1.30

Description: Average amount of cached memory over the last minute

Syntax: Unsigned32

Access: read-only

Status: deprecated

31.6.31 memoryOneMinuteAvailable

OID: 1.3.6.1.4.1.3709.3.6.4.2.2.1.31

Description: Average amount of available memory over the last minute

Syntax: Unsigned32

Access: read-only

Status: deprecated

31.6.32 memoryOneMinuteSlabRecl

OID: 1.3.6.1.4.1.3709.3.6.4.2.2.1.32

Description: Average amount of reclaimable slab memory over the last minute

Syntax: Unsigned32

Access: read-only

Status: deprecated

31.6.33 memoryOneMinuteSlabUnrecl

OID: 1.3.6.1.4.1.3709.3.6.4.2.2.1.33

Description: Average amount of unreclaimable slab memory over the last minute

Syntax: Unsigned32

Access: read-only

Status: deprecated

31.6.34 memoryFiveSecondsTotalKB

OID: 1.3.6.1.4.1.3709.3.6.4.2.2.1.34

Description: Average amount of total memory over the last five seconds

Syntax: Unsigned32

Access: read-only

Status: current

31.6.35 memoryFiveSecondsUsedKB

OID: 1.3.6.1.4.1.3709.3.6.4.2.2.1.35

Description: Average amount of used memory over the last five seconds

Syntax: Unsigned32

Access: read-only

Status: current

31.6.36 memoryFiveSecondsFreeKB

OID: 1.3.6.1.4.1.3709.3.6.4.2.2.1.36

Description: Average amount of free memory over the last five seconds

Syntax: Unsigned32

Access: read-only

Status: current

31.6.37 memoryFiveSecondsBufferedKB

OID: 1.3.6.1.4.1.3709.3.6.4.2.2.1.37

Description: Average amount of buffered memory over the last five seconds

Syntax: Unsigned32

Access: read-only

Status: current

31.6.38 memoryFiveSecondsCachedKB

OID: 1.3.6.1.4.1.3709.3.6.4.2.2.1.38

Description: Average amount of cached memory over the last five seconds

Syntax: Unsigned32

Access: read-only

Status: current

31.6.39 memoryFiveSecondsAvailableKB

OID: 1.3.6.1.4.1.3709.3.6.4.2.2.1.39

Description: Average amount of available memory over the last five seconds

Syntax: Unsigned32

Access: read-only

Status: current

31.6.40 memoryFiveSecondsSlabReclKB

OID: 1.3.6.1.4.1.3709.3.6.4.2.2.1.40

Description: Average amount of reclaimable slab memory over the last five seconds

Syntax: Unsigned32

Access: read-only

Status: current

31.6.41 memoryFiveSecondsSlabUnreclKB

OID: 1.3.6.1.4.1.3709.3.6.4.2.2.1.41

Description: Average amount of unreclaimable slab memory over the last five seconds

Syntax: Unsigned32

Access: read-only

Status: current

31.6.42 memoryFiveMinutesTotalKB

OID: 1.3.6.1.4.1.3709.3.6.4.2.2.1.42

Description: Average amount of total memory over the last five minutes

Syntax: Unsigned32

Access: read-only

Status: current

31.6.43 memoryFiveMinutesUsedKB

OID: 1.3.6.1.4.1.3709.3.6.4.2.2.1.43

Description: Average amount of used memory over the last five minutes

Syntax: Unsigned32

Access: read-only

Status: current

31.6.44 memoryFiveMinutesFreeKB

OID: 1.3.6.1.4.1.3709.3.6.4.2.2.1.44

Description: Average amount of free memory over the last five minutes

Syntax: Unsigned32

Access: read-only

Status: current

31.6.45 memoryFiveMinutesBufferedKB

OID: 1.3.6.1.4.1.3709.3.6.4.2.2.1.45

Description: Average amount of buffered memory over the last five minutes

Syntax: Unsigned32

Access: read-only

Status: current

31.6.46 memoryFiveMinutesCachedKB

OID: 1.3.6.1.4.1.3709.3.6.4.2.2.1.46

Description: Average amount of cached memory over the last five minutes

Syntax: Unsigned32

Access: read-only

Status: current

31.6.47 memoryFiveMinutesAvailableKB

OID: 1.3.6.1.4.1.3709.3.6.4.2.2.1.47

Description: Average amount of available memory over the last five minutes

Syntax: Unsigned32

Access: read-only

Status: current

31.6.48 memoryFiveMinutesSlabReclKB

OID: 1.3.6.1.4.1.3709.3.6.4.2.2.1.48

Description: Average amount of reclaimable slab memory over the last five minutes

Syntax: Unsigned32

Access: read-only

Status: current

31.6.49 memoryFiveMinutesSlabUnreclKB

OID: 1.3.6.1.4.1.3709.3.6.4.2.2.1.49

Description: Average amount of unreclaimable slab memory over the last five minutes

Syntax: Unsigned32

Access: read-only

Status: current

31.6.50 memoryThirtyMinutesTotalKB

OID: 1.3.6.1.4.1.3709.3.6.4.2.2.1.50

Description: Average amount of total memory over the last thirty minutes

Syntax: Unsigned32

Access: read-only

Status: current

31.6.51 memoryThirtyMinutesUsedKB

OID: 1.3.6.1.4.1.3709.3.6.4.2.2.1.51

Description: Average amount of used memory over the last thirty minutes

Syntax: Unsigned32

Access: read-only

Status: current

31.6.52 memoryThirtyMinutesFreeKB

OID: 1.3.6.1.4.1.3709.3.6.4.2.2.1.52

Description: Average amount of free memory over the last thirty minutes

Syntax: Unsigned32

Access: read-only

Status: current

31.6.53 memoryThirtyMinutesBufferedKB

OID: 1.3.6.1.4.1.3709.3.6.4.2.2.1.53

Description: Average amount of buffered memory over the last thirty minutes

Syntax: Unsigned32

Access: read-only

Status: current

31.6.54 memoryThirtyMinutesCachedKB

OID: 1.3.6.1.4.1.3709.3.6.4.2.2.1.54

Description: Average amount of cached memory over the last thirty minutes

Syntax: Unsigned32

Access: read-only

Status: current

31.6.55 memoryThirtyMinutesAvailableKB

OID: 1.3.6.1.4.1.3709.3.6.4.2.2.1.55

Description: Average amount of available memory over the last thirty minutes

Syntax: Unsigned32

Access: read-only

Status: current

31.6.56 memoryThirtyMinutesSlabReclKB

OID: 1.3.6.1.4.1.3709.3.6.4.2.2.1.56

Description: Average amount of reclaimable slab memory over the last thirty minutes

Syntax: Unsigned32

Access: read-only

Status: current

31.6.57 memoryThirtyMinutesSlabUnreclKB

OID: 1.3.6.1.4.1.3709.3.6.4.2.2.1.57

Description: Average amount of unreclaimable slab memory over the last thirty minutes

Syntax: Unsigned32

Access: read-only

Status: current

31.6.58 memoryOneMinuteTotalKB

OID: 1.3.6.1.4.1.3709.3.6.4.2.2.1.58

Description: Average amount of total memory over the last minute

Syntax: Unsigned32

Access: read-only

Status: current

31.6.59 memoryOneMinuteUsedKB

OID: 1.3.6.1.4.1.3709.3.6.4.2.2.1.59

Description: Average amount of used memory over the last minute

Syntax: Unsigned32

Access: read-only

Status: current

31.6.60 memoryOneMinuteFreeKB

OID: 1.3.6.1.4.1.3709.3.6.4.2.2.1.60

Description: Average amount of free memory over the last minute

Syntax: Unsigned32

Access: read-only

Status: current

31.6.61 memoryOneMinuteBufferedKB

OID: 1.3.6.1.4.1.3709.3.6.4.2.2.1.61

Description: Average amount of buffered memory over the last minute

Syntax: Unsigned32

Access: read-only

Status: current

31.6.62 memoryOneMinuteCachedKB

OID: 1.3.6.1.4.1.3709.3.6.4.2.2.1.62

Description: Average amount of cached memory over the last minute

Syntax: Unsigned32

Access: read-only

Status: current

31.6.63 memoryOneMinuteAvailableKB

OID: 1.3.6.1.4.1.3709.3.6.4.2.2.1.63

Description: Average amount of available memory over the last minute

Syntax: Unsigned32

Access: read-only

Status: current

31.6.64 memoryOneMinuteSlabReclKB

OID: 1.3.6.1.4.1.3709.3.6.4.2.2.1.64

Description: Average amount of reclaimable slab memory over the last minute

Syntax: Unsigned32

Access: read-only

Status: current

31.6.65 memoryOneMinuteSlabUnreclKB

OID: 1.3.6.1.4.1.3709.3.6.4.2.2.1.65

Description: Average amount of unreclaimable slab memory over the last minute

Syntax: Unsigned32

Access: read-only

Status: current

32 DMOS-TC-MIB

MIB file: DMOS-TC-MIB.mib

This MIB file has the following root objects:

- **dmosTcMIB**
 - **OID:** 1.3.6.1.4.1.3709.3.6.5
 - **Description:** This module contains DmOS Textual Conventions

33 DMOS-TRANSCEIVER-MIB

MIB file: DMOS-TRANSCEIVER-MIB.mib

This MIB file has the following root objects:

- **dmosTransceiverMIB**
 - **OID:** 1.3.6.1.4.1.3709.3.6.8
 - **Description:** This module contains DmOS transceivers status monitoring objects.
 - **Object identities:**
 - transceiver (1.3.6.1.4.1.3709.3.6.8.1)
 - transceiverLane (1.3.6.1.4.1.3709.3.6.8.2)

33.1 transceiverTable

OID: 1.3.6.1.4.1.3709.3.6.8.1.1

Description: List of transceivers for which status information is available

Syntax: SEQUENCE OF transceiverEntry (OID: 1.3.6.1.4.1.3709.3.6.8.1.1.1)

Access: not-accessible

Status: current

33.1.1 temperature

OID: 1.3.6.1.4.1.3709.3.6.8.1.1.1.1

Description: Current transceiver temperature

Syntax: TransceiverTemperature

Access: read-only

Status: current

33.1.2 voltage

OID: 1.3.6.1.4.1.3709.3.6.8.1.1.1.2

Description: Current transceiver voltage

Syntax: TransceiverVoltage

Access: read-only

Status: current

33.1.3 laneCount

OID: 1.3.6.1.4.1.3709.3.6.8.1.1.1.3

Description: Number of lanes (lasers) in the transceiver

Syntax: Integer32

Access: read-only

Status: current

33.1.4 osnr

OID: 1.3.6.1.4.1.3709.3.6.8.1.1.1.4

Description: Current transceiver OSNR, represented in hundredths of a dB. OSNR (Optical Signal to Noise Ratio) represents the ratio between the optical signal power and the noise power within a specific bandwidth. Higher OSNR indicates better optical signal quality and cleaner transmission. OSNR is expressed in dB. Example: The value 2000 represents an OSNR of 20.0 dB.

Syntax: Integer32

Access: read-only

Status: current

33.1.5 prefec

OID: 1.3.6.1.4.1.3709.3.6.8.1.1.1.5

Description: Current transceiver Pre-FEC BER. Pre-FEC BER (Bit Error Rate before Forward Error Correction) it is the total number of errored bits that were corrected by the FEC during an interval divided by the total number of bits received in that interval. Note that different FEC schemes, will have different maximum Pre-FEC BER requirements for a specific corrected BER maximum target. Example: The value 1.0E-3 represents a Pre-FEC BER of 1 error per 1000 bits.

Syntax: String

Access: read-only

Status: current

33.1.6 ferc

OID: 1.3.6.1.4.1.3709.3.6.8.1.1.1.6

Description: Current transceiver FERC. FERC (Frame Error Count), which is a rate of non-corrected bits. Until a certain value of Pre-FEC BER, the FERC must be zero. The existence of FERC generates real bit errors in the data traffic. Example: The value 5000000 represents 5000000 uncorrected errors.

Syntax: String

Access: read-only

Status: current

33.1.7 qvalue

OID: 1.3.6.1.4.1.3709.3.6.8.1.1.1.7

Description: Current transceiver Qvalue, represented in hundredths of a dB. QValue represents the digital estimation of signal quality after processing. It reflects how far the received signal is from decision errors. Higher Q-Value means better performance and lower error probability. Q-Value is expressed in dB. Example: The value 750 represents a Q-Value of 7.50 dB.

Syntax: Integer32

Access: read-only

Status: current

33.1.8 qfactor

OID: 1.3.6.1.4.1.3709.3.6.8.1.1.1.8

Description: Current transceiver Qfactor, represented in hundredths of a dB. QFactor represents the analog signal to noise ratio. It suggests the minimum correctable BER for a given signal. The higher the Q-Factor, the better. Q-Factor is expressed in dB. Example: The value 365 represents a Q-Factor of 3.65 dB.

Syntax: Integer32

Access: read-only

Status: current

33.1.9 chromaticDispersion

OID: 1.3.6.1.4.1.3709.3.6.8.1.1.1.9

Description: Current transceiver Chromatic Dispersion, represented in picoseconds per nanometer. Chromatic Dispersion represents the distortion in the optical signal caused by different wavelengths traveling at different speeds through the fiber. High chromatic dispersion leads to signal broadening and higher BER. It is typically expressed in ps/nm. Example: The value 12500 represents 12500 ps/nm of chromatic dispersion.

Syntax: Integer32

Access: read-only

Status: current

33.2 transceiverLaneTable

OID: 1.3.6.1.4.1.3709.3.6.8.2.1

Description: List of transceiver lanes for which status information is available

Syntax: SEQUENCE OF transceiverLaneEntry (OID: 1.3.6.1.4.1.3709.3.6.8.2.1.1)

Access: not-accessible

Status: current

33.2.1 laneIndex

OID: 1.3.6.1.4.1.3709.3.6.8.2.1.1.1

Description: A lane on this transceiver

Syntax: Unsigned32

Syntax details: (Range) 1 - 1000

Access: read-only

Status: current

33.2.2 laneRxPower

OID: 1.3.6.1.4.1.3709.3.6.8.2.1.1.2

Description: Current transceiver lane RX power

Syntax: TransceiverOpticalPower

Access: read-only

Status: current

33.2.3 laneTxPower

OID: 1.3.6.1.4.1.3709.3.6.8.2.1.1.3

Description: Current transceiver lane TX power

Syntax: TransceiverOpticalPower

Access: read-only

Status: current

33.2.4 laneTxBias

OID: 1.3.6.1.4.1.3709.3.6.8.2.1.1.4

Description: Current transceiver lane TX bias current

Syntax: TransceiverCurrent

Access: read-only

Status: current

34 DMOS-USER-DEFINED-COUNTERS

MIB file: DMOS-USER-DEFINED-COUNTERS.mib

This MIB file has the following root objects:

- **dmosUserDefinedCountersMIB**
 - **OID:** 1.3.6.1.4.1.3709.3.6.9
 - **Description:** This module contains the YANG definitions for user-defined counters.

34.1 countersIngressTable

OID: 1.3.6.1.4.1.3709.3.6.9.1

Description: Ingress counters

Syntax: SEQUENCE OF countersIngressEntry (OID: 1.3.6.1.4.1.3709.3.6.9.1.1)

Access: not-accessible

Status: current

34.1.1 countersIngressId

OID: 1.3.6.1.4.1.3709.3.6.9.1.1.1

Syntax: Unsigned32

Access: read-only

Status: current

34.1.2 countersIngressDescription

OID: 1.3.6.1.4.1.3709.3.6.9.1.1.2

Description: User-friendly counter identification

Syntax: String

Syntax details: (Size) 1 - 128

Access: read-only

Status: current

34.1.3 countersIngressValue

OID: 1.3.6.1.4.1.3709.3.6.9.1.1.3

Syntax: Counter64

Access: read-only

Status: current

34.1.4 countersIngressType

OID: 1.3.6.1.4.1.3709.3.6.9.1.1.4

Description: Type of counter

Syntax: Counter_type

Access: read-only

Status: current

34.2 countersEgressTable

OID: 1.3.6.1.4.1.3709.3.6.9.2

Description: Egress counters

Syntax: SEQUENCE OF countersEgressEntry (OID: 1.3.6.1.4.1.3709.3.6.9.2.1)

Access: not-accessible

Status: current

34.2.1 countersEgressId

OID: 1.3.6.1.4.1.3709.3.6.9.2.1.1

Syntax: Unsigned32

Access: read-only

Status: current

34.2.2 countersEgressDescription

OID: 1.3.6.1.4.1.3709.3.6.9.2.1.2

Description: User-friendly counter identification

Syntax: String

Syntax details: (Size) 1 - 128

Access: read-only

Status: current

34.2.3 countersEgressValue

OID: 1.3.6.1.4.1.3709.3.6.9.2.1.3

Syntax: Counter64

Access: read-only

Status: current

34.2.4 countersEgressType

OID: 1.3.6.1.4.1.3709.3.6.9.2.1.4

Description: Type of counter

Syntax: Counter_type

Access: read-only

Status: current

35 GPON-ONU-IF-MIB

MIB file: GPON-ONU-IF-MIB.mib

This MIB file has the following root objects:

- **gponOnulfMIB**
 - **OID:** 1.3.6.1.4.1.3709.3.6.2
 - **Description:** This module contains GPON ONU and UNI interfaces operational data for SNMP

35.1 onulfTable

OID: 1.3.6.1.4.1.3709.3.6.2.1

Description: This table represents ONU associated entities (e.g. ONU, Ethernet UNI)

Syntax: SEQUENCE OF onulfEntry (OID: 1.3.6.1.4.1.3709.3.6.2.1.1)

Access: not-accessible

Status: current

35.1.1 onuifIndex

OID: 1.3.6.1.4.1.3709.3.6.2.1.1.2

Description: Table index

Syntax: Integer32

Syntax details: (Range) 1 - 2147483647

Access: not-accessible

Status: current

35.1.2 onuifDescr

OID: 1.3.6.1.4.1.3709.3.6.2.1.1.3

Description: Interface description

Syntax: String

Syntax details: (Size) 0 - 255

Access: read-write

Status: current

35.1.3 onuifType

OID: 1.3.6.1.4.1.3709.3.6.2.1.1.4

Description: Global IANA interface type for this table entry

Syntax: INTEGER

Syntax details: (Enumeration) 'a12MppSwitch': 130, 'aal2': 187, 'aal5': 49, 'actelisMetaLOOP': 223, 'adsl': 94, 'adsl2': 230, 'adsl2plus': 238, 'aflane8023': 59, 'aflane8025': 60, 'aluELP': 249, 'aluEpon': 266, 'aluEponLogicalLink': 269, 'aluEponOnu': 267, 'aluEponPhysicalUni': 268, 'aluGponOnu': 270, 'aluGponPhysicalUni': 271, 'arap': 88, 'arcnet': 35, 'arcnetPlus': 36, 'async': 84, 'atm': 37, 'atmDxi': 105, 'atmFuni': 106, 'atmIma': 107, 'atmLogical': 80, 'atmRadio': 189, 'atmSubInterface': 134, 'atmVciEndPt': 194, 'atmVirtual': 149, 'atmbond': 234, 'aviciOpticalEther': 233, 'basicISDN': 20, 'bgppolicyaccounting': 162, 'bits': 255, 'bridge': 209, 'bsc': 83, 'cableDownstreamRfPort': 257, 'capwapDot11Bss': 253, 'capwapDot11Profile': 252, 'capwapWtpVirtualRadio': 254, 'cblVectaStar': 228, 'cctEmul': 61, 'ces': 133, 'channel': 70, 'ciscoSLvlan': 222, 'cnr': 85, 'coffee': 132, 'compositeLink': 155, 'dcn': 141, 'ddnX25': 4, 'digitalPowerline': 138, 'digitalWrapperOverheadChannel': 186, 'dlsw': 74, 'docsCableDownstream': 128, 'docsCableMCmtsDownstream': 229, 'docsCableMacLayer': 127, 'docsCableUpstream': 129, 'docsCableUpstreamChannel': 205, 'docsCableUpstreamRfPort': 256, 'docsOfdmDownstream': 277, 'docsOfdmaUpstream': 278, 'ds0': 81, 'ds0Bundle': 82, 'ds1': 18, 'ds1FDL': 170, 'ds3': 30, 'dtm': 140, 'dvbAsiIn': 172, 'dvbAsiOut': 173, 'dvbRccDownstream': 147, 'dvbRccMacLayer': 146, 'dvbRccUpstream': 148, 'dvbRcsMacLayer': 239, 'dvbRcsTdma': 241, 'dvbTdm': 240, 'e1': 19, 'econet': 206, 'eon': 25, 'eplrs': 87, 'escon': 73, 'ethernet3Mbit': 26, 'ethernetCsmacd': 6, 'fast': 125, 'fastEther': 62, 'fastEtherFX': 69, 'fcipLink': 224, 'fdci': 15, 'fibreChannel': 56, 'frDciEndPt': 193, 'frForward': 158, 'frameRelay': 32, 'frameRelayInterconnect': 58, 'frameRelayMPI': 92, 'frameRelayService': 44, 'frf16MfrBundle': 163, 'g703at2mb': 67, 'g703at64k': 66, 'g9981': 263, 'g9982': 264, 'g9983': 265, 'gfast': 279, 'gfp': 221, 'gigabitEthernet': 117, 'gpon': 250, 'gr303IDT': 178, 'gr303RDT': 177, 'gtp': 216, 'h323Gatekeeper': 164, 'h323Proxy': 165, 'hdh1822': 3, 'hdlc': 118, 'hdl2': 168, 'hiperlan2': 183, 'hippi': 47, 'hippiInterface': 57, 'homepna': 220, 'hostPad': 90, 'hssi': 46, 'hyperchannel': 14, 'ibm370parChan': 72, 'idsl': 154, 'ieee1394': 144, 'ieee80211': 71, 'ieee80212': 55, 'ieee802154': 259, 'ieee80216WMAN': 237, 'ieee8023adLag': 161, 'if-gsn': 145, 'ifPwType': 246, 'ifVfiType': 262, 'ilan': 247, 'imt': 190, 'infiniband': 199, 'interleave': 124, 'ip': 126, 'ipForward': 142, 'ipOverAtm': 114, 'ipOverCdlc': 109, 'ipOverClaw': 110, 'ipSwitch': 78, 'isdn': 63, 'isdns': 75, 'isdnu': 76, 'iso88022llc': 41, 'iso88023Csmacd': 7, 'iso88024TokenBus': 8, 'iso88025CRFPInt': 98, 'iso88025Dtr': 86, 'iso88025Fiber': 115, 'iso88025TokenRing': 9, 'iso88026Man': 10, 'isup': 179, 'l2vlan': 135, 'l3ipvlan': 136, 'l3ipxvlan': 137, 'lapb': 16, 'lapd': 77, 'lapf': 119, 'linegroup': 210, 'lmp': 227, 'localTalk': 42, 'macSecControlledIF': 231, 'macSecUncontrolledIF': 232, 'mediaMailOverIp': 139, 'mfSigLink': 167, 'miox25': 38, 'mocaVersion1': 236, 'modem': 48, 'mpc': 113, 'mpegTransport': 214, 'mpls': 166, 'mplsTunnel': 150, 'msdsl': 143, 'mvl': 191, 'myrinet': 99, 'nfas': 175, 'nsip': 27, 'opticalChannel': 195, 'opticalChannelGroup': 219, 'opticalTransport': 196, 'other': 1, 'otnOdu': 260, 'otnOtu': 261, 'para': 34, 'pdnEtherLoop1': 217, 'pdnEtherLoop2': 218, 'pip': 248, 'plc': 174, 'pon155': 207, 'pon622': 208, 'pos': 171, 'ppp': 23, 'pppMultilinkBundle': 108, 'primaryISDN': 21, 'propAtm': 197, 'propBWAp2Mp': 184, 'propCnls': 89, 'propDocsWirelessDownstream': 181, 'propDocsWirelessMacLayer': 180, 'propDocsWirelessUpstream': 182, 'propMultiplexor': 54, 'propPointToPointSerial': 22, 'propVirtual': 53, 'propWirelessP2P': 157, 'proteon10Mbit': 12, 'proteon80Mbit': 13, 'q2931': 201, 'qam': 226, 'qllc': 68, 'radioMAC': 188, 'radsl': 95, 'reachDSL': 192, 'regular1822': 2, 'rfc1483': 159, 'rfc877x25': 5, 'rpr': 225, 'rs232': 33, 'rsrb': 79, 'sdci': 280, 'sdlc': 17, 'sdsl': 96, 'shdsl': 169, 'sip': 31, 'sipSig': 204, 'sipTg': 203, 'sixToFour': 215, 'slip': 28, 'smdsDxi': 43, 'smdsIcip': 52, 'softwareLoopback': 24, 'sonet': 39,

'sonetOverheadChannel': 185, 'sonetPath': 50, 'sonetVT': 51, 'srp': 151, 'ss7SigLink': 156, 'stackToStack': 111, 'starLan': 11, 'tdlc': 116, 'teLink': 200, 'termPad': 91, 'tr008': 176, 'transpHdlc': 123, 'tunnel': 131, 'ultra': 29, 'usb': 160, 'v11': 64, 'v35': 45, 'v36': 65, 'v37': 120, 'vdsl': 97, 'vdsl2': 251, 'virtualIpAddress': 112, 'virtualTg': 202, 'vmwareNicTeam': 272, 'vmwareVirtualNic': 258, 'voiceDID': 213, 'voiceEBS': 245, 'voiceEM': 100, 'voiceEMFGD': 211, 'voiceEncap': 103, 'voiceFGDEANA': 212, 'voiceFGDOS': 235, 'voiceFXO': 101, 'voiceFXS': 102, 'voiceOverAtm': 152, 'voiceOverCable': 198, 'voiceOverFrameRelay': 153, 'voiceOverIp': 104, 'wwanPP': 243, 'wwanPP2': 244, 'x213': 93, 'x25huntGroup': 122, 'x25mlp': 121, 'x25ple': 40, 'x86Laps': 242

Access: read-write

Status: current

35.1.4 onuifName

OID: 1.3.6.1.4.1.3709.3.6.2.1.1.5

Description: Interface name

Syntax: String

Syntax details: (Size) 0 - 48

Access: read-write

Status: current

35.1.5 onuifAdminStatus

OID: 1.3.6.1.4.1.3709.3.6.2.1.1.6

Description: Interface administrative state

Syntax: INTEGER

Syntax details: (Enumeration) 'down': 2, 'testing': 3, 'up': 1

Access: read-write

Status: current

35.1.6 onuifOperStatus

OID: 1.3.6.1.4.1.3709.3.6.2.1.1.7

Description: Interface operational state

Syntax: INTEGER

Syntax details: (Enumeration) 'dormant': 5, 'down': 2, 'lowerLayerDown': 7, 'notPresent': 6, 'testing': 3, 'unknown': 4, 'up': 1

Access: read-write

Status: current

35.1.7 onulfStatisticsInOctets

OID: 1.3.6.1.4.1.3709.3.6.2.1.1.8

Description: Ethernet UNI input octets

Syntax: Counter64

Access: read-only

Status: current

35.1.8 onulfStatisticsInUcastPkts

OID: 1.3.6.1.4.1.3709.3.6.2.1.1.9

Description: Ethernet UNI input unicast packets

Syntax: Counter64

Access: read-only

Status: current

35.1.9 onulfStatisticsInMulticastPkts

OID: 1.3.6.1.4.1.3709.3.6.2.1.1.10

Description: Ethernet UNI input multicast packets

Syntax: Counter64

Access: read-only

Status: current

35.1.10 onulfStatisticsInBroadcastPkts

OID: 1.3.6.1.4.1.3709.3.6.2.1.1.11

Description: Ethernet UNI input broadcast packets

Syntax: Counter64

Access: read-only

Status: current

35.1.11 onulfStatisticsInDiscards

OID: 1.3.6.1.4.1.3709.3.6.2.1.1.12

Description: Ethernet UNI input discarded packets

Syntax: Counter64

Access: read-only

Status: current

35.1.12 onulfStatisticsInErrors

OID: 1.3.6.1.4.1.3709.3.6.2.1.1.13

Description: Ethernet UNI input packets with errors

Syntax: Counter64

Access: read-only

Status: current

35.1.13 onulfStatisticsInUnknownProtos

OID: 1.3.6.1.4.1.3709.3.6.2.1.1.14

Description: Ethernet UNI input packets with unknown protocol

Syntax: Counter64

Access: read-only

Status: current

35.1.14 onulfStatisticsOutOctets

OID: 1.3.6.1.4.1.3709.3.6.2.1.1.15

Description: Ethernet UNI output octets

Syntax: Counter64

Access: read-only

Status: current

35.1.15 onulfStatisticsOutUcastPkts

OID: 1.3.6.1.4.1.3709.3.6.2.1.1.16

Description: Ethernet UNI output unicast packets

Syntax: Counter64

Access: read-only

Status: current

35.1.16 onulfStatisticsOutMulticastPkts

OID: 1.3.6.1.4.1.3709.3.6.2.1.1.17

Description: Ethernet UNI output multicast packets

Syntax: Counter64

Access: read-only

Status: current

35.1.17 onulfStatisticsOutBroadcastPkts

OID: 1.3.6.1.4.1.3709.3.6.2.1.1.18

Description: Ethernet UNI output broadcast packets

Syntax: Counter64

Access: read-only

Status: current

35.1.18 onulfStatisticsOutDiscards

OID: 1.3.6.1.4.1.3709.3.6.2.1.1.19

Description: Ethernet UNI output discarded packets

Syntax: Counter64

Access: read-only

Status: current

35.1.19 onulfStatisticsOutErrors

OID: 1.3.6.1.4.1.3709.3.6.2.1.1.20

Description: Ethernet UNI output packets with errors

Syntax: Counter64

Access: read-only

Status: current

35.1.20 onulfOnuPowerTx

OID: 1.3.6.1.4.1.3709.3.6.2.1.1.21

Description: ONU Tx optical power

Syntax: String

Access: read-write

Status: current

35.1.21 onulfOnuPowerRx

OID: 1.3.6.1.4.1.3709.3.6.2.1.1.22

Description: ONU Rx optical power

Syntax: String

Access: read-write

Status: current

35.1.22 onulfAlias

OID: 1.3.6.1.4.1.3709.3.6.2.1.1.23

Description: Interface textual description

Syntax: String

Syntax details: (Size) 0 - 64

Access: read-only

Status: current

35.1.23 onulfStatisticsInBwUsage

OID: 1.3.6.1.4.1.3709.3.6.2.1.1.24

Description: Ethernet UNI input bandwidth usage in bps

Syntax: Counter64

Access: read-only

Status: current

35.1.24 onulfStatisticsOutBwUsage

OID: 1.3.6.1.4.1.3709.3.6.2.1.1.25

Description: Ethernet UNI output bandwidth usage in bps

Syntax: Counter64

Access: read-only

Status: current

35.1.25 onuSysUpTime

OID: 1.3.6.1.4.1.3709.3.6.2.1.1.26

Description: ONU system uptime

Syntax: TimeTicks

Access: read-only

Status: current

35.1.26 onuGemInOctets

OID: 1.3.6.1.4.1.3709.3.6.2.1.1.27

Description: GEM input octets

Syntax: Counter64

Access: read-only

Status: current

35.1.27 onuGemInPackets

OID: 1.3.6.1.4.1.3709.3.6.2.1.1.28

Description: GEM input packets

Syntax: Counter64

Access: read-only

Status: current

35.1.28 onuGemOutOctets

OID: 1.3.6.1.4.1.3709.3.6.2.1.1.29

Description: GEM output octets

Syntax: Counter64

Access: read-only

Status: current

35.1.29 onuGemOutPackets

OID: 1.3.6.1.4.1.3709.3.6.2.1.1.30

Description: GEM output packets

Syntax: Counter64

Access: read-only

Status: current

36 TWAMP-MIB

MIB file: TWAMP-MIB.mib

This MIB file has the following root objects:

- **twampMIB**
 - **OID:** 1.3.6.1.4.1.3709.3.6.7
 - **Description:** The MIB for Datacom TWAMP sessions and statistics

36.1 twampSessionTable

OID: 1.3.6.1.4.1.3709.3.6.7.1

Description: A table that contains all information about all TWAMP Sessions, indexed by the Session ID.

Syntax: SEQUENCE OF twampSessionEntry (OID: 1.3.6.1.4.1.3709.3.6.7.1.1)

Access: not-accessible

Status: current

36.1.1 twampSessionId

OID: 1.3.6.1.4.1.3709.3.6.7.1.1.1

Description: The TWAMP session identifier

Syntax: Unsigned32

Syntax details: (Range) 1 - 4294967295

Access: read-only

Status: current

36.1.2 twampSessionDuration

OID: 1.3.6.1.4.1.3709.3.6.7.1.1.2

Description: The duration of a TWAMP session

Syntax: Unsigned32

Syntax details: (Range) 0 - 4294967295

Access: read-only

Status: current

36.1.3 twampSessionInterval

OID: 1.3.6.1.4.1.3709.3.6.7.1.1.3

Description: The TWAMP session timeout

Syntax: Unsigned32

Syntax details: (Range) 0 - 4294967295

Access: read-only

Status: current

36.1.4 twampSessionState

OID: 1.3.6.1.4.1.3709.3.6.7.1.1.4

Description: Identifies whether the session is active or inactive

Syntax: INTEGER

Syntax details: (Enumeration) 'active': 1, 'inactive': 0

Access: read-only

Status: current

36.1.5 twampSessionSrcAddr

OID: 1.3.6.1.4.1.3709.3.6.7.1.1.5

Description: Represents local IP

Syntax: InetAddress

Access: read-only

Status: current

36.1.6 twampSessionDstAddr

OID: 1.3.6.1.4.1.3709.3.6.7.1.1.6

Description: Represents the remote IP

Syntax: InetAddress

Access: read-only

Status: current

36.1.7 twampSessionDstPort

OID: 1.3.6.1.4.1.3709.3.6.7.1.1.7

Description: Represents the destination port on the reflector side

Syntax: InetPortNumber

Access: read-only

Status: current

36.1.8 twampSessionPktSize

OID: 1.3.6.1.4.1.3709.3.6.7.1.1.8

Description: Represents the size of the packet

Syntax: Unsigned32

Syntax details: (Range) 0 - 65535

Access: read-only

Status: current

36.1.9 twampSessionDSCP

OID: 1.3.6.1.4.1.3709.3.6.7.1.1.9

Description: Represents the DSCP value used by TWAMP packets, ranging from 0 to 63.

Syntax: Unsigned32

Syntax details: (Range) 0 - 63

Access: read-only

Status: current

36.1.10 twampSessionTotalTests

OID: 1.3.6.1.4.1.3709.3.6.7.1.1.10

Description: Represents the total of tests within the session

Syntax: Unsigned32

Syntax details: (Range) 1 - 4294967295

Access: read-only

Status: current

36.1.11 twampSessionTotalTxPkts

OID: 1.3.6.1.4.1.3709.3.6.7.1.1.11

Description: Represents the total of transmitted packets

Syntax: Unsigned32

Syntax details: (Range) 1 - 4294967295

Access: read-only

Status: current

36.1.12 twampSessionTotalRxPkts

OID: 1.3.6.1.4.1.3709.3.6.7.1.1.12

Description: Represents the total of received packets

Syntax: Unsigned32

Syntax details: (Range) 1 - 4294967295

Access: read-only

Status: current

36.1.13 twampSessionDescription

OID: 1.3.6.1.4.1.3709.3.6.7.1.1.13

Description: Description of session

Syntax: DisplayString

Syntax details: (Size) 0 - 128

Access: read-only

Status: current

36.2 twampTestTable

OID: 1.3.6.1.4.1.3709.3.6.7.2

Description: A table that contains the two-way test results of each TWAMP session, indexed by the Session ID and Test index, respectively.

Syntax: SEQUENCE OF twampTestEntry (OID: 1.3.6.1.4.1.3709.3.6.7.2.1)

Access: not-accessible

Status: current

36.2.1 twampTestSessionId

OID: 1.3.6.1.4.1.3709.3.6.7.2.1.1

Description: The TWAMP session identifier

Syntax: Unsigned32

Syntax details: (Range) 1 - 4294967295

Access: read-only

Status: current

36.2.2 twampTestIndex

OID: 1.3.6.1.4.1.3709.3.6.7.2.1.2

Description: The table index of a TWAMP test within the session

Syntax: Unsigned32

Syntax details: (Range) 1 - 4294967295

Access: read-only

Status: current

36.2.3 twampTestId

OID: 1.3.6.1.4.1.3709.3.6.7.2.1.3

Description: The TWAMP test identifier within the session

Syntax: Unsigned32

Syntax details: (Range) 1 - 4294967295

Access: read-only

Status: current

36.2.4 twampTestDelayMin

OID: 1.3.6.1.4.1.3709.3.6.7.2.1.4

Description: The minimum delay value identified during the test

Syntax: TwampMeasure

Access: read-only

Status: current

36.2.5 twampTestDelayMax

OID: 1.3.6.1.4.1.3709.3.6.7.2.1.5

Description: The maximum delay value identified during the test

Syntax: TwampMeasure

Access: read-only

Status: current

36.2.6 twampTestDelayAvg

OID: 1.3.6.1.4.1.3709.3.6.7.2.1.6

Description: The average delay value identified during the test

Syntax: TwampMeasure

Access: read-only

Status: current

36.2.7 twampTestJitterMin

OID: 1.3.6.1.4.1.3709.3.6.7.2.1.7

Description: The minimum Jitter value identified during the test

Syntax: TwampMeasure

Access: read-only

Status: current

36.2.8 twampTestJitterMax

OID: 1.3.6.1.4.1.3709.3.6.7.2.1.8

Description: The maximum Jitter value identified during the test

Syntax: TwampMeasure

Access: read-only

Status: current

36.2.9 twampTestJitterAvg

OID: 1.3.6.1.4.1.3709.3.6.7.2.1.9

Description: The average Jitter value identified during the test

Syntax: TwampMeasure

Access: read-only

Status: current

36.2.10 twampTestTxPkts

OID: 1.3.6.1.4.1.3709.3.6.7.2.1.10

Description: The number of packets sent during the test

Syntax: Unsigned32

Access: read-only

Status: current

36.2.11 twampTestRxPkts

OID: 1.3.6.1.4.1.3709.3.6.7.2.1.11

Description: The number of packets received during the test

Syntax: Unsigned32

Access: read-only

Status: current

36.2.12 twampTestLossRatio

OID: 1.3.6.1.4.1.3709.3.6.7.2.1.12

Description: The percentage of packets lost during the test

Syntax: TwampTestLossRatio

Access: read-only

Status: current

36.2.13 twampTestConnectivity

OID: 1.3.6.1.4.1.3709.3.6.7.2.1.13

Description: Identifies whether the test has connectivity with the reflector

Syntax: INTEGER

Syntax details: (Enumeration) 'no': 0, 'yes': 1

Access: read-only

Status: current

36.2.14 twampTestRoundTripDelayMin

OID: 1.3.6.1.4.1.3709.3.6.7.2.1.14

Description: The minimum round-trip delay value identified during the test

Syntax: TwampMeasure

Access: read-only

Status: current

36.2.15 twampTestRoundTripDelayMax

OID: 1.3.6.1.4.1.3709.3.6.7.2.1.15

Description: The maximum round-trip delay value identified during the test

Syntax: TwampMeasure

Access: read-only

Status: current

36.2.16 twampTestRoundTripDelayAvg

OID: 1.3.6.1.4.1.3709.3.6.7.2.1.16

Description: The average round-trip delay value identified during the test

Syntax: TwampMeasure

Access: read-only

Status: current

36.2.17 twampTestState

OID: 1.3.6.1.4.1.3709.3.6.7.2.1.17

Description: Identifies the state of test

Syntax: INTEGER

Syntax details: (Enumeration) 'last-run-fail': 2, 'last-run-success': 3, 'running': 1, 'unknown': 0

Access: read-only

Status: current

36.2.18 twampTestDescription

OID: 1.3.6.1.4.1.3709.3.6.7.2.1.18

Description: Description of test session

Syntax: DisplayString

Syntax details: (Size) 0 - 128

Access: read-only

Status: current

36.3 twampFarEndTestTable

OID: 1.3.6.1.4.1.3709.3.6.7.3

Description: A table that contains the far-end test results of each TWAMP session, indexed by the Session ID and Test index, respectively.

Syntax: SEQUENCE OF twampFarEndTestEntry (OID: 1.3.6.1.4.1.3709.3.6.7.3.1)

Access: not-accessible

Status: current

36.3.1 twampFarEndTestSessionId

OID: 1.3.6.1.4.1.3709.3.6.7.3.1.1

Description: The TWAMP session identifier

Syntax: Unsigned32

Syntax details: (Range) 1 - 4294967295

Access: read-only

Status: current

36.3.2 twampFarEndTestIndex

OID: 1.3.6.1.4.1.3709.3.6.7.3.1.2

Description: The table index of a TWAMP test within the session

Syntax: Unsigned32

Syntax details: (Range) 1 - 4294967295

Access: read-only

Status: current

36.3.3 twampFarEndTestId

OID: 1.3.6.1.4.1.3709.3.6.7.3.1.3

Description: The TWAMP test identifier within the session

Syntax: Unsigned32

Syntax details: (Range) 1 - 4294967295

Access: read-only

Status: current

36.3.4 twampFarEndTestDelayMin

OID: 1.3.6.1.4.1.3709.3.6.7.3.1.4

Description: The minimum delay value identified during the test

Syntax: TwampMeasure

Access: read-only

Status: current

36.3.5 twampFarEndTestDelayMax

OID: 1.3.6.1.4.1.3709.3.6.7.3.1.5

Description: The maximum delay value identified during the test

Syntax: TwampMeasure

Access: read-only

Status: current

36.3.6 twampFarEndTestDelayAvg

OID: 1.3.6.1.4.1.3709.3.6.7.3.1.6

Description: The average delay value identified during the test

Syntax: TwampMeasure

Access: read-only

Status: current

36.3.7 twampFarEndTestJitterMin

OID: 1.3.6.1.4.1.3709.3.6.7.3.1.7

Description: The minimum Jitter value identified during the test

Syntax: TwampMeasure

Access: read-only

Status: current

36.3.8 twampFarEndTestJitterMax

OID: 1.3.6.1.4.1.3709.3.6.7.3.1.8

Description: The maximum Jitter value identified during the test

Syntax: TwampMeasure

Access: read-only

Status: current

36.3.9 twampFarEndTestJitterAvg

OID: 1.3.6.1.4.1.3709.3.6.7.3.1.9

Description: The average Jitter value identified during the test

Syntax: TwampMeasure

Access: read-only

Status: current

36.3.10 twampFarEndTestTxPkts

OID: 1.3.6.1.4.1.3709.3.6.7.3.1.10

Description: The number of packets sent during the test

Syntax: Unsigned32

Access: read-only

Status: current

36.3.11 twampFarEndTestRxPkts

OID: 1.3.6.1.4.1.3709.3.6.7.3.1.11

Description: The number of packets received during the test

Syntax: Unsigned32

Access: read-only

Status: current

36.3.12 twampFarEndTestLossRatio

OID: 1.3.6.1.4.1.3709.3.6.7.3.1.12

Description: The percentage of packets lost during the test

Syntax: TwampTestLossRatio

Access: read-only

Status: current

36.3.13 twampFarEndTestConnectivity

OID: 1.3.6.1.4.1.3709.3.6.7.3.1.13

Description: Identifies whether the test has connectivity with the reflector

Syntax: INTEGER

Syntax details: (Enumeration) 'no': 0, 'yes': 1

Access: read-only

Status: current

36.4 twampNearEndTestTable

OID: 1.3.6.1.4.1.3709.3.6.7.4

Description: A table that contains the near-end test results of each TWAMP session, indexed by the Session ID and Test index, respectively.

Syntax: SEQUENCE OF twampNearEndTestEntry (OID: 1.3.6.1.4.1.3709.3.6.7.4.1)

Access: not-accessible

Status: current

36.4.1 twampNearEndTestSessionId

OID: 1.3.6.1.4.1.3709.3.6.7.4.1.1

Description: The TWAMP session identifier

Syntax: Unsigned32

Syntax details: (Range) 1 - 4294967295

Access: read-only

Status: current

36.4.2 twampNearEndTestIndex

OID: 1.3.6.1.4.1.3709.3.6.7.4.1.2

Description: The table index of a TWAMP test within the session

Syntax: Unsigned32

Syntax details: (Range) 1 - 4294967295

Access: read-only

Status: current

36.4.3 twampNearEndTestId

OID: 1.3.6.1.4.1.3709.3.6.7.4.1.3

Description: The TWAMP test identifier within the session

Syntax: Unsigned32

Syntax details: (Range) 1 - 4294967295

Access: read-only

Status: current

36.4.4 twampNearEndTestDelayMin

OID: 1.3.6.1.4.1.3709.3.6.7.4.1.4

Description: The minimum delay value identified during the test

Syntax: TwampMeasure

Access: read-only

Status: current

36.4.5 twampNearEndTestDelayMax

OID: 1.3.6.1.4.1.3709.3.6.7.4.1.5

Description: The maximum delay value identified during the test

Syntax: TwampMeasure

Access: read-only

Status: current

36.4.6 twampNearEndTestDelayAvg

OID: 1.3.6.1.4.1.3709.3.6.7.4.1.6

Description: The average delay value identified during the test

Syntax: TwampMeasure

Access: read-only

Status: current

36.4.7 twampNearEndTestJitterMin

OID: 1.3.6.1.4.1.3709.3.6.7.4.1.7

Description: The minimum Jitter value identified during the test

Syntax: TwampMeasure

Access: read-only

Status: current

36.4.8 twampNearEndTestJitterMax

OID: 1.3.6.1.4.1.3709.3.6.7.4.1.8

Description: The maximum Jitter value identified during the test

Syntax: TwampMeasure

Access: read-only

Status: current

36.4.9 twampNearEndTestJitterAvg

OID: 1.3.6.1.4.1.3709.3.6.7.4.1.9

Description: The average Jitter value identified during the test

Syntax: TwampMeasure

Access: read-only

Status: current

36.4.10 twampNearEndTestTxPkts

OID: 1.3.6.1.4.1.3709.3.6.7.4.1.10

Description: The number of packets sent during the test

Syntax: Unsigned32

Access: read-only

Status: current

36.4.11 twampNearEndTestRxPkts

OID: 1.3.6.1.4.1.3709.3.6.7.4.1.11

Description: The number of packets received during the test

Syntax: Unsigned32

Access: read-only

Status: current

36.4.12 twampNearEndTestLossRatio

OID: 1.3.6.1.4.1.3709.3.6.7.4.1.12

Description: The percentage of packets lost during the test

Syntax: TwampTestLossRatio

Access: read-only

Status: current

36.4.13 twampNearEndTestConnectivity

OID: 1.3.6.1.4.1.3709.3.6.7.4.1.13

Description: Identifies whether the test has connectivity with the reflector

Syntax: INTEGER

Syntax details: (Enumeration) 'no': 0, 'yes': 1

Access: read-only

Status: current

Legal Note

In spite the fact that all the precautions were taken in development of the present document, DATACOM shall not be held responsible for eventual errors or omissions as well as no obligation is assumed due to damages resulting from the use of the information included in this guide. The specifications provided in this manual shall be subject to changes with no prior notification and are not acknowledged as any type of contract.

© 2026 DATACOM - All rights reserved.

Warranty

DATACOM's products are covered by a warranty against manufacturing defects during a minimum period of 12 (twelve) months including the legal term of 90 days, as from the date of issue of the supply Nota Fiscal (Invoice).

Our warranty is standard counter warranty, this means, for exercise of the warranty, the customer should send the product to DATACOM Authorized Technical Assistance with paid freight. The return freight of the equipment will be DATACOM responsibility.

To obtain additional information, see our warranty policy in <https://www.datacom.com.br/en>.

Telephone Number: **+55 51 3933-3094**