

UWT

Universal Wireless Tester User Manual



Document date	4/21/2026
Document version	3.7.0

Table of contents

- [1. Mandatory Commands](#)
 - [2. Bluetooth](#)
 - [3. GSM](#)
 - [4. LTE](#)
 - [5. NR](#)
 - [6. RFSG](#)
 - [7. Wcdma](#)
 - [8. Wlan](#)
-

1. Mandatory Commands

:DBG <enable>

Availability: Command Only **Default:** N/A

Description: Enable debug messages for scpi response reports.

Parameters: <enable> Boolean

:ESE

Availability: Command and Query **Default:** N/A

Description: Event Status Enable

:ESR

Availability: Query Only **Default:** N/A

Description: Event Status Enable Register

Return type: String

:IDN

Availability: Query Only **Default:** N/A

Description: Returns a unique identifier '<manufacturer>,<product>,<serial_number>,<software_version>,<switch>,<instrument1>,<instrument2>,...', where <switch> contains information about the current port's switch separated by ':', and <instrumentN> holds information about the available VSTs. The exact form of <switch> and <instrumentN> depends on the actual hardware.

Return type: SystemInformation

:OPT

Availability: Query Only **Default:** N/A

Description: Identify Options Query

Return type: String

:SRE <i>

Availability: Command and Query **Default:** N/A

Description: Service Request Enable

Parameters: <i> Int32

:SYS:ERR

Availability: Query Only **Default:** N/A

Description: Returns a list of errors occurred in the RF-Switch.

Return type: String

:SYS:LOSS:EXtErnal:ADD <tableType> <frequency_MHz> <attenuation_dB>**Availability:** Command Only**Default:** N/A

Description: Adds attenuation information to the chosen external attenuation table.
Usage: SYS:ATTENuation:EXtErnal:ADD {SG|SA|Both} [FREQ,...]
[ATTEN,...]

Parameters:

<tableType>	SG SA Both
<frequency_MHz>	Double[]
<attenuation_dB>	Double[]

:SYS:LOSS:EXtErnal:ADD:POWer <tableType> <frequency_MHz> <power_dBm> <attenuation_dB>**Availability:** Command Only**Default:** N/A

Description: Adds attenuation information to the chosen external attenuation table.
Usage: SYS:ATTENuation:EXtErnal:ADD:POWer {SG|SA|Both} [FREQ,...]
[PWR,...] [ATTEN,...]

Parameters:

<tableType>	SG SA Both
<frequency_MHz>	Double[]
<power_dBm>	Double[]
<attenuation_dB>	Double[]

:SYS:LOSS:EXtErnal:ATTENuation <tableType>**Availability:** Query Only**Default:** N/A

Description: Returns the attenuation values [dB] from the selected external attenuation table.

Parameters: <tableType> SG | SA | Both

Return type: Double[]

:SYS:LOSS:EXtErnal:CLEar <tableType>**Availability:** Command Only**Default:** N/A

Description: Clears the selected external attenuation table. Usage:
SYS:ATTENuation:EXtErnal:CLEar {SG|SA|Both}

Parameters: <tableType> SG | SA | Both

:SYS:LOSS:EXtErnal:FREQuency <tableType>**Availability:** Query Only**Default:** N/A

Description: Returns the frequencies [MHz] from the selected external attenuation table.

Parameters: <tableType> SG | SA | Both

Return type: Double[]

:SYS:LOSS:EXtErnal:POWer <tableType>**Availability:** Query Only**Default:** N/A

Description: Returns the power levels [dBm] from the selected external attenuation table.

Parameters: <tableType> SG | SA | Both

Return type: Double[]

:SYS:RDY**Availability:** Query Only**Default:** N/A**Description:** Returns true when the instrument is initialized and ready to be used.**Return type:** Boolean

:TST**Availability:** Query Only**Default:** N/A**Description:** Result of Self-test Query**Return type:** String

:WAI**Availability:** Command Only**Default:** N/A**Description:** Wait

2. Bluetooth

:BT:INITiate <resultSpace>

Availability: Command Only **Default:** N/A

Description: Initiates the analyzer.

Parameters: <resultSpace> Int32

:BT:MEASurement:STATE

Availability: Query Only **Default:** N/A

Description: Returns the current state of the measurement.

Return type: READY | PROCESSING | OFF | PENDING | ACTIVE

:BT:RESet

Availability: Command Only **Default:** N/A

Description: Reset the analyzer to the default state.

:CONFigure:BT:20DB:AVG:COUNt <TwentyDbBandwidthAveragingCount>

Availability: Command and Query **Default:** 10

Description: Sets the number of acquisitions used for averaging when TwentyDbBandwidth averaging is enabled.

Parameters: <TwentyDbBandwidthAveragingCount> Int32

:CONFigure:BT:20DB:AVG:ENABLE <TwentyDbBandwidthAveragingEnabled>

Availability: Command and Query **Default:** 0

Description: Sets whether to enable averaging for the 20dBBandwidth measurement.

Parameters: <TwentyDbBandwidthAveragingEnabled> Boolean

:CONFigure:BT:20DB:ENABLE <TwentyDbBandwidthEnabled>

Availability: Command and Query **Default:** 0

Description: Sets whether to enable the 20dBBandwidth measurement specified in section 4.5.5 of the Bluetooth Test Specification v5.1.0. The measurement uses a span of 3 MHz internally. This measurement is valid only for basic rate (BR) packets.

Parameters: <TwentyDbBandwidthEnabled> Boolean

:CONFigure:BT:20DB:NTHReads <TwentyDbBandwidthNumberOfAnalysisThreads>

Availability: Command and Query **Default:** 1

Description: Sets the maximum number of threads used for parallelism for the 20dB bandwidth measurement. The number of threads can range from 1 to the number of physical cores. The number of threads you set may not be used in calculations. The actual number of threads used depends on the problem size, system resources, data availability, and other considerations.

Parameters: <TwentyDbBandwidthNumberOfAnalysisThreads> Int32

:CONFigure:BT:20DB:TRACe:ENABLE <TwentyDbBandwidthAllTracesEnable>

Availability: Command and Query **Default:** 0

Description: Sets whether to enable all the traces for the 20dBBandwidth measurement.

Parameters: <TwentyDbBandwidthAllTracesEnable> Boolean

:CONFigure:BT:ACCess:ADDReSS <BTAccessAddress>

Availability: Command and Query **Default:** 1903575337

Description: Sets the 32-bit LE access address.

Parameters: <BTAccessAddress> Int32

:CONFigure:BT:ACP:AVG:COUNt <AcpAveragingCount>

Availability: Command and Query **Default:** 10

Description: Sets the number of acquisitions used for averaging when Acp averaging is enabled.

Parameters: <AcpAveragingCount> Int32

:CONFigure:BT:ACP:AVG:ENABLE <AcpAveragingEnable>

Availability: Command and Query **Default:** 0

Description: Sets whether to enable averaging for the ACP measurement.

Parameters: <AcpAveragingEnable> Boolean

:CONFigure:BT:ACP:BURSt:SYNC:TYPE <AcpBurstSyncType>

Availability: Command and Query **Default:** Preamble

Description: Sets the type of synchronization used for detecting the start of the EDR packet in the adjacent channel power (ACP) measurement.

Parameters: <AcpBurstSyncType> None | Preamble | SyncWord

:CONFigure:BT:ACP:ENABLE <AcpEnable>

Availability: Command and Query **Default:** 1

Description: Sets whether to enable the ACP measurement.

Parameters: <AcpEnable> Boolean

:CONFigure:BT:ACP:NTHReads <AcpNumberOfAnalysisThreads>

Availability: Command and Query **Default:** 1

Description: Sets the maximum number of threads used for parallelism for adjacent channel power (ACP) measurement.

Parameters: <AcpNumberOfAnalysisThreads> Int32

:CONFigure:BT:ACP:OFFSet:MODE <AcpOffsetChannelMode>

Availability: Command and Query **Default:** Symmetric

Description: Sets which offset channels are used for the measurement.

Parameters: <AcpOffsetChannelMode> InBand | Symmetric

:CONFigure:BT:ACP:OFFSet:NUMBER <AcpNumberOfOffsets>

Availability: Command and Query **Default:** 5

Description: Sets the number of offset channels used on either side of the reference channel for the adjacent channel power (ACP) measurement when user sets the OffsetChannelMode to Symmetric. This method also returns the actual number of offsets used in the ACP measurement when user sets the ACP Offset Channel Mode method to InBand.

Parameters: <AcpNumberOfOffsets> Int32

:CONFigure:BT:ACP:TRACe:ENABLE <AcpAllTracesEnable>

Availability: Command and Query **Default:** 0

Description: Sets whether to enable all traces for the adjacent channel power (ACP) measurements.

Parameters: <AcpAllTracesEnable> Boolean

:CONFigure:BT:BDADdress:LAP <BTBDAddressLap>

Availability: Command and Query **Default:** 0

Description: Sets the 24-bit lower address part (LAP) of the bluetooth device address (BD_ADDR).

Parameters: <BTBDAddressLap> Int32

:CONFigure:BT:CHANnel <BTChannelNumber>

Availability: Command and Query **Default:** 0

Description: Sets the RF channel number of the signal generated by the device under test (DUT), as defined in the bluetooth specification. This method is applicable when you enable the ACP measurement and when user sets the OffsetChannelMode to InBand.

Parameters: <BTChannelNumber> Int32

:CONFigure:BT:CTE:LENGth <BTCteLength_s>

Availability: Command and Query **Default:** 0.00016

Description: Sets the length of the constant tone extension (CTE) field in the generated signal. This value is expressed in seconds. This method is applicable only when user sets the BTDirectionFindingMode property to either AngleOfArrival or AngleOfDepature.

Parameters: <BTCteLength_s> Double

:CONFigure:BT:CTE:SLOT:DURation <BTCteSlotDuration_s>

Availability: Command and Query **Default:** 0

Description: Sets the length of the transmit slots and sampling slots in the constant tone extension field of the generated signal. This value is expressed in seconds. This method is applicable only when user sets the BTDirectionFindingMode property to either AngleOfArrival or AngleOfDepature.

Parameters: <BTCteSlotDuration_s> Double

:CONFigure:BT:DRATE <BTDataRate_Bps>

Availability: Command and Query **Default:** 1000000

Description: Specifies the mode of direction finding. This method is applicable only to LE packet type.

Parameters: <BTDataRate_Bps> Int32

:CONFigure:BT:FRANge:AVG:COUNT <FrequencyRangeAveragingCount>

Availability: Command and Query **Default:** 10

Description: Sets the number of acquisitions used for averaging when FrequencyRange averaging is enabled.

Parameters: <FrequencyRangeAveragingCount> Int32

:CONFigure:BT:FRANge:AVG:ENABLE <FrequencyRangeAveragingEnabled>

Availability: Command and Query **Default:** 0

Description: Sets whether to enable all the traces for FrequencyRange measurement.

Parameters: <FrequencyRangeAveragingEnabled> Boolean

:CONFigure:BT:FRANge:ENABLE <FrequencyRangeEnabled>

Availability: Command and Query **Default:** 0

Description: Sets whether to enable the FrequencyRange measurement specified in the section 4.5.4 of the Bluetooth Test Specification v5.1.0. This measurement is valid only for basic rate (BR) packets.

Parameters: <FrequencyRangeEnabled> Boolean

:CONFigure:BT:FRANge:NTHReads <FrequencyRangeNumberOfAnalysisThreads>

Availability: Command and Query **Default:** 1

Description: Sets the maximum number of threads used for parallelism for the frequency range measurement. The number of threads can range from 1 to the number of physical cores. The number of threads you set may not be used in calculations. The actual number of threads used depends on the problem size, system resources, data availability, and other considerations.

Parameters: <FrequencyRangeNumberOfAnalysisThreads> Int32

:CONFigure:BT:FRANge:SPAN <FrequencyRangeSpan_Hz>

Availability: Command and Query **Default:** 10000000

Description: Sets the span for the FrequencyRange measurement. This value is expressed in Hz. You must adjust the span according the center frequency as specified in section 4.5.4 of the Bluetooth Test Specification v5.1.0. It is recommended to use the span of 6 MHz for a center frequency of 2.402 GHz and 10 MHz for a center frequency of 2.48 GHz.

Parameters: <FrequencyRangeSpan_Hz> Double

:CONFigure:BT:FRANge:TRACe:ENABLE <FrequencyRangeAllTracesEnable>

Availability: Command and Query **Default:** 0

Description: Sets whether to enable all the traces for FrequencyRange measurement.

Parameters: <FrequencyRangeAllTracesEnable> Boolean

:CONFigure:BT:FREQuency:CENTer <CenterFrequency_Hz>

Availability: Command and Query **Default:** 2402000000

Description: Sets the expected carrier frequency of the RF signal that needs to be acquired. This value is expressed in Hz. The signal analyzer tunes to this frequency.

Parameters: <CenterFrequency_Hz> Double

:CONFigure:BT:LE:DIRection:FINDing:MODE <BTLeDirectionFindingMode>

Availability: Command and Query **Default:** Disabled

Description: Specifies the mode of direction finding. Disabled 0 Specifies that the LE packet does not have fields required for direction finding. AngleOfArrival 1 Specifies that the LE packets uses the Angle of Arrival method of direction finding. AngleOfDeparture 2 Specifies that the LE packets uses the Angle of Departure method of direction finding.

Parameters: <BTLeDirectionFindingMode> Disabled | AngleOfArrival | AngleOfDeparture

:CONFigure:BT:MODacc:AVG:COUNT <ModAccAveragingCount>

Availability: Command and Query **Default:** 10

Description: Sets the number of acquisitions used for averaging when ModAcc averaging is enabled.

Parameters: <ModAccAveragingCount> Int32

:CONFigure:BT:MODacc:AVG:ENABLE <ModAccAveragingEnabled>

Availability: Command and Query **Default:** 0

Description: Sets whether to enable averaging for the ModAcc measurements.

Parameters: <ModAccAveragingEnabled> Boolean

:CONFigure:BT:MODacc:BURSt:SYNC:TYPE <ModAccBurstSyncType>

Availability: Command and Query **Default:** Preamble

Description: Sets the type of synchronization used for detecting the start of packet in ModAcc measurement.

Parameters: <ModAccBurstSyncType> None | Preamble | SyncWord

:CONFigure:BT:MODacc:ENABLE <ModAccEnabled>

Availability: Command and Query **Default:** 1

Description: Sets whether to enable the ModAcc measurements. You can use this method to determine the modulation quality of the bluetooth transmitter.

Parameters: <ModAccEnabled> Boolean

:CONFigure:BT:MODacc:IQ:ORIGin:OFFSet:ENABLE <ModAccIQOriginOffsetEnabled>

Availability: Command and Query **Default:** 0

Description: Sets whether to enable the I/Q origin offset correction for EDR packets. If you set this method to true, the DEVM results are computed after correcting for the I/Q origin offset.

Parameters: <ModAccIQOriginOffsetEnabled> Boolean

:CONFigure:BT:MODacc:NTHReads <ModAccNumberOfAnalysisThreads>

Availability: Command and Query **Default:** 1

Description: Sets the maximum number of threads used for parallelism for the ModAcc measurement. The number of threads can range from 1 to the number of physical cores. The number of threads you set may not be used in calculations. The actual number of threads used depends on the problem size, system resources, data availability, and other considerations.

Parameters: <ModAccNumberOfAnalysisThreads> Int32

:CONFigure:BT:MODacc:TRACe:ENABLE <ModAccAllTracesEnable>

Availability: Command and Query **Default:** 0

Description: Sets whether to enable all the traces computed by ModAcc measurements.

Parameters: <ModAccAllTracesEnable> Boolean

:CONFigure:BT:PACKet:TYPE <BTPacketType>

Availability: Command and Query **Default:** PacketTypeDH1

Description: Sets the type of the Bluetooth packet to be measured.

Parameters: <BTPacketType> PacketType2DH1 | PacketType2DH3 |
PacketType2DH5 | PacketType2EV3 |
PacketType2EV5 | PacketType3DH1 |
PacketType3DH3 | PacketType3DH5 |
PacketType3EV3 | PacketType3EV5 |
PacketTypeDH1 | PacketTypeDH3 |
PacketTypeDH5 | PacketTypeDM1 |
PacketTypeDM3 | PacketTypeDM5 |
PacketTypeLE | Unknown

:CONFigure:BT:PAYLoad:LENGth <BTPayloadLength_B>

Availability: Command and Query **Default:** 10

Description: Sets the payload length of the signal in bytes. This method is applicable only when user sets the PayloadLengthMode parameter to Manual. This method returns the payload length used for measurement if you set the Payload Length Mode method to Auto.

Parameters: <BTPayloadLength_B> Int32

:CONFigure:BT:PAYLoad:MODE <BTPayloadLengthMode>

Availability: Command and Query **Default:** Auto

Description: Sets the payload length mode of the signal to be measured. The payload length mode and BTPayloadLength properties decide the length of the payload to be used for measurement.

Parameters: <BTPayloadLengthMode> Auto | Manual

:CONFigure:BT:PAYLoad:PATtern <BTPayloadBitPattern>

Availability: Command and Query **Default:** Pattern10101010

Description: Sets the bit pattern present in the payload of the packet. This value is used to determine the set of ModAcc measurements to be performed.

Parameters: <BTPayloadBitPattern> Pattern10101010 | Pattern11110000 |
StandardDefined

:CONFigure:BT:REfERENCE:AUTO:INITial <AutoLevelInitialReferenceLevel_dBm>

Availability: Command and Query **Default:** 0

Description: Sets the initial reference level which the RFmxBT Auto Level function uses to estimate the peak power of the input signal. This value is expressed in dBm.

Parameters: <AutoLevelInitialReferenceLevel_dBm> Double

:CONFigure:BT:REfERENCE:LEVel <ReferenceLevel_dBm>

Availability: Command and Query **Default:** 0

Description: Configures the reference level which represents the maximum expected power of an RF input signal.

Parameters: <ReferenceLevel_dBm> Double

:CONFigure:BT:TRACe:ENABle <TraceEnable>

Availability: Command and Query **Default:** 0

Description: Enable traces for all measurements.

Parameters: <TraceEnable> Boolean

:CONFigure:BT:TXP:AVG:COUNt <TxpAveragingCount>

Availability: Command and Query **Default:** 10

Description: Sets the number of acquisitions used for averaging when TxP averaging is enabled.

Parameters: <TxpAveragingCount> Int32

:CONFigure:BT:TXP:AVG:ENABle <TxpAveragingEnabled>

Availability: Command and Query **Default:** 0

Description: Sets whether to enable averaging for the transmit power (TxP) measurements.

Parameters: <TxpAveragingEnabled> Boolean

:CONFigure:BT:TXP:BURSt:SYNC:TYPE <TxpBurstSyncType>

Availability: Command and Query **Default:** Preamble

Description: Sets the type of synchronization used for detecting the start of packet in the transmit power (TxP) measurement.

Parameters: <TxpBurstSyncType> None | Preamble | SyncWord

:CONFigure:BT:TXP:ENABle <TxpEnabled>

Availability: Command and Query **Default:** 1

Description: Sets whether to enable the transmit power (TxP) measurements.

Parameters: <TxpEnabled> Boolean

:CONFigure:BT:TXP:NTHReads <TxpNumberOfAnalysisThreads>

Availability: Command and Query **Default:** 1

Description: Sets the maximum number of threads used for parallelism for TXP measurement. The number of threads can range from 1 to the number of physical cores. The number of threads you set may not be used in calculations. The actual number of threads used depends on the problem size, system resources, data availability, and other considerations.

Parameters: <TxpNumberOfAnalysisThreads> Int32

:CONFigure:BT:TXP:TRACe:ENABLe <TxpAllTracesEnable>

Availability: Command and Query **Default:** 0

Description: Sets whether to enable all the traces used for transmit power (TxP) measurements.

Parameters: <TxpAllTracesEnable> Boolean

:FETCh:BT:RESUltS<i>

Availability: Query Only **Default:** N/A

Description: Returns the results of the measurement on resultSpace = i.

Return type: <Acp>, <ModAcc>, <Txp>, <FreqRange>, <20DB>

:FETCh:BT:RESUltS<i>:20DB

Availability: Query Only **Default:** N/A

Description: Results of BT 20 dB measurement.

Return type: <PeakPower_dBm: double>, <Bandwidth_Hz: double>, <LowFrequency_Hz: double>, <HighFrequency_Hz: double>

:FETCh:BT:RESUltS<i>:20DB:BW

Availability: Query Only **Default:** NaN

Description: Contains the 20dB bandwidth of the received signal. It is computed as the difference between highFrequency and lowFrequency parameters. This value is expressed in Hz.

Return type: Double

:FETCh:BT:RESUltS<i>:20DB:FREQuency:HIGH

Availability: Query Only **Default:** NaN

Description: Contains the highest frequency above the center frequency at which the transmit power drops below -30 dBm measured in a 100 kHz bandwidth. This value is expressed in Hz.

Return type: Double

:FETCh:BT:RESUltS<i>:20DB:FREQuency:LOW

Availability: Query Only **Default:** NaN

Description: Contains the lowest frequency below the center frequency at which the transmit power drops below -30 dBm measured in a 100 kHz bandwidth. This value is expressed in Hz.

Return type: Double

:FETch:BT:RESults<i>:20DB:POWer:PEAK**Availability:** Query Only**Default:** NaN**Description:** Contains the peak power of the measured spectrum. This value is expressed in dBm.**Return type:** Double

:FETch:BT:RESults<i>:ACP**Availability:** Query Only**Default:** N/A**Description:** Results of BT Acp measurement.**Return type:** <ReferenceChannelPower_dBm: double>,
<LowerOffsetAbsolutePower_dBm: double,...>,
<LowerOffsetRelativePower_dB: double,...>,
<UpperOffsetAbsolutePower_dBm: double,...>,
<UpperOffsetRelativePower_dB: double,...>, <LowerMargin_dB:
double,...>, <UpperMargin_dB: double,...>

:FETch:BT:RESults<i>:ACP:MARGin:LOWer<i>**Availability:** Query Only**Default:** NaN**Description:** Contains the array of margin from the limit specified by the mask with Exception for lower offset channel. This value is expressed in dB. Margin is defined as the difference between the Offset Absolute Power and Mask with Exception. This parameter is valid only if AcpOffsetChannelMode is set to InBand. This parameter returns NaN if AcpOffsetChannelMode is set to Symetric.**Return type:** Double

:FETch:BT:RESults<i>:ACP:MARGin:UPPer<i>**Availability:** Query Only**Default:** NaN**Description:** Contains the array of the margin from the limit specified by the mask with Exception for upper offset channel. This value is expressed in dB. Margin is defined as the difference between the offset absolute power and mask with exception. This parameter is valid only if AcpOffsetChannelMode is set to InBand. This parameter returns NaN if AcpOffsetChannelMode is set to Symetric.**Return type:** Double

:FETch:BT:RESults<i>:ACP:OFFSet:LOWer:POWer:ABSolute<i>**Availability:** Query Only**Default:** NaN**Description:** Contains the array of absolute power measured in the lower offset channel. This value is expressed in dBm.**Return type:** Double

:FETch:BT:RESults<i>:ACP:OFFSet:LOWer:POWer:RELative<i>**Availability:** Query Only**Default:** NaN**Description:** Contains the array of relative power in the lower offset channel measured with respect to the reference channel power. This value is expressed in dB.**Return type:** Double

:FETch:BT:RESults<i>:ACP:OFFSet:UPPer:POWer:ABSolute<i>**Availability:** Query Only**Default:** NaN**Description:** Contains the array of absolute power measured in the upper offset channel. This value is expressed in dBm.**Return type:** Double

:FETch:BT:RESults<i>:ACP:OFFSet:UPPer:POWer:RELative<i>**Availability:** Query Only**Default:** NaN**Description:** Contains array of the relative power in the upper offset channel measured with respect to the reference channel power. This value is expressed in dB.**Return type:** Double

:FETch:BT:RESults<i>:ACP:REFerence:CHANnel:POWer**Availability:** Query Only**Default:** NaN**Description:** Contains the measured power of the reference channel. This value is expressed in dBm.**Return type:** Double

:FETch:BT:RESults<i>:FRANge**Availability:** Query Only**Default:** N/A**Description:** Results of BT frequency range measurement.**Return type:** <LowFrequency_Hz: double>, <HighFrequency_Hz: double>

:FETch:BT:RESults<i>:FRANge:FREQuency:HIGH**Availability:** Query Only**Default:** NaN**Description:** Contains the highest frequency above the center frequency at which the transmit power drops below -30 dBm measured in a 100 kHz bandwidth. This value is expressed in Hz.**Return type:** Double

:FETch:BT:RESults<i>:FRANge:FREQuency:LOW**Availability:** Query Only**Default:** NaN**Description:** Contains the lowest frequency below the center frequency at which the transmit power drops below -30 dBm measured in a 100 kHz bandwidth. This value is expressed in Hz.**Return type:** Double

:FETch:BT:RESults<i>:MODacc**Availability:** Query Only**Default:** N/A**Description:** Results of BT ModAcc measurement.

Return type: <InitialFrequencyErrorMaximum_Hz: double>, <PeakFrequencyDriftMaximum_Hz: double>, <PeakFrequencyDriftRateMaximum_Hz: double>, <NinetyNinePercentDevM_pct: double>, <Df1AverageMaximum_Hz: double>, <Df1AverageMean_Hz: double>, <Df1AverageMinimum_Hz: double>, <Df2AverageMaximum_Hz: double>, <Df2AverageMean_Hz: double>, <Df2AverageMinimum_Hz: double>, <EdrHeaderFrequencyErrorWiMaximum_Hz: double>, <EdrPeakFrequencyErrorWiPlusW0Maximum_Hz: double>, <EdrPeakFrequencyErrorW0Maximum_Hz: double>, <IQOriginOffsetMean_dB: double>, <LEInitialFrequencyError_Hz: double>, <LEInitialFrequencyDriftMaximum_Hz: double>, <LEPeakFrequencyDriftMaximum_Hz: double>, <LEPeakFrequencyDriftRateMaximum_Hz: double>, <LEPeakFrequencyErrorMaximum_Hz: double>, <MinimumDf1MaxMinimum_Hz: double>, <MinimumDf2MaxMinimum_Hz: double>, <PeakDevMMaximum_pct: double>, <PeakDf2MaxMaximum_Hz: double>, <PeakRmsDevMMaximum_pct: double>, <PercentageOfSymbolsAboveDf2MaxThreshold_pct: double>, <PercentageOfSymbolsBelow99PercentDevMLimit_pct: double>, <RmsDevMMean_pct: double>

:FETch:BT:RESults<i>:MODacc:AVG:RMS:MERRor:MEAN**Availability:** Query Only**Default:** NaN

Description: Gets the average of the RMS magnitude error values computed on each 50 us block of EDR portion of the EDR packet.

Return type: Double

:FETch:BT:RESults<i>:MODacc:AVG:RMS:PERRor:MEAN**Availability:** Query Only**Default:** NaN

Description: Return the average of the RMS phase error values computed on each 50 us block of EDR portion of the EDR packet.

Return type: Double

:FETch:BT:RESults<i>:MODacc:BITTrace:DEModulated<i>**Availability:** Query Only**Default:** N/A

Description: Return the peak of the RMS phase error values computed on each 50 us block of EDR portion of the EDR packet.

Return type: SByte

:FETch:BT:RESults<i>:MODacc:DEVM:99PCT**Availability:** Query Only**Default:** NaN

Description: Contains the 99th percentile of the DEVM values computed on symbols of the EDR portion of all measured EDR packets. This value is expressed in percentage.

Return type: Double

:FETch:BT:RESults<i>:MODacc:DEVM:PEAK:MAXimum**Availability:** Query Only**Default:** NaN

Description: Contains the peak of the DEVM values computed on symbols in the EDR portion of the EDR packet. When averaging is enabled, it returns the maximum of the peak symbol DEVM values computed for each averaging count. This value is expressed in percentage.

Return type: Double

:FETch:BT:RESults<i>:MODacc:DEVM:RMS:MEAN**Availability:** Query Only**Default:** NaN

Description: Contains the RMS differential EVM (DEVM) value computed on the EDR portion of the EDR packet. When averaging is enabled, it returns the value corresponding to the absolute mean of the RMS differential EVM (DEVM) values computed for each averaging count. This value is expressed as a percentage.

Return type: Double

:FETch:BT:RESults<i>:MODacc:DEVM:RMS:PEAK:MAXimum**Availability:** Query Only**Default:** NaN

Description: Contains the peak of the RMS DEVM values computed on each 50us block of the EDR portion of the EDR packet. When averaging is enabled, it returns the maximum of the peak RMS DEVM values computed for each averaging count. This value is expressed in percentage.

Return type: Double

:FETch:BT:RESults<i>:MODacc:DF1:AVG:MAX**Availability:** Query Only**Default:** NaN

Description: Contains the df1avg value computed on the signal. This value is expressed in Hz. When averaging is enabled, it returns the maximum of the df1avg results computed for each averaging count.

Return type: Double

:FETch:BT:RESults<i>:MODacc:DF1:AVG:MEAN**Availability:** Query Only**Default:** NaN

Description: Contains the df1avg value computed on the signal. When averaging is enabled, it returns the mean of the df1avg results computed for each averaging count. This value is expressed in Hz.

Return type: Double

:FETch:BT:RESults<i>:MODacc:DF1:AVG:MIN**Availability:** Query Only**Default:** NaN

Description: Contains the df1avg value computed on the signal. This value is expressed in Hz. When averaging is enabled, it returns the minimum of the df1avg results computed for each averaging count.

Return type: Double

:FETch:BT:RESults<i>:MODacc:DF1Max:MINimum**Availability:** Query Only**Default:** NaN

Description: Contains the minimum df1max value computed on the signal. The measurement computes df1max deviation values on a packet and reports the minimum value. When averaging is enabled, it returns the minimum of the Min df1max results computed for each averaging count. This value is expressed in Hz.

Return type: Double

:FETch:BT:RESults<i>:MODacc:DF1Max:PEAK:MAXimum**Availability:** Query Only**Default:** NaN

Description: Contains the peak df1max value computed on the signal. The measurement computes df1max deviation values on a packet and reports the peak value. When averaging is enabled, it returns the maximum of the peak df1max results computed for each averaging count. This value is expressed in Hz.

Return type: Double

:FETch:BT:RESults<i>:MODacc:DF2:AVG:MAX**Availability:** Query Only**Default:** NaN

Description: Contains the df2avg value computed on the signal. This value is expressed in Hz. When averaging is enabled, it returns the maximum of the df2avg results computed for each averaging count.

Return type: Double

:FETch:BT:RESults<i>:MODacc:DF2:AVG:MEAN**Availability:** Query Only**Default:** NaN

Description: Contains the df2avg value computed on the signal. When averaging is enabled, it returns the mean of the df2avg results computed for each averaging count. This value is expressed in Hz.

Return type: Double

:FETch:BT:RESults<i>:MODacc:DF2:AVG:MIN**Availability:** Query Only**Default:** NaN

Description: Contains the df2avg value computed on the signal. When averaging is enabled, it returns the minimum of the df2avg results computed for each averaging count. This value is expressed in Hz.

Return type: Double

:FETch:BT:RESults<i>:MODacc:DF2Max:MINimum**Availability:** Query Only**Default:** NaN

Description: Contains the minimum df2max value computed on the signal. The measurement computes df2max deviation values on a packet and reports the minimum value. When averaging is enabled, it returns the minimum of the Min df2max results computed for each averaging count. This value is expressed in Hz.

Return type: Double

:FETch:BT:RESults<i>:MODacc:DF2Max:PEAK:MAXimum**Availability:** Query Only**Default:** NaN

Description: Contains the peak df2max value computed on the signal. The measurement computes df2max deviation values on a packet and reports the peak value. When averaging is enabled, it returns the maximum of the peak df2max results computed for each averaging count. This value is expressed in Hz.

Return type: Double

:FETch:BT:RESults<i>:MODacc:EDR:HEADer:FERRor:WI:MAXimum**Availability:** Query Only**Default:** NaN

Description: Contains the frequency error value computed on the header of the EDR packet. When averaging is enabled, it returns the value corresponding to the maximum of absolute header frequency error values computed for each averaging count. This value is expressed in Hz.

Return type: Double

:FETch:BT:RESults<i>:MODacc:EDR:PEAK:FERRor:W0:MAXimum**Availability:** Query Only**Default:** NaN

Description: Contains the peak frequency error value computed on the EDR portion of the EDR packet, relative to the header frequency error. When averaging is enabled, it returns the value corresponding to the maximum of absolute peak frequency error values computed for each averaging count. This value is expressed in Hz.

Return type: Double

:FETch:BT:RESults<i>:MODacc:EDR:PEAK:FERRor:WIW0:MAXimum**Availability:** Query Only**Default:** NaN

Description: Contains the peak frequency error value computed on the EDR portion of the EDR packet. When averaging is enabled, it returns the value corresponding to the maximum of absolute peak frequency error values computed for each averaging count. This value is expressed in Hz.

Return type: Double

:FETch:BT:RESults<i>:MODacc:IFError:MAXimum**Availability:** Query Only**Default:** NaN

Description: Contains the initial frequency error value computed on the preamble of the BR packet. When averaging is enabled, value corresponding to the maximum of absolute initial frequency error values computed for each averaging count. This value is expressed in Hz.

Return type: Double

:FETch:BT:RESults<i>:MODacc:IQ:ORIGin:OFFSet:MEAN**Availability:** Query Only**Default:** NaN

Description: Contains the I/Q origin offset estimated over the EDR portion of the EDR packets. This value is expressed in dB. When averaging is enabled, it returns the mean of the I/Q origin offset values computed for each averaging count.

Return type: Double

:FETch:BT:RESults<i>:MODacc:LE:FDRift:PEAK:MAXimum**Availability:** Query Only**Default:** NaN

Description: Contains the peak frequency drift value computed on the LE packet. When averaging is enabled, it returns the value corresponding to the maximum of absolute peak frequency drift values computed for each averaging count. This value is expressed in Hz.

Return type: Double

:FETch:BT:RESults<i>:MODacc:LE:FDRift:RATE:PEAK:MAXimum**Availability:** Query Only**Default:** NaN

Description: Contains the peak frequency drift rate value computed on the LE packet. When averaging is enabled, it returns the value corresponding to the maximum of absolute peak frequency drift rate values computed for each averaging count. This value is expressed in Hz.

Return type: Double

:FETch:BT:RESults<i>:MODacc:LE:FERRor:PEAK:MAXimum**Availability:** Query Only**Default:** NaN

Description: When averaging is enabled, it returns the peak frequency error value computed on the preamble and payload portion of the LE packet. When the DirectionFindingMode is set to AngleOfDepature for LE packets, it returns the peak frequency error value computed on the Constant tone extension field of the LE packet. When averaging is enabled, it returns the value corresponding to the maximum of absolute peak frequency error values computed for each averaging count. This value is expressed in Hz.

Return type: Double

:FETch:BT:RESults<i>:MODacc:LE:IFDRift:MAXimum**Availability:** Query Only**Default:** NaN

Description: Contains the initial frequency drift value computed on the LE packet. When averaging is enabled, it returns the value corresponding to the maximum of absolute initial frequency drift values computed for each averaging count. This value is expressed in Hz.

Return type: Double

:FETch:BT:RESults<i>:MODacc:LE:IFError**Availability:** Query Only**Default:** NaN

Description: Contains the initial frequency error value computed on the LE packet. This value is expressed in Hz.

Return type: Double

:FETch:BT:RESults<i>:MODacc:PEAK:FREQuency:DRIFt:MAXimum**Availability:** Query Only**Default:** NaN

Description: Contains the peak frequency drift value computed on the BR packet. When averaging is enabled, it returns the value corresponding to the maximum of absolute peak frequency drift values computed for each averaging count. This value is expressed in Hz.

Return type: Double

:FETch:BT:RESults<i>:MODacc:PEAK:FREQuency:DRIFt:MINimum**Availability:** Query Only**Default:** NaN

Description: Contains the peak frequency drift rate value computed on the BR packet. When averaging is enabled, it returns the value corresponding to the maximum of absolute peak frequency drift rate values computed for each averaging count. This value is expressed in Hz.

Return type: Double

:FETch:BT:RESults<i>:MODacc:PEAK:RMS:MERRor:MAXimum**Availability:** Query Only**Default:** NaN

Description: Gets the peak of the RMS magnitude error values computed on each 50 us block of EDR portion of the EDR packet.

Return type: Double

:FETch:BT:RESults<i>:MODacc:PEAK:RMS:PERRor:MAXimum**Availability:** Query Only**Default:** NaN

Description: Return the peak of the RMS phase error values computed on each 50 us block of EDR portion of the EDR packet.

Return type: Double

:FETch:BT:RESults<i>:MODacc:SYMBols:PCT:DEVM**Availability:** Query Only**Default:** NaN

Description: Contains the percentage of symbols in the EDR portion of all the measured EDR packets with differential EVM (DEVM) less than or equal to 99% DEVM threshold as defined in section 4.5.11 of the Bluetooth Test Specification v5.1.0.. This value is expressed as a percentage.

Return type: Double

:FETch:BT:RESults<i>:MODacc:SYMBols:PCT:DF2Max**Availability:** Query Only**Default:** NaN

Description: Contains the percentage of symbols with df2max values that are greater than the df2max threshold defined by the standard. When averaging is enabled, it computes this result using the df2max values from all averaging counts. This value is expressed as a percentage.

Return type: Double

:FETch:BT:RESults<i>:MODacc:SYMBolsabovedf1:PERCentage:TREShold:MAXimum**Availability:** Query Only**Default:** NaN

Description: Gets the percentage of symbols with df1max values that are greater than the df1max threshold defined by the standard. This result is valid only for the LE packet with a data rate of 125 Kbps.

Return type: Double

:FETch:BT:RESults<i>:TXP**Availability:** Query Only**Default:** N/A**Description:** Results of BT Txp measurement.**Return type:** <AveragePowerMean_dBm: double>, <AveragePowerMaximum_dBm: double>, <AveragePowerMinimum_dBm: double>, <PeakPowerMaximum_dBm: double>, <PeakToPeakAvgPowerRatioMaximum_dB: double>, <EdrGfskAveragePowerMean_dBm: double>, <EdrDpskAveragePowerMean_dBm: double>, <EdrDpskGfskAveragePowerRatioMean_dB: double>

:FETch:BT:RESults<i>:TXP:EDR:DPSK:POWer:AVERage:MEAN**Availability:** Query Only**Default:** NaN**Description:** Contains the average power of the DPSK portion of the EDR packet. When averaging is enabled, it returns the mean of the DPSK average power results computed for each averaging count. This value is expressed in dBm.**Return type:** Double

:FETch:BT:RESults<i>:TXP:EDR:GSFK:POWer:AVERage:MEAN**Availability:** Query Only**Default:** NaN**Description:** Contains the average power of the GFSK portion of the EDR packet. When averaging is enabled, it returns the mean of the GFSK average power results computed for each averaging count. This value is expressed in dBm.**Return type:** Double

:FETch:BT:RESults<i>:TXP:EDR:RATio:AVERage:MEAN**Availability:** Query Only**Default:** NaN**Description:** Contains the ratio of the average power of the DPSK portion to the average power of the GFSK portion of the EDR packet. When averaging is enabled, it returns the mean of the DPSK GFSK average power ratio results computed for each averaging count. This value is expressed in dB.**Return type:** Double

:FETch:BT:RESults<i>:TXP:PAPR:MAXimum**Availability:** Query Only**Default:** NaN**Description:** Contains the peak to average power ratio computed over the measurement interval. When the DirectionFindingMode is set to AngleOfDepature for LE packets, it will exclude guard period and all the switching slots for the peak to average power ratio computation. When averaging is enabled, it returns the maximum of the peak to average power ratio results computed for each averaging count. This value is expressed in dB.**Return type:** Double

:FETch:BT:RESults<i>:TXP:POWer:AVERage:MAXimum**Availability:** Query Only**Default:** NaN

Description: Contains the average power computed over the measurement interval. When the DirectionFindingMode is set to AngleOfDepature for LE packets, it will exclude guard period and all the switching slots for the average power computation. When averaging is enabled, it returns the maximum of the average power results computed for each averaging count. This value is expressed in dBm.

Return type: Double

:FETch:BT:RESults<i>:TXP:POWer:AVERage:MEAN**Availability:** Query Only**Default:** NaN

Description: Contains the average power computed over the measurement interval. When the DirectionFindingMode is set to AngleOfDepature for LE packets, it will exclude guard period and all the switching slots for the average power computation. When averaging is enabled, it returns the mean of the average power results computed for each averaging count. This value is expressed in dBm.

Return type: Double

:FETch:BT:RESults<i>:TXP:POWer:AVERage:MINimum**Availability:** Query Only**Default:** NaN

Description: Contains the average power computed over the measurement interval. When the DirectionFindingMode is set to AngleOfDepature for LE packets, it will exclude guard period and all the switching slots for the average power computation. When averaging is enabled, it returns the minimum of the average power results computed for each averaging count. This value is expressed in dBm.

Return type: Double

:FETch:BT:RESults<i>:TXP:POWer:PEAK:MAXimum**Availability:** Query Only**Default:** NaN

Description: Contains the peak power computed over the measurement interval. When the DirectionFindingMode is set to AngleOfDepature for LE packets, it will exclude guard period and all the switching slots for the peak power computation. When averaging is enabled, it returns the maximum of the peak power results computed for each averaging count. This value is expressed in dBm.

Return type: Double

:TRIGger:BT:DElay <TriggerDelay_sec>**Availability:** Command and Query**Default:** N/A

Description: Specifies the delay (in seconds) between the trigger onset and the start of data acquisition.

Parameters: <TriggerDelay_sec> Double

:TRIGger:BT:EDGE <TriggerEdge>**Availability:** Command and Query**Default:** RISING

Description: Specifies whether to trigger on the rising or falling edge for digital or power triggering.

Parameters: <TriggerEdge> RISING | FALLING

:TRIGger:BT:MQTime <TriggerMinQuietDuration_sec>

Availability: Command and Query **Default:** N/A

Description: Specifies the Minimum Quiet Time between triggers. Negative value (e.g. -1) enables automatic duration.

Parameters: <TriggerMinQuietDuration_sec> Double

:TRIGger:BT:SOURce <TriggerSource>

Availability: Command and Query **Default:** IMMEDIATE

Description: Specifies the trigger source.

Parameters: <TriggerSource> IMM | RF0 | VIDEO | GENERATOR |
INTERNAL | IMMEDIATE

:TRIGger:BT:THReshold <TriggerThreshold>

Availability: Command and Query **Default:** -20

Description: Specifies the trigger threshold to use when power triggering. Absolute level type is in dBm, relative level type (to reference level) is in dB.

Parameters: <TriggerThreshold> Double

:TRIGger:BT:TOUT <TriggerTimeout_sec>

Availability: Command and Query **Default:** 10

Description: Specifies the trigger timeout in seconds.

Parameters: <TriggerTimeout_sec> Double

3. GSM

:CONFigure:GSM:BAND <Band>

Availability: Command and Query **Default:** PGSM

Description: Configures the band of operation.

Parameters: <Band> PGSM | EGSM | RGSM | DCS1800 |
PCS1900 | GSM450 | GSM480 |
GSM850 | GSM750 | TGSM810

:CONFigure:GSM:BURSt:SYNC:TYPe <BurstSynchronizationType>

Availability: Command and Query **Default:** TSP

Description: Configures the burst synchronization type.

Parameters: <BurstSynchronizationType> TSP | AMP | NONE

:CONFigure:GSM:CONFig:CHANge <LimitedConfigChange>

Availability: Command and Query **Default:** Disabled

Description: Sets the set of properties that are considered by RFmx in the locked signal configuration state.

Parameters: <LimitedConfigChange> Disabled | NoChange | Frequency |
ReferenceLevel |
FrequencyAndReferenceLevel |
SelectedPortsFrequencyAndReferenceLevel

:CONFigure:GSM:FREQuency:CENTer <CenterFrequency>

Availability: Command and Query **Default:** 890200000

Description: Configures the center frequency of the RF signal to acquire.

Parameters: <CenterFrequency> Double

:CONFigure:GSM:LINK:DIRection <LinkDirection>

Availability: Command and Query **Default:** Uplink

Description: Sets the source of the signal to be measured.

Parameters: <LinkDirection> Uplink | Downlink | Sidelink

:CONFigure:GSM:MODacc:AVG:COUNt <ModAccAveragingCount>

Availability: Command and Query **Default:** 10

Description: Sets the number of acquisitions used for averaging when ModAcc averaging is enabled.

Parameters: <ModAccAveragingCount> Int32

:CONFigure:GSM:MODacc:AVG:ENABle <ModAccAveragingEnabled>

Availability: Command and Query **Default:** 0

Description: Sets whether to enable averaging for the modulation accuracy (ModAcc) measurement.

Parameters: <ModAccAveragingEnabled> Boolean

**:CONFigure:GSM:MODacc:DCOMpensation:ENABLE
<ModAccDroopCompensationEnabled>**

Availability: Command and Query **Default:** 0

Description: Configures whether to enable droop compensation for the modulation accuracy (ModAcc) measurement.

Parameters: <ModAccDroopCompensationEnabled> Boolean

:CONFigure:GSM:MODacc:ENABLE <ModAccEnabled>

Availability: Command and Query **Default:** 1

Description: Sets whether to enable modulation accuracy (ModAcc) measurements on the acquired signal.

Parameters: <ModAccEnabled> Boolean

:CONFigure:GSM:MODacc:NTHReads <ModAccNumberOfAnalysisThreads>

Availability: Command and Query **Default:** 1

Description: Sets the maximum number of threads used for parallelism for the ModAcc measurement. The number of threads can range from 1 to the number of physical cores. The number of threads you set may not be used in calculations. The actual number of threads used depends on the problem size, system resources, data availability, and other considerations.

Parameters: <ModAccNumberOfAnalysisThreads> Int32

:CONFigure:GSM:ORFS:AVG:COUNT <OrfsAveragingCount>

Availability: Command and Query **Default:** 10

Description: Sets the number of acquisitions used for averaging when Orfs averaging is enabled.

Parameters: <OrfsAveragingCount> Int32

:CONFigure:GSM:ORFS:AVG:ENABLE <OrfsAveragingEnabled>

Availability: Command and Query **Default:** 0

Description: Sets whether to enable averaging for the output radio frequency spectrum (ORFS) measurement.

Parameters: <OrfsAveragingEnabled> Boolean

:CONFigure:GSM:ORFS:AVG:TYPE <OrfsAveragingType>

Availability: Command and Query **Default:** Log

Description: Sets the averaging type for averaging multiple spectrum acquisitions. The averaged spectrum is used for the output radio frequency spectrum (ORFS) measurement.

Parameters: <OrfsAveragingType> Rms | Log | Scalar | Max | Min | Vector

:CONFigure:GSM:ORFS:ENABLE <OrfsEnabled>

Availability: Command and Query **Default:** 1

Description: Sets whether to enable the output radio frequency spectrum (ORFS) measurement.

Parameters: <OrfsEnabled> Boolean

:CONFigure:GSM:ORFS:ESYMBOL:START <OrfsEvaluationSymbolStart>

Availability: Command and Query **Default:** 50

Description: Sets the start position of the burst over which you perform the output radio frequency spectrum (ORFS) measurement. This value is expressed as a percentage.

Parameters: <OrfsEvaluationSymbolStart> Double

:CONFigure:GSM:ORFS:ESYMBOL:STOP <OrfsEvaluationSymbolStop>

Availability: Command and Query **Default:** 90

Description: Sets the stop position of the burst over which you perform the output radio frequency spectrum (ORFS) measurement. This value is expressed as a percentage.

Parameters: <OrfsEvaluationSymbolStop> Double

:CONFigure:GSM:ORFS:ESYMBOL:TSC:INCLUDE <OrfsEvaluationSymbolIncludeTsc>

Availability: Command and Query **Default:** 0

Description: Sets whether to include the training sequence code (TSC) portion of the burst in the output radio frequency spectrum (ORFS) measurement.

Parameters: <OrfsEvaluationSymbolIncludeTsc> Boolean

:CONFigure:GSM:ORFS:EVALUATION:SYMBOLS:SCOPE <OrfsEvaluationSymbolsScope>

Availability: Command and Query **Default:** Offset

Description: -

Parameters: <OrfsEvaluationSymbolsScope> Offset | OffsetAndCarrier

:CONFigure:GSM:ORFS:MODULATION:CARRIER:RBW <OrfsModulationCarrierRbw>

Availability: Command and Query **Default:** 300000

Description: -

Parameters: <OrfsModulationCarrierRbw> Double

:CONFigure:GSM:ORFS:NCOMP:ENABLE <OrfsNoiseCompensationEnabled>

Availability: Command and Query **Default:** 0

Description: Configures whether to enable compensation of the channel powers for the inherent noise floor of the signal analyzer. supportedDevices: NI 5663/5665, NI 5668R

Parameters: <OrfsNoiseCompensationEnabled> Boolean

:CONFigure:GSM:ORFS:NTHREADS <OrfsNumberOfAnalysisThreads>

Availability: Command and Query **Default:** 1

Description: Sets the maximum number of threads used for parallelism for the output radio frequency spectrum (ORFS) measurement. The number of threads can range from 1 to the number of physical cores. The number of threads you set may not be used in calculations. The actual number of threads used depends on the problem size, system resources, data availability, and other considerations.

Parameters: <OrfsNumberOfAnalysisThreads> Int32

:CONFigure:GSM:ORFS:OFFSet:FREQuency:MODE <OrfsOffsetFrequencyMode>

Availability: Command and Query **Default:** STANDARD

Description: Configures the list of frequency offsets for which you can perform the output radio frequency spectrum (ORFS) measurements.

Parameters: <OrfsOffsetFrequencyMode> STANDARD | SHORT | CUSTOM

:CONFigure:GSM:ORFS:SWITChing:CARRier:RBW <OrfsSwitchingCarrierRbw>

Availability: Command and Query **Default:** 300000

Description: -

Parameters: <OrfsSwitchingCarrierRbw> Double

:CONFigure:GSM:ORFS:TYPE <OrfsMeasurementType>

Availability: Command and Query **Default:** BOTH

Description: Configures the type of spectral distortion to be measured.

Parameters: <OrfsMeasurementType> BOTH | MODULATION | SWITCHING

:CONFigure:GSM:ORFS<i>:OFFSet:FREQuency <OffsetFrequency_Hz>

Availability: Command and Query **Default:** 100000

Description: Sets the value of positive frequency offset for which to measure the spectrum due to modulation measurement. This value is expressed in Hz.

Parameters: <OffsetFrequency_Hz> Single

:CONFigure:GSM:ORFS<i>:OFFSet:NAME <OffsetName>

Availability: Command and Query **Default:** offset0

Description: Name of the offset.

Parameters: <OffsetName> String

:CONFigure:GSM:POWER:MAX <ReferenceLevel_dBm>

Availability: Command and Query **Default:** -20

Description: Sets the reference level that represents the maximum expected power of the RF input signal. This value is expressed in dBm for RF devices and Vpk-pk for baseband devices.

Parameters: <ReferenceLevel_dBm> Double

:CONFigure:GSM:PVT:AVG:COUNT <PvtAveragingCount>

Availability: Command and Query **Default:** 10

Description: Sets the number of acquisitions used for averaging when Pvt averaging is enabled.

Parameters: <PvtAveragingCount> Int32

:CONFigure:GSM:PVT:AVG:ENABLE <PvtAveragingEnabled>

Availability: Command and Query **Default:** 0

Description: Sets whether to enable averaging for the power versus time (PVT) measurement.

Parameters: <PvtAveragingEnabled> Boolean

:CONFigure:GSM:PVT:AVG:TYPE <PvtAveragingType>

Availability: Command and Query **Default:** Rms

Description: Sets the averaging type for multiple acquisitions.

Parameters: <PvtAveragingType> Rms | Log | Scalar | Max | Min | Vector

:CONFigure:GSM:PVT:ENABLE <PvtEnabled>

Availability: Command and Query **Default:** 1

Description: Sets whether to enable the power versus time (PVT) measurement.

Parameters: <PvtEnabled> Boolean

:CONFigure:GSM:PVT:NTHReads <PvtNumberOfAnalysisThreads>

Availability: Command and Query **Default:** 0

Description: Sets the number of acquisitions used for averaging when averaging is enabled.

Parameters: <PvtNumberOfAnalysisThreads> Int32

:CONFigure:GSM:REference:AUTO:INITial <AutoLevelInitialReferenceLevel>

Availability: Command and Query **Default:** 0

Description: Sets the initial reference level the function uses to estimate the peak power of the input signal. This value is expressed in dBm.

Parameters: <AutoLevelInitialReferenceLevel> Double

:CONFigure:GSM:SIGNAL:STRUCTure <SignalStructure>

Availability: Command and Query **Default:** Bursted

Description: Sets whether the signal is bursted or continuous. For bursted signal and continuous signals, set the TriggerType to IQPowerEdge and None, respectively.

Parameters: <SignalStructure> Bursted | Continuous

:CONFigure:GSM:SLOT<i>:BURSt <BurstType>

Availability: Command and Query **Default:** NB

Description: Sets the burst type.

Parameters: <BurstType> NB | HB | AB

:CONFigure:GSM:SLOT<i>:HBFilter:WIDTh <HBFilterWidth>

Availability: Command and Query **Default:** Narrow

Description: Sets the filter width when user sets the BurstType to HB.

Parameters: <HBFilterWidth> Narrow | Wide

:CONFigure:GSM:SLOT<i>:MODulation:TYPE <ModulationType>

Availability: Command and Query **Default:** GMSK

Description: Sets the modulation scheme used for the signal.

Parameters: <ModulationType> GMSK | PSK8 | QPSK | Q16 | Q32

:CONFigure:GSM:SLOT<i>:NAME <SlotName>

Availability: Command and Query **Default:** slot0

Description: Name of the slot.

Parameters: <SlotName> String

:CONFigure:GSM:SLOT<i>:PCL <PowerControlLevel>

Availability: Command and Query **Default:** 0

Description: Sets the power control level corresponding to the transmitted power, as defined in section 4.1 of the 3GPP TS 45.005 v8.0.0 specifications.

Parameters: <PowerControlLevel> Int32

:CONFigure:GSM:SLOT<i>:TIMing:ADVance <TimingAdvance>

Availability: Command and Query **Default:** 0

Description: Specifies the timing advance value as specified in the 3GPP TS 45.010 specification for GSM access burst.

Parameters: <TimingAdvance> Int32

:CONFigure:GSM:SLOT<i>:TSC <Tsc>

Availability: Command and Query **Default:** TSC0

Description: Configures the training sequence code (TSC) in the burst.

Parameters: <Tsc> AUTO | TSC0 | TSC1 | TSC2 | TSC3 |
TSC4 | TSC5 | TSC6 | TSC7

:CONFigure:GSM:TRACe:ENABle <TraceEnable>

Availability: Command and Query **Default:** 0

Description: Sets whether to enable the traces to be stored and retrieved for all measurements.

Parameters: <TraceEnable> Boolean

:CONFigure:GSM:TSC:DETection:AUTO:ENABle <AutoTscDetectionEnabled>

Availability: Command and Query **Default:** 1

Description: Configures whether to auto detect the training sequence code (TSC).

Parameters: <AutoTscDetectionEnabled> Boolean

:FETch:GSM:RESults<i>

Availability: Query Only **Default:** N/A

Description: Returns the results of the measurement on resultSpace = i.

Return type: <ModAcc>, <Pvt>, <Orfs>

:FETch:GSM:RESults<i>:MODacc**Availability:** Query Only**Default:** N/A**Description:** Gsm Mod Acc measurement results.**Return type:** <PercentileEVM95th_pct: double>, <MaximumPeakEVM_pct: double>, <MeanRmsEVM_pct: double>, <MaxRmsEVM_pct: double>, <MeanPeakEVM_pct: double>, <MeanFrequencyError_Hz: double>, <MaxFrequencyError_Hz: double>, <PeakEVMSymbol: double>, <MeanMagnitudeError_pct: double>, <MaxMagnitudeError_pct: double>, <MeanPhaseError_deg: double>, <MaxPhaseError_deg: double>, <MeanAmpDroop_dBperSym: double>, <MaxAmpDroop_dBperSym: double>, <PferMeanFrequencyError_Hz: double>, <PferMaxFrequencyError_Hz: double>, <PferMaxPeakPhaseError_deg: double>, <PferMeanPeakPhaseError_deg: double>, <PferMeanRMSPhaseError_deg: double>, <PferMaxRMSPhaseError_deg: double>, <PferPeakSymbol: double>, <MaxIQGainImbalance_dB: double>, <MaxIQGainImbalance_dB: double>, <MaxIQOriginOffset_dB: double>, <MeanIQGainImbalance_dB: double>, <MeanIQOriginOffset_dB: double>, <AUTO | TSC0 | TSC1 | TSC2 | TSC3 | TSC4 | TSC5 | TSC6 | TSC7>

:FETch:GSM:RESults<i>:MODacc:ADRoop:MAXimum**Availability:** Query Only**Default:** NaN**Description:** Contains the maximum of amplitude droop values measured over all acquisition time slots. This value is expressed in dB/symbol.**Return type:** Double

:FETch:GSM:RESults<i>:MODacc:ADRoop:MEAN**Availability:** Query Only**Default:** NaN**Description:** Contains the mean of amplitude droop values measured over all acquisition time slots. This value is expressed in dB/symbol.**Return type:** Double

:FETch:GSM:RESults<i>:MODacc:EVM:95PCT**Availability:** Query Only**Default:** NaN**Description:** Contains the EVM value, at which no more than 5 percent of the symbols have an EVM exceeding this value. This value is expressed as a percentage.**Return type:** Double

:FETch:GSM:RESults<i>:MODacc:EVM:PEAK:MAXimum**Availability:** Query Only**Default:** NaN**Description:** Contains the maximum of peak EVM values measured over all acquisition time slots. This value is expressed as a percentage.**Return type:** Double

:FETch:GSM:RESults<i>:MODacc:EVM:PEAK:MEAN**Availability:** Query Only**Default:** NaN**Description:** Contains the mean of peak EVM values measured over all acquisition time slots. This value is expressed as a percentage.**Return type:** Double

:FETch:GSM:RESults<i>:MODacc:EVM:PEAK:SYMBol**Availability:** Query Only**Default:** 0

Description: Contains the symbol number in the burst measurement interval corresponding to the EVM value returned by the maximumPeakEVM parameter.

Return type: Int32

:FETch:GSM:RESults<i>:MODacc:EVM:RMS:MAXimum**Availability:** Query Only**Default:** NaN

Description: Contains the maximum of RMS EVM values measured over all acquisition time slots. This value is expressed as a percentage.

Return type: Double

:FETch:GSM:RESults<i>:MODacc:EVM:RMS:MEAN**Availability:** Query Only**Default:** NaN

Description: Contains the mean of RMS EVM values measured over all acquisition time slots. This value is expressed as a percentage.

Return type: Double

:FETch:GSM:RESults<i>:MODacc:FERRor:MAXimum**Availability:** Query Only**Default:** NaN

Description: Contains the maximum of the frequency error values measured over all acquisition time slots. This value is expressed in Hz. The method returns this result for EDGE/EGPRS measurements.

Return type: Double

:FETch:GSM:RESults<i>:MODacc:FERRor:MEAN**Availability:** Query Only**Default:** NaN

Description: Contains the mean of frequency error values measured over all acquisition time slots. This value is expressed in Hz.

Return type: Double

:FETch:GSM:RESults<i>:MODacc:IQ:GAIN:IMBalance:MAXimum**Availability:** Query Only**Default:** NaN

Description: Contains the maximum of I/Q gain imbalance values measured over all acquisition time slots. This value is expressed in dB. The presence of quadrature skew in the signal affects the measurement of I/Q gain imbalance.

Return type: Double

:FETch:GSM:RESults<i>:MODacc:IQ:GAIN:IMBalance:MEAN**Availability:** Query Only**Default:** NaN

Description: Contains the mean of I/Q gain imbalance values measured over all acquisition time slots. This value is expressed in dB. The presence of quadrature skew in the signal affects the measurement of I/Q gain imbalance.

Return type: Double

:FETch:GSM:RESults<i>:MODacc:IQ:ORIGin:OFFSet:MAXimum**Availability:** Query Only**Default:** NaN

Description: Contains the maximum of I/Q origin offset values measured over all acquisition time slots. This value is expressed in dB. Presence of I/Q gain imbalance in the signal affects the I/Q origin offset measurement. The measurement returns this result for GSM/EDGE/EGPRS.

Return type: Double

:FETch:GSM:RESults<i>:MODacc:IQ:ORIGin:OFFSet:MEAN**Availability:** Query Only**Default:** NaN

Description: Contains the mean of I/Q origin offset values measured over all acquisition time slots. This value is expressed in dB. Presence of I/Q gain imbalance in the signal affects the I/Q origin offset measurement. The measurement returns this result for GSM/EDGE/EGPRS.

Return type: Double

:FETch:GSM:RESults<i>:MODacc:MERRor:MAXimum**Availability:** Query Only**Default:** NaN

Description: Contains the maximum of magnitude error values measured over all acquisition time slots. This value is expressed as a percentage.

Return type: Double

:FETch:GSM:RESults<i>:MODacc:MERRor:MEAN**Availability:** Query Only**Default:** NaN

Description: Contains the mean of magnitude error values measured over all acquisition time slots. This value is expressed as a percentage.

Return type: Double

:FETch:GSM:RESults<i>:MODacc:PERRor:MAXimum**Availability:** Query Only**Default:** NaN

Description: Contains the maximum of phase error values measured over all acquisition time slots. This value is expressed in degrees.

Return type: Double

:FETch:GSM:RESults<i>:MODacc:PERRor:MEAN**Availability:** Query Only**Default:** NaN

Description: Contains the mean of phase error values measured over all acquisition time slots. This value is expressed in degrees.

Return type: Double

:FETch:GSM:RESults<i>:MODacc:PFER:FERRor:MAXimum**Availability:** Query Only**Default:** NaN

Description: Contains the maximum of the frequency error values measured over all acquisition time slots. This value is expressed in Hz. The method returns this result for GSM ModAcc measurements.

Return type: Double

:FETch:GSM:RESults<i>:MODacc:PFER:FERRor:MEAN**Availability:** Query Only**Default:** NaN

Description: Contains the mean of frequency error values measured over all acquisition time slots. This value is expressed in Hz.

Return type: Double

:FETch:GSM:RESults<i>:MODacc:PFER:PEAK:SYMBOL**Availability:** Query Only**Default:** 0

Description: Contains the symbol number in the useful portion of the burst corresponding to phase error value in the maximumPeakPhaseError parameter.

Return type: Int32

:FETch:GSM:RESults<i>:MODacc:PFER:PERRor:PEAK:MAXimum**Availability:** Query Only**Default:** NaN

Description: Contains the maximum of peak phase error values measured over all acquisition time slots. This value is expressed in degrees.

Return type: Double

:FETch:GSM:RESults<i>:MODacc:PFER:PERRor:PEAK:MEAN**Availability:** Query Only**Default:** NaN

Description: Contains the mean of peak phase error values measured over all acquisition time slots. This value is expressed in degrees.

Return type: Double

:FETch:GSM:RESults<i>:MODacc:PFER:RMS:PERRor:MAXimum**Availability:** Query Only**Default:** NaN

Description: Contains the maximum of RMS phase error values measured over all acquisition time slots. This value is expressed in degrees.

Return type: Double

:FETch:GSM:RESults<i>:MODacc:PFER:RMS:PERRor:MEAN**Availability:** Query Only**Default:** NaN

Description: Contains the mean of RMS phase error values measured over all acquisition time slots. This value is expressed in degrees.

Return type: Double

:FETch:GSM:RESults<i>:MODacc:TSC:DETECTED<i>**Availability:** Query Only**Default:** N/A

Description: Fetches the detected training sequence code (TSC) of the last acquisition for GSM/EDGE/EGPRS

Return type: GsmTrainingSequence

:FETch:GSM:RESults<i>:ORFS**Availability:** Query Only**Default:** N/A

Description: Gsm Orfs measurement results.

Return type: <ModulationCarrierPower_dBm: double>, <SwitchingCarrierPower_dBm: double>, <OrfsModulationReport,...>, <OrfsSwitchingReports,...>

:FETch:GSM:RESults<i>:ORFS:MODulation:CARRier:POWer**Availability:** Query Only**Default:** NaN**Description:** Contains the modulation carrier power. This value is expressed in dBm.**Return type:** Double

:FETch:GSM:RESults<i>:ORFS:MODulation<i>**Availability:** Query Only**Default:** N/A**Description:** Results of the Gsm Orfs modulation.**Return type:** <OffsetFrequency_Hz: double>, <LowerAbsolutePower_dBm: double>, <UpperAbsolutePower_dBm: double>, <LowerRelativePower_dB: double>, <UpperRelativePower_dB: double>

:FETch:GSM:RESults<i>:ORFS:MODulation<i>:FREQuency**Availability:** Query Only**Default:** NaN**Description:** Contains an array of modulation offset frequencies at which the measurement is performed in an ascending order. This value is expressed in Hz. Note that it is only fetched from the instrument when tracing is enabled (TraceEnable = true).**Return type:** Single

:FETch:GSM:RESults<i>:ORFS:MODulation<i>:LOWer:POWer:ABSolute**Availability:** Query Only**Default:** NaN**Description:** Contains an array of absolute powers measured at the negative modulation offset frequencies. This value is expressed in dBm.**Return type:** Double

:FETch:GSM:RESults<i>:ORFS:MODulation<i>:LOWer:POWer:RELative**Availability:** Query Only**Default:** NaN**Description:** Contains an array of relative powers measured at the negative modulation offset frequencies. This value is expressed in dB. The relative powers are measured relative to the integrated modulation power of the carrier.**Return type:** Double

:FETch:GSM:RESults<i>:ORFS:MODulation<i>:UPPer:POWer:ABSolute**Availability:** Query Only**Default:** NaN**Description:** Contains an array of absolute powers measured at the positive modulation offset frequencies. This value is expressed in dBm.**Return type:** Double

:FETch:GSM:RESults<i>:ORFS:MODulation<i>:UPPer:POWer:RELative**Availability:** Query Only**Default:** NaN**Description:** Contains an array of relative powers measured at the positive modulation offset frequencies. This value is expressed in dB. The relative powers are measured relative to the integrated modulation power of the carrier.**Return type:** Double

:FETch:GSM:RESults<i>:ORFS:SWITching:CARRier:POWer**Availability:** Query Only**Default:** NaN**Description:** Contains the switching carrier power. This value is expressed in dBm.**Return type:** Double

:FETch:GSM:RESults<i>:ORFS:SWITching<i>**Availability:** Query Only**Default:** N/A**Description:** Results of Gsm Orfs switching.**Return type:** <OffsetFrequency_Hz: double>, <LowerAbsolutePower_dBm: double>, <UpperAbsolutePower_dBm: double>, <LowerRelativePower_dB: double>, <UpperRelativePower_dB: double>

:FETch:GSM:RESults<i>:ORFS:SWITching<i>:FREQUency**Availability:** Query Only**Default:** NaN**Description:** Contains an array of modulation offset frequencies at which the measurement is performed in an ascending order. This value is expressed in Hz. Note that it is only fetched from the instrument when tracing is enabled (TraceEnable = true).**Return type:** Single

:FETch:GSM:RESults<i>:ORFS:SWITching<i>:LOWer:POWer:ABSolute**Availability:** Query Only**Default:** NaN**Description:** Contains an array of absolute powers measured at the negative modulation offset frequencies. This value is expressed in dBm.**Return type:** Double

:FETch:GSM:RESults<i>:ORFS:SWITching<i>:LOWer:POWer:RELative**Availability:** Query Only**Default:** NaN**Description:** Contains an array of relative powers measured at the negative modulation offset frequencies. This value is expressed in dB. The relative powers are measured relative to the integrated modulation power of the carrier.**Return type:** Double

:FETch:GSM:RESults<i>:ORFS:SWITching<i>:UPPer:POWer:ABSolute**Availability:** Query Only**Default:** NaN**Description:** Contains an array of absolute powers measured at the positive modulation offset frequencies. This value is expressed in dBm.**Return type:** Double

:FETch:GSM:RESults<i>:ORFS:SWITching<i>:UPPer:POWer:RELative**Availability:** Query Only**Default:** NaN**Description:** Contains an array of relative powers measured at the positive modulation offset frequencies. This value is expressed in dB. The relative powers are measured relative to the integrated modulation power of the carrier.**Return type:** Double

:FETch:GSM:RESults<i>:PVT**Availability:** Query Only**Default:** N/A**Description:** Gsm Pvt measurement results.**Return type:** <MeasurementStatus: bool>, <PvtReport,...>

:FETch:GSM:RESults<i>:PVT:MEASurement:STATus**Availability:** Query Only**Default:** N/A**Description:** Defines if the measurement is ongoing or not.**Return type:** Boolean

:FETch:GSM:RESults<i>:PVT:RESults<i>**Availability:** Query Only**Default:** N/A**Description:** List of the Gsm Pvt slot measurement results.**Return type:** <SlotMinimumPower_dBm: double>, <SlotMaximumPower_dBm: double>, <SlotAveragePower_dBm: double>, <SlotBurstWidth_sec: double>, <SlotBurstThreshold_dBm: double>, <SlotMeasurementStatus: bool>

:FETch:GSM:RESults<i>:PVT:RESults<i>:SLOT:BURSt:THReshold**Availability:** Query Only**Default:** N/A**Description:** Contains an array of thresholds that the PVT measurement uses to determine the burst validity. This value is expressed in dBm.**Return type:** Double

:FETch:GSM:RESults<i>:PVT:RESults<i>:SLOT:BURSt:WIDTh**Availability:** Query Only**Default:** N/A**Description:** Contains an array of burst widths for the slots where the -3 dB transition points occur. This value is expressed in seconds.**Return type:** Double

:FETch:GSM:RESults<i>:PVT:RESults<i>:SLOT:MEASurement:STATus**Availability:** Query Only**Default:** N/A**Description:** Indicates an array of PVT measurement statuses for multiple slots.**Return type:** Boolean

:FETch:GSM:RESults<i>:PVT:RESults<i>:SLOT:POWer:AVG**Availability:** Query Only**Default:** N/A**Description:** Contains an array of mean powers of the signal, averaged over corresponding slots of each acquisition. This value is expressed in dBm.**Return type:** Double

:FETch:GSM:RESults<i>:PVT:RESults<i>:SLOT:POWer:MAXimum**Availability:** Query Only**Default:** N/A**Description:** Contains an array of maximum powers of the signal, averaged over corresponding slots of each acquisition. This value is expressed in dBm.**Return type:** Double

:FETch:GSM:RESults<i>:PVT:RESults<i>:SLOT:POWer:MINimum**Availability:** Query Only**Default:** N/A

Description: Contains an array of minimum powers of the signal, averaged over corresponding slots of each acquisition. This value is expressed in dBm.

Return type: Double

:GSM:INITiate <resultSpace>**Availability:** Command Only**Default:** N/A

Description: Initieates Gsm analyzer.

Parameters: <resultSpace> Int32

:GSM:MEASurement:STATe**Availability:** Query Only**Default:** N/A

Description: Returns the current state of the measurement.

Return type: READY | PROCESSING | OFF | PENDING | ACTIVE

:GSM:RESet**Availability:** Command Only**Default:** N/A

Description: Resets Gsm anaylzer.

:TRIGger:GSM:DELaY <TriggerDelay_sec>**Availability:** Command and Query**Default:** N/A

Description: Specifies the delay (in seconds) between the trigger onset and the start of data acquisition.

Parameters: <TriggerDelay_sec> Double

:TRIGger:GSM:EDGE <TriggerEdge>**Availability:** Command and Query**Default:** RISING

Description: Specifies whether to trigger on the rising or falling edge for digital or power triggering.

Parameters: <TriggerEdge> RISING | FALLING

:TRIGger:GSM:MQTime <TriggerMinQuietDuration_sec>**Availability:** Command and Query**Default:** N/A

Description: Specifies the Minimum Quiet Time between triggers. Negative value (e.g. -1) enables automatic duration.

Parameters: <TriggerMinQuietDuration_sec> Double

:TRIGger:GSM:SOURce <TriggerSource>**Availability:** Command and Query**Default:** IMMEDIATE

Description: Specifies the trigger source.

Parameters: <TriggerSource> IMM | RF0 | VIDEO | GENERATOR | INTERNAL | IMMEDIATE

:TRIGger:GSM:THReshold <TriggerThreshold>**Availability:** Command and Query**Default:** -20**Description:** Specifies the trigger threshold to use when power triggering. Absolute level type is in dBm, relative level type (to reference level) is in dB.**Parameters:** <TriggerThreshold> Double

:TRIGger:GSM:TOUT <TriggerTimeout_sec>**Availability:** Command and Query**Default:** 10**Description:** Specifies the trigger timeout in seconds.**Parameters:** <TriggerTimeout_sec> Double

4. LTE

:CONFigure:LTE:AANTenna <TransmitAntennaToAnalyze>

Availability: Command and Query **Default:** 0

Description: Sets the physical antenna connected to the analyzer.

Parameters: <TransmitAntennaToAnalyze> Int32

:CONFigure:LTE:ACP:ACP:IF:OPower:FAR <AcpFarIfOutputPowerOffset_dB>

:CONFigure:LTE:ACP:ACP:IF:OPower:FAR:OFFSet <AcpFarIfOutputPowerOffset_dB>

Availability: Command and Query **Default:** 0

Description: Sets the offset that is needed to adjust the IF output power levels for the offset channels that are far from the carrier channel to improve the dynamic range. This value is expressed in dB. This method is applicable only when user sets the AcpIfOutputPowerOffsetAuto to False and AcpMeasurementMode to DynamicRange.

Parameters: <AcpFarIfOutputPowerOffset_dB> Double

:CONFigure:LTE:ACP:ACType <AcpAmplitudeCorrectionType>

Availability: Command and Query **Default:** RFCenterFreq

Description: Sets whether the amplitude of the frequency bins, used in measurements, is corrected for external attenuation at the RF center frequency, or at the individual frequency bins. Use the RFmxInstr_CfgExternalAttenuationTable function to configure the external attenuation table.

Parameters: <AcpAmplitudeCorrectionType> RFCenterFreq | SpectrumFrequencyBin

:CONFigure:LTE:ACP:AVG:COUNT <AcpAveragingCount>

Availability: Command and Query **Default:** 10

Description: Sets the number of acquisitions used for averaging when Acp averaging is enabled.

Parameters: <AcpAveragingCount> Int32

:CONFigure:LTE:ACP:AVG:ENABLE <AcpAveragingEnable>

Availability: Command and Query **Default:** 0

Description: Sets whether to enable averaging for the ACP measurement.

Parameters: <AcpAveragingEnable> Boolean

:CONFigure:LTE:ACP:AVG:TYPE <AcpAveragingType>

Availability: Command and Query **Default:** Rms

Description: Sets the averaging type for averaging multiple spectrum acquisitions. The averaged spectrum is used for ACP measurement.

Parameters: <AcpAveragingType> Rms | Log | Scalar | Max | Min | Vector

:CONFigure:LTE:ACP:ENABLE <AcpEnable>

Availability: Command and Query **Default:** 1

Description: Sets whether to enable the ACP measurement.

Parameters: <AcpEnable> Boolean

:CONFigure:LTE:ACP:IF:OPower:FAR:AUTO <AcplfOutputPowerOffsetAuto>

Availability: Command and Query **Default:** 1

Description: Sets whether the measurement computes an appropriate IF output power level offset for the offset channels to improve the dynamic range of the ACP measurement. This method is applicable only when user sets the AcpMeasurementMode to DynamicRange.

Parameters: <AcplfOutputPowerOffsetAuto> Boolean

:CONFigure:LTE:ACP:IF:OPower:NEAR <AcpNearlfOutputPowerOffset_dB>**:CONFigure:LTE:ACP:IF:OPower:NEAR:OFFSet <AcpNearlfOutputPowerOffset_dB>**

Availability: Command and Query **Default:** 0

Description: Sets the offset that is needed to adjust the IF output power levels for the offset channels that are near the carrier channel to improve the dynamic range. This value is expressed in dB. This method is applicable only when user sets the AcplfOutputPowerOffsetAuto to False and AcpMeasurementMode to DynamicRange.

Parameters: <AcpNearlfOutputPowerOffset_dB> Double

:CONFigure:LTE:ACP:MEASurement:METHod <AcpMeasurementMethod>

Availability: Command and Query **Default:** NORM

Description: Sets the method for performing the ACP measurement.

Parameters: <AcpMeasurementMethod> NORM | DYNrange | SEQFFT

:CONFigure:LTE:ACP:MEASurement:MODE <AcpMeasurementMode>

Availability: Command and Query **Default:** Measure

Description: Defines if measurement calibrates the noise floor of analyzer or performs the ACP measurement. Refer to the measurement guidelines section in the Noise Compensation Algorithm topic for more information.

Parameters: <AcpMeasurementMode> CalibrateNoiseFloor | Measure

:CONFigure:LTE:ACP:NComp:ENABLE <AcpNoiseCompensationEnable>

Availability: Command and Query **Default:** 0

Description: Sets whether to enable compensation of the channel powers for the inherent noise floor of the signal analyzer.

Parameters: <AcpNoiseCompensationEnable> Boolean

:CONFigure:LTE:ACP:NOFFsets:ENABLE <AcpEnableConfigurableNumberOfOffsets>

Availability: Command and Query **Default:** 1

Description: Sets whether the number of offsets is computed by measurement or configured by you.

Parameters: <AcpEnableConfigurableNumberOfOffsets> Boolean

:CONFigure:LTE:ACP:NOFFsets:EUTRa <AcpNumberOfEutraOffsets>

Availability: Command and Query **Default:** 1

Description: Sets the number of evolved universal terrestrial radio access (E-UTRA) adjacent channel offsets to be configured at offset positions, when user sets the ACP Configurable Number of Offset Enabled method to True.

Parameters: <AcpNumberOfEutraOffsets> Int32

:CONFigure:LTE:ACP:NOFFsets:GSM <AcpNumberOfGsmOffsets>

Availability: Command and Query **Default:** 0

Description: Sets the number of GSM adjacent channel offsets to be configured when the channel bandwidth is 200 kHz (NB-IOT), when user sets the ACP Configurable Number of Offset Enabled method to True.

Parameters: <AcpNumberOfGsmOffsets> Int32

:CONFigure:LTE:ACP:NOFFsets:UTRa <AcpNumberOfUtraOffsets>

Availability: Command and Query **Default:** 2

Description: Sets the number of universal terrestrial radio access (UTRA) adjacent channel offsets to be configured at offset positions, when user sets the ACP Configurable Number of Offset Enabled method to True.

Parameters: <AcpNumberOfUtraOffsets> Int32

:CONFigure:LTE:ACP:NTHReads <AcpNumberOfAnalysisThreads>

Availability: Command and Query **Default:** 1

Description: Sets the maximum number of threads used for parallelism for the ACP measurement. The number of threads can range from 1 to the number of physical cores. The number of threads you set may not be used in calculations. The actual number of threads used depends on the problem size, system resources, data availability, and other considerations.

Parameters: <AcpNumberOfAnalysisThreads> Int32

:CONFigure:LTE:ACP:OFFSet:EUTRa:DEFinition <AcpEutraOffsetDefinition>

Availability: Command and Query **Default:** AUTO

Description: Sets the evolved universal terrestrial radio access (E-UTRA) offset channel definition.

Parameters: <AcpEutraOffsetDefinition> AUTO | CLOSEST | COMPOSITE

:CONFigure:LTE:ACP:POWER:UNITs <AcpPowerUnits>

Availability: Command and Query **Default:** dBm

Description: Units for the absolute power.

Parameters: <AcpPowerUnits> dBm | dBmByHz

:CONFigure:LTE:ACP:RBW:BW <AcpRbwBandwidth_Hz>

Availability: Command and Query **Default:** 3720

Description: Sets the bandwidth of the RBW filter, used to sweep the acquired signal, when user sets the AcpRbwAutoBandwidth to False. This value is expressed in Hz.

Parameters: <AcpRbwBandwidth_Hz> Double

:CONFigure:LTE:ACP:RBW:BWAUTO <AcpRbwAutoBandwidth>

Availability: Command and Query **Default:** 1

Description: Sets whether the measurement computes the RBW.

Parameters: <AcpRbwAutoBandwidth> Boolean

:CONFigure:LTE:ACP:RBW:FILTER <AcpRwbFilterType>

Availability: Command and Query **Default:** FFT

Description: Sets the shape of the RBW filter.

Parameters: <AcpRwbFilterType> FFT | GAUSSIAN | FLAT | ST4 | ST5

:CONFigure:LTE:ACP:SFFT:SIZE <AcpSequentialFftSize>

Availability: Command and Query **Default:** 16

Description: Sets the FFT size, when user sets the AcpMeasurementMode to SequentialFft.

Parameters: <AcpSequentialFftSize> Int32

:CONFigure:LTE:ACP:SWEep:AUTO <AcpSweepTimeAuto>

Availability: Command and Query **Default:** 1

Description: Sets whether the measurement computes the sweep time.

Parameters: <AcpSweepTimeAuto> Boolean

:CONFigure:LTE:ACP:SWEep:INTERval <AcpSweepTimeInterval_s>

Availability: Command and Query **Default:** 0.001

Description: Sets the sweep time when user sets the AcpSweepTimeAuto to False. This value is expressed in seconds.

Parameters: <AcpSweepTimeInterval_s> Double

:CONFigure:LTE:ACP:TRACe:ENABLE <AcpAllTracesEnable>

Availability: Command and Query **Default:** 0

Description: Sets whether to enable the traces to be stored and retrieved after performing the ACP measurement.

Parameters: <AcpAllTracesEnable> Boolean

:CONFigure:LTE:CHP:ACType <ChpAmplitudeCorrectionType>

Availability: Command and Query **Default:** RFCenterFreq

Description: Sets whether the amplitude of the frequency bins, used in measurements, is corrected for external attenuation at the RF center frequency, or at the individual frequency bins. Use the RFmxInstr_CfgExternalAttenuationTable function to configure the external attenuation table.

Parameters: <ChpAmplitudeCorrectionType> RFCenterFreq | SpectrumFrequencyBin

:CONFigure:LTE:CHP:AVG:COUNT <ChpAveragingCount>

Availability: Command and Query **Default:** 10

Description: Sets the number of acquisitions used for averaging when Chp averaging is enabled.

Parameters: <ChpAveragingCount> Int32

:CONFigure:LTE:CHP:AVG:ENABLE <ChpAveragingEnable>

Availability: Command and Query **Default:** 0

Description: Sets whether to enable averaging for the CHP measurement.

Parameters: <ChpAveragingEnable> Boolean

:CONFigure:LTE:CHP:AVG:TYPE <ChpAveragingType>

Availability: Command and Query **Default:** Rms

Description: Sets the averaging type for averaging multiple spectrum acquisitions. The averaged spectrum is used for CHP measurement.

Parameters: <ChpAveragingType> Rms | Log | Scalar | Max | Min | Vector

:CONFigure:LTE:CHP:ENABLE <ChpEnable>

Availability: Command and Query **Default:** 1

Description: Sets whether to enable the channel power measurement.

Parameters: <ChpEnable> Boolean

:CONFigure:LTE:CHP:INTEgration:BWType <ChpIntegrationBandwidthType>

Availability: Command and Query **Default:** SignalBW

Description: Sets the integration bandwidth (IBW) type used to measure the power of the acquired signal. Integration bandwidth is the frequency interval over which the power in each frequency bin is added to measure the total power in that interval.

Parameters: <ChpIntegrationBandwidthType> SignalBW | ChannelBW

:CONFigure:LTE:CHP:MEASurement:MODE <ChpMeasurementMode>

Availability: Command and Query **Default:** Measure

Description: Defines if measurement calibrates the noise floor of analyzer or performs the CHP measurement. Refer to the measurement guidelines section in the Noise Compensation Algorithm topic for more information.

Parameters: <ChpMeasurementMode> CalibrateNoiseFloor | Measure

:CONFigure:LTE:CHP:NTHReads <ChpNumberOfAnalysisThreads>

Availability: Command and Query **Default:** 1

Description: Sets the maximum number of threads used for parallelism for the CHP measurement. The number of threads can range from 1 to the number of physical cores. The number of threads you set may not be used in calculations. The actual number of threads used depends on the problem size, system resources, data availability, and other considerations.

Parameters: <ChpNumberOfAnalysisThreads> Int32

:CONFigure:LTE:CHP:RBW:BWAUTO <ChpRbwAutoBandwidth>

Availability: Command and Query **Default:** 1

Description: Sets whether the CHP measurement computes the RBW.

Parameters: <ChpRbwAutoBandwidth> Boolean

:CONFigure:LTE:CHP:RBW:BWIDth <ChpRbwBandwidth_Hz>

Availability: Command and Query **Default:** 3720

Description: Sets the bandwidth of the RBW filter, used to sweep the acquired signal, when user sets the ObwRbwAutoBandwidth to False. This value is expressed in Hz.

Parameters: <ChpRbwBandwidth_Hz> Double

:CONFigure:LTE:CHP:RBW:FILTer <ChpRwbFilterType>

Availability: Command and Query **Default:** FFT

Description: Sets the shape of the digital RBW filter.

Parameters: <ChpRwbFilterType> FFT | GAUSSIAN | FLAT | ST4 | ST5

:CONFigure:LTE:CHP:SWEep:AUTO <ChpSweepTimeAuto>

Availability: Command and Query **Default:** 1

Description: Sets whether the measurement computes the sweep time.

Parameters: <ChpSweepTimeAuto> Boolean

:CONFigure:LTE:CHP:SWEep:INTerval <ChpSweepTimeInterval_s>

Availability: Command and Query **Default:** 0.001

Description: Sets the sweep time when user sets the ChpSweepTimeAuto to False. This value is expressed in seconds.

Parameters: <ChpSweepTimeInterval_s> Double

:CONFigure:LTE:CHP:TRACe:ENABle <ChpAllTracesEnable>

Availability: Command and Query **Default:** 0

Description: Sets whether to enable the traces to be stored and retrieved after performing the CHP measurement.

Parameters: <ChpAllTracesEnable> Boolean

:CONFigure:LTE:CP <CyclicPrefix>

Availability: Command and Query **Default:** Normal

Description: Sets the cyclic prefix (CP) duration and the number of symbols in a slot for the signal being measured.

Parameters: <CyclicPrefix> Normal | Extended

:CONFigure:LTE:CSRatio <LteCellSpecificRatio>

Availability: Command and Query **Default:** PB0

Description: Sets the ratio Rhob/Rhoa for the cell-specific ratio of one, two, or four cell-specific antenna ports as described in Table 5.2-1 in section 5.2 of the 3GPP TS 36.213 specification. This method determines the power of the channel resource element (RE) in the symbols that do not contain the reference symbols.

Parameters: <LteCellSpecificRatio> PB0 | PB1 | PB2 | PB3

:CONFigure:LTE:DUPLIex <DuplexScheme>

Availability: Command and Query **Default:** FDD

Description: Sets the duplexing technique of the signal being measured.

Parameters: <DuplexScheme> FDD | TDD

:CONFigure:LTE:ENB:CATegory <eNodeBCategory>

Availability: Command and Query **Default:** HomeBaseStation

Description: Sets the downlink eNodeB (Base station) category. Refer to the 3GPP 36.141 specification for more details.

Parameters: <eNodeBCategory> WideAreaBaseStationCategoryA |
WideAreaBaseStationCategoryBOption1
|
WideAreaBaseStationCategoryBOption2
| LocalAreaBaseStation |
HomeBaseStation |
MediumRangeBaseStation

:CONFigure:LTE:LINK:DIRection <LinkDirection>

Availability: Command and Query **Default:** Uplink

Description: Sets the link direction of the signal being measured.

Parameters: <LinkDirection> Uplink | Downlink | Sidelink

:CONFigure:LTE:MIDInt:OFFSet <ModIntervalOffset>

Availability: Command and Query **Default:** 0

Description: Sets the measurement offset to skip from the synchronization boundary. The synchronization boundary is specified by the method. This value is expressed in slots.

Parameters: <ModIntervalOffset> Int32

:CONFigure:LTE:MODacc:AVG:COUNt <ModAccAveragingCount>

Availability: Command and Query **Default:** 10

Description: Sets the number of acquisitions used for averaging when ModAcc averaging is enabled.

Parameters: <ModAccAveragingCount> Int32

:CONFigure:LTE:MODacc:AVG:ENABle <ModAccAveragingEnable>

Availability: Command and Query **Default:** 0

Description: Sets whether to enable averaging for the ModAcc measurement.

Parameters: <ModAccAveragingEnable> Boolean

:CONFigure:LTE:MODacc:CCLock:ENABle <ModAccCommonClockSourceEnable>

Availability: Command and Query **Default:** 1

Description: Sets whether the same Reference Clock is used for the local oscillator and the digital-to-analog converter in the transmitter. When the same Reference Clock is used, the carrier frequency offset is proportional to Sample Clock error.

Parameters: <ModAccCommonClockSourceEnable> Boolean

:CONFigure:LTE:MODacc:CEType <ModAccChannelEstimationType>

Availability: Command and Query **Default:** ReferenceAndData

Description: Sets the method used for the channel estimation for the ModAcc measurement.

Parameters: <ModAccChannelEstimationType> Reference | ReferenceAndData

:CONFigure:LTE:MODacc:CONDition <ModAccCondition>

Availability: Command and Query **Default:** Normal

Description: Sets the frequency ranges at which to measure spectral flatness.

Parameters: <ModAccCondition> Normal | Extreme

:CONFigure:LTE:MODacc:ENABLE <ModAccEnable>

Availability: Command and Query **Default:** 1

Description: Sets whether to enable the ModAcc measurement.

Parameters: <ModAccEnable> Boolean

**:CONFigure:LTE:MODacc:EVM:EPERiod:ENABLE
<ModAccEvmExclusionPeriodEnable>**

Availability: Command and Query **Default:** 1

Description: Sets whether to exclude some portion of the slots when calculating the EVM. This method is applicable only when there is a power change at the slot boundary. Refer to section 6.5.2.1A of the 3GPP TS 36.521-1 specification for more information about exclusion.

Parameters: <ModAccEvmExclusionPeriodEnable> Boolean

:CONFigure:LTE:MODacc:EVM:UNIT <ModAccEvmUnit>

Availability: Command and Query **Default:** Percentage

Description: Sets the units of the EVM results.

Parameters: <ModAccEvmUnit> Percentage | dB

:CONFigure:LTE:MODacc:FFT:WINDow <ModAccFftWindowType>**:CONFigure:LTE:MODacc:FFT:WINDow:TYPE <ModAccFftWindowType>**

Availability: Command and Query **Default:** TypeCustom

Description: Sets the FFT window type used for the EVM calculation for the ModAcc measurement.

Parameters: <ModAccFftWindowType> Type3GPP | TypeCustom

:CONFigure:LTE:MODacc:FFT:WINDow:LENGth <ModAccFftWindowLength_pct>

Availability: Command and Query **Default:** -1

Description: Sets the FFT window length (W). This value is expressed as a percentage of the cyclic prefix length. This method is used when user sets the ModAccFftWindowType to Type3GPP, where it is needed to calculate the EVM using two different FFT window positions, Delta_C-W/2, and Delta_C+W/2. Refer to the Annexe E.3.2 of 3GPP 36.521 specification for more information.

Parameters: <ModAccFftWindowLength_pct> Double

:CONFigure:LTE:MODacc:FFT:WINDow:OFFSet <ModAccFftWindowOffset_pct>

Availability: Command and Query **Default:** 50

Description: Sets the position of the FFT window used to calculate the EVM. The offset is expressed as a percentage of the cyclic prefix length. If you set this method to 0, the EVM window starts at the end of cyclic prefix. If you set this method to 100, the EVM window starts at the beginning of cyclic prefix. The default value is 50. Valid values are 0 to 100, inclusive.

Parameters: <ModAccFftWindowOffset_pct> Double

:CONFigure:LTE:MODacc:IBE:MASK:TYPE <ModAcclnBandEmmissionMaskType>

Availability: Command and Query **Default:** Release8_10

Description: Sets the in-band emissions mask type to be used for measuring in-band emission margin (dB) and subblock in-Band emission margin (dB) results.

Parameters: <ModAcclnBandEmmissionMaskType> Release8_10 | Release11Onwards

**:CONFigure:LTE:MODacc:IQ:GAINImbalance:CORRection:ENABLE
<ModAcclQGainImbalanceCorrectionEnabled>**

Availability: Command and Query **Default:** 0

Description: Enable/Disable IQ gain imbalance correction.

Parameters: <ModAcclQGainImbalanceCorrectionEnabled> Boolean

**:CONFigure:LTE:MODacc:IQ:MISMatch:ESTimation:ENABLE
<ModAcclQMismatchEstimationsEnabled>**

Availability: Command and Query **Default:** 0

Description: -

Parameters: <ModAcclQMismatchEstimationsEnabled> Boolean

**:CONFigure:LTE:MODacc:IQ:ORIGin:OFFSet:ESTimation:ENABLE
<ModAcclQOriginOffsetEstimationEnabled>**

Availability: Command and Query **Default:** 0

Description: IQ origin offset estimation is supported only when you set the Link direction property to Uplink or Sidelink.

Parameters: <ModAcclQOriginOffsetEstimationEnabled> Boolean

**:CONFigure:LTE:MODacc:IQ:QERRor:CORRection:ENABLE
<ModAcclQQuadratureErrorCorrectionEnabled>**

Availability: Command and Query **Default:** 0

Description: Enable/Disable IQ quadrature error correction.

Parameters: <ModAcclQQuadratureErrorCorrectionEnabled> Boolean

**:CONFigure:LTE:MODacc:IQ:TIMingskew:CORRection:ENABLE
<ModAcclQTimingSkewCorrectionEnabled>**

Availability: Command and Query **Default:** 0

Description: Enable/Disable IQ timing skew correction.

Parameters: <ModAcclQTimingSkewCorrectionEnabled> Boolean

:CONFigure:LTE:MODacc:MCFILTER:ENABLE <ModAccMulticarrierFilterEnable>

Availability: Command and Query **Default:** 1

Description: Sets whether to use a filter to suppress the interference from out of band emissions into the carriers being measured.

Parameters: <ModAccMulticarrierFilterEnable> Boolean

:CONFigure:LTE:MODacc:MMODE <ModAccMeasMode>

Availability: Command and Query **Default:** Slot

Description: Sets whether the measurement is performed from the frame or the slot boundary.

Parameters: <ModAccMeasMode> Frame | Slot | Arbitrary | Marker | AUTO

:CONFigure:LTE:MODacc:NTHReads <ModAccNumberOfAnalysisThreads>

Availability: Command and Query **Default:** 1

Description: Sets the maximum number of threads used for parallelism for the ModAcc measurement. The number of threads can range from 1 to the number of physical cores. The number of threads you set may not be used in calculations. The actual number of threads used depends on the problem size, system resources, data availability, and other considerations.

Parameters: <ModAccNumberOfAnalysisThreads> Int32

:CONFigure:LTE:MODacc:SINVerted <ModAccSpectrumInverted>

Availability: Command and Query **Default:** 0

Description: Sets whether the spectrum of the measured signal is inverted. The inversion happens when the I and the Q components of the baseband complex signal are swapped.

Parameters: <ModAccSpectrumInverted> Boolean

:CONFigure:LTE:MODacc:SYNC <ModAccSyncMode>

Availability: Command and Query **Default:** Frame

Description: Sets the synchronization mode for the ModAcc measurement.

Parameters: <ModAccSyncMode> Frame | Slot | Arbitrary | Marker

:CONFigure:LTE:MODacc:TRACe:ENABLE <ModAccAllTracesEnable>

Availability: Command and Query **Default:** 0

Description: Sets whether to enable the traces to be stored and retrieved after performing the ModAcc measurement.

Parameters: <ModAccAllTracesEnable> Boolean

:CONFigure:LTE:MODInt:COUNt <ModIntervalCount>

Availability: Command and Query **Default:** 1

Description: Sets the number of slots to be measured. This value is expressed in slots.

Parameters: <ModIntervalCount> Int32

:CONFigure:LTE:NDUT <NumberOfDutAntennas>

Availability: Command and Query **Default:** 1

Description: Sets the number of physical antennas available at the DUT for transmission in a MIMO setup.

Parameters: <NumberOfDutAntennas> Int32

**:CONFigure:LTE:NPUSch:CDETection:AUTO:ENABLE
<AutoNPuschChannelDetectionEnabled>**

Availability: Command and Query **Default:** 1

Description: Configures whether the values of the ToneOffset, Number of Tones and ModulationType for the NPUSCH channel are auto-detected by the measurement or specified by user.

Parameters: <AutoNPuschChannelDetectionEnabled> Boolean

:CONFigure:LTE:OBW:ACType <ObwAmplitudeCorrectionType>

Availability: Command and Query **Default:** RFCenterFreq

Description: Sets whether the amplitude of the frequency bins, used in measurements, is corrected for external attenuation at the RF center frequency, or at the individual frequency bins. Use the RFmxInstr_CfgExternalAttenuationTable function to configure the external attenuation table.

Parameters: <ObwAmplitudeCorrectionType> RFCenterFreq | SpectrumFrequencyBin

:CONFigure:LTE:OBW:AVG:COUNt <ObwAveragingCount>

Availability: Command and Query **Default:** 10

Description: Sets the number of acquisitions used for averaging when Obw averaging is enabled.

Parameters: <ObwAveragingCount> Int32

:CONFigure:LTE:OBW:AVG:ENABLE <ObwAveragingEnable>

Availability: Command and Query **Default:** 0

Description: Sets whether to enable averaging for the OBW measurement.

Parameters: <ObwAveragingEnable> Boolean

:CONFigure:LTE:OBW:AVG:TYPE <ObwAveragingType>

Availability: Command and Query **Default:** Rms

Description: Sets the averaging type for averaging multiple spectrum acquisitions. The averaged spectrum is used for the OBW measurement.

Parameters: <ObwAveragingType> Rms | Log | Scalar | Max | Min | Vector

:CONFigure:LTE:OBW:ENABLE <ObwEnable>

Availability: Command and Query **Default:** 1

Description: Sets whether to enable the OBW measurement.

Parameters: <ObwEnable> Boolean

:CONFigure:LTE:OBW:NTHReads <ObwNumberOfAnalysisThreads>

Availability: Command and Query **Default:** 1

Description: Sets the maximum number of threads used for parallelism for the OBW measurement. The number of threads can range from 1 to the number of physical cores. The number of threads you set may not be used in calculations. The actual number of threads used depends on the problem size, system resources, data availability, and other considerations.

Parameters: <ObwNumberOfAnalysisThreads> Int32

:CONFigure:LTE:OBW:RBW:BW <ObwRbwBandwidth_Hz>

Availability: Command and Query **Default:** 200000

Description: Sets the bandwidth of the RBW filter used to sweep the acquired signal, when user sets the ObwRbwAutoBandwidth to False. This value is expressed in Hz.

Parameters: <ObwRbwBandwidth_Hz> Double

:CONFigure:LTE:OBW:RBW:BWAUTO <ObwRbwAutoBandwidth>

Availability: Command and Query **Default:** 1

Description: Sets whether the measurement computes the RBW.

Parameters: <ObwRbwAutoBandwidth> Boolean

:CONFigure:LTE:OBW:RBW:FILTer <ObwRbwFilterType>

Availability: Command and Query **Default:** GAUSSIAN

Description: Sets the shape of the digital RBW filter.

Parameters: <ObwRbwFilterType> FFT | GAUSSIAN | FLAT | ST4 | ST5

:CONFigure:LTE:OBW:SWEep:AUTO <ObwSweepTimeAuto>

Availability: Command and Query **Default:** 1

Description: Sets whether the measurement computes the sweep time.

Parameters: <ObwSweepTimeAuto> Boolean

:CONFigure:LTE:OBW:SWEep:INTERval <ObwSweepTimeInterval_s>

Availability: Command and Query **Default:** 0.001

Description: Sets the sweep time when user sets the ObwSweepTimeAuto to False. This value is expressed in seconds.

Parameters: <ObwSweepTimeInterval_s> Double

:CONFigure:LTE:OBW:TRACe:ENABle <ObwAllTracesEnable>

Availability: Command and Query **Default:** 0

Description: Sets whether to enable the traces to be stored and retrieved after performing the OBW measurement.

Parameters: <ObwAllTracesEnable> Boolean

:CONFigure:LTE:PVT:AVG:COUNT <PvtAveragingCount>

Availability: Command and Query **Default:** 10

Description: Sets the number of acquisitions used for averaging when Pvt averaging is enabled.

Parameters: <PvtAveragingCount> Int32

:CONFigure:LTE:PVT:AVG:ENABLE <PvtAveragingEnable>

Availability: Command and Query **Default:** 0

Description: Sets whether to enable averaging for the power versus time (PVT) measurement.

Parameters: <PvtAveragingEnable> Boolean

:CONFigure:LTE:PVT:AVG:TYPE <PvtAveragingType>

Availability: Command and Query **Default:** Rms

Description: Sets the averaging type for averaging multiple spectrum acquisitions. The averaged spectrum is used for the power versus time (PVT) measurement.

Parameters: <PvtAveragingType> Rms | Log | Scalar | Max | Min | Vector

:CONFigure:LTE:PVT:ENABLE <PvtEnable>

Availability: Command and Query **Default:** 0

Description: Sets whether to enable the power versus time (PVT) measurement.

Parameters: <PvtEnable> Boolean

:CONFigure:LTE:PVT:METHod <PvtMeasurementMode>

Availability: Command and Query **Default:** NORM

Description: Sets the method for performing the power versus time (PVT) measurement.

Parameters: <PvtMeasurementMode> NORM | DYNrange | SEQFFT

:CONFigure:LTE:PVT:NTHReads <PvtNumberOfAnalysisThreads>

Availability: Command and Query **Default:** 1

Description: Sets the maximum number of threads used for parallelism for the power versus time (PVT) measurement. The number of threads can range from 1 to the number of physical cores. The number of threads you set may not be used in calculations. The actual number of threads used depends on the problem size, system resources, data availability, and other considerations.

Parameters: <PvtNumberOfAnalysisThreads> Int32

:CONFigure:LTE:PVT:POWer:OFF:EXCLusion:AFTer <PvtOffPowerExclusionAfter_s>

Availability: Command and Query **Default:** 0

Description: Sets the time excluded from the Off region after the burst. This value is expressed in seconds.

Parameters: <PvtOffPowerExclusionAfter_s> Double

**:CONFigure:LTE:PVT:POWER:OFF:EXCLusion:BEFore
<PvtOffPowerExclusionBefore_s>****Availability:** Command and Query **Default:** 0**Description:** Sets the time excluded from the Off region before the burst. This value is expressed in seconds.**Parameters:** <PvtOffPowerExclusionBefore_s> Double

:CONFigure:LTE:PVT:TRACe:ENABLe <PvtAllTracesEnable>**Availability:** Command and Query **Default:** 0**Description:** Sets whether to enable the traces to be stored and retrieved after performing the power versus time (PVT) measurement.**Parameters:** <PvtAllTracesEnable> Boolean

:CONFigure:LTE:RB:DETection:AUTO <RBAutoDetection>**Availability:** Command and Query **Default:** 1**Description:** Configures whether the values of the ModulationType, NumberOfResourceBlockClusters, PuschNumberOfResourceBlockClusters, and NumberOfResourceBlocks properties are automatically detected by the measurement or if the user specifies the values of these properties.**Parameters:** <RBAutoDetection> Boolean

:CONFigure:LTE:SCS:Spacing <SubcarrierSpacing>**Availability:** Command and Query **Default:** K15**Description:** Sets the subcarrier bandwidth of an NB-IoT signal. This method specifies the spacing between adjacent subcarriers.**Parameters:** <SubcarrierSpacing> K7 | K15

:CONFigure:LTE:SEM:ACType <SemAmplitudeCorrectionType>**Availability:** Command and Query **Default:** RFCenterFreq**Description:** Sets whether the amplitude of the frequency bins, used in measurements, is corrected for external attenuation at the RF center frequency, or at the individual frequency bins. Use the RFmxInstr_CfgExternalAttenuationTable function to configure the external attenuation table.**Parameters:** <SemAmplitudeCorrectionType> RFCenterFreq | SpectrumFrequencyBin

:CONFigure:LTE:SEM:AVG:COUNT <SemAveragingCount>**Availability:** Command and Query **Default:** 10**Description:** Sets the number of acquisitions used for averaging when Sem averaging is enabled.**Parameters:** <SemAveragingCount> Int32

:CONFigure:LTE:SEM:AVG:ENABLe <SemAveragingEnable>**Availability:** Command and Query **Default:** 0**Description:** Sets whether to enable averaging for the SEM measurement.**Parameters:** <SemAveragingEnable> Boolean

:CONFigure:LTE:SEM:AVG:TYPE <SemAveragingType>

Availability: Command and Query **Default:** Rms

Description: Sets the averaging type for averaging multiple spectrum acquisitions. The averaged spectrum is used for SEM measurement.

Parameters: <SemAveragingType> Rms | Log | Scalar | Max | Min | Vector

:CONFigure:LTE:SEM:DFREquency:MAXimum <SemDeltaFMaximum_Hz>

Availability: Command and Query **Default:** 15000000

Description: Sets the stop frequency for the last offset segment to be used in the measurement. This value is expressed in Hz.

Parameters: <SemDeltaFMaximum_Hz> Double

:CONFigure:LTE:SEM:DLInk:MTYPE <SemDownlinkMaskType>

Availability: Command and Query **Default:** BAND46

Description: Sets the limits to be used in the measurement for downlink. Refer to section 6.6.3 of the 3GPP 36.141 specification for more information about standard-defined mask types.

Parameters: <SemDownlinkMaskType> ENodeBCatBased | BAND46 | CUSTOM

:CONFigure:LTE:SEM:ENABLE <SemEnable>

Availability: Command and Query **Default:** 1

Description: Sets whether to enable the SEM measurement.

Parameters: <SemEnable> Boolean

:CONFigure:LTE:SEM:MTYPE:STD <SemStandardMaskType>

Availability: Command and Query **Default:** General_NS01

Description: Configures standard mask type for Sem measurements. The following mask types are supported: CANS04, General_NS01, NS03_Or_NS11_Or_NS20, NS04, NS06_Or_NS07 and CUSTOM.

Parameters: <SemStandardMaskType> CANS04 | Custom | General_NS01 | NS03_Or_NS11_Or_NS20 | NS04 | NS06_Or_NS07

:CONFigure:LTE:SEM:NOFFset <SemNumberOfOffsets>

Availability: Command and Query **Default:** 4

Description: Sets the number of SEM offset segments.

Parameters: <SemNumberOfOffsets> Int32

:CONFigure:LTE:SEM:NTHReads <SemNumberOfAnalysisThreads>

Availability: Command and Query **Default:** 1

Description: Sets the maximum number of threads used for parallelism for the SEM measurement. The number of threads can range from 1 to the number of physical cores. The number of threads you set may not be used in calculations. The actual number of threads used depends on the problem size, system resources, data availability, and other considerations.

Parameters: <SemNumberOfAnalysisThreads> Int32

:CONFigure:LTE:SEM:OFFSet:BW:INTEgral <SemOffsetBandwidthIntegral>

Availability: Command and Query **Default:** 3

Description: Sets the resolution of a spectrum to compare with the spectral mask limits as an integer multiple of the RBW.

Parameters: <SemOffsetBandwidthIntegral> Int32

:CONFigure:LTE:SEM:OFFSet:FREQUENCY:STARt <SemOffsetStartFrequency_Hz>

Availability: Command and Query **Default:** 15000

Description: Sets the start frequency of an offset segment relative to the edge (single carrier) or edge (multi-carrier). This value is expressed in Hz.

Parameters: <SemOffsetStartFrequency_Hz> Double

:CONFigure:LTE:SEM:OFFSet:FREQUENCY:STOP <SemOffsetStopFrequency_Hz>

Availability: Command and Query **Default:** 985000

Description: Sets the stop frequency of an offset segment relative to the edge (single carrier) or edge (multi-carrier). This value is expressed in Hz.

Parameters: <SemOffsetStopFrequency_Hz> Double

**:CONFigure:LTE:SEM:OFFSet:LIMit:ABSoulte:STARt
<SemOffsetAbsoulteLimitStart_dBm>**

Availability: Command and Query **Default:** -16.5

Description: Sets the absolute power limit corresponding to the beginning of an offset segment. This value is expressed in dBm.

Parameters: <SemOffsetAbsoulteLimitStart_dBm> Double

**:CONFigure:LTE:SEM:OFFSet:LIMit:ABSoulte:STOP
<SemOffsetAbsoulteLimitStop_dBm>**

Availability: Command and Query **Default:** -16.5

Description: Sets the absolute power limit corresponding to the end of an offset segment. This value is expressed in dBm.

Parameters: <SemOffsetAbsoulteLimitStop_dBm> Double

:CONFigure:LTE:SEM:OFFSet:LIMit:FMAsk <SemOffsetLimitFailMask>

Availability: Command and Query **Default:** ABS

Description: Sets the criteria to determine the measurement fail status.

Parameters: <SemOffsetLimitFailMask> ABSnREL | ABSorREL | ABS | REL

**:CONFigure:LTE:SEM:OFFSet:LIMit:RELative:STARt
<SemOffsetRelativeLimitStart_dBm>**

Availability: Command and Query **Default:** -51.5

Description: Sets the relative power limit corresponding to the beginning of the offset segment. This value is expressed in dB.

Parameters: <SemOffsetRelativeLimitStart_dBm> Double

**:CONFigure:LTE:SEM:OFFSet:LIMit:RELative:STOP
<SemOffsetRelativeLimitStop_dBm>**

Availability: Command and Query **Default:** -58.5

Description: Sets the relative power limit corresponding to the end of the offset segment. This value is expressed in dB.

Parameters: <SemOffsetRelativeLimitStop_dBm> Double

:CONFigure:LTE:SEM:OFFSet:SBANd <SemOffsetSideband>

Availability: Command and Query **Default:** BOTH

Description: Sets whether the offset segment is present either on one side or on both sides of a carrier.

Parameters: <SemOffsetSideband> NEG | POS | BOTH

**:CONFigure:LTE:SEM:POWER:MAX:AGGRegated
<SemAggregatedMaximumPower_dBm>**

Availability: Command and Query **Default:** 0

Description: Sets the aggregated maximum output power of all transmit antenna connectors. This value is expressed in dBm. Refer to the Section 6.6.3 of 3GPP 36.141 specification for more details.

Parameters: <SemAggregatedMaximumPower_dBm> Double

:CONFigure:LTE:SEM:RBW:BW <SemRbwBandwidth_Hz>

Availability: Command and Query **Default:** 10000

Description: Sets the bandwidth of an RBW filter used to sweep an acquired offset segment. This value is expressed in Hz.

Parameters: <SemRbwBandwidth_Hz> Double

:CONFigure:LTE:SEM:RBW:TYPE <SemRwbFilterType>

Availability: Command and Query **Default:** GAUSSIAN

Description: Sets the shape of a digital RBW filter.

Parameters: <SemRwbFilterType> FFT | GAUSSIAN | FLAT | ST4 | ST5

:CONFigure:LTE:SEM:SWEep:AUTO <SemSweepTimeAuto>

Availability: Command and Query **Default:** 1

Description: Sets whether the measurement computes the sweep time.

Parameters: <SemSweepTimeAuto> Boolean

:CONFigure:LTE:SEM:SWEep:INTERval <SemSweepTimeInterval_s>

Availability: Command and Query **Default:** 0.001

Description: Sets the sweep time when user sets the SemSweepTimeAuto to False. This value is expressed in seconds.

Parameters: <SemSweepTimeInterval_s> Double

:CONFigure:LTE:SEM:TRACe:ENABle <SemAllTracesEnable>

Availability: Command and Query **Default:** 0

Description: Sets whether to enable the traces to be stored and retrieved after performing the SEM measurement.

Parameters: <SemAllTracesEnable> Boolean

:CONFigure:LTE:SEM:ULInk:MTYPe <SemUplinkMaskType>

Availability: Command and Query **Default:** General_NS01

Description: Sets the spectrum emission mask used in the measurement for uplink. The following mask types are supported: General_NS01, NS03_Or_NS11_Or_NS20_Or_NS21, NS04, NS06_Or_NS07, CANS04, CUSTOM, General_CAClassB, CANCENS01, NS27 and NS35. Each mask type refers to a different Network Signalled (NS) value. General_CAClassB, CANS04, and CANCENS01 refers to carrier aggregation case. You must set the mask type to Custom to configure the custom offset masks. Refer to section 6.6.2.1 of the 3GPP 36.521 specification for more information about standard-defined mask types.

Parameters: <SemUplinkMaskType> General_NS01 |
NS03_Or_NS11_Or_NS20_Or_NS21 |
NS04 | NS06_Or_NS07 | CANS04 |
Custom | General_CAClassB |
CANCENS01 | NS27 | NS35

**:CONFigure:LTE:SLOT:PHASe:CClock:ENABle
<SlotPhaseCommonClockSourceEnabled>**

Availability: Command and Query **Default:** 1

Description: Sets whether the same Reference Clock is used for local oscillator and the digital-to-analog converter. When the same Reference Clock is used, the carrier frequency offset is proportional to Sample Clock error.

Parameters: <SlotPhaseCommonClockSourceEnabled> Boolean

:CONFigure:LTE:SLOT:PHASe:EPERiod:ENABle <SlotPhaseExclusionPeriodEnabled>

Availability: Command and Query **Default:** 1

Description: Sets whether to exclude some portions of the slots when calculating the phase. This method is applicable only when there is a power change at the slot boundary. Refer to section 6.5.2.1A of the 3GPP 36.521-1 specification for more information about the exclusion.

Parameters: <SlotPhaseExclusionPeriodEnabled> Boolean

**:CONFigure:LTE:SLOT:PHASe:MEASurement:ENABle
<SlotPhaseMeasurementEnabled>**

Availability: Command and Query **Default:** 0

Description: Sets whether to enable the SlotPhase measurement.

Parameters: <SlotPhaseMeasurementEnabled> Boolean

:CONFigure:LTE:SLOT:PHASe:MEASurement:LENGth <SlotPhaseMeasurementLength>

Availability: Command and Query **Default:** 20

Description: Sets the number of slots to be measured. This value is expressed in slots.

Parameters: <SlotPhaseMeasurementLength> Int32

:CONFigure:LTE:SLOT:PHASe:MEASurement:OFFSet <SlotPhaseMeasurementOffset>

Availability: Command and Query **Default:** 0

Description: Sets the measurement offset to skip from the synchronization boundary. This value is expressed in slots. The synchronization boundary is specified by the method.

Parameters: <SlotPhaseMeasurementOffset> Int32

:CONFigure:LTE:SLOT:PHASe:SPECTrum:INVerted <SlotPhaseSpectrumInverted>

Availability: Command and Query **Default:** 0

Description: Sets whether the spectrum of the measured signal is inverted. The inversion happens when the I and the Q components of the baseband complex signal are swapped.

Parameters: <SlotPhaseSpectrumInverted> Boolean

:CONFigure:LTE:SLOT:PHASe:SYNC <SlotPhaseSynchronizationMode>

Availability: Command and Query **Default:** Frame

Description: Sets whether the measurement is performed from the frame or the slot boundary.

Parameters: <SlotPhaseSynchronizationMode> Frame | Slot

:CONFigure:LTE:SLOT:PHASe:TRACe:ENABLE <SlotPhaseAllTracesEnable>

Availability: Command and Query **Default:** 0

Description: Sets whether to enable the traces to be stored and retrieved after performing the SlotPhase measurement.

Parameters: <SlotPhaseAllTracesEnable> Boolean

**:CONFigure:LTE:SLOT:POWer:CClock:ENABLE
<SlotPowerCommonClockSourceEnabled>**

Availability: Command and Query **Default:** 1

Description: Sets whether the same Reference Clock is used for the local oscillator and the digital-to-analog converter in the transmitter. When the same Reference Clock is used, the carrier frequency offset is proportional to Sample Clock error.

Parameters: <SlotPowerCommonClockSourceEnabled> Boolean

**:CONFigure:LTE:SLOT:POWer:MEASurement:ENABLE
<SlotPowerMeasurementEnabled>**

Availability: Command and Query **Default:** 0

Description: Sets whether to enable the SlotPower measurement.

Parameters: <SlotPowerMeasurementEnabled> Boolean

:CONFigure:LTE:SLOT:POWer:MEASurement:LENGth <SlotPowerMeasurementLength>

Availability: Command and Query **Default:** 10

Description: Sets the number of subframes to be measured. This value is expressed in subframe.

Parameters: <SlotPowerMeasurementLength> Int32

:CONFigure:LTE:SLOT:POWer:MEASurement:OFFSet <SlotPowerMeasurementOffset>

Availability: Command and Query **Default:** 0

Description: Sets the measurement offset to skip from the frame boundary or the marker (external trigger) location. This value is expressed in subframe.

Parameters: <SlotPowerMeasurementOffset> Int32

:CONFigure:LTE:SLOT:POWer:SPECTrum:INVerted <SlotPowerSpectrumInverted>

Availability: Command and Query **Default:** 0

Description: Sets whether the spectrum of the measured signal is inverted. The inversion happens when the I and the Q components of the baseband complex signal are swapped.

Parameters: <SlotPowerSpectrumInverted> Boolean

:CONFigure:LTE:SLOT:POWer:TRACe:ENABle <SlotPowerAllTracesEnable>

Availability: Command and Query **Default:** 0

Description: Sets whether to enable the traces to be stored and retrieved after performing the SlotPower measurement.

Parameters: <SlotPowerAllTracesEnable> Boolean

:CONFigure:LTE:TRACe:ENABle <TraceEnable>

Availability: Command and Query **Default:** 0

Description: Enable traces for all measurements.

Parameters: <TraceEnable> Boolean

:CONFigure:LTE:ULDL <UldlConfiguration>

Availability: Command and Query **Default:** 0

Description: Sets the configuration of the LTE frame structure in the time division duplex (TDD) mode. Refer to table 4.2-2 of the 3GPP TS 36.211 specification to configure the LTE frame.

Parameters: <UldlConfiguration> Int32

:CONFigure:LTE<i>:CCARrier<i>:BSMMode <BaseSequenceMode>**:CONFigure:LTE:SBLoCk<i>:CCARrier<i>:BSMMode <BaseSequenceMode>**

Availability: Command and Query **Default:** 0

Description: Specifies whether the NPuschDmrsBaseSequenceIndex is computed by the measurement or user-specified.

Parameters: <BaseSequenceMode> Boolean

:CONFigure:LTE<i>:CCARrier<i>:BW <CarrierChannelBandwidth>**:CONFigure:LTE:SBLoCk<i>:CCARrier<i>:BW <CarrierChannelBandwidth>**

Availability: Command and Query **Default:** M10

Description: Specifies the channel bandwidths of the signal being measured.

Parameters: <CarrierChannelBandwidth> k200 | M1_4 | M3 | M5 | M10 | M15 | M20

:CONFigure:LTE<i>:CCARrier<i>:CID <CarrierCellId>

:CONFigure:LTE:SBLoCk<i>:CCARrier<i>:CID <CarrierCellId>

Availability: Command and Query **Default:** 0

Description: Sets a physical layer cell identity.

Parameters: <CarrierCellId> Int32

:CONFigure:LTE<i>:CCARrier<i>:GHOPping:ENABle <GroupHoppingEnable>

:CONFigure:LTE:SBLoCk<i>:CCARrier<i>:GHOPping:ENABle <GroupHoppingEnable>

Availability: Command and Query **Default:** 0

Description: Sets whether the sequence group number hopping for demodulation reference signal (DMRS) is enabled, as defined in section 5.5.1.3 of the 3GPP TS 36.211 specification.

Parameters: <GroupHoppingEnable> Boolean

**:CONFigure:LTE<i>:CCARrier<i>:NBIOt:UPLink:SCSpacing
<NBloTUplinkSubcarrierSpacing>**

**:CONFigure:LTE:SBLoCk<i>:CCARrier<i>:NBIOt:UPLink:SCSpacing
<NBloTUplinkSubcarrierSpacing>**

Availability: Command and Query **Default:** SubcarrierSpacing15kHz

Description: Sets the subcarrier bandwidth of an NB-IoT signal. This method specifies the spacing between adjacent subcarriers.

Parameters: <NBloTUplinkSubcarrierSpacing> SubcarrierSpacing15kHz |
SubcarrierSpacing3_75kHz

:CONFigure:LTE<i>:CCARrier<i>:NCID <NCellIDs>

:CONFigure:LTE:SBLoCk<i>:CCARrier<i>:NCID <NCellIDs>

Availability: Command and Query **Default:** 0

Description: Sets the narrowband physical layer cell identity.

Parameters: <NCellIDs> Int32

**:CONFigure:LTE<i>:CCARrier<i>:NPUSch:DMRSignal:BSIndex
<NPuschDmrsBaseSequenceIndex>**

**:CONFigure:LTE:SBLoCk<i>:CCARrier<i>:NPUSch:DMRSignal:BSIndex
<NPuschDmrsBaseSequenceIndex>**

Availability: Command and Query **Default:** 0

Description: Specifies the base sequence index of the NPUSCH DMRS as defined in section 10.1.4.1.2 of the 3GPP TS 36.211 specification. This parameter is valid when user sets the GroupHoppingEnable parameter to False, the BaseSequenceMode parameter to Manual, and the value of NPuschNumberOfTones to 3, 6, or 12.

Parameters: <NPuschDmrsBaseSequenceIndex> Int32

**:CONFigure:LTE<i>:CCARrier<i>:NPUSch:DMRSIGNAL:CSHift
<NPuschDmrsCyclicShift>**

**:CONFigure:LTE:SBLOCK<i>:CCARrier<i>:NPUSch:DMRSIGNAL:CSHift
<NPuschDmrsCyclicShift>**

Availability: Command and Query **Default:** 0

Description: Specifies the cyclic shift of the NPUSCHDMRS as defined in table 10.1.4.1.2-3 of the 3GPP TS 36.211 specification. This parameter is valid when NPuschNumberOfTones is 3 or 6.

Parameters: <NPuschDmrsCyclicShift> Int32

:CONFigure:LTE<i>:CCARrier<i>:NPUSch:DMRSIGNAL:DSS <NPuschDmrsDeltaSS>

**:CONFigure:LTE:SBLOCK<i>:CCARrier<i>:NPUSch:DMRSIGNAL:DSS
<NPuschDmrsDeltaSS>**

Availability: Command and Query **Default:** 0

Description: Specifies the delta sequence shift of the NPUSCH DMRS that is used to calculate the sequence shift pattern, which in turn is used to compute the sequence group number as defined in section 10.1.4.1.3 of the 3GPP TS 36.211 specification. This parameter is valid when user sets the GroupHoppingEnable parameter to True. Valid values are 0 to 29, inclusive.

Parameters: <NPuschDmrsDeltaSS> Int32

:CONFigure:LTE<i>:CCARrier<i>:NPUSch:FORMat <NPuschFormat>

:CONFigure:LTE:SBLOCK<i>:CCARrier<i>:NPUSch:FORMat <NPuschFormat>

Availability: Command and Query **Default:** 1

Description: Configures the format of the narrowband physical uplink shared channel (NPUSCH).

Parameters: <NPuschFormat> Int32

:CONFigure:LTE<i>:CCARrier<i>:NPUSch:MODulation:TYPE <NPuschModulationType>

**:CONFigure:LTE:SBLOCK<i>:CCARrier<i>:NPUSch:MODulation:TYPE
<NPuschModulationType>**

Availability: Command and Query **Default:** Bpsk

Description: Specifies the modulation type that is used by the NPUSCH channel. This parameter is valid when numberOfTones is equal to 1 and is equal to 1. The modulation type for other configurations is defined in Table 10.1.3.2-1 of the 3GPP TS 36.211 specification.

Parameters: <NPuschModulationType> Bpsk | Qpsk

:CONFigure:LTE<i>:CCARrier<i>:NPUSch:NTONes <NPuschNumberOfTones>

:CONFigure:LTE:SBLOCK<i>:CCARrier<i>:NPUSch:NTONes <NPuschNumberOfTones>

Availability: Command and Query **Default:** 1

Description: Specifies the number of subcarriers (tones) within the 200 kHz bandwidth that is allocated to the NPUSCH channel.

Parameters: <NPuschNumberOfTones> Int32

:CONFigure:LTE<i>:CCARrier<i>:NPUSch:SSLOt <NPuschStartingSlot>		
:CONFigure:LTE:SBLOck<i>:CCARrier<i>:NPUSch:SSLOt <NPuschStartingSlot>		
	Availability: Command and Query	Default: 0
Description:	Configures the starting slot of the NPUSCH burst.	
Parameters:	<NPuschStartingSlot> Int32	
:CONFigure:LTE<i>:CCARrier<i>:NPUSch:TOFFsets <NPuschToneOffsets>		
:CONFigure:LTE:SBLOck<i>:CCARrier<i>:NPUSch:TOFFsets <NPuschToneOffsets>		
	Availability: Command and Query	Default: 0
Description:	Specifies the location of the starting subcarrier (tone) within the 200 kHz bandwidth that is allocated to the NPUSCH channel.	
Parameters:	<NPuschToneOffsets> Int32	
:CONFigure:LTE<i>:CCARrier<i>:PCFICH:CFIS <PcfichCfis>		
:CONFigure:LTE:SBLOck<i>:CCARrier<i>:PCFICH:CFIS <PcfichCfis>		
	Availability: Command and Query	Default: 0
Description:	Specifies the control format indicator (CFI) carried by PCFICH. CFI is used to compute the number of OFDM symbols which will determine the size of physical downlink control channel (PDCCH) within a subframe.	
Parameters:	<PcfichCfis> Int32	
:CONFigure:LTE<i>:CCARrier<i>:PCFICH:POWER <PcfichPower_dB>		
:CONFigure:LTE:SBLOck<i>:CCARrier<i>:PCFICH:POWER <PcfichPower_dB>		
	Availability: Command and Query	Default: 0
Description:	Specifies the power of the PCFICH relative to the power of the cell-specific reference signal. This value is expressed in dB.	
Parameters:	<PcfichPower_dB> Double	
:CONFigure:LTE<i>:CCARrier<i>:PUSCh:DMRS:AUTO:ENABLE <AutoDmrsDetectionEnable>		
:CONFigure:LTE:SBLOck<i>:CCARrier<i>:PUSCh:DMRS:AUTO:ENABLE <AutoDmrsDetectionEnable>		
	Availability: Command and Query	Default: 0
Description:	Configures whether the demodulation reference signal (DMRS) parameters are configured by a user or automatically detected by a measurement.	
Parameters:	<AutoDmrsDetectionEnable> Boolean	
:CONFigure:LTE<i>:CCARrier<i>:PUSCh:DMRSsignal:DSS <DeltaSequenceShift>		
:CONFigure:LTE:SBLOck<i>:CCARrier<i>:PUSCh:DMRSsignal:DSS <DeltaSequenceShift>		
	Availability: Command and Query	Default: 0
Description:	Sets the delta sequence shift of the narrowband physical uplink shared channel (NPUSCH) DMRS, which is used to calculate the sequence shift pattern. This value is used to compute the sequence group number as defined in section 10.1.4.1.3 of the 3GPP TS 36.211 specification. This method is valid when user sets the GroupHoppingEnable to True.	
Parameters:	<DeltaSequenceShift> Int32	

:CONFigure:LTE<i>:CCARrier<i>:PUSCh:DMRSIGNAL:ONE <PuschDMRSn1>
:CONFigure:LTE:SBLOCK<i>:CCARrier<i>:PUSCh:DMRSIGNAL:ONE <PuschDMRSn1>

Availability: Command and Query **Default:** 0

Description: Sets the n_DMRS_1 value, which is used to calculate the cyclic shift of the demodulation reference signal (DMRS) in a frame. The valid values for this method are defined in table 5.5.2.1.1-2 of the 3GPP TS 36.211 specification.

Parameters: <PuschDMRSn1> Int32

:CONFigure:LTE<i>:CCARrier<i>:PUSCh:DMRSIGNAL:TWO <PuschDMRSn2>
:CONFigure:LTE:SBLOCK<i>:CCARrier<i>:PUSCh:DMRSIGNAL:TWO <PuschDMRSn2>

Availability: Command and Query **Default:** 0

Description: Sets the n_DMRS_2 value, which is used to calculate the cyclic shift of the demodulation reference signal (DMRS) in a slot. The valid values for this method are, as defined in table 5.5.2.1.1-1 of the 3GPP TS 36.211 specification.

Parameters: <PuschDMRSn2> Int32

:CONFigure:LTE<i>:CCARrier<i>:PUSCh:DOWNlink:TMODeI <DownlinkTestModel>
:CONFigure:LTE:SBLOCK<i>:CCARrier<i>:PUSCh:DOWNlink:TMODeI <DownlinkTestModel>

Availability: Command and Query **Default:** TM1_1

Description: Sets the EUTRA test model type when user sets DownlinkChannelConfigurationMode to TestModel. Refer to section 6.1.1 of the 3GPP 36.141 specification for more information regarding test model configurations.

Parameters: <DownlinkTestModel> TM1_1 | TM1_2 | TM2 | TM2A | TM3_1 |
TM3_2 | TM3_3 | TM3_1A

:CONFigure:LTE<i>:CCARrier<i>:PUSCh:EMTC:ENABLE <EmtcAnalysisEnable>
:CONFigure:LTE:SBLOCK<i>:CCARrier<i>:PUSCh:EMTC:ENABLE <EmtcAnalysisEnable>

Availability: Command and Query **Default:** 0

Description: Specifies whether the component carrier contains an eMTC transmission.

Parameters: <EmtcAnalysisEnable> Boolean

:CONFigure:LTE<i>:CCARrier<i>:PUSCh:MODulation:TYPE <PuschModulationType>
:CONFigure:LTE:SBLOCK<i>:CCARrier<i>:PUSCh:MODulation:TYPE <PuschModulationType>

Availability: Command and Query **Default:** Qpsk

Description: Configures the modulation scheme used in the physical uplink shared channel (PUSCH) channel of the signal being measured.

Parameters: <PuschModulationType> PiBy2_Bpsk | Qpsk | Qam16 | Qam64 |
Qam256 | Qam1024

:CONFigure:LTE<i>:CCARrier<i>:PUSCh:POWEr:PBCH <PbchPower_dB>
:CONFigure:LTE:SBLock<i>:CCARrier<i>:PUSCh:POWEr:PBCH <PbchPower_dB>

Availability: Command and Query **Default:** 0

Description: Specifies the power of the PBCH relative to the power of the cell-specific reference signal. This value is expressed in dB.

Parameters: <PbchPower_dB> Double

:CONFigure:LTE<i>:CCARrier<i>:PUSCh:POWEr:PDCCH <PdcchPower_dB>
:CONFigure:LTE:SBLock<i>:CCARrier<i>:PUSCh:POWEr:PDCCH <PdcchPower_dB>

Availability: Command and Query **Default:** 0

Description: Specifies the power of the PDCCH relative to the power of the cell-specific reference signal. This value is expressed in dB.

Parameters: <PdcchPower_dB> Double

:CONFigure:LTE<i>:CCARrier<i>:PUSCh:POWEr:PSS <PssPower_dB>
:CONFigure:LTE:SBLock<i>:CCARrier<i>:PUSCh:POWEr:PSS <PssPower_dB>

Availability: Command and Query **Default:** 0

Description: Sets the power of primary synchronization signal (PSS) relative to the power of cell-specific reference signal. This value is expressed in dB.

Parameters: <PssPower_dB> Double

:CONFigure:LTE<i>:CCARrier<i>:PUSCh:POWEr:SSS <SssPower_dB>
:CONFigure:LTE:SBLock<i>:CCARrier<i>:PUSCh:POWEr:SSS <SssPower_dB>

Availability: Command and Query **Default:** 0

Description: Sets the power of secondary synchronization signal (SSS) relative to the power of cell-specific reference signal. This value is expressed in dB.

Parameters: <SssPower_dB> Double

:CONFigure:LTE<i>:CCARrier<i>:PUSCh:RBCLuster<i>:NRB <RBCount>
:CONFigure:LTE:SBLock<i>:CCARrier<i>:PUSCh:RBCLuster<i>:NRB <RBCount>

Availability: Command and Query **Default:** N/A

Description: Specifies the number of consecutive resource blocks in a PUSCH cluster.

Parameters: <RBCount> Int32

:CONFigure:LTE<i>:CCARrier<i>:SUBFrame<i>:PDSCH:MODulation:TYPE <PdschModulationType>
:CONFigure:LTE:SBLock<i>:CCARrier<i>:SUBFrame<i>:PDSCH:MODulation:TYPE <PdschModulationType>

Availability: Command and Query **Default:** N/A

Description: Specifies the modulation type of Codeword0 PDSCH allocation.

Parameters: <PdschModulationType> Qpsk | Qam16 | Qam64 | Qam256 |
Qam1024

**:CONFigure:LTE<i>:CCARrier<i>:SUBFrame<i>:PDSCH:NCH
<NumberOfPdschChannels>**

**:CONFigure:LTE:SBLOCK<i>:CCARrier<i>:SUBFrame<i>:PDSCH:NCH
<NumberOfPdschChannels>**

Availability: Command and Query **Default:** N/A

Description: Sets the number of physical downlink shared channel (PDSCH) allocations in a subframe.

Parameters: <NumberOfPdschChannels> Int32

:CONFigure:LTE<i>:CCARrier<i>:SUBFrame<i>:PDSCH:POWER <PdschPower_dB>

**:CONFigure:LTE:SBLOCK<i>:CCARrier<i>:SUBFrame<i>:PDSCH:POWER
<PdschPower_dB>**

Availability: Command and Query **Default:** N/A

Description: Specifies the PDSCH power level (rho_a) relative to the power of the cell-specific reference signal. This value is expressed in dB. Measurement uses the cell specific Ratio method to calculate rho_b. Refer to section 3.3 of the 3GPP 36.521 Specifications for more information about rho_a.

Parameters: <PdschPower_dB> Double

**:CONFigure:LTE<i>:CCARrier<i>:SUBFrame<i>:PDSCH:RBLOCK
<PdschResourceBlockAllocation>**

**:CONFigure:LTE:SBLOCK<i>:CCARrier<i>:SUBFrame<i>:PDSCH:RBLOCK
<PdschResourceBlockAllocation>**

Availability: Command and Query **Default:** N/A

Description: Specifies the resource blocks of the PDSCH allocation.

Parameters: <PdschResourceBlockAllocation> String

:CONFigure:LTE<i>:CCARrier<i>:SUBFrame<i>:PHICH:DURATION <PhichDuration>

**:CONFigure:LTE:SBLOCK<i>:CCARrier<i>:SUBFrame<i>:PHICH:DURATION
<PhichDuration>**

Availability: Command and Query **Default:** N/A

Description: Specifies the PHICH duration.

Parameters: <PhichDuration> Normal

:CONFigure:LTE<i>:CCARrier<i>:SUBFrame<i>:PHICH:POWER <PhichPower_dB>

**:CONFigure:LTE:SBLOCK<i>:CCARrier<i>:SUBFrame<i>:PHICH:POWER
<PhichPower_dB>**

Availability: Command and Query **Default:** N/A

Description: Specifies the power of all BPSK symbols in a PHICH sequence. This value is expressed in dB.

Parameters: <PhichPower_dB> Double

**:CONFigure:LTE<i>:CCARrier<i>:SUBFrame<i>:PHICH:RESOource
<PhichResource_Ng>**

**:CONFigure:LTE:SBLock<i>:CCARrier<i>:SUBFrame<i>:PHICH:RESOource
<PhichResource_Ng>**

Availability: Command and Query **Default:** N/A

Description: Specifies the PHICH resource value. This value is expressed in Ng. This parameter is used to calculate number of PHICH resource groups. Refer to section 6.9 of the 3GPP 36.211 specification for more information about PHICH.

Parameters: <PhichResource_Ng> OneSixth | Half | One | Two

:CONFigure:LTE<i>:CENTer:INDex <ComponentCarrierAtCenterFrequency>

:CONFigure:LTE:SBLock<i>:CENTer:INDex <ComponentCarrierAtCenterFrequency>

Availability: Command and Query **Default:** N/A

Description: Sets the index of the component carrier having its center at the user-configured center frequency. RFmxLTE uses this method along with ComponentCarrierSpacingType to calculate the value of the CenterFrequency.

Parameters: <ComponentCarrierAtCenterFrequency> Int32

:CONFigure:LTE<i>:FREQUency <CenterFrequency_Hz>

:CONFigure:LTE<i>:FREQUency:CENTer <CenterFrequency_Hz>

:CONFigure:LTE:SBLock<i>:FREQUency <CenterFrequency_Hz>

:CONFigure:LTE:SBLock<i>:FREQUency:CENTer <CenterFrequency_Hz>

Availability: Command and Query **Default:** 1950000000

Description: For a single carrier, this method specifies the center frequency of the acquired RF signal.

Parameters: <CenterFrequency_Hz> Double

:CONFigure:LTE<i>:FREQUency:DEFinition <FrequencyDefinition>

:CONFigure:LTE:SBLock<i>:FREQUency:DEFinition <FrequencyDefinition>

Availability: Command and Query **Default:** Absolute

Description: Configures the subblock center frequency definition, which can be an absolute frequency or relative to the absolute frequency of the first subblock.

Parameters: <FrequencyDefinition> Relative | Absolute

:CONFigure:LTE<i>:POWER:MAX <MaxInputPower_dBm>

:CONFigure:LTE:SBLock<i>:POWER:MAX <MaxInputPower_dBm>

Availability: Command and Query **Default:** 0

Description: Sets the maximum expected power of the RF input signal. This value is expressed in dBm for RF devices and Vpk-pk for baseband devices.

Parameters: <MaxInputPower_dBm> Double

:CONFigure:LTE<i>:SType <ComponentCarrierSpacingType>**:CONFigure:LTE:SBlock<i>:SType <ComponentCarrierSpacingType>****Availability:** Command and Query **Default:** N/A**Description:** Specifies the spacing between the two adjacent component carriers within a subblock.**Parameters:** <ComponentCarrierSpacingType> Nominal | User | Minimum

:CONFigure:LTE<i>:UMARgin <UserMargin_dB>**:CONFigure:LTE:SBlock<i>:UMARgin <UserMargin_dB>****Availability:** Command and Query **Default:** 9**Description:** Sets user margin**Parameters:** <UserMargin_dB> Double

:FETch:LTE:RESults<i>:ACP:SBlock<i>**Availability:** Query Only **Default:** N/A**Description:** Sets results of ACP sub-blocks**Return type:** <TotalAggregatedPower_dBm: double>, <Subblock>, <Carrier,...>, <Offset,...>

:FETch:LTE:RESults<i>:ACP:SBlock<i>:ALL**Availability:** Query Only **Default:** N/A**Description:** Returns string with results for NRModAccCarrier.**Return type:** <TotalAggregatedPower_dBm: double>, <Subblock>, <Carrier,...>, <Offset,...>

:FETch:LTE:RESults<i>:ACP:SBlock<i>:CCARrier<i>**Availability:** Query Only **Default:** N/A**Description:** Contains the results of the carrier measurements.**Return type:** CarrierMeasurementResults

:FETch:LTE:RESults<i>:ACP:SBlock<i>:CCARrier<i>:POWER:ABSolute**Availability:** Query Only **Default:** NaN**Description:** Contains the array of powers measured over the integration bandwidths of the component carriers in a subblock.**Return type:** Double

:FETch:LTE:RESults<i>:ACP:SBlock<i>:CCARrier<i>:POWER:RELative**Availability:** Query Only **Default:** NaN**Description:** Contains the array of component carrier powers relative to their subblock powers measured over the integration bandwidths of the component carriers in the subblock.**Return type:** Double

:FETch:LTE:RESults<i>:ACP:SBlock<i>:MEAS**Availability:** Query Only **Default:** N/A**Description:** Contains the results of the subblock measurements.**Return type:** SubblockMeasurementResults

:FETch:LTE:RESults<i>:ACP:SBlock<i>:MEAS:ALL

Availability: Query Only **Default:** N/A

Description: Returns string with results for NRModAccCarrier.

Return type: String

:FETch:LTE:RESults<i>:ACP:SBlock<i>:MEAS:FREquency

Availability: Query Only **Default:** NaN

Description: Contains the absolute center frequency of the subblock. This value is the center of the subblock integration bandwidth.

Return type: Double

:FETch:LTE:RESults<i>:ACP:SBlock<i>:MEAS:IBANDwidth

Availability: Query Only **Default:** NaN

Description: Contains the integration bandwidth used in calculating the power of the subblock. Integration bandwidth is the span from left edge of the leftmost carrier to the right edge of the rightmost carrier within a subblock.

Return type: Double

:FETch:LTE:RESults<i>:ACP:SBlock<i>:MEAS:POWER

Availability: Query Only **Default:** NaN

Description: Contains the sum of powers of all the frequency bins over the integration bandwidth of the subblock.

Return type: Double

:FETch:LTE:RESults<i>:ACP:SBlock<i>:OFFSet:COUNT

Availability: Query Only **Default:** N/A

Description: Contains the number of offsets in the measurement.

Return type: Int32

:FETch:LTE:RESults<i>:ACP:SBlock<i>:OFFSet<i>

Availability: Query Only **Default:** N/A

Description: Contains the results of the offset measurements.

Return type: AcpOffsetChannelMeasurements

:FETch:LTE:RESults<i>:ACP:SBlock<i>:OFFSet<i>:LOWer:POWER:ABSolute

Availability: Query Only **Default:** N/A

Description: Contains the array of lower (negative) offset channel power. For the intra-band noncontiguous type of carrier aggregation, if this offset is not applicable, a NaN is returned. For more information about the applicability of offset channel, refer to 3GPP TS 36.521 specification.

Return type: Double

:FETch:LTE:RESults<i></i>:ACP:SBlock<i></i>:OFFSet<i></i>:LOWer:POWer:RELative**Availability:** Query Only**Default:** N/A

Description: Contains the array of power in lower (negative) offset channel relative to the value returned by the method. For the intra-band noncontiguous type of carrier aggregation, if this offset is not applicable, a NaN is returned. For more information about the applicability of the offset channel, refer to the 3GPP TS 36.521 specification.

Return type: Double

:FETch:LTE:RESults<i></i>:ACP:SBlock<i></i>:OFFSet<i></i>:UPPer:POWer:ABSolute**Availability:** Query Only**Default:** N/A

Description: Contains the array of upper (positive) offset channel powers. For the intra-band noncontiguous type of carrier aggregation, if this offset is not applicable, a NaN is returned. For more information about the applicability of offset channel, refer 3GPP TS 36.521 specification.

Return type: Double

:FETch:LTE:RESults<i></i>:ACP:SBlock<i></i>:OFFSet<i></i>:UPPer:POWer:RELative**Availability:** Query Only**Default:** N/A

Description: Contains the array of powers in upper (positive) offset channel relative to the value returned by the ACP Results Total Aggregated Pwr method. For the intra-band noncontiguous type of carrier aggregation, if this offset is not applicable, a NaN is returned. For more information about the applicability of the offset channel, refer to the 3GPP TS 36.521 specification.

Return type: Double

:FETch:LTE:RESults<i></i>:ACP:SBlock<i></i>:POWer:TOTal**Availability:** Query Only**Default:** NaN

Description: Contains the sum of powers of all the subblocks. This value includes the power in the inter-carrier gaps within a subblock, but it does not include the power in the subblock gaps.

Return type: Double

:FETch:LTE:RESults<i></i>:CHP:SBlock<i></i>**Availability:** Query Only**Default:** N/A

Description: Sets results of CHP sub-blocks

Return type: <TotalAggregatedPower_dBm: double>, <Subblock>, <Carrier,...>

:FETch:LTE:RESults<i></i>:CHP:SBlock<i></i>:ALL**Availability:** Query Only**Default:** N/A

Description: Returns string with results for NRModAccCarrier.

Return type: <TotalAggregatedPower_dBm: double>, <Subblock>, <Carrier,...>

:FETch:LTE:RESults<i></i>:CHP:SBlock<i></i>:CCARrier<i></i>**Availability:** Query Only**Default:** N/A

Description: Contains the results of the carrier measurements.

Return type: CarrierMeasurementResults

:FETch:LTE:RESults<i></i>:CHP:SBlock<i></i>:CCARrier<i></i>:POWer:ABSolute**Availability:** Query Only**Default:** NaN**Description:** Contains the array of powers measured over the integration bandwidths of the component carriers in a subblock.**Return type:** Double

:FETch:LTE:RESults<i></i>:CHP:SBlock<i></i>:CCARrier<i></i>:POWer:RELative**Availability:** Query Only**Default:** NaN**Description:** Contains the array of component carrier powers relative to their subblock powers measured over the integration bandwidths of the component carriers in the subblock.**Return type:** Double

:FETch:LTE:RESults<i></i>:CHP:SBlock<i></i>:MEAS**Availability:** Query Only**Default:** N/A**Description:** Contains the results of the subblock measurements.**Return type:** SubblockMeasurementResults

:FETch:LTE:RESults<i></i>:CHP:SBlock<i></i>:MEAS:ALL**Availability:** Query Only**Default:** N/A**Description:** Returns string with results for NRModAccCarrier.**Return type:** String

:FETch:LTE:RESults<i></i>:CHP:SBlock<i></i>:MEAS:FREQuency**Availability:** Query Only**Default:** NaN**Description:** Contains the absolute center frequency of the subblock. This value is the center of the subblock integration bandwidth.**Return type:** Double

:FETch:LTE:RESults<i></i>:CHP:SBlock<i></i>:MEAS:IBANDwidth**Availability:** Query Only**Default:** NaN**Description:** Contains the integration bandwidth used in calculating the power of the subblock. Integration bandwidth is the span from left edge of the leftmost carrier to the right edge of the rightmost carrier within a subblock.**Return type:** Double

:FETch:LTE:RESults<i></i>:CHP:SBlock<i></i>:MEAS:POWer**Availability:** Query Only**Default:** NaN**Description:** Contains the sum of powers of all the frequency bins over the integration bandwidth of the subblock.**Return type:** Double

:FETch:LTE:RESults<i></i>:CHP:SBlock<i></i>:POWer:TOTal**Availability:** Query Only**Default:** NaN**Description:** Contains the sum of powers of all the subblocks. This value includes the power in the inter-carrier gaps within a subblock, but it does not include the power in the subblock gaps.**Return type:** Double

:FETch:LTE:RESults<i>:MODacc:SBlock<i>:CCARrier<i>:DETECTED:CID**Availability:** Query Only**Default:** -1

Description: Contains detected cell IDs calculated on PDSCH data symbols over the slots specified by the ModAccMeasurementLength.

Return type: Int32

:FETch:LTE:RESults<i>:MODacc:SBlock<i>:CCARrier<i>:EVM:PEAK:INDEX:SCARrier**Availability:** Query Only**Default:** -1

Description: Contains the subcarrier index of the Max Pk Composite EVM method.

Return type: Int32

:FETch:LTE:RESults<i>:MODacc:SBlock<i>:CCARrier<i>:EVM:PEAK:INDEX:SLOT**Availability:** Query Only**Default:** -1

Description: Contains the slot index where the ModAcc maximum peak composite EVM occurs.

Return type: Int32

:FETch:LTE:RESults<i>:MODacc:SBlock<i>:CCARrier<i>:EVM:PEAK:INDEX:SYMBOL**Availability:** Query Only**Default:** -1

Description: Contains the symbol index where the ModAcc maximum peak composite EVM occurs.

Return type: Int32

:FETch:LTE:RESults<i>:MODacc:SBlock<i>:CCARrier<i>:EVM:PEAK:MAX**Availability:** Query Only**Default:** NaN

Description: Contains the maximum value of peak EVMs calculated on all configured channels over the slots specified by the ModAccMeasurementLength.

Return type: Double

:FETch:LTE:RESults<i>:MODacc:SBlock<i>:CCARrier<i>:EVM:RMS:CSRS:MEAN**Availability:** Query Only**Default:** NaN

Description: Contains the mean value of the RMS CSRs calculated on PDSCH data symbols over the slots specified by the ModAccMeasurementLength.

Return type: Double

:FETch:LTE:RESults<i>:MODacc:SBlock<i>:CCARrier<i>:EVM:RMS:MEAN**Availability:** Query Only**Default:** NaN

Description: Contains the mean value of the RMS EVMs calculated on all configured channels over the slots specified by the ModAccMeasurementLength.

Return type: Double

:FETch:LTE:RESults<i>:MODacc:SBlock<i>:CCARrier<i>:EVM:RMS:PSS:MEAN**Availability:** Query Only**Default:** NaN

Description: Contains the mean value of the RMS PSs calculated on PDSCH data symbols over the slots specified by the ModAccMeasurementLength.

Return type: Double

:FETch:LTE:RESults<i>:MODacc:SBlock<i>:CCARrier<i>:EVM:RMS:SRS:MEAN**Availability:** Query Only**Default:** NaN

Description: Contains the mean value of RMS EVMs calculated on the SRS symbols over the slots specified by the ModAccMeasurementLength. When ModAccEvmUnit is set to Percentage, the result is returned as a percentage, and when ModAccEvmUnit is set to dB, the result is returned in dB.

Return type: Double

:FETch:LTE:RESults<i>:MODacc:SBlock<i>:CCARrier<i>:EVM:RMS:SSS:MEAN**Availability:** Query Only**Default:** NaN

Description: Contains the mean value of the RMS SSs calculated on PDSCH data symbols over the slots specified by the ModAccMeasurementLength.

Return type: Double

:FETch:LTE:RESults<i>:MODacc:SBlock<i>:CCARrier<i>:IBE:MARGIN**Availability:** Query Only**Default:** NaN

Description: Contains the in-band emission margins. The margin is the least difference between the in-band emission measurement trace and limit trace. The limit is defined in section 6.5.2.3.5 of the 3GPP TS 36.521 specification. The in-band emissions are a measure of the interference falling into the non-allocated resources blocks.

Return type: Double

:FETch:LTE:RESults<i>:MODacc:SBlock<i>:CCARrier<i>:IQ:MEAN:GAIN:IMBalances**Availability:** Query Only**Default:** NaN

Description: Contains the estimated I/Q gain imbalance averaged over the slots specified by the ModAccMeasurementLength. The I/Q gain imbalance is the ratio of the amplitude of the I component to the Q component of the I/Q signal being measured. when user sets the CC Bandwidth property to 200.0 k and the NPUSCH Num Tones property to 12, this result is available. For other values of NPUSCH Num Tones, this result will be reported as NaN.

Return type: Double

:FETch:LTE:RESults<i>:MODacc:SBlock<i>:CCARrier<i>:IQ:MEAN:ORIGin:OFFSets**Availability:** Query Only**Default:** NaN

Description: Contains the estimated I/Q origin offset averaged over the slots specified by the ModAccMeasurementLength. The ModAcc measurement ignores this parameter, when user sets the LinkDirection to Uplink.

Return type: Double

:FETch:LTE:RESults<i>:MODacc:SBlock<i>:CCARrier<i>:IQ:MEAN:QUADrature:ERRors**Availability:** Query Only**Default:** NaN

Description: Contains the estimated quadrature error averaged over the slots specified by the ModAccMeasurementLength. Quadrature error is a measure of the skewness of the I component with respect to the Q component of the I/Q signal being measured. This value is expressed in degrees. when user sets the CC Bandwidth property to 200.0 k and the NPUSCH Num Tones property to 12, this result is available. For other values of NPUSCH Num Tones, this result will be reported as NaN.

Return type: Double

:FETch:LTE:RESults<i>:MODacc:SBlock<i>:CCARrier<i>:MEAN:FREQuency:ERRor**Availability:** Query Only**Default:** NaN

Description: Contains the estimated carrier frequency offset averaged over the slots specified by the ModAccMeasurementLength.

Return type: Double

:FETch:LTE:RESults<i>:MODacc:SBlock<i>:CCARrier<i>:MEAN:IQ:TIMingskew**Availability:** Query Only**Default:** NaN

Description: Returns the estimated IQ timing skew averaged over measured length. IQ timing skew is the difference between the group delay of the in-phase (I) and quadrature (Q) components of the signal. This value is expressed in seconds.

Return type: Double

:FETch:LTE:RESults<i>:MODacc:SBlock<i>:CCARrier<i>:MEAN:TOFFsets**Availability:** Query Only**Default:** NaN

Description: Returns the time difference between the detected slot or frame boundary and the reference trigger location depending on the value of ModAccSynchronizationMode method. This value is expressed in seconds.

Return type: Double

:FETch:LTE:RESults<i>:MODacc:SBlock<i>:CCARrier<i>:NPUSch:EVM:DMRS:PEAK:MAX**Availability:** Query Only**Default:** NaN

Description: Contains the maximum value of the peak EVMs calculated on NPUSCHDMRS over the slots specified by the ModAccMeasurementLength. When ModAccEvmUnit is set to Percentage, the result is returned as a percentage, and when ModAccEvmUnit is set to dB, the result is returned in dB.

Return type: Double

:FETch:LTE:RESults<i>:MODacc:SBlock<i>:CCARrier<i>:NPUSch:EVM:PEAK:MAX**Availability:** Query Only**Default:** NaN

Description: Contains the maximum value of the peak EVMs calculated on the NPUSCH data symbols over the slots specified by the ModAccMeasurementLength. When ModAccEvmUnit is set to Percentage, the result is returned as a percentage, and when ModAccEvmUnit is set to dB, the result is returned in dB.

Return type: Double

:FETch:LTE:RESults<i>:MODacc:SBlock<i>:CCARrier<i>:NPUSch:EVM:RMS:DMRS:MEAN		
	Availability: Query Only	Default: NaN
Description:	Contains the mean value of the RMS EVMs calculated on the NPUSCH DMRS over the slots specified by the method. When ModAccEvmUnit is set to Percentage, the result is returned as a percentage, and when ModAccEvmUnit is set to dB, the result is returned in dB.	
Return type:	Double	

:FETch:LTE:RESults<i>:MODacc:SBlock<i>:CCARrier<i>:NPUSch:EVM:RMS:MEAN		
	Availability: Query Only	Default: NaN
Description:	Contains the mean value of the RMS EVMs calculated on the NPUSCH data symbols over the slots specified by the method. When ModAccEvmUnit is set to Percentage, the result is returned as a percentage, and when ModAccEvmUnit is set to dB, the result is returned in dB.	
Return type:	Double	

:FETch:LTE:RESults<i>:MODacc:SBlock<i>:CCARrier<i>:NPUSch:POWER:DMRS:MEAN		
	Availability: Query Only	Default: NaN
Description:	Contains the mean value of the power calculated on PUSCH DMRS over the slots specified by the ModAccMeasurementLength.	
Return type:	Double	

:FETch:LTE:RESults<i>:MODacc:SBlock<i>:CCARrier<i>:NPUSch:POWER:MEAN		
	Availability: Query Only	Default: NaN
Description:	Contains the mean value of the power calculated on PUSCH data symbols over the slots specified by the method.	
Return type:	Double	

:FETch:LTE:RESults<i>:MODacc:SBlock<i>:CCARrier<i>:OFDM:SYMBOL:TPOWER		
	Availability: Query Only	Default: NaN
Description:	Contains the OFDM symbol transit power value calculated on PDSCH data symbols over the slots specified by the ModAccMeasurementLength.	
Return type:	Double	

:FETch:LTE:RESults<i>:MODacc:SBlock<i>:CCARrier<i>:PDSch:EVM:RMS:MEAN		
	Availability: Query Only	Default: NaN
Description:	Contains the mean value of the RMS EVMs calculated on PDSCH data symbols over the slots specified by the ModAccMeasurementLength.	
Return type:	Double	

:FETch:LTE:RESults<i>:MODacc:SBlock<i>:CCARrier<i>:PDSch:EVM:RMS:QAM:1024:MEAN		
	Availability: Query Only	Default: NaN
Description:	Contains the mean value of the RMS EVMs calculated on PDSCH data symbols on over the slots specified by the ModAccMeasurementLength 1024QAM modulation.	
Return type:	Double	

:FETch:LTE:RESults<i>:MODacc:SBlock<i>:CCARrier<i>:PDSCh:EVM:RMS:QAM:16:MEAN

Availability: Query Only**Default:** NaN

Description: Contains the mean value of the RMS EVMs calculated on PDSCH data symbols over the slots specified by the ModAccMeasurementLength on 16QAM modulation.

Return type: Double

:FETch:LTE:RESults<i>:MODacc:SBlock<i>:CCARrier<i>:PDSCh:EVM:RMS:QAM:256:MEAN

Availability: Query Only**Default:** NaN

Description: Contains the mean value of the RMS EVMs calculated on PDSCH data symbols over the slots specified by the ModAccMeasurementLength on 256QAM modulation.

Return type: Double

:FETch:LTE:RESults<i>:MODacc:SBlock<i>:CCARrier<i>:PDSCh:EVM:RMS:QAM:64:MEAN

Availability: Query Only**Default:** NaN

Description: Contains the mean value of the RMS EVMs calculated on PDSCH data symbols over the slots specified by the ModAccMeasurementLength on 64QAM modulation.

Return type: Double

:FETch:LTE:RESults<i>:MODacc:SBlock<i>:CCARrier<i>:PDSCh:EVM:RMS:QPSK:MEAN

Availability: Query Only**Default:** NaN

Description: Contains the mean value of the RMS EVMs calculated on PDSCH data symbols over the slots specified by the ModAccMeasurementLength on QPSK modulation.

Return type: Double

:FETch:LTE:RESults<i>:MODacc:SBlock<i>:CCARrier<i>:PEAK:MAGNitude:ERRors:MAX

Availability: Query Only**Default:** NaN

Description: Contains the peak value of magnitude error calculated over the slots specified by the ModAccMeasurementLength on all the configured channels.

Return type: Double

:FETch:LTE:RESults<i>:MODacc:SBlock<i>:CCARrier<i>:PEAK:PHASe:ERRors:MAX

Availability: Query Only**Default:** NaN

Description: Contains the peak value of phase error calculated over the slots specified by the ModAccMeasurementLength on all the configured channels. This value is expressed in degrees.

Return type: Double

:FETch:LTE:RESults<i>:MODacc:SBlock<i>:CCARrier<i>:POWER:SRS:MEAN

Availability: Query Only**Default:** NaN

Description: Contains the mean value of power calculated on SRS over the slots specified by the ModAccMeasurementLength. This value is expressed in dB.

Return type: Double

:FETch:LTE:RESults<i>:MODacc:SBlock<i>:CCARrier<i>:PUSCh:EVM:DMR:PEAK:MAX		
	Availability: Query Only	Default: NaN
Description:	Contains the maximum value of peak EVMs calculated on PUSCH DMRS over the slots specified by the ModAccMeasurementLength. This value is expressed in dB or in percentage.	
Return type:	Double	
:FETch:LTE:RESults<i>:MODacc:SBlock<i>:CCARrier<i>:PUSCh:EVM:PEAK:MAX		
	Availability: Query Only	Default: NaN
Description:	Contains the maximum value of the peak EVMs calculated on PUSCH data symbols over the slots specified by the ModAccMeasurementLength.	
Return type:	Double	
:FETch:LTE:RESults<i>:MODacc:SBlock<i>:CCARrier<i>:PUSCh:POWer:DMRS:MEAN		
	Availability: Query Only	Default: NaN
Description:	Contains the mean value of the power calculated on PUSCH DMRS over the slots specified by the ModAccMeasurementLength.	
Return type:	Double	
:FETch:LTE:RESults<i>:MODacc:SBlock<i>:CCARrier<i>:PUSCh:POWer:MEAN		
	Availability: Query Only	Default: NaN
Description:	Contains the mean value of the power calculated on PUSCH data symbols over the slots specified by the ModAccMeasurementLength.	
Return type:	Double	
:FETch:LTE:RESults<i>:MODacc:SBlock<i>:CCARrier<i>:PUSCh:RMS:EVM:DMR:MEAN		
	Availability: Query Only	Default: NaN
Description:	Contains the mean value of RMS EVMs calculated on PUSCH DMRS over the slots specified by the ModAccMeasurementLength.	
Return type:	Double	
:FETch:LTE:RESults<i>:MODacc:SBlock<i>:CCARrier<i>:PUSCh:RMS:EVM:MEAN		
	Availability: Query Only	Default: NaN
Description:	Contains the mean value of the RMS EVMs calculated on PUSCH data symbols over the slots specified by the ModAccMeasurementLength.	
Return type:	Double	
:FETch:LTE:RESults<i>:MODacc:SBlock<i>:CCARrier<i>:R1MAX:R1MIN		
	Availability: Query Only	Default: NaN
Description:	Contains the peak-to-peak ripple of the EVM equalizer coefficients within the frequency Range1. The frequency Range1 is as defined in section 6.5.2.4.5 of the 3GPP TS 36.521 specification.	
Return type:	Double	

:FETch:LTE:RESults<i>:MODacc:SBlock<i>:CCARrier<i>:R1MAX:R2MIN**Availability:** Query Only**Default:** NaN

Description: Contains the peak-to-peak ripple of the EVM equalizer coefficients from the frequency Range1 to the frequency Range2. The frequency Range1 and 2 are defined in the section 6.5.2.4.5 of the 3GPP TS 36.521 specification.

Return type: Double

:FETch:LTE:RESults<i>:MODacc:SBlock<i>:CCARrier<i>:R2MAX:R1MIN**Availability:** Query Only**Default:** NaN

Description: Contains the peak-to-peak ripple of the EVM equalizer coefficients from frequency Range2 to frequency Range1. The frequency Range1 and 2 are defined in section 6.5.2.4.5 of the 3GPP TS 36.521 specification.

Return type: Double

:FETch:LTE:RESults<i>:MODacc:SBlock<i>:CCARrier<i>:R2MAX:R2MIN**Availability:** Query Only**Default:** NaN

Description: Contains the peak-to-peak ripple of the EVM equalizer coefficients within the frequency Range2. The frequency Range2 is defined in section 6.5.2.4.5 of the 3GPP TS 36.521 specification.

Return type: Double

:FETch:LTE:RESults<i>:MODacc:SBlock<i>:CCARrier<i>:REServed:1**Availability:** Query Only**Default:** NaN

Description: Contains the reserved 1s.

Return type: Double

:FETch:LTE:RESults<i>:MODacc:SBlock<i>:CCARrier<i>:REServed:2**Availability:** Query Only**Default:** NaN

Description: Contains the reserved 2s.

Return type: Double

:FETch:LTE:RESults<i>:MODacc:SBlock<i>:CCARrier<i>:RMS:MEAN:MAGNitude:ERRors**Availability:** Query Only**Default:** NaN

Description: Contains the RMS mean value of the magnitude error calculated over the slots specified by the ModAccMeasurementLength on all the configured channels.

Return type: Double

:FETch:LTE:RESults<i>:MODacc:SBlock<i>:CCARrier<i>:RMS:MEAN:PHASe:ERRors**Availability:** Query Only**Default:** NaN

Description: Contains the RMS mean value of the phase error calculated over the slots specified by the ModAccMeasurementLength on all the configured channels. This value is expressed in degrees.

Return type: Double

:FETch:LTE:RESults<i>:MODacc:SBlock<i>:CCARrier<i>:RS:TPOWer**Availability:** Query Only**Default:** NaN

Description: Contains the RS transit power value calculated on PDSCH data symbols over the slots specified by the ModAccMeasurementLength.

Return type: Double

:FETch:LTE:RESults<i>:MODacc:SBlock<i>:IBE:MARGin**Availability:** Query Only**Default:** NaN

Description: Gets the in-band emission margin of a subblock aggregated bandwidth. This value is expressed in dB.

Return type: Double

:FETch:LTE:RESults<i>:MODacc:SBlock<i>:IQ:MEAN:GAIN:IMBalances**Availability:** Query Only**Default:** NaN

Description: Contains the estimated I/Q gain imbalance averaged over the slots specified by the ModAccMeasurementLength method. This value is expressed in dB. The I/Q gain imbalance is the ratio of the amplitude of the I component to the Q component of the I/Q signal being measured in the subblock.

Return type: Double

:FETch:LTE:RESults<i>:MODacc:SBlock<i>:IQ:MEAN:ORIGin:OFFSets**Availability:** Query Only**Default:** NaN

Description: Contains the estimated I/Q origin offset averaged over the slots specified by the ModAccMeasurementLength in a subblock. This value is expressed in dBc.

Return type: Double

:FETch:LTE:RESults<i>:MODacc:SBlock<i>:IQ:MEAN:QUADrature:ERRors**Availability:** Query Only**Default:** NaN

Description: Contains the estimated quadrature error averaged over the slots specified by the ModAccMeasurementLength method. This value is expressed in degrees. Quadrature error is a measure of the skewness of the I component with respect to the Q component of the I/Q signal being measured in the subblock.

Return type: Double

:FETch:LTE:RESults<i>:MODacc:SBlock<i>:NUMBER**Availability:** Query Only**Default:** 0

Description: Gets number of sub-blocks

Return type: Int32

:FETch:LTE:RESults<i>:OBW:SBlock<i>**Availability:** Query Only**Default:** N/A

Description: Sets results of OBW sub-blocks

Return type: <SubBlockNumber: double>, <AverageTotalPower_dBm: double>, <OccupiedBandwidth_Hz: double>, <StartFrequency_Hz: double>, <StopFrequency_Hz: double>

:FETch:LTE:RESults<i></i>:OBW:SBlock<i></i>:ALL**Availability:** Query Only**Default:** N/A**Description:** Returns string with results for NRModAccCarrier.**Return type:** <SubBlockNumber: double>, <AverageTotalPower_dBm: double>, <OccupiedBandwidth_Hz: double>, <StartFrequency_Hz: double>, <StopFrequency_Hz: double>

:FETch:LTE:RESults<i></i>:OBW:SBlock<i></i>:BANDwidth**Availability:** Query Only**Default:** NaN**Description:** Contains the bandwidth that occupies 99 percentage of the total power of the signal within a carrier/subblock.**Return type:** Double

:FETch:LTE:RESults<i></i>:OBW:SBlock<i></i>:FREQuency:START**Availability:** Query Only**Default:** NaN**Description:** Contains the start frequency of the subblock. The occupied bandwidth of a carrier/subblock is calculated using the following equation: Stop frequency - Start frequency = Occupied bandwidth.**Return type:** Double

:FETch:LTE:RESults<i></i>:OBW:SBlock<i></i>:FREQuency:STOP**Availability:** Query Only**Default:** NaN**Description:** Contains the stop frequency of the subblock. The occupied bandwidth of a carrier/subblock is calculated using the following equation: Stop frequency - Start frequency = Occupied bandwidth.**Return type:** Double

:FETch:LTE:RESults<i></i>:OBW:SBlock<i></i>:POWER:ABSolute**Availability:** Query Only**Default:** NaN**Description:** Contains the power measured over the integration bandwidth of the carrier/subblock.**Return type:** Double

:FETch:LTE:RESults<i></i>:PVT:SBlock<i></i>:CARRier<i></i>:BURSt:WIDth**Availability:** Query Only**Default:** NaN**Description:** Contains the array of the width of the captured burst.**Return type:** Double

:FETch:LTE:RESults<i></i>:PVT:SBlock<i></i>:CARRier<i></i>:POWER:OFF:ABSolute:MEAN:AFter**Availability:** Query Only**Default:** NaN**Description:** Contains the array of the mean power in the segment after the captured burst. This value is expressed in dBm.**Return type:** Double

:FETch:LTE:RESults<i>:PVT:SBlock<i>:CARRier<i>:POWer:OFF:ABSolute:MEAN:BEFore**Availability:** Query Only**Default:** NaN

Description: Contains the array of the mean power in the segment before the captured burst. The segment is defined as one subframe prior to the burst for the FDD mode and 10 SCFDMA symbols prior to the burst for the TDD mode. This value is expressed in dBm.

Return type: Double

:FETch:LTE:RESults<i>:PVT:SBlock<i>:CARRier<i>:POWer:ON:ABSolute:MEAN**Availability:** Query Only**Default:** NaN

Description: Contains the array of the average power of the subframes within the captured burst, excluding a transient period of 20 us at the beginning. This value is expressed in dBm.

Return type: Double

:FETch:LTE:RESults<i>:PVT:SBlock<i>:CARRier<i>:STATus**Availability:** Query Only**Default:** 0

Description: Contains the array of the measurement status indicating whether the power before and after the burst is within the standard defined limit.

Return type: Boolean

:FETch:LTE:RESults<i>:PVT:SBlock<i>:SBNumber**Availability:** Query Only**Default:** N/A

Description: Defines the subblock where the results belongs to.

Return type: Int32

:FETch:LTE:RESults<i>:SEM:SBlock<i>:ALL**Availability:** Query Only**Default:** N/A

Description: Returns all results for Sem measurement.

Return type: String

:FETch:LTE:RESults<i>:SEM:SBlock<i>:CCARRier<i>**Availability:** Query Only**Default:** N/A

Description: Contains the results of the carrier measurements.

Return type: SemCarrierMeasurementResults

:FETch:LTE:RESults<i>:SEM:SBlock<i>:CCARRier<i>:FREQuency:PEAK**Availability:** Query Only**Default:** NaN

Description: Peak frequency in Hz.

Return type: Double

:FETch:LTE:RESults<i>:SEM:SBlock<i>:CCARRier<i>:IPOWer:ABSolute**Availability:** Query Only**Default:** NaN

Description: Carrier power values. The carrier power is the integrated power of the RRC-filtered signal. The RRC filter uses a bandwidth of 3.84 MHz with a roll-off factor of 0.22. The carrier is centered at a frequency determined by the Center Frequency and methods. This value is expressed in dBm.

Return type: Double

:FETch:LTE:RESults<i>:SEM:SBlock<i>:CCARrier<i>:IPOWER:RELative**Availability:** Query Only**Default:** NaN**Description:** Carrier power values relative to the total carrier power of all enabled carriers. This value is expressed in dB.**Return type:** Double

:FETch:LTE:RESults<i>:SEM:SBlock<i>:CCARrier<i>:POWER:PEAK:ABS**Availability:** Query Only**Default:** N/A**Description:** Absolute peak power in dBm.**Return type:** Double

:FETch:LTE:RESults<i>:SEM:SBlock<i>:MEAS**Availability:** Query Only**Default:** N/A**Description:** Contains the results of the subblock measurements.**Return type:** SubblockMeasurementResults

:FETch:LTE:RESults<i>:SEM:SBlock<i>:MEAS:ALL**Availability:** Query Only**Default:** N/A**Description:** Returns string with results for NRModAccCarrier.**Return type:** String

:FETch:LTE:RESults<i>:SEM:SBlock<i>:MEAS:FREquency**Availability:** Query Only**Default:** NaN**Description:** Contains the absolute center frequency of the subblock. This value is the center of the subblock integration bandwidth.**Return type:** Double

:FETch:LTE:RESults<i>:SEM:SBlock<i>:MEAS:IBANDwidth**Availability:** Query Only**Default:** NaN**Description:** Contains the integration bandwidth used in calculating the power of the subblock. Integration bandwidth is the span from left edge of the leftmost carrier to the right edge of the rightmost carrier within a subblock.**Return type:** Double

:FETch:LTE:RESults<i>:SEM:SBlock<i>:MEAS:POWER**Availability:** Query Only**Default:** NaN**Description:** Contains the sum of powers of all the frequency bins over the integration bandwidth of the subblock.**Return type:** Double

:FETch:LTE:RESults<i>:SEM:SBlock<i>:OFFSet:MARGin**Availability:** Query Only**Default:** N/A**Description:** Builds the offset margin results.**Return type:** [<LowerOffsetMargins>,...], [<UpperOffsetMargins>,...]

:FETch:LTE:RESults<i>:SEM:SBlock<i>:OFFSet:MARGin:LOWer<i>**Availability:** Query Only**Default:** N/A**Description:** Contains the results of the lower offset margin results.**Return type:** <Margin_dB>, <MarginFrequency_Hz>, <MarginAbsolutePower_dBm>, <MarginRelativePower_dB>, <StatusOfMeasurement>

:FETch:LTE:RESults<i>:SEM:SBlock<i>:OFFSet:MARGin:LOWer<i>:FREQuency**Availability:** Query Only**Default:** N/A**Description:** Contains the array of frequency at which the margin occurs in the lower (negative) offset. For the intra-band noncontiguous type of carrier aggregation, the offset segment may be truncated or discarded based on offset overlap rules as defined in the 3GPP TS 36.521 specification. If the offset segment is truncated, the SEM results lower offset start frequency and SEM results lower offset stop frequency are updated, and the measurement is performed on the updated offset segment. If the offset segment is discarded, a NaN is returned.**Return type:** Double

:FETch:LTE:RESults<i>:SEM:SBlock<i>:OFFSet:MARGin:LOWer<i>:MARGin**Availability:** Query Only**Default:** N/A**Description:** Contains the array of margins from the standard-defined absolute limit mask for the lower (negative) offset. Margin is defined as the minimum difference between the spectrum and the limit mask. For the intra-band noncontiguous type of carrier aggregation, the offset segment may be truncated or discarded based on offset overlap rules as defined in the 3GPP TS 36.521 specification. If the offset segment is truncated, the SEM results lower offset start frequency and SEM results lower offset stop frequency are updated, and the measurement is performed on the updated offset segment. If the offset segment is discarded, a NaN is returned.**Return type:** Double

:FETch:LTE:RESults<i>:SEM:SBlock<i>:OFFSet:MARGin:LOWer<i>:POWER:ABSolute**Availability:** Query Only**Default:** N/A**Description:** Contains the array of power at which the margin occurs in the upper (positive) offset segment. For the intra-band noncontiguous type of carrier aggregation, the offset segment may be truncated or discarded based on offset overlap rules as defined in the 3GPP TS 36.521 specification. If the offset segment is truncated, the SEM results lower offset start frequency and SEM results lower offset stop frequency are updated, and the measurement is performed on the updated offset segment. If the offset segment is discarded, a NaN is returned.**Return type:** Double

:FETch:LTE:RESults<i>:SEM:SBlock<i>:OFFSet:MARGin:LOWer<i>:POWER:RELative**Availability:** Query Only**Default:** N/A

Description: Contains the array of powers at which the margin occurs in the upper (positive) offset segment relative to the value of TotalAggregatedPower. For the intra-band noncontiguous type of carrier aggregation, the offset segment may be truncated or discarded based on offset overlap rules as defined in the 3GPP TS 36.521 specification. If the offset segment is truncated the measurement is performed on the updated offset segment. If the offset segment is discarded, a NaN is returned.

Return type: Double

:FETch:LTE:RESults<i>:SEM:SBlock<i>:OFFSet:MARGin:LOWer<i>:STATus**Availability:** Query Only**Default:** N/A

Description: Contains the array of the measurement status indicating whether the power before and after the burst is within the standard defined limit.

Return type: Boolean

:FETch:LTE:RESults<i>:SEM:SBlock<i>:OFFSet:MARGin:UPPer<i>**Availability:** Query Only**Default:** N/A

Description: Contains the results of the upper offset margin.

Return type: <Margin_dB>, <MarginFrequency_Hz>, <MarginAbsolutePower_dBm>, <MarginRelativePower_dB>, <StatusOfMeasurement>

:FETch:LTE:RESults<i>:SEM:SBlock<i>:OFFSet:MARGin:UPPer<i>:FREQuency**Availability:** Query Only**Default:** N/A

Description: Contains the array of frequency at which the margin occurs in the lower (negative) offset. For the intra-band noncontiguous type of carrier aggregation, the offset segment may be truncated or discarded based on offset overlap rules as defined in the 3GPP TS 36.521 specification. If the offset segment is truncated, the SEM results lower offset start frequency and SEM results lower offset stop frequency are updated, and the measurement is performed on the updated offset segment. If the offset segment is discarded, a NaN is returned.

Return type: Double

:FETch:LTE:RESults<i>:SEM:SBlock<i>:OFFSet:MARGin:UPPer<i>:MARGin**Availability:** Query Only**Default:** N/A

Description: Contains the array of margins from the standard-defined absolute limit mask for the lower (negative) offset. Margin is defined as the minimum difference between the spectrum and the limit mask. For the intra-band noncontiguous type of carrier aggregation, the offset segment may be truncated or discarded based on offset overlap rules as defined in the 3GPP TS 36.521 specification. If the offset segment is truncated, the SEM results lower offset start frequency and SEM results lower offset stop frequency are updated, and the measurement is performed on the updated offset segment. If the offset segment is discarded, a NaN is returned.

Return type: Double

:FETch:LTE:RESults<i>:SEM:SBlock<i>:OFFSet:MARGin:UPPer<i>:POWer:ABSolute**Availability:** Query Only**Default:** N/A

Description: Contains the array of power at which the margin occurs in the upper (positive) offset segment. For the intra-band noncontiguous type of carrier aggregation, the offset segment may be truncated or discarded based on offset overlap rules as defined in the 3GPP TS 36.521 specification. If the offset segment is truncated, the SEM results lower offset start frequency and SEM results lower offset stop frequency are updated, and the measurement is performed on the updated offset segment. If the offset segment is discarded, a NaN is returned.

Return type: Double

:FETch:LTE:RESults<i>:SEM:SBlock<i>:OFFSet:MARGin:UPPer<i>:POWer:RELative**Availability:** Query Only**Default:** N/A

Description: Contains the array of powers at which the margin occurs in the upper (positive) offset segment relative to the value of TotalAggregatedPower. For the intra-band noncontiguous type of carrier aggregation, the offset segment may be truncated or discarded based on offset overlap rules as defined in the 3GPP TS 36.521 specification. If the offset segment is truncated the measurement is performed on the updated offset segment. If the offset segment is discarded, a NaN is returned.

Return type: Double

:FETch:LTE:RESults<i>:SEM:SBlock<i>:OFFSet:MARGin:UPPer<i>:STATus**Availability:** Query Only**Default:** N/A

Description: Contains the array of the measurement status indicating whether the power before and after the burst is within the standard defined limit.

Return type: Boolean

:FETch:LTE:RESults<i>:SEM:SBlock<i>:OFFSet:POWer**Availability:** Query Only**Default:** N/A

Description: Builds the offset power results.

Return type: [<LowerOffsetPowers>,...], [<UpperOffsetPowers>,...]

:FETch:LTE:RESults<i>:SEM:SBlock<i>:OFFSet:POWer:LOWer<i>**Availability:** Query Only**Default:** N/A

Description: Contains the results of the lower offset power measurements.

Return type: <PeakFrequency_Hz>, <RelativePeakPower_dBm
AbsolutePeakPower_dBm>, <RelativeIntegratedPower_dBm>,
<AbsoluteIntegratedPower_dBm>

:FETch:LTE:RESults<i>:SEM:SBlock<i>:OFFSet:POWer:LOWer<i>:FREQuency**Availability:** Query Only**Default:** N/A

Description: Peak frequency in Hz.

Return type: Double

:FETch:LTE:RESults<i>:SEM:SBlock<i>:OFFSet:POWer:LOWer<i>:IPOWer:ABSolute**Availability:** Query Only**Default:** N/A

Description: Contains the array of lower (negative) offset segment powers. For the intra-band noncontiguous type of carrier aggregation, the offset segment may be truncated or discarded based on offset overlap rules as defined in the 3GPP TS 36.521 specification. If the offset segment is truncated the measurement is performed on the updated offset segment. If the offset segment is discarded, a NaN is returned.

Return type: Double

:FETch:LTE:RESults<i>:SEM:SBlock<i>:OFFSet:POWer:LOWer<i>:IPOWer:RELative**Availability:** Query Only**Default:** N/A

Description: Carrier power values relative to the total carrier power of all enabled carriers. This value is expressed in dB.

Return type: Double

:FETch:LTE:RESults<i>:SEM:SBlock<i>:OFFSet:POWer:LOWer<i>:POWer:ABSolute**Availability:** Query Only**Default:** N/A

Description: Absolute peak power in dBm.

Return type: Double

:FETch:LTE:RESults<i>:SEM:SBlock<i>:OFFSet:POWer:LOWer<i>:POWer:RELative**Availability:** Query Only**Default:** N/A

Description: Contains the array of peak power in the upper (positive) offset segment relative to the value returned by the SEM Results Total Aggregated Pwr method. For the intra-band noncontiguous type of carrier aggregation, the offset segment may be truncated or discarded based on offset overlap rules as defined in the 3GPP TS 36.521 specification. If the offset segment is truncated the measurement is performed on the updated offset segment. If the offset segment is discarded, a NaN is returned.

Return type: Double

:FETch:LTE:RESults<i>:SEM:SBlock<i>:OFFSet:POWer:UPPer<i>**Availability:** Query Only**Default:** N/A

Description: Contains the results of the upper offset power results.

Return type: <PeakFrequency_Hz>, <RelativePeakPower_dBm
AbsolutePeakPower_dBm>, <RelativeIntegratedPower_dBm>,
<AbsoluteIntegratedPower_dBm>

:FETch:LTE:RESults<i>:SEM:SBlock<i>:OFFSet:POWer:UPPer<i>:FREQuency**Availability:** Query Only**Default:** N/A

Description: Peak frequency in Hz.

Return type: Double

:FETch:LTE:RESults<i>:SEM:SBlock<i>:OFFSet:POWer:UPPer<i>:IPOWer:ABSolute**Availability:** Query Only**Default:** N/A

Description: Contains the array of lower (negative) offset segment powers. For the intra-band noncontiguous type of carrier aggregation, the offset segment may be truncated or discarded based on offset overlap rules as defined in the 3GPP TS 36.521 specification. If the offset segment is truncated the measurement is performed on the updated offset segment. If the offset segment is discarded, a NaN is returned.

Return type: Double

:FETch:LTE:RESults<i>:SEM:SBlock<i>:OFFSet:POWer:UPPer<i>:IPOWer:RELative**Availability:** Query Only**Default:** N/A

Description: Carrier power values relative to the total carrier power of all enabled carriers. This value is expressed in dB.

Return type: Double

:FETch:LTE:RESults<i>:SEM:SBlock<i>:OFFSet:POWer:UPPer<i>:POWer:ABSolute**Availability:** Query Only**Default:** N/A

Description: Absolute peak power in dBm.

Return type: Double

:FETch:LTE:RESults<i>:SEM:SBlock<i>:OFFSet:POWer:UPPer<i>:POWer:RELative**Availability:** Query Only**Default:** N/A

Description: Contains the array of peak power in the upper (positive) offset segment relative to the value returned by the SEM Results Total Aggregated Pwr method. For the intra-band noncontiguous type of carrier aggregation, the offset segment may be truncated or discarded based on offset overlap rules as defined in the 3GPP TS 36.521 specification. If the offset segment is truncated the measurement is performed on the updated offset segment. If the offset segment is discarded, a NaN is returned.

Return type: Double

:FETch:LTE:RESults<i>:SEM:SBlock<i>:POWer:TOTal**Availability:** Query Only**Default:** NaN

Description: Contains the sum of powers of all the subblocks. This value includes the power in the inter-carrier gaps within a subblock, but it does not include the power in the subblock gaps.

Return type: Double

:FETch:LTE:RESults<i>:SEM:SBlock<i>:STATus**Availability:** Query Only**Default:** 0

Description: Contains the measurement status indicating whether the power before and after the burst is within the standard defined limit.

Return type: Boolean

:FETch:LTE:RESults<i>:SLOT:PHASe:SBlock<i>:PHASe:DISContinuity:MAX**Availability:** Query Only**Default:** NaN

Description: Gets the maximum value of phase difference at the slot boundaries within the SlotPhaseMeasurementLength. This value is expressed in degrees.

Return type: Double

:FETch:LTE:RESults<i>:SLOT:PHASe:SBlock<i>:PHASe:DISContinuity<i>**Availability:** Query Only**Default:** N/A**Description:** Fetches the array of phase differences at slot boundaries within measurement interval.**Return type:** Double

:FETch:LTE:RESults<i>:SLOT:POWER:SBlock<i>:SFRame:POWER:DELTA<i>**Availability:** Query Only**Default:** N/A**Description:** Contains the array of subframe power delta values over the measurement interval. Subframe power delta values are the power difference between the two consecutive subframes. The values are expressed in dB.**Return type:** Double

:FETch:LTE:RESults<i>:SLOT:POWER:SBlock<i>:SFRame:POWER<i>**Availability:** Query Only**Default:** N/A**Description:** Contains the array of subframe power values over the measurement interval. The values are expressed in dBm.**Return type:** Double

:LTE:FETch <resultSpace>**Availability:** Command and Query**Default:** N/A**Description:** Fetch LTE results**Parameters:** <resultSpace> Int32

:LTE:INITiate <resultSpace>**Availability:** Command Only**Default:** N/A**Description:** Initiate LTE parameters**Parameters:** <resultSpace> Int32

:LTE:MEASurement:STATe**Availability:** Query Only**Default:** N/A**Description:** Returns the current state of the measurement.**Return type:** READY | PROCESSING | OFF | PENDING | ACTIVE

:LTE:RESet**Availability:** Command Only**Default:** N/A**Description:** Reset LTE parameters.

:TRIGger:LTE:DELAy <TriggerDelay_sec>**Availability:** Command and Query**Default:** N/A**Description:** Specifies the delay (in seconds) between the trigger onset and the start of data acquisition.**Parameters:** <TriggerDelay_sec> Double

:TRIGger:LTE:EDGE <TriggerEdge>

Availability: Command and Query **Default:** RISING

Description: Specifies whether to trigger on the rising or falling edge for digital or power triggering.

Parameters: <TriggerEdge> RISING | FALLING

:TRIGger:LTE:MQTime <TriggerMinQuietDuration_sec>

Availability: Command and Query **Default:** N/A

Description: Specifies the Minimum Quiet Time between triggers. Negative value (e.g. -1) enables automatic duration.

Parameters: <TriggerMinQuietDuration_sec> Double

:TRIGger:LTE:SOURce <TriggerSource>

Availability: Command and Query **Default:** IMMEDIATE

Description: Specifies the trigger source.

Parameters: <TriggerSource> IMM | RF0 | VIDEO | GENERATOR |
INTERNAL | IMMEDIATE

:TRIGger:LTE:THReshold <TriggerThreshold>

Availability: Command and Query **Default:** -20

Description: Specifies the trigger threshold to use when power triggering. Absolute level type is in dBm, relative level type (to reference level) is in dB.

Parameters: <TriggerThreshold> Double

:TRIGger:LTE:TOUT <TriggerTimeout_sec>

Availability: Command and Query **Default:** 10

Description: Specifies the trigger timeout in seconds.

Parameters: <TriggerTimeout_sec> Double

5. NR

:CONFigure:NR:ACP:ACType <AcpAmplitudeCorrectionType>

Availability: Command and Query **Default:** RFCenterFreq

Description: Sets whether the amplitude of the frequency bins, used in measurements, is corrected for external attenuation at the RF center frequency, or at the individual frequency bins. Use the RFmxInstr_CfgExternalAttenuationTable function to configure the external attenuation table.

Parameters: <AcpAmplitudeCorrectionType> RFCenterFreq | SpectrumFrequencyBin

:CONFigure:NR:ACP:AVG:COUNT <AcpAveragingCount>

Availability: Command and Query **Default:** 10

Description: Sets the number of acquisitions used for averaging when Acp averaging is enabled.

Parameters: <AcpAveragingCount> Int32

:CONFigure:NR:ACP:AVG:ENABLE <AcpAveragingEnable>

Availability: Command and Query **Default:** 0

Description: Sets whether to enable averaging for the ACP measurement.

Parameters: <AcpAveragingEnable> Boolean

:CONFigure:NR:ACP:AVG:TYPE <AcpAveragingType>

Availability: Command and Query **Default:** Rms

Description: Sets the averaging type for averaging multiple spectrum acquisitions. The averaged spectrum is used for ACP measurement.

Parameters: <AcpAveragingType> Rms | Log | Scalar | Max | Min | Vector

:CONFigure:NR:ACP:ENABLE <AcpEnable>

Availability: Command and Query **Default:** 1

Description: Sets whether to enable the ACP measurement.

Parameters: <AcpEnable> Boolean

:CONFigure:NR:ACP:IF:OPower:FAR <AcpFarIfOutputPowerOffset_dB>

:CONFigure:NR:ACP:IF:OPower:FAR:OFFSet <AcpFarIfOutputPowerOffset_dB>

Availability: Command and Query **Default:** N/A

Description: Sets the offset that is needed to adjust the IF output power levels for the offset channels that are far from the carrier channel to improve the dynamic range. This value is expressed in dB. This method is applicable only when user sets the AcplfOutputPowerOffsetAuto to False and AcpMeasurementMethod to DynamicRange.

Parameters: <AcpFarIfOutputPowerOffset_dB> Double

:CONFigure:NR:ACP:IF:OPower:FAR:AUTO <AcplfOutputPowerOffsetAuto>

Availability: Command and Query **Default:** 1

Description: Sets whether the measurement computes an appropriate IF output power level offset for the offset channels to improve the dynamic range of the ACP measurement. This method is applicable only when user sets the AcpMeasurementMethod to DynamicRange.

Parameters: <AcplfOutputPowerOffsetAuto> Boolean

:CONFigure:NR:ACP:IF:OPower:NEAR <AcpNearlfOutputPowerOffset_dB>**:CONFigure:NR:ACP:IF:OPower:NEAR:OFFSet <AcpNearlfOutputPowerOffset_dB>**

Availability: Command and Query **Default:** 10

Description: Sets the offset that is needed to adjust the IF output power levels for the offset channels that are near the carrier channel to improve the dynamic range. This value is expressed in dB. This method is applicable only when user sets the AcplfOutputPowerOffsetAuto to False and AcpMeasurementMethod to DynamicRange.

Parameters: <AcpNearlfOutputPowerOffset_dB> Double

:CONFigure:NR:ACP:METHod <AcpMeasurementMethod>

Availability: Command and Query **Default:** NORM

Description: Sets the method for performing the ACP measurement.

Parameters: <AcpMeasurementMethod> NORM | DYNrange | SEQFFT

:CONFigure:NR:ACP:NComp:ENABLE <AcpNoiseCompensationEnable>

Availability: Command and Query **Default:** 0

Description: Sets whether to enable compensation of the channel powers for the inherent noise floor of the signal analyzer.

Parameters: <AcpNoiseCompensationEnable> Boolean

:CONFigure:NR:ACP:NOFFsets:EUTRa <AcpNumberOfEutraOffsets>

Availability: Command and Query **Default:** 0

Description: Sets the number of evolved universal terrestrial radio access (E-UTRA) adjacent channel offsets to be configured at offset positions. For uplink ACP measurement, and for downlink ACP measurement in frequency range 2, this method has to be 0.

Parameters: <AcpNumberOfEutraOffsets> Int32

:CONFigure:NR:ACP:NOFFsets:UTRa <AcpNumberOfUtraOffsets>

Availability: Command and Query **Default:** 2

Description: Sets the number of universal terrestrial radio access (UTRA) adjacent channel offsets to be configured at offset positions. For uplink ACP measurement in frequency range 2, and for downlink ACP measurement, the ACP Num UTRA Offsets has to be 0.

Parameters: <AcpNumberOfUtraOffsets> Int32

:CONFigure:NR:ACP:NR <AcpNumberOfNROffsets>

Availability: Command and Query **Default:** 1

Description: Sets the number of NR adjacent channel offsets to be configured at offset positions.

Parameters: <AcpNumberOfNROffsets> Int32

:CONFigure:NR:ACP:NTHReads <AcpNumberOfAnalysisThreads>

Availability: Command and Query **Default:** 1

Description: Sets the maximum number of threads used for parallelism for the ACP measurement.

Parameters: <AcpNumberOfAnalysisThreads> Int32

:CONFigure:NR:ACP:POWER:UNITs <AcpPowerUnits>

Availability: Command and Query **Default:** dBm

Description: Unit for absolute power.

Parameters: <AcpPowerUnits> dBm | dBmByHz

:CONFigure:NR:ACP:RBW:BW <AcpRbwBandwidth_Hz>

Availability: Command and Query **Default:** 3720

Description: Sets the bandwidth of the RBW filter, used to sweep the acquired signal, when user sets the AcpRbwAutoBandwidth to False. This value is expressed in Hz.

Parameters: <AcpRbwBandwidth_Hz> Double

:CONFigure:NR:ACP:RBW:BWAUTO <AcpRbwAutoBandwidth>

Availability: Command and Query **Default:** 1

Description: Sets whether the measurement computes the RBW.

Parameters: <AcpRbwAutoBandwidth> Boolean

:CONFigure:NR:ACP:RBW:FILTter <AcpRbwFilterType>

Availability: Command and Query **Default:** FFT

Description: Sets the shape of the RBW filter.

Parameters: <AcpRbwFilterType> FFT | GAUSSIAN | FLAT | ST4 | ST5

:CONFigure:NR:ACP:SFFT:SIZE <AcpSequentialFftSize>

Availability: Command and Query **Default:** 512

Description: Sets the number of bins to be used for FFT computation, when user sets the AcpMeasurementMethod to SequentialFft.

Parameters: <AcpSequentialFftSize> Int32

:CONFigure:NR:ACP:SWEep:AUTO <AcpSweepTimeAuto>

Availability: Command and Query **Default:** 1

Description: Sets whether the measurement sets the sweep time.

Parameters: <AcpSweepTimeAuto> Boolean

:CONFigure:NR:ACP:SWEep:INTerval <AcpSweepTimeInterval_s>

Availability: Command and Query **Default:** 0.001

Description: Sets the sweep time when user sets the AcpSweepTimeAuto to False. This value is expressed in seconds.

Parameters: <AcpSweepTimeInterval_s> Double

:CONFigure:NR:ACP:TRACe:ENABle <AcpAllTracesEnable>

Availability: Command and Query **Default:** 0

Description: Sets whether to enable the traces to be stored and retrieved after performing the ACP measurement.

Parameters: <AcpAllTracesEnable> Boolean

:CONFigure:NR:ANTenna <TransmitAntennaToAnalyze>

Availability: Command and Query **Default:** 0

Description: Sets the physical antenna that is currently connected to the analyzer.

Parameters: <TransmitAntennaToAnalyze> Int32

:CONFigure:NR:CHP:ACType <ChpAmplitudeCorrectionType>

Availability: Command and Query **Default:** RFCenterFreq

Description: Sets whether the amplitude of frequency bins in the spectrum used by the measurement is corrected for external attenuation at RF center frequency or corrected for external attenuation at individual frequency bins Use the RFmxInstr_CfgExternalAttenuationTable function to configure the external attenuation table.

Parameters: <ChpAmplitudeCorrectionType> RFCenterFreq | SpectrumFrequencyBin

:CONFigure:NR:CHP:AVG:COUNt <ChpAveragingCount>

Availability: Command and Query **Default:** 10

Description: Sets the number of acquisitions used for averaging when Chp averaging is enabled.

Parameters: <ChpAveragingCount> Int32

:CONFigure:NR:CHP:AVG:ENABle <ChpAveragingEnable>

Availability: Command and Query **Default:** 0

Description: Sets whether to enable averaging for the CHP measurement.

Parameters: <ChpAveragingEnable> Boolean

:CONFigure:NR:CHP:AVG:TYPE <ChpAveragingType>

Availability: Command and Query **Default:** Rms

Description: Sets the averaging type for averaging multiple spectrum acquisitions. The averaged spectrum is used for CHP measurement.

Parameters: <ChpAveragingType> Rms | Log | Scalar | Max | Min | Vector

:CONFigure:NR:CHP:ENABle <ChpEnable>

Availability: Command and Query **Default:** 1

Description: Sets whether to enable the channel power measurement.

Parameters: <ChpEnable> Boolean

:CONFigure:NR:CHP:NTHReads <ChpNumberOfAnalysisThreads>

Availability: Command and Query **Default:** 1

Description: Sets the maximum number of threads used for parallelism for the CHP measurement. The number of threads can range from 1 to the number of physical cores. The number of threads you set may not be used in calculations. The actual number of threads used depends on the problem size, system resources, data availability, and other considerations.

Parameters: <ChpNumberOfAnalysisThreads> Int32

:CONFigure:NR:CHP:RBW:BW <ChpRbwBandwidth_Hz>

Availability: Command and Query **Default:** 3720

Description: Sets the bandwidth of the RBW filter, used to sweep the acquired signal, when user sets the ChpRbwAutoBandwidth to False. This value is expressed in Hz.

Parameters: <ChpRbwBandwidth_Hz> Double

:CONFigure:NR:CHP:RBW:BWAUTO <ChpRbwAutoBandwidth>

Availability: Command and Query **Default:** 1

Description: Sets whether the measurement computes the RBW.

Parameters: <ChpRbwAutoBandwidth> Boolean

:CONFigure:NR:CHP:RBW:FILTER <ChpRbwFilterType>

Availability: Command and Query **Default:** FFT

Description: Sets the shape of the digital RBW filter.

Parameters: <ChpRbwFilterType> FFT | GAUSSIAN | FLAT | ST4 | ST5

:CONFigure:NR:CHP:SWEep:AUTO <ChpSweepTimeAuto>

Availability: Command and Query **Default:** 1

Description: Sets whether the measurement sets the sweep time.

Parameters: <ChpSweepTimeAuto> Boolean

:CONFigure:NR:CHP:SWEep:INTERval <ChpSweepTimeInterval_s>

Availability: Command and Query **Default:** 0.001

Description: Sets the sweep time when user sets the ChpSweepTimeAuto method to False. This value is expressed in seconds.

Parameters: <ChpSweepTimeInterval_s> Double

:CONFigure:NR:CHP:TRACe:ENABLE <ChpAllTracesEnable>

Availability: Command and Query **Default:** 0

Description: Sets whether to enable the traces to be stored and retrieved after performing the CHP measurement.

Parameters: <ChpAllTracesEnable> Boolean

:CONFigure:NR:COMPensation:PHASe <PhaseCompensation>

Availability: Command and Query **Default:** Disabled

Description: Sets whether phase compensation is disabled, auto-set by the measurement or set by you.

Parameters: <PhaseCompensation> Disabled | Auto | UserDefined

:CONFigure:NR:GNB:CATegory <gNodeBCategory>

Availability: Command and Query **Default:** WideAreaBaseStationCategoryA

Description: Sets the downlink gNodeB (base station) category. Refer to the 3GPP 38.104 specification for more information about gNodeB category.

Parameters: <gNodeBCategory> WideAreaBaseStationCategoryA |
WideAreaBaseStationCategoryBOption1
|
WideAreaBaseStationCategoryBOption2
| LocalAreaBaseStation |
MediumRangeBaseStation

:CONFigure:NR:GNODEb:TYPE <GNodeBType>

Availability: Command and Query **Default:** Type1C

Description: Downlink gNodeB (Base Station) type. Refer to the 3GPP 38.104 specification for more information about gNodeB Type.

Parameters: <GNodeBType> Type1C | Type1H | Type1O | Type2O

:CONFigure:NR:GRId:SIZE:MODE <GridSizeMode>

Availability: Command and Query **Default:** Auto

Description: Grid size of all BWPs and SSB in a component carrier automatically or manually.

Parameters: <GridSizeMode> Manual | Auto

:CONFigure:NR:LINK:DIRection <LinkDirection>

Availability: Command and Query **Default:** Uplink

Description: Sets the link direction of the received signal.

Parameters: <LinkDirection> Uplink | Downlink | Sidelink

:CONFigure:NR:MODacc:AVG:COUNT <ModAccAveragingCount>

Availability: Command and Query **Default:** 10

Description: Sets the number of acquisitions used for averaging when ModAcc averaging is enabled.

Parameters: <ModAccAveragingCount> Int32

:CONFigure:NR:MODacc:AVG:ENABLE <ModAccAveragingEnable>

Availability: Command and Query **Default:** 0

Description: Enables averaging for the measurement.

Parameters: <ModAccAveragingEnable> Boolean

:CONFigure:NR:MODacc:CClock:ENABLE <ModAccCommonClockSourceEnable>

Availability: Command and Query **Default:** 1

Description: Sets whether same reference clock is used for local oscillator and digital-to-analog converter. When same reference clock is used the Carrier Frequency Offset is proportional to Sample Clock Error.

Parameters: <ModAccCommonClockSourceEnable> Boolean

:CONFigure:NR:MODacc:CEType <ModAccChannelEstimationType>

Availability: Command and Query **Default:** ReferenceAndData

Description: Sets the method used for channel estimation.

Parameters: <ModAccChannelEstimationType> Reference | ReferenceAndData

**:CONFigure:NR:MODacc:DC:SCRemoval:ENABLE
<ModAccDCSubcarrierRemovalEnable>**

Availability: Command and Query **Default:** 1

Description: Sets whether the DC subcarrier is removed from the EVM results.

Parameters: <ModAccDCSubcarrierRemovalEnable> Boolean

:CONFigure:NR:MODacc:ENABLE <ModAccEnable>

Availability: Command and Query **Default:** 1

Description: Sets whether to enable the ModAcc measurement.

Parameters: <ModAccEnable> Boolean

**:CONFigure:NR:MODacc:Evm:REference:DATA:SYMBOLs:MODE
<ModAccEvmReferenceDataSymbolsMode>**

Availability: Command and Query **Default:** AcquiredWaveform

Description: Sets whether to either use a reference waveform or an acquired waveform to create reference data symbols for EVM computation.

Parameters: <ModAccEvmReferenceDataSymbolsMode> AcquiredWaveform | ReferenceWaveform

:CONFigure:NR:MODacc:EVM:UNIT <ModAccEvmUnit>

Availability: Command and Query **Default:** Percentage

Description: Sets the units of the EVM results.

Parameters: <ModAccEvmUnit> Percentage | dB

:CONFigure:NR:MODacc:FERR:ESTimation <ModAccFrequencyErrorEstimation>

Availability: Command and Query **Default:** Normal

Description: Sets the operation mode of frequency error estimation. If frequency error is absent in the signal to be analyzed, you may disable frequency estimation to reduce measurement time or to avoid measurement inaccuracy due to error in frequency error estimation.

Parameters: <ModAccFrequencyErrorEstimation> Disabled | Normal | Wide

:CONFigure:NR:MODacc:FFT:WINDow <ModAccFftWindowType>
:CONFigure:NR:MODacc:FFT:WINDow:TYPE <ModAccFftWindowType>
Availability: Command and Query **Default:** TypeCustom
Description: Sets the FFT window type used for EVM calculation.
Parameters: <ModAccFftWindowType> Type3GPP | TypeCustom

:CONFigure:NR:MODacc:FFT:WINDow:LENGth <ModAccFftWindowLength_pct>
Availability: Command and Query **Default:** -1
Description: Sets the FFT window length (W). This value is expressed as a percentage of the cyclic prefix length. This method is used when user sets the ModAccFftWindowType to Type3GPP, where it is needed to calculate the EVM using two different FFT window positions, Delta_C-W/2, and Delta_C+W/2.
Parameters: <ModAccFftWindowLength_pct> Double

:CONFigure:NR:MODacc:FFT:WINDow:OFFSet <ModAccFftWindowOffset_pct>
Availability: Command and Query **Default:** 50
Description: Sets the position of the FFT window used to calculate the EVM when ModAccFftWindowType is set to TypeCustom. The offset is expressed as a percentage of the cyclic prefix length. If you set this method to 0, the EVM window starts at the end of cyclic prefix. If you set this method to 100, the EVM window starts at the beginning of cyclic prefix.
Parameters: <ModAccFftWindowOffset_pct> Double

:CONFigure:NR:MODacc:IQ:GAINImbalance:CORRection:ENABLE <ModAcclQGainImbalanceCorrectionEnabled>
Availability: Command and Query **Default:** 0
Description: Enable/Disable IQ gain imbalance correction
Parameters: <ModAcclQGainImbalanceCorrectionEnabled> Boolean

:CONFigure:NR:MODacc:IQ:IMPairments:ESTimation:ENABLE <ModAcctlQImpairmentsEstimationEnabled>
Availability: Command and Query **Default:** 0
Description: Enable/Disable IQ impairments estimation
Parameters: <ModAcctlQImpairmentsEstimationEnabled> Boolean

:CONFigure:NR:MODacc:IQ:IMPairments:MODEl <ModAcclQImpairmentsModel>
Availability: Command and Query **Default:** TX
Description: Specifies the I/Q impairments model used by the measurement for estimating I/Q impairments.
Parameters: <ModAcclQImpairmentsModel> TX | RX

:CONFigure:NR:MODacc:IQ:IMPairmentsersubcarrier:ENABLE <ModAcclQImpairmentsPerSubcarrierEnabled>
Availability: Command and Query **Default:** 0
Description: Enable/Disable IQ impairments per subcarrier
Parameters: <ModAcclQImpairmentsPerSubcarrierEnabled> Boolean

**:CONFigure:NR:MODacc:IQ:MISMatch:ESTimation:ENABLE
<ModAccIQMismatchEstimationEnabled>**

Availability: Command and Query **Default:** 1

Description: Enable/Disable IQ mismatch estimation

Parameters: <ModAccIQMismatchEstimationEnabled> Boolean

**:CONFigure:NR:MODacc:IQ:ORIGin:OFFSet:ESTimation:ENABLE
<ModAccIQOriginOffsetEstimationEnabled>**

Availability: Command and Query **Default:** 1

Description: Enable/Disable IQ origin offset estimation

Parameters: <ModAccIQOriginOffsetEstimationEnabled> Boolean

**:CONFigure:NR:MODacc:IQ:QERRor:CORRection:ENABLE
<ModAccIQQuadratureErrorCorrectionEnabled>**

Availability: Command and Query **Default:** 0

Description: Enable/Disable IQ quadrature error correction

Parameters: <ModAccIQQuadratureErrorCorrectionEnabled> Boolean

**:CONFigure:NR:MODacc:IQ:TIMingskew:CORRection:ENABLE
<ModAccIQTimingSkewCorrectionEnabled>**

Availability: Command and Query **Default:** 0

Description: Enable/Disable IQ timing skew correction

Parameters: <ModAccIQTimingSkewCorrectionEnabled> Boolean

**:CONFigure:NR:MODacc:MAGNitudeandphase:ERRor:ENABLE
<ModAccMagnitudeAndPhaseErrorEnabled>**

Availability: Command and Query **Default:** 1

Description: Sets the operation mode of frequency error estimation. If frequency error is absent in the signal to be analyzed, you may disable frequency estimation to reduce measurement time or to avoid measurement inaccuracy due to error in frequency error estimation.

Parameters: <ModAccMagnitudeAndPhaseErrorEnabled> Boolean

:CONFigure:NR:MODacc:MCFilter:ENABLE <ModAccMulticarrierFilterEnable>

Availability: Command and Query **Default:** 0

Description: Sets whether to use the filter in single carrier configurations to minimize leakage into the carrier.

Parameters: <ModAccMulticarrierFilterEnable> Boolean

:CONFigure:NR:MODacc:MEASurement:LENgth <ModAccMeasLength>

Availability: Command and Query **Default:** 1

Description: Sets the measurement length in units specified by Measurement Length Unit method.

Parameters: <ModAccMeasLength> Double

:CONFigure:NR:MODacc:MEASurement:MODE <ModAccMeasurementMode>

Availability: Command and Query **Default:** Measure

Description: Sets whether the measurement should calibrate the noise floor of the analyzer or perform the ModAcc measurement.

Parameters: <ModAccMeasurementMode> CalibrateNoiseFloor | Measure

:CONFigure:NR:MODacc:MEASurement:OFFSet <ModAccMeasOffset>

Availability: Command and Query **Default:** 0

Description: Sets the measurement offset to skip from the synchronization boundary. The synchronization boundary is specified by the method. The unit for this is specified by ModAcc Measurement Length Unit.

Parameters: <ModAccMeasOffset> Double

:CONFigure:NR:MODacc:MEASurement:UNIT <ModAccMeasLengthUnit>

Availability: Command and Query **Default:** Slot

Description: Sets the units in which measurement offset and measurement length are specified.

Parameters: <ModAccMeasLengthUnit> Slot | Subframe | Time

:CONFigure:NR:MODacc:NTHReads <ModAccNumberOfAnalysisThreads>

Availability: Command and Query **Default:** 1

Description: Sets the maximum number of threads used for parallelism for the ModAcc measurement.

Parameters: <ModAccNumberOfAnalysisThreads> Int32

:CONFigure:NR:MODacc:SFCCondition <ModAccSpectralFlattness>

Availability: Command and Query **Default:** Normal

Description: Sets the test condition for Spectral Flatness measurement.

Parameters: <ModAccSpectralFlattness> Normal | Extreme

:CONFigure:NR:MODacc:SINVerted <ModAccSpectrumInverted>

Availability: Command and Query **Default:** 0

Description: Sets whether the spectrum of the signal being measured is inverted. This happens when I and Q component of the baseband complex signal is swapped.

Parameters: <ModAccSpectrumInverted> Boolean

**:CONFigure:NR:MODacc:SYMBOL:CERRor:ESTimation:ENABLE
<ModAccSymbolClockErrorEstimationEnabled>**

Availability: Command and Query **Default:** 1

Description: Enable/Disable symbol clock error estimation

Parameters: <ModAccSymbolClockErrorEstimationEnabled> Boolean

:CONFigure:NR:MODacc:SYNC <ModAccSyncMode>

Availability: Command and Query **Default:** Slot

Description: Sets whether the measurement is performed from slot or frame boundary.

Parameters: <ModAccSyncMode> Frame | Slot

:CONFigure:NR:MODacc:TRACe:ENABle <ModAccAllTracesEnable>

Availability: Command and Query **Default:** 0

Description: Sets whether to enable the traces to be stored and retrieved after performing the ModAcc measurement.

Parameters: <ModAccAllTracesEnable> Boolean

:CONFigure:NR:MODacc:TRACking:PHASe <ModAccPhaseTrackingEnabled>

Availability: Command and Query **Default:** 1

Description: Sets whether phase tracking is enabled.

Parameters: <ModAccPhaseTrackingEnabled> Boolean

:CONFigure:NR:MODacc:TRACking:TIME <ModAccTimingTrackingEnabled>

Availability: Command and Query **Default:** 1

Description: Sets whether timing tracking is enabled.

Parameters: <ModAccTimingTrackingEnabled> Boolean

:CONFigure:NR:OBW:ACTYpe <ObwAmplitudeCorrectionType>

Availability: Command and Query **Default:** RFCenterFreq

Description: Sets whether the amplitude of frequency bins in the spectrum used by the measurement is corrected for external attenuation at RF center frequency or corrected for external attenuation at individual frequency bins. Use the RFmxInstr_CfgExternalAttenuationTable function to configure the external attenuation table.

Parameters: <ObwAmplitudeCorrectionType> RFCenterFreq | SpectrumFrequencyBin

:CONFigure:NR:OBW:AVG:COUNT <ObwAveragingCount>

Availability: Command and Query **Default:** 10

Description: Sets the number of acquisitions used for averaging when Obw averaging is enabled.

Parameters: <ObwAveragingCount> Int32

:CONFigure:NR:OBW:AVG:ENABle <ObwAveragingEnable>

Availability: Command and Query **Default:** 0

Description: Sets whether to enable averaging for the OBW measurement.

Parameters: <ObwAveragingEnable> Boolean

:CONFigure:NR:OBW:AVG:TYPE <ObwAveragingType>

Availability: Command and Query **Default:** Rms

Description: Sets the averaging type for averaging multiple spectrum acquisitions. The averaged spectrum is used for the OBW measurement.

Parameters: <ObwAveragingType> Rms | Log | Scalar | Max | Min | Vector

:CONFigure:NR:OBW:ENABle <ObwEnable>

Availability: Command and Query **Default:** 1

Description: Sets whether to enable the OBW measurement.

Parameters: <ObwEnable> Boolean

:CONFigure:NR:OBW:NTHReads <ObwNumberOfAnalysisThreads>

Availability: Command and Query **Default:** 1

Description: Sets the maximum number of threads used for parallelism for the OBW measurement. The number of threads can range from 1 to the number of physical cores. The number of threads you set may not be used in calculations. The actual number of threads used depends on the problem size, system resources, data availability, and other considerations.

Parameters: <ObwNumberOfAnalysisThreads> Int32

:CONFigure:NR:OBW:RBW:BW <ObwRbwBandwidth_Hz>

Availability: Command and Query **Default:** 10000

Description: Sets the bandwidth of the RBW filter used to sweep the acquired signal, when user sets the ObwRbwAutoBandwidth to False. This value is expressed in Hz.

Parameters: <ObwRbwBandwidth_Hz> Double

:CONFigure:NR:OBW:RBW:BWAUTO <ObwRbwAutoBandwidth>

Availability: Command and Query **Default:** 1

Description: Sets whether the measurement computes the RBW.

Parameters: <ObwRbwAutoBandwidth> Boolean

:CONFigure:NR:OBW:RBW:TYPE <ObwRbwFilterType>

Availability: Command and Query **Default:** GAUSSIAN

Description: Sets the shape of the digital RBW filter.

Parameters: <ObwRbwFilterType> FFT | GAUSSIAN | FLAT | ST4 | ST5

:CONFigure:NR:OBW:SWEep:AUTO <ObwSweepTimeAuto>

Availability: Command and Query **Default:** 1

Description: Sets whether the measurement sets the sweep time.

Parameters: <ObwSweepTimeAuto> Boolean

:CONFigure:NR:OBW:SWEep:INTERval <ObwSweepTimeInterval_s>

Availability: Command and Query **Default:** 0.001

Description: Sets the sweep time when user sets the ObwSweepTimeAuto to False. This value is expressed in seconds.

Parameters: <ObwSweepTimeInterval_s> Double

:CONFigure:NR:OBW:TRACe:ENABLE <ObwAllTracesEnable>

Availability: Command and Query **Default:** 0

Description: Sets whether to enable the traces to be stored and retrieved after performing the OBW measurement.

Parameters: <ObwAllTracesEnable> Boolean

:CONFigure:NR:POWClass <PowerClass>**Availability:** Command and Query **Default:** PowerClass_3**Description:** Sets the power class for the UE as specified in section 6.2 of 3GPP 38.101-1/2/3 specification.**Parameters:** <PowerClass> PowerClass_1 | PowerClass_2 |
PowerClass_3 | PowerClass_4

:CONFigure:NR:RBAuto:ENABLE <AutoResourceBlockDetectionEnabled>**Availability:** Command and Query **Default:** 1**Description:** Sets whether the values of modulation type, number of resource block clusters, resource block offsets, and number of resource blocks are auto-detected by the measurement or configured by you.**Parameters:** <AutoResourceBlockDetectionEnabled> Boolean

:CONFigure:NR:SBlock<i>:BAND <NRBand>**Availability:** Command and Query **Default:** 78**Description:** Sets the evolved universal terrestrial radio access (E-UTRA) or NR operating frequency band of a subblock as specified in section 5.2 of the 3GPP 38.101-1/2/3 specification. Band determines the spectral flatness mask and spectral emission mask.**Parameters:** <NRBand> Int32

:CONFigure:NR:SBlock<i>:CCARrier<i>:BW <CarrierChannelBandwidth>**Availability:** Command and Query **Default:** M100**Description:** Sets the channel bandwidth of the signal being measured. This value is expressed in Hz.**Parameters:** <CarrierChannelBandwidth> M5 | M10 | M15 | M20 | M25 | M30 |
M40 | M50 | M60 | M70 | M80 | M90 |
M100 | M200 | M400

:CONFigure:NR:SBlock<i>:CCARrier<i>:BWP:NUMBER <NumberOfBandwithParts>**Availability:** Command and Query **Default:** 1**Description:** Sets the number of bandwidth parts present in the component carrier.**Parameters:** <NumberOfBandwithParts> Int32

:CONFigure:NR:SBlock<i>:CCARrier<i>:BWP<i>:CPMode <CyclicPrefixMode>**Availability:** Command and Query **Default:** Normal**Description:** Sets the cyclic prefix (CP) duration and the number of symbols in a slot for the signal being measured.**Parameters:** <CyclicPrefixMode> Normal | Extended

:CONFigure:NR:SBlock<i>:CCARrier<i>:BWP<i>:GRID:START <GridStart>**Availability:** Command and Query **Default:** 0**Description:** Sets the resource grid start relative to Reference Point A in terms of resource block offset when user sets the Reference Grid Alignment Mode method to Manual.**Parameters:** <GridStart> Int32

:CONFigure:NR:SBLock<i>:CCARrier<i>:BWP<i>:RBNum <NumberOfRBs>

Availability: Command and Query **Default:** -1

Description: Sets the number of consecutive resource blocks in a bandwidth part.

Parameters: <NumberOfRBs> Int32

:CONFigure:NR:SBLock<i>:CCARrier<i>:BWP<i>:RBOffset <RBOffset>

Availability: Command and Query **Default:** 0

Description: Sets the resource block offset of a bandwidth part relative to the resource GridStart.

Parameters: <RBOffset> Int32

:CONFigure:NR:SBLock<i>:CCARrier<i>:BWP<i>:SCSPacing <SubcarrierSpacing>

Availability: Command and Query **Default:** k30

Description: Sets the subcarrier spacing of the bandwidth part used in the component carrier.

Parameters: <SubcarrierSpacing> k15 | k30 | k60 | k120

:CONFigure:NR:SBLock<i>:CCARrier<i>:BWP<i>:USER:NUMBER <NumberOfUsers>

Availability: Command and Query **Default:** 1

Description: Sets the number of users present in the bandwidth part.

Parameters: <NumberOfUsers> Int32

**:CONFigure:NR:SBLock<i>:CCARrier<i>:BWP<i>:USER<i>:PDsch:NUMBER
<NumberOfPdschConfiguration>**

Availability: Command and Query **Default:** 1

Description: Sets the number of PDSCH slot configurations.

Parameters: <NumberOfPdschConfiguration> Int32

**:CONFigure:NR:SBLock<i>:CCARrier<i>:BWP<i>:USER<i>:PDsch<i>:ALlocation:SLOT
<SlotAllocation>**

Availability: Command and Query **Default:** 0-Last

Description: Sets the slot allocation in NR Frame. This defines the indices of the allocated slots.

Parameters: <SlotAllocation> String

**:CONFigure:NR:SBLock<i>:CCARrier<i>:BWP<i>:USER<i>:PDsch<i>:ALlocation:SYMBOL
<SymbolAllocation>**

Availability: Command and Query **Default:** 0-Last

Description: Sets the symbol allocation of each slot allocation.

Parameters: <SymbolAllocation> String

**:CONFigure:NR:SBLock<i>:CCARrier<i>:BWP<i>:USER<i>:PDSCh<i>:CLUSter<i>:RBNum
<NumberOfRbs>**

Availability: Command and Query **Default:** 1

Description: Sets the number of clusters of resource allocations with each cluster including one or more consecutive resource blocks.

Parameters: <NumberOfRbs> Int32

**:CONFigure:NR:SBLock<i>:CCARrier<i>:BWP<i>:USER<i>:PDSCh<i>:CLUSter<i>:RBOffset
<RbOffset>**

Availability: Command and Query **Default:** 0

Description: Sets the starting resource block number of a PDSCH cluster.

Parameters: <RbOffset> Int32

**:CONFigure:NR:SBLock<i>:CCARrier<i>:BWP<i>:USER<i>:PDSCh<i>:DMRS:ANTenna:PORT
<DmrsAntennaPorts>**

Availability: Command and Query **Default:** 1000

Description: Sets the antenna ports used for DMRS transmission.

Parameters: <DmrsAntennaPorts> String

**:CONFigure:NR:SBLock<i>:CCARrier<i>:BWP<i>:USER<i>:PDSCh<i>:DMRS:CFG:TYPE
<DmrsConfigurationType>**

Availability: Command and Query **Default:** Type1

Description: Sets the configuration type of DMRS.

Parameters: <DmrsConfigurationType> Type1 | Type2

**:CONFigure:NR:SBLock<i>:CCARrier<i>:BWP<i>:USER<i>:PDSCh<i>:DMRS:MAPPING:APOSITION
<DmrsAdditionalPositions>**

Availability: Command and Query **Default:** 0

Description: Sets the number of additional sets of consecutive DMRS symbols in a slot.

Parameters: <DmrsAdditionalPositions> Int32

**:CONFigure:NR:SBLock<i>:CCARrier<i>:BWP<i>:USER<i>:PDSCh<i>:DMRS:MAPPING:DURATION
<DmrsDuration>**

Availability: Command and Query **Default:** SingleSymbol

Description: Sets whether the DMRS is single-symbol or double-symbol.

Parameters: <DmrsDuration> SingleSymbol | DoubleSymbol

**:CONFigure:NR:SBLock<i>:CCARrier<i>:BWP<i>:USER<i>:PDSCh<i>:DMRS:MAPPING:TYPE
<MappingType>**

Availability: Command and Query **Default:** TypeA

Description: Sets the mapping type of DMRS.

Parameters: <MappingType> TypeA | TypeB

**:CONFigure:NR:SBLock<i>:CCARrier<i>:BWP<i>:USER<i>:PDSCh<i>:DMRS:MAPPING:TYPE:A:PO
<DmrsTypeAPosition>**

Availability: Command and Query **Default:** 2

Description: Sets the position of first DMRS symbol in a slot for Type A configurations.

Parameters: <DmrsTypeAPosition> Int32

**:CONFigure:NR:SBLock<i>:CCARrier<i>:BWP<i>:USER<i>:PDSCh<i>:DMRS:NCDMgroups
<DmrsNumberOfCdmGroups>**

Availability: Command and Query **Default:** N/A

Description: Sets the number of CDM groups.

Parameters: <DmrsNumberOfCdmGroups> Int32

**:CONFigure:NR:SBLock<i>:CCARrier<i>:BWP<i>:USER<i>:PDSCh<i>:DMRS:NSCid
<DmrsScramblingIdMode>**

Availability: Command and Query **Default:** N/A

Description: Sets the value of scrambling ID used for reference signal generation.

Parameters: <DmrsScramblingIdMode> CellID | UserDefined

**:CONFigure:NR:SBLock<i>:CCARrier<i>:BWP<i>:USER<i>:PDSCh<i>:DMRS:POWer
<DmrsPower_dB>**

Availability: Command and Query **Default:** 0

Description: Sets the factor by which the PDSCH DMRS REs are boosted. This value is expressed in dB.

Parameters: <DmrsPower_dB> Double

**:CONFigure:NR:SBLock<i>:CCARrier<i>:BWP<i>:USER<i>:PDSCh<i>:DMRS:POWer:MODE
<DmrsPowerMode>**

Availability: Command and Query **Default:** CdmGroups

Description: Sets whether the value of DmrsPowerMode is calculated based on the DmrsNumberOfCdmGroups or specified by user.

Parameters: <DmrsPowerMode> CdmGroups | UserDefined

**:CONFigure:NR:SBLock<i>:CCARrier<i>:BWP<i>:USER<i>:PDSCh<i>:MODulation:TYPE
<ModulationType>**

Availability: Command and Query **Default:** Qpsk

Description: Sets the modulation scheme used in PDSCH channel of the signal being measured.

Parameters: <ModulationType> Qpsk | Qam16 | Qam64 | Qam256 |
Qam1024

**:CONFigure:NR:SBLock<i>:CCARrier<i>:BWP<i>:USER<i>:PDSCh<i>:PTRS:ENABLE
<PtrsEnabled>**

Availability: Command and Query **Default:** 0

Description: Sets whether PT-RS is present in the transmitted signal.

Parameters: <PtrsEnabled> Boolean

**:CONFigure:NR:SBLock<i>:CCARrier<i>:BWP<i>:USER<i>:PDSCh<i>:SSB
<PresentInSsbRb>**

Availability: Command and Query **Default:** 1

Description: Sets whether the subset of RBs for certain symbols in a slot are occupied by SS/PBCH resources depending on the SS/PBCH block configuration. If this method is enabled, PDSCH RBs are allocated in the remaining symbols of this RB subset. If this method is disabled, any RBs occupied by SS/PBCH resources are not allocated on all symbols in this slot.

Parameters: <PresentInSsbRb> Boolean

**:CONFigure:NR:SBLock<i>:CCARrier<i>:BWP<i>:USER<i>:PUSCh:NUMBER
<NumberOfPuschConfiguration>**

Availability: Command and Query **Default:** 1

Description: Sets the number of PUSCH slot configurations.

Parameters: <NumberOfPuschConfiguration> Int32

**:CONFigure:NR:SBLock<i>:CCARrier<i>:BWP<i>:USER<i>:PUSCh<i>:ALlocation:SLOT
<SlotAllocation>**

Availability: Command and Query **Default:** 0-Last

Description: Sets the slot allocation in NR Frame. This defines the indices of the allocated slots.

Parameters: <SlotAllocation> String

**:CONFigure:NR:SBLock<i>:CCARrier<i>:BWP<i>:USER<i>:PUSCh<i>:ALlocation:SYMBOL
<SymbolAllocation>**

Availability: Command and Query **Default:** 0-Last

Description: Sets the symbol allocation of each slot allocation.

Parameters: <SymbolAllocation> String

**:CONFigure:NR:SBLock<i>:CCARrier<i>:BWP<i>:USER<i>:PUSCh<i>:DMRS:ANTenna:PORT
<DmrsAntennaPorts>**

Availability: Command and Query **Default:** 0

Description: Sets the antenna ports used for DMRS transmission.

Parameters: <DmrsAntennaPorts> String

**:CONFigure:NR:SBLock<i>:CCARrier<i>:BWP<i>:USER<i>:PUSCh<i>:DMRS:CFG:TYPE
<DmrsConfigurationType>**

Availability: Command and Query **Default:** Type1

Description: Sets the configuration type of DMRS.

Parameters: <DmrsConfigurationType> Type1 | Type2

**:CONFigure:NR:SBLock<i>:CCARrier<i>:BWP<i>:USER<i>:PUSCh<i>:DMRS:MAPPING:APOSITION
<DmrsAdditionalPositions>**

Availability: Command and Query **Default:** 0

Description: Sets the number of additional sets of consecutive DMRS symbols in a slot.

Parameters: <DmrsAdditionalPositions> Int32

:CONFigure:NR:SBLock<i>:CCARrier<i>:BWP<i>:USER<i>:PUSCh<i>:DMRS:MAPPING:Duration<DmrsDuration>

Availability: Command and Query **Default:** SingleSymbol

Description: Sets whether the DMRS is single-symbol or double-symbol.

Parameters: <DmrsDuration> SingleSymbol | DoubleSymbol

:CONFigure:NR:SBLock<i>:CCARrier<i>:BWP<i>:USER<i>:PUSCh<i>:DMRS:MAPPING:TYPE<MappingType>

Availability: Command and Query **Default:** TypeA

Description: Sets the mapping type of DMRS.

Parameters: <MappingType> TypeA | TypeB

:CONFigure:NR:SBLock<i>:CCARrier<i>:BWP<i>:USER<i>:PUSCh<i>:DMRS:MAPPING:TYPE:A:Position<DmrsTypeAPosition>

Availability: Command and Query **Default:** 2

Description: Sets the position of first DMRS symbol in a slot for Type A configurations.

Parameters: <DmrsTypeAPosition> Int32

:CONFigure:NR:SBLock<i>:CCARrier<i>:BWP<i>:USER<i>:PUSCh<i>:DMRS:NCDMgroups<DmrsNumberOfCdmGroups>

Availability: Command and Query **Default:** 1

Description: Sets the number of CDM groups.

Parameters: <DmrsNumberOfCdmGroups> Int32

:CONFigure:NR:SBLock<i>:CCARrier<i>:BWP<i>:USER<i>:PUSCh<i>:DMRS:NSCid<DmrsScramblingIdMode>

Availability: Command and Query **Default:** N/A

Description: Sets the value of scrambling ID used for reference signal generation.

Parameters: <DmrsScramblingIdMode> CellID | UserDefined

:CONFigure:NR:SBLock<i>:CCARrier<i>:BWP<i>:USER<i>:PUSCh<i>:DMRS:POWER<DmrsPower_dB>

Availability: Command and Query **Default:** 0

Description: Sets the factor by which the PDSCH DMRS REs are boosted. This value is expressed in dB.

Parameters: <DmrsPower_dB> Double

:CONFigure:NR:SBLock<i>:CCARrier<i>:BWP<i>:USER<i>:PUSCh<i>:DMRS:POWER:MODE<DmrsPowerMode>

Availability: Command and Query **Default:** CdmGroups

Description: Sets whether the value of DmrsPowerMode is calculated based on the DmrsNumberOfCdmGroups or specified by user.

Parameters: <DmrsPowerMode> CdmGroups | UserDefined

**:CONFigure:NR:SBLock<i>:CCARrier<i>:BWP<i>:USER<i>:PUSCh<i>:MODulation:TYPE
<ModulationType>**

Availability: Command and Query **Default:** Qpsk

Description: Sets the modulation scheme used in PDSCH channel of the signal being measured.

Parameters: <ModulationType> PiBy2_Bpsk | Qpsk | Qam16 | Qam64 |
Qam256 | Qam1024

**:CONFigure:NR:SBLock<i>:CCARrier<i>:BWP<i>:USER<i>:PUSCh<i>:PTRS:ENABLE
<PtrsEnabled>**

Availability: Command and Query **Default:** 0

Description: Sets whether PT-RS is present in the transmitted signal.

Parameters: <PtrsEnabled> Boolean

**:CONFigure:NR:SBLock<i>:CCARrier<i>:BWP<i>:USER<i>:PUSCh<i>:TRPCoding:ENABLE
<TransformPrecodingEnabled>**

Availability: Command and Query **Default:** 0

Description: Sets whether transform precoding is enabled. Enable transform precoding when analyzing a DFT-s-OFDM waveform.

Parameters: <TransformPrecodingEnabled> Boolean

:CONFigure:NR:SBLock<i>:CCARrier<i>:BWP<i>:USER<i>:RNTI <Rnti>

Availability: Command and Query **Default:** 1

Description: Sets the RNTI.

Parameters: <Rnti> Int32

:CONFigure:NR:SBLock<i>:CCARrier<i>:CID <CarrierCellId>

Availability: Command and Query **Default:** 0

Description: Sets a physical layer cell identity.

Parameters: <CarrierCellId> Int32

:CONFigure:NR:SBLock<i>:CCARrier<i>:FREQUENCY <Frequency_Hz>

Availability: Command and Query **Default:** 0

Description: Sets the offset of the component carrier from the subblock center frequency that you configure in the Center Frequency method. This value is expressed in Hz.

Parameters: <Frequency_Hz> Double

**:CONFigure:NR:SBLock<i>:CCARrier<i>:RBALignment:GRID:SCSPacing
<ReferenceGridSubcarrierSpacing>**

Availability: Command and Query **Default:** k30

Description: Sets the subcarrier spacing of the reference resource grid when user sets the Reference Grid Alignment Mode method to Manual. This should be the largest subcarrier spacing used in the component carrier. This value is expressed in Hz.

Parameters: <ReferenceGridSubcarrierSpacing> k15 | k30 | k60 | k120

:CONFigure:NR:SBLock<i>:CCARrier<i>:RBAligment:GRID:START<ReferenceGridStart>

Availability: Command and Query **Default:** 0

Description: Sets the reference resource grid start relative to Reference Point A in terms of resource block offset when user sets the Reference Grid Alignment Mode method to Manual. Center of subcarrier 0 in common resource block 0 is considered as Reference Point A.

Parameters: <ReferenceGridStart> Int32

:CONFigure:NR:SBLock<i>:CCSType <CCSpacingType>

Availability: Command and Query **Default:** Nominal

Description: Sets the spacing between adjacent component carriers (CCs) within a subblock.

Parameters: <CCSpacingType> Nominal | User

:CONFigure:NR:SBLock<i>:CENTER:INDEX <CCatCenterFrequency>

Availability: Command and Query **Default:** -1

Description: Sets the index of the component carrier having its center at the user-configured center frequency. The measurement uses this method along with CCSpacingType to calculate the value of the Frequency. This method is ignored if you set the CCSpacingTypes to User.

Parameters: <CCatCenterFrequency> Int32

:CONFigure:NR:SBLock<i>:CHRaster <ChannelRaster>

Availability: Command and Query **Default:** k15

Description: Sets the subblock channel raster which is used for computing nominal spacing between aggregated carriers as specified in section 5.4A.1 of 3GPP 38.101-1/2 specification and section 5.4.1.2 of 3GPP TS 38.104 specification. The value is expressed in Hz.

Parameters: <ChannelRaster> k15 | k60 | k100

:CONFigure:NR:SBLock<i>:FRANge <FrequencyRange>

Availability: Command and Query **Default:** Range_1

Description: Sets whether to use channel bandwidth and subcarrier spacing configuration supported in the frequency range 1 (sub 6 GHz) or the frequency range 2 (above 24 GHz).

Parameters: <FrequencyRange> Range_1 | Range_2

:CONFigure:NR:SBLock<i>:FREQUENCY:CENTER <CenterFrequency_Hz>

Availability: Command and Query **Default:** 5500000000

Description: Sets the center frequency of the acquired RF signal for a single carrier. This value is expressed in Hz. For intraband carrier aggregation, this method specifies the reference frequency of a subblock. Depending on the Subblock Frequency Definition method, the center frequency can either be absolute or relative to first subblock's center frequency. All component carrier frequencies within the subblock are defined with respect to this frequency.

Parameters: <CenterFrequency_Hz> Double

:CONFigure:NR:SBLock<i>:FREQUENCY:DEFinition <FrequencyDefinition>

Availability: Command and Query **Default:** Absolute

Description: Sets if the subblock center frequency definition is an absolute frequency or relative to the absolute frequency of the first subblock. This method is ignored for the first subblock and is considered to be absolute by the measurement.

Parameters: <FrequencyDefinition> Absolute | Relative

**:CONFigure:NR:SBLock<i>:FREQUENCY:PHASecomp
<PhaseCompensationFrequency_Hz>**

Availability: Command and Query **Default:** 0

Description: Sets the frequency used for phase compensation of the signal when user sets the PhaseCompensation to UserDefined. This value is expressed in Hz.

Parameters: <PhaseCompensationFrequency_Hz> Double

:CONFigure:NR:SBLock<i>:FREQUENCY:TXLO <TXLOFrequency_Hz>

Availability: Command and Query **Default:** 0

Description: Sets the frequency of the transmitters local oscillator. This value is expressed in Hz. The frequency is defined per subblock and relative to the respective subblock center frequency.

Parameters: <TXLOFrequency_Hz> Double

:CONFigure:NR:SBLock<i>:POWER:MAX <MaxInputPower_dBm>

Availability: Command and Query **Default:** 22

Description: Maximum power value of the input signal.

Parameters: <MaxInputPower_dBm> Double

:CONFigure:NR:SBLock<i>:UMARgin <UserMargin_dB>

Availability: Command and Query **Default:** 8

Description: Returns the value of a user margin in dB.

Parameters: <UserMargin_dB> Double

:CONFigure:NR:SEM:ACType <SemAmplitudeCorrectionType>

Availability: Command and Query **Default:** RFCenterFreq

Description: Sets whether the amplitude of the frequency bins, used in measurements, is corrected for external attenuation at the RF center frequency, or at the individual frequency bins. Use the RFmxInstr_CfgExternalAttenuationTable function to configure the external attenuation table.

Parameters: <SemAmplitudeCorrectionType> RFCenterFreq | SpectrumFrequencyBin

:CONFigure:NR:SEM:AVG:COUNT <SemAveragingCount>

Availability: Command and Query **Default:** 10

Description: Sets the number of acquisitions used for averaging when Sem averaging is enabled.

Parameters: <SemAveragingCount> Int32

:CONFigure:NR:SEM:AVG:ENABLE <SemAveragingEnable>

Availability: Command and Query **Default:** 0

Description: Sets whether to enable averaging for the SEM measurement.

Parameters: <SemAveragingEnable> Boolean

:CONFigure:NR:SEM:AVG:TYPE <SemAveragingType>

Availability: Command and Query **Default:** Rms

Description: Sets the averaging type for averaging multiple spectrum acquisitions. The averaged spectrum is used for SEM measurement.

Parameters: <SemAveragingType> Rms | Log | Scalar | Max | Min | Vector

:CONFigure:NR:SEM:DFREquency:MAXimum <SemDeltaFMaximum_Hz>

Availability: Command and Query **Default:** 15000000

Description: Sets the stop frequency for 3rd offset segment to be used in the measurement. This method is valid only for downlink and when user sets the SemDownlinkMaskType to Standard.

Parameters: <SemDeltaFMaximum_Hz> Double

:CONFigure:NR:SEM:DLInk:MTYPE <SemDownlinkMaskType>

Availability: Command and Query **Default:** Standard

Description: Sets the limits to be used in the measurement for Downlink.

Parameters: <SemDownlinkMaskType> Standard | Custom

:CONFigure:NR:SEM:ENABLE <SemEnable>

Availability: Command and Query **Default:** 1

Description: Sets whether to enable the SEM measurement.

Parameters: <SemEnable> Boolean

:CONFigure:NR:SEM:NOFFset <SemNumberOfOffsets>

Availability: Command and Query **Default:** 1

Description: Sets the number of SEM offset segments.

Parameters: <SemNumberOfOffsets> Int32

:CONFigure:NR:SEM:NTHReads <SemNumberOfAnalysisThreads>

Availability: Command and Query **Default:** 1

Description: Sets the maximum number of threads used for parallelism for the SEM measurement. The number of threads can range from 1 to the number of physical cores. The number of threads you set may not be used in calculations. The actual number of threads used depends on the problem size, system resources, data availability, and other considerations.

Parameters: <SemNumberOfAnalysisThreads> Int32

:CONFigure:NR:SEM:OFFSet:FREquency:START <SemOffsetStartFrequency_Hz>

Availability: Command and Query **Default:** 0

Description: Sets the start frequency of an offset segment relative to the edge (single carrier) or edge (multi-carrier). This value is expressed in Hz.

Parameters: <SemOffsetStartFrequency_Hz> Double

:CONFigure:NR:SEM:OFFSet:FREQuency:STOP <SemOffsetStopFrequency_Hz>

Availability: Command and Query **Default:** 1000000

Description: Sets the stop frequency of an offset segment relative to the edge (single carrier) or edge (multi-carrier). This value is expressed in Hz.

Parameters: <SemOffsetStopFrequency_Hz> Double

**:CONFigure:NR:SEM:OFFSet:LIMit:ABSolute:START
<SemOffsetAbsoulteLimitStart_dBm>**

Availability: Command and Query **Default:** -21

Description: Sets the absolute power limit corresponding to the beginning of an offset segment. This value is expressed in dBm.

Parameters: <SemOffsetAbsoulteLimitStart_dBm> Double

**:CONFigure:NR:SEM:OFFSet:LIMit:ABSolute:STOP
<SemOffsetAbsoulteLimitStop_dBm>**

Availability: Command and Query **Default:** -21

Description: Sets the absolute power limit corresponding to the end of an offset segment. This value is expressed in dBm.

Parameters: <SemOffsetAbsoulteLimitStop_dBm> Double

:CONFigure:NR:SEM:OFFSet:LIMit:MASK <SemOffsetLimitFailMask>

Availability: Command and Query **Default:** ABS

Description: Sets the criteria to determine the measurement fail status.

Parameters: <SemOffsetLimitFailMask> ABSnREL | ABSorREL | ABS | REL

**:CONFigure:NR:SEM:OFFSet:LIMit:RELative:START
<SemOffsetRelativeLimitStart_dBm>**

Availability: Command and Query **Default:** -53

Description: Sets the relative power limit corresponding to the beginning of the offset segment. This value is expressed in dB.

Parameters: <SemOffsetRelativeLimitStart_dBm> Double

**:CONFigure:NR:SEM:OFFSet:LIMit:RELative:STOP
<SemOffsetRelativeLimitStop_dBm>**

Availability: Command and Query **Default:** -60

Description: Sets the relative power limit corresponding to the end of the offset segment. This value is expressed in dB.

Parameters: <SemOffsetRelativeLimitStop_dBm> Double

:CONFigure:NR:SEM:OFFSet:SBANd <SemOffsetSideband>

Availability: Command and Query **Default:** BOTH

Description: Sets whether the offset segment is present either on one side or on both sides of a carrier.

Parameters: <SemOffsetSideband> NEG | POS | BOTH

:CONFigure:NR:SEM:RBW:BW <SemRbwBandwidth_Hz>

Availability: Command and Query **Default:** 30000

Description: Sets the bandwidth of the resolution bandwidth (RBW) filter used to sweep the acquired offset segment, when user sets the SEM Offset RBW Auto method to False. This value is expressed in Hz.

Parameters: <SemRbwBandwidth_Hz> Double

:CONFigure:NR:SEM:RBW:INTegral <SemOffsetBandwidthIntegral>

Availability: Command and Query **Default:** 1

Description: Sets the resolution of a spectrum to compare with the spectral mask limits as an integer multiple of the RBW.

Parameters: <SemOffsetBandwidthIntegral> Int32

:CONFigure:NR:SEM:RBW:TYPE <SemRbwFilterType>

Availability: Command and Query **Default:** GAUSSIAN

Description: Sets the shape of a digital RBW filter.

Parameters: <SemRbwFilterType> FFT | GAUSSIAN | FLAT | ST4 | ST5

:CONFigure:NR:SEM:SWEep:AUTO <SemSweepTimeAuto>

Availability: Command and Query **Default:** 1

Description: Sets whether the measurement sets the sweep time.

Parameters: <SemSweepTimeAuto> Boolean

:CONFigure:NR:SEM:SWEep:INTerval <SemSweepTimeInterval_s>

Availability: Command and Query **Default:** 0.001

Description: Sets the sweep time when user sets the SemSweepTimeAuto to False. This value is expressed in seconds.

Parameters: <SemSweepTimeInterval_s> Double

:CONFigure:NR:SEM:TRACe:ENABle <SemAllTracesEnable>

Availability: Command and Query **Default:** 0

Description: Sets whether to enable the traces to be stored and retrieved after performing the SEM measurement.

Parameters: <SemAllTracesEnable> Boolean

:CONFigure:NR:SEM:ULink:MTYPE <SemUplinkMaskType>

Availability: Command and Query **Default:** General

Description: Sets the spectrum emission mask used in the measurement for uplink. You must set the mask type to to configure the custom offset masks. Refer to section 6.5.2 of the 3GPP 38.101 specification for more information about standard-defined mask types.

Parameters: <SemUplinkMaskType> General | NS35 | Custom | NS03 | NS04 | NS06

:CONFigure:NR:TRACe:ENABLE <TraceEnable>

Availability: Command and Query **Default:** 0

Description: Enable traces for all measurements.

Parameters: <TraceEnable> Boolean

:CONFigure:NR:TXP:AVG:COUNT <TxpAveragingCount>

Availability: Command and Query **Default:** 10

Description: Sets the number of acquisitions used for averaging when Txp averaging is enabled.

Parameters: <TxpAveragingCount> Int32

:CONFigure:NR:TXP:AVG:ENABLE <TxpAveragingEnable>

Availability: Command and Query **Default:** 0

Description: Sets whether to enable the Txp averaging.

Parameters: <TxpAveragingEnable> Boolean

:CONFigure:NR:TXP:ENABLE <TxpEnable>

Availability: Command and Query **Default:** 1

Description: Sets whether to enable the Txp measurement.

Parameters: <TxpEnable> Boolean

:CONFigure:NR:TXP:MEASurement:INTERval <TxpMeasurementInterval_sec>

Availability: Command and Query **Default:** 0.01

Description: Gets the measurement interval. This value is expressed in seconds.

Parameters: <TxpMeasurementInterval_sec> Double

:CONFigure:NR:TXP:MEASurement:OFFSet <TxpMeasurementOffset_sec>

Availability: Command and Query **Default:** 0

Description: Sets the measurement offset to skip from the start of acquired waveform for TXP measurement. This value is expressed in seconds.

Parameters: <TxpMeasurementOffset_sec> Double

:CONFigure:NR:TXP:NTHReads <TxpNumberOfAnalysisThreads>

Availability: Command and Query **Default:** 1

Description: Maximum number of threads used for parallelism inside TXP measurement.

Parameters: <TxpNumberOfAnalysisThreads> Int32

:CONFigure:NR:TXP:TRACe:ENABLE <TxpAllTracesEnable>

Availability: Command and Query **Default:** 0

Description: Sets whether to enable the traces to be stored and retrieved after performing the Txp measurement.

Parameters: <TxpAllTracesEnable> Boolean

:FETch:NR:RESults<i>:ACP:SBLoCk<i>**Availability:** Query Only**Default:** N/A**Description:** Set of parameters for NR acp sub block measurement results.**Return type:** <TotalAggregatedPower_dBm: double>, <Subblock>, <Carrier,...>, <Offset,...>

:FETch:NR:RESults<i>:ACP:SBLoCk<i>:ALL**Availability:** Query Only**Default:** N/A**Description:** Returns string with results for NRModAccCarrier.**Return type:** <TotalAggregatedPower_dBm: double>, <Subblock>, <Carrier,...>, <Offset,...>

:FETch:NR:RESults<i>:ACP:SBLoCk<i>:CCARrier<i>**Availability:** Query Only**Default:** N/A**Description:** Contains the results of the carrier measurements.**Return type:** CarrierMeasurementResults

:FETch:NR:RESults<i>:ACP:SBLoCk<i>:CCARrier<i>:POWER:ABSolute**Availability:** Query Only**Default:** NaN**Description:** Contains the array of powers measured over the integration bandwidths of the component carriers in a subblock.**Return type:** Double

:FETch:NR:RESults<i>:ACP:SBLoCk<i>:CCARrier<i>:POWER:RELative**Availability:** Query Only**Default:** NaN**Description:** Contains the array of component carrier powers relative to their subblock powers measured over the integration bandwidths of the component carriers in the subblock.**Return type:** Double

:FETch:NR:RESults<i>:ACP:SBLoCk<i>:MEAS**Availability:** Query Only**Default:** N/A**Description:** Contains the results of the subblock measurements.**Return type:** SubblockMeasurementResults

:FETch:NR:RESults<i>:ACP:SBLoCk<i>:MEAS:ALL**Availability:** Query Only**Default:** N/A**Description:** Returns string with results for NRModAccCarrier.**Return type:** String

:FETch:NR:RESults<i>:ACP:SBLoCk<i>:MEAS:FREquency**Availability:** Query Only**Default:** NaN**Description:** Contains the absolute center frequency of the subblock. This value is the center of the subblock integration bandwidth.**Return type:** Double

:FETch:NR:RESults<i>:ACP:SBLOCK<i>:MEAS:IBANDwidth**Availability:** Query Only**Default:** NaN

Description: Contains the integration bandwidth used in calculating the power of the subblock. Integration bandwidth is the span from left edge of the leftmost carrier to the right edge of the rightmost carrier within a subblock.

Return type: Double

:FETch:NR:RESults<i>:ACP:SBLOCK<i>:MEAS:POWER**Availability:** Query Only**Default:** NaN

Description: Contains the sum of powers of all the frequency bins over the integration bandwidth of the subblock.

Return type: Double

:FETch:NR:RESults<i>:ACP:SBLOCK<i>:OFFSet:COUNT**Availability:** Query Only**Default:** N/A

Description: Contains the number of offsets in the measurement.

Return type: Int32

:FETch:NR:RESults<i>:ACP:SBLOCK<i>:OFFSet<i>**Availability:** Query Only**Default:** N/A

Description: Contains the results of the offset measurements.

Return type: AcpOffsetChannelMeasurements

:FETch:NR:RESults<i>:ACP:SBLOCK<i>:OFFSet<i>:LOWer:POWER:ABSolute**Availability:** Query Only**Default:** N/A

Description: Contains the array of lower (negative) offset channel power. For the intra-band noncontiguous type of carrier aggregation, if this offset is not applicable, a NaN is returned. For more information about the applicability of offset channel, refer to 3GPP TS 36.521 specification.

Return type: Double

:FETch:NR:RESults<i>:ACP:SBLOCK<i>:OFFSet<i>:LOWer:POWER:RELative**Availability:** Query Only**Default:** N/A

Description: Contains the array of power in lower (negative) offset channel relative to the value returned by the method. For the intra-band noncontiguous type of carrier aggregation, if this offset is not applicable, a NaN is returned. For more information about the applicability of the offset channel, refer to the 3GPP TS 36.521 specification.

Return type: Double

:FETch:NR:RESults<i>:ACP:SBLOCK<i>:OFFSet<i>:UPPer:POWER:ABSolute**Availability:** Query Only**Default:** N/A

Description: Contains the array of upper (positive) offset channel powers. For the intra-band noncontiguous type of carrier aggregation, if this offset is not applicable, a NaN is returned. For more information about the applicability of offset channel, refer 3GPP TS 36.521 specification.

Return type: Double

:FETch:NR:RESults<i>:ACP:SBLOCK<i>:OFFSet<i>:UPPer:POWer:RELative**Availability:** Query Only**Default:** N/A

Description: Contains the array of powers in upper (positive) offset channel relative to the value returned by the ACP Results Total Aggregated Pwr method. For the intra-band noncontiguous type of carrier aggregation, if this offset is not applicable, a NaN is returned. For more information about the applicability of the offset channel, refer to the 3GPP TS 36.521 specification.

Return type: Double

:FETch:NR:RESults<i>:ACP:SBLOCK<i>:POWer:TOTal**Availability:** Query Only**Default:** NaN

Description: Contains the sum of powers of all the subblocks. This value includes the power in the inter-carrier gaps within a subblock, but it does not include the power in the subblock gaps.

Return type: Double

:FETch:NR:RESults<i>:CHP:SBLOCK<i>**Availability:** Query Only**Default:** N/A

Description: Set of parameters for NR chp sub block measurement results.

Return type: <TotalAggregatedPower_dBm: double>, <Subblock>, <Carrier,...>

:FETch:NR:RESults<i>:CHP:SBLOCK<i>:ALL**Availability:** Query Only**Default:** N/A

Description: Returns string with results for NRModAccCarrier.

Return type: <TotalAggregatedPower_dBm: double>, <Subblock>, <Carrier,...>

:FETch:NR:RESults<i>:CHP:SBLOCK<i>:CCARrier<i>**Availability:** Query Only**Default:** N/A

Description: Contains the results of the carrier measurements.

Return type: CarrierMeasurementResults

:FETch:NR:RESults<i>:CHP:SBLOCK<i>:CCARrier<i>:POWer:ABSolute**Availability:** Query Only**Default:** NaN

Description: Contains the array of powers measured over the integration bandwidths of the component carriers in a subblock.

Return type: Double

:FETch:NR:RESults<i>:CHP:SBLOCK<i>:CCARrier<i>:POWer:RELative**Availability:** Query Only**Default:** NaN

Description: Contains the array of component carrier powers relative to their subblock powers measured over the integration bandwidths of the component carriers in the subblock.

Return type: Double

:FETch:NR:RESults<i>:CHP:SBLOCK<i>:MEAS**Availability:** Query Only**Default:** N/A

Description: Contains the results of the subblock measurements.

Return type: SubblockMeasurementResults

:FETch:NR:RESults<i>:CHP:SBLock<i>:MEAS:ALL

Availability: Query Only **Default:** N/A

Description: Returns string with results for NRModAccCarrier.

Return type: String

:FETch:NR:RESults<i>:CHP:SBLock<i>:MEAS:FREQuency

Availability: Query Only **Default:** NaN

Description: Contains the absolute center frequency of the subblock. This value is the center of the subblock integration bandwidth.

Return type: Double

:FETch:NR:RESults<i>:CHP:SBLock<i>:MEAS:IBANDwidth

Availability: Query Only **Default:** NaN

Description: Contains the integration bandwidth used in calculating the power of the subblock. Integration bandwidth is the span from left edge of the leftmost carrier to the right edge of the rightmost carrier within a subblock.

Return type: Double

:FETch:NR:RESults<i>:CHP:SBLock<i>:MEAS:POWer

Availability: Query Only **Default:** NaN

Description: Contains the sum of powers of all the frequency bins over the integration bandwidth of the subblock.

Return type: Double

:FETch:NR:RESults<i>:CHP:SBLock<i>:POWer:TOtal

Availability: Query Only **Default:** NaN

Description: Contains the sum of powers of all the subblocks. This value includes the power in the inter-carrier gaps within a subblock, but it does not include the power in the subblock gaps.

Return type: Double

:FETch:NR:RESults<i>:MODacc<i>:ALL

Availability: Query Only **Default:** N/A

Description: Returns string with results for NRModAccCarrier.

Return type: String

:FETch:NR:RESults<i>:MODacc<i>:CCARrier<i>:ALL

Availability: Query Only **Default:** N/A

Description: Returns string with results for NRModAccCarrier.

Return type: String

:FETch:NR:RESults<i>:MODacc<i>:CCARrier<i>:EVM:ALL

Availability: Query Only **Default:** N/A

Description: Returns results for NRModAccCarrier Error Vector Magnitude (EVM) measurement.

Return type: String

:FETch:NR:RESults<i>:MODacc<i>:CCARrier<i>:EVM:PEAK

:FETch:NR:RESults<i>:MODacc<i>:CCARrier<i>:EVM:PEAK:MAXimum

Availability: Query Only

Default: N/A

Description: Contains the symbol index where the ModAcc maximum peak composite EVM occurs.

Return type: Double

:FETch:NR:RESults<i>:MODacc<i>:CCARrier<i>:EVM:PEAK:BW

:FETch:NR:RESults<i>:MODacc<i>:CCARrier<i>:EVM:PEAK:BW:INDEX

Availability: Query Only

Default: N/A

Description: Contains the index of NR Mod Acc Peak Composite Evm Bandwidth.

Return type: Int32

:FETch:NR:RESults<i>:MODacc<i>:CCARrier<i>:EVM:PEAK:SLOT

:FETch:NR:RESults<i>:MODacc<i>:CCARrier<i>:EVM:PEAK:SLOT:INDEX

Availability: Query Only

Default: N/A

Description: Contains the index of NR Mod Acc Peak Composite Evm Slot.

Return type: Int32

:FETch:NR:RESults<i>:MODacc<i>:CCARrier<i>:EVM:PEAK:SUBCarrier

:FETch:NR:RESults<i>:MODacc<i>:CCARrier<i>:EVM:PEAK:SUBCarrier:INDEX

Availability: Query Only

Default: N/A

Description: Contains the index of NR Mod Acc Peak Composite Evm SubCarrier.

Return type: Int32

:FETch:NR:RESults<i>:MODacc<i>:CCARrier<i>:EVM:PEAK:SYMBOL

<PeakCompositeEvmSymbolIndex>

:FETch:NR:RESults<i>:MODacc<i>:CCARrier<i>:EVM:PEAK:SYMBOL:INDEX

<PeakCompositeEvmSymbolIndex>

Availability: Command and Query

Default: N/A

Description: Contains the index of NR Mod Acc Peak Composite Evm Symbol.

Parameters: <PeakCompositeEvmSymbolIndex> Int32

:FETch:NR:RESults<i>:MODacc<i>:CCARrier<i>:EVM:RMS

:FETch:NR:RESults<i>:MODacc<i>:CCARrier<i>:EVM:RMS:MEAN

Availability: Query Only

Default: N/A

Description: Contains the mean value of the RMS EVMs calculated on all configured channels over the slots specified by the MeasurementLength. When ModAccEvmUnit is set to Percentage, the measurement returns this result as a percentage. When ModAccEvmUnit is set to dB, the measurement returns this result in dB.

Return type: Double

:FETch:NR:RESults<i>:MODacc<i>:CCARrier<i>:IBE:MARGin**Availability:** Query Only**Default:** N/A

Description: Returns In-Band Emission Margin of the subblock's aggregated bandwidth. This value is expressed in dB.

Return type: Double

:FETch:NR:RESults<i>:MODacc<i>:CCARrier<i>:IMPairments**Availability:** Query Only**Default:** N/A

Description: Returns results for NRModAccCarrier Impairments measurement.

Return type: String

:FETch:NR:RESults<i>:MODacc<i>:CCARrier<i>:IMPairments:FERRor**:FETch:NR:RESults<i>:MODacc<i>:CCARrier<i>:IMPairments:FERRor:MEAN****Availability:** Query Only**Default:** N/A

Description: Contains the frequency error in Hz in case of NR Mod Acc measurements.

Return type: Double

:FETch:NR:RESults<i>:MODacc<i>:CCARrier<i>:IMPairments:IQGain**:FETch:NR:RESults<i>:MODacc<i>:CCARrier<i>:IMPairments:IQGain:IMBalance****Availability:** Query Only**Default:** N/A

Description: Gets the estimated IQ gain imbalance averaged over measurement length. This value is expressed in dB. IQ gain imbalance is the ratio of the amplitude of the I component to the Q component of the IQ signal being measured.

Return type: Double

:FETch:NR:RESults<i>:MODacc<i>:CCARrier<i>:IMPairments:IQOrigin**:FETch:NR:RESults<i>:MODacc<i>:CCARrier<i>:IMPairments:IQOrigin:OFFSet****Availability:** Query Only**Default:** N/A

Description: Gets the estimated IQ origin offset averaged over measurement length. This value is expressed in dBc.

Return type: Double

:FETch:NR:RESults<i>:MODacc<i>:CCARrier<i>:IMPairments:IQQuadrature**Availability:** Query Only**Default:** N/A

Description: Gets the estimated quadrature error averaged over measurement length. This value is expressed in degrees. Quadrature error is the measure of skewness in degree of the I component with respect to the Q component of the IQ signal being measured.

Return type: Double

:FETch:NR:RESults<i>:MODacc<i>:CCARrier<i>:IQ:TIMingskew:MEAN**Availability:** Query Only**Default:** NaN

Description: Estimated IQ Timing Skew averaged over Meas Length.

Return type: Double

:FETch:NR:RESults<i>:MODacc<i>:CCARrier<i>:MAGNitude:PEAK
:FETch:NR:RESults<i>:MODacc<i>:CCARrier<i>:MAGNitude:PEAK:MAXimum

Availability: Query Only

Default: N/A

Description: Gets the peak value of magnitude error calculated over measurement length on all configured channels.

Return type: Double

:FETch:NR:RESults<i>:MODacc<i>:CCARrier<i>:MAGNitude:RMS
:FETch:NR:RESults<i>:MODacc<i>:CCARrier<i>:MAGNitude:RMS:MEAN

Availability: Query Only

Default: N/A

Description: Gets the RMS mean value of magnitude error calculated over measurement length on all configured channels.

Return type: Double

:FETch:NR:RESults<i>:MODacc<i>:CCARrier<i>:NOISe:COMPensation:APPLied

Availability: Query Only

Default: 0

Description: Gets whether the noise compensation is applied to the EVM measurement.

Return type: Boolean

:FETch:NR:RESults<i>:MODacc<i>:CCARrier<i>:PBCH:DATA:PEAK:EVM:MAXimum

Availability: Query Only

Default: NaN

Description: Gets the maximum value calculated over measurement length of RMS EVMs calculated on PBCH data symbols. When you set the SetEvmUnit(String, RFmxNRMXModAccEvmUnit) method to Percentage, the measurement returns this result as a percentage. When you set the ModAcc EVM Unit method to dB, the measurement returns this result in dB.

Return type: Double

:FETch:NR:RESults<i>:MODacc<i>:CCARrier<i>:PBCH:DATA:RMS:EVM:MEAN

Availability: Query Only

Default: NaN

Description: Gets the mean value calculated over measurement length of RMS EVMs calculated on PBCH data symbols. When you set the SetEvmUnit(String, RFmxNRMXModAccEvmUnit) method to Percentage, the measurement returns this result as a percentage. When you set the ModAcc EVM Unit method to dB, the measurement returns this result in dB.

Return type: Double

:FETch:NR:RESults<i>:MODacc<i>:CCARrier<i>:PBCH:DMRS:PEAK:EVM:MAXium

Availability: Query Only

Default: NaN

Description: Gets the maximum value calculated over measurement length of peak EVMs calculated on PBCH data symbols. When you set the SetEvmUnit(String, RFmxNRMXModAccEvmUnit) method to Percentage, the measurement returns this result as a percentage. When you set the ModAcc EVM Unit method to dB, the measurement returns this result in dB.

Return type: Double

:FETch:NR:RESults<i>:MODacc<i>:CCARrier<i>:PBCH:DMRS:RMS:EVM:MEAN**Availability:** Query Only**Default:** NaN

Description: Gets the mean value calculated over measurement length of peak EVMs calculated on PBCH data symbols. When you set the SetEvmUnit(String, RFmxNRMXModAccEvmUnit) method to Percentage, the measurement returns this result as a percentage. When you set the ModAcc EVM Unit method to dB, the measurement returns this result in dB.

Return type: Double

:FETch:NR:RESults<i>:MODacc<i>:CCARrier<i>:PDSCh**Availability:** Query Only**Default:** N/A

Description: Returns results for NRModAccCarrier PDSCH clusters measurement.

Return type: String

:FETch:NR:RESults<i>:MODacc<i>:CCARrier<i>:PDSCh:EVM:DATA:PEAK**:FETch:NR:RESults<i>:MODacc<i>:CCARrier<i>:PDSCh:EVM:DATA:PEAK:MAXimum****Availability:** Query Only**Default:** N/A

Description: Returns the maximum value of peak EVMs calculated over measurement length on PDSCH data symbols.

Return type: Double

:FETch:NR:RESults<i>:MODacc<i>:CCARrier<i>:PDSCh:EVM:DATA:RMS**:FETch:NR:RESults<i>:MODacc<i>:CCARrier<i>:PDSCh:EVM:DATA:RMS:MEAN****Availability:** Query Only**Default:** N/A

Description: Returns the mean value of RMS EVMs calculated over measurement length on PDSCH data symbols.

Return type: Double

:FETch:NR:RESults<i>:MODacc<i>:CCARrier<i>:PDSCh:EVM:DMRS:PEAK**:FETch:NR:RESults<i>:MODacc<i>:CCARrier<i>:PDSCh:EVM:DMRS:PEAK:MAXimum****Availability:** Query Only**Default:** N/A

Description: Returns the maximum value of peak EVMs calculated over measurement length on PDSCH DMRS.

Return type: Double

:FETch:NR:RESults<i>:MODacc<i>:CCARrier<i>:PDSCh:EVM:DMRS:RMS**:FETch:NR:RESults<i>:MODacc<i>:CCARrier<i>:PDSCh:EVM:DMRS:RMS:MEAN****Availability:** Query Only**Default:** N/A

Description: Returns the mean value of RMS EVMs calculated over measurement length on PDSCH DMRS.

Return type: Double

:FETch:NR:RESults<i>:MODacc<i>:CCARrier<i>:PDSCh:EVM:PTRS:RMS**:FETch:NR:RESults<i>:MODacc<i>:CCARrier<i>:PDSCh:EVM:PTRS:RMS:MEAN****Availability:** Query Only**Default:** N/A

Description: Returns the mean value of RMS EVMs calculated over measurement length on PDSCH PTRS.

Return type: Double

:FETch:NR:RESults<i>:MODacc<i>:CCARrier<i>:PDSCh:POWers:DATA
:FETch:NR:RESults<i>:MODacc<i>:CCARrier<i>:PDSCh:POWers:DATA:MEAN

Availability: Query Only **Default:** N/A

Description: Returns the mean data power value of PDSCH measurement in dBm.

Return type: Double

:FETch:NR:RESults<i>:MODacc<i>:CCARrier<i>:PDSCh:POWers:DMRS
:FETch:NR:RESults<i>:MODacc<i>:CCARrier<i>:PDSCh:POWers:DMRS:MEAN

Availability: Query Only **Default:** N/A

Description: Returns the mean DMRS power value of PDSCH measurement in dBm.

Return type: Double

:FETch:NR:RESults<i>:MODacc<i>:CCARrier<i>:PDSCh:POWers:PTRS
:FETch:NR:RESults<i>:MODacc<i>:CCARrier<i>:PDSCh:POWers:PTRS:MEAN

Availability: Query Only **Default:** N/A

Description: Returns the mean PTRS power value of PDSCH measurement in dBm.

Return type: Double

:FETch:NR:RESults<i>:MODacc<i>:CCARrier<i>:PHASe:PEAK
:FETch:NR:RESults<i>:MODacc<i>:CCARrier<i>:PHASe:PEAK:MAXimum

Availability: Query Only **Default:** N/A

Description: Gets the peak value of Phase error calculated over measurement length on all configured channels. This value is expressed in degrees.

Return type: Double

:FETch:NR:RESults<i>:MODacc<i>:CCARrier<i>:PHASe:RMS
:FETch:NR:RESults<i>:MODacc<i>:CCARrier<i>:PHASe:RMS:MEAN

Availability: Query Only **Default:** N/A

Description: Gets the RMS mean value of Phase error calculated over measurement length on all configured channels. This value is expressed in degrees.

Return type: Double

:FETch:NR:RESults<i>:MODacc<i>:CCARrier<i>:PSS:PEAK:EVM:MAXimum

Availability: Query Only **Default:** NaN

Description: Gets the maximum value of EVMs calculated over measurement length on PSS symbols. When you set the SetEvmUnit(String, RFmxNRMXModAccEvmUnit) method to Percentage, the measurement returns this result as a percentage. When you set the ModAcc EVM Unit method to dB, the measurement returns this result in dB.

Return type: Double

:FETch:NR:RESults<i></i>:MODacc<i></i>:CCARrier<i></i>:PSS:RMS:EVM:MEAN**Availability:** Query Only**Default:** NaN

Description: Gets the mean value of EVMs calculated over measurement length on PSS symbols. When you set the SetEvmUnit(String, RFmxNRMXModAccEvmUnit) method to Percentage, the measurement returns this result as a percentage. When you set the ModAcc EVM Unit method to dB, the measurement returns this result in dB.

Return type: Double

:FETch:NR:RESults<i></i>:MODacc<i></i>:CCARrier<i></i>:PUSCh**Availability:** Query Only**Default:** N/A

Description: Returns results for NRModAccCarrier PUSCH clusters measurement.

Return type: String

:FETch:NR:RESults<i></i>:MODacc<i></i>:CCARrier<i></i>:PUSCh:EVM:DATA:PEAK**:FETch:NR:RESults<i></i>:MODacc<i></i>:CCARrier<i></i>:PUSCh:EVM:DATA:PEAK:MAXimum****Availability:** Query Only**Default:** N/A

Description: Returns the maximum value of peak EVMs calculated over measurement length on PUSCH data symbols.

Return type: Double

:FETch:NR:RESults<i></i>:MODacc<i></i>:CCARrier<i></i>:PUSCh:EVM:DATA:RMS**:FETch:NR:RESults<i></i>:MODacc<i></i>:CCARrier<i></i>:PUSCh:EVM:DATA:RMS:MEAN****Availability:** Query Only**Default:** N/A

Description: Returns the mean value of RMS EVMs calculated over measurement length on PUSCH data symbols.

Return type: Double

:FETch:NR:RESults<i></i>:MODacc<i></i>:CCARrier<i></i>:PUSCh:EVM:DMRS:PEAK**:FETch:NR:RESults<i></i>:MODacc<i></i>:CCARrier<i></i>:PUSCh:EVM:DMRS:PEAK:MAXimum****Availability:** Query Only**Default:** N/A

Description: Returns the maximum value of peak EVMs calculated over measurement length on PUSCH DMRS.

Return type: Double

:FETch:NR:RESults<i></i>:MODacc<i></i>:CCARrier<i></i>:PUSCh:EVM:DMRS:RMS**:FETch:NR:RESults<i></i>:MODacc<i></i>:CCARrier<i></i>:PUSCh:EVM:DMRS:RMS:MEAN****Availability:** Query Only**Default:** N/A

Description: Returns the mean value of RMS EVMs calculated over measurement length on PUSCH DMRS.

Return type: Double

:FETch:NR:RESults<i></i>:MODacc<i></i>:CCARrier<i></i>:PUSCh:EVM:PTRS:PEAK**:FETch:NR:RESults<i></i>:MODacc<i></i>:CCARrier<i></i>:PUSCh:EVM:PTRS:PEAK:MAXimum****Availability:** Query Only**Default:** N/A

Description: Returns the maximum value of peak EVMs calculated over measurement length on PUSCH PTRS.

Return type: Double

:FETch:NR:RESults<i>:MODacc<i>:CCARrier<i>:PUSCh:EVM:PTRS:RMS
:FETch:NR:RESults<i>:MODacc<i>:CCARrier<i>:PUSCh:EVM:PTRS:RMS:MEAN

Availability: Query Only

Default: N/A

Description: Returns the mean value of RMS EVMs calculated over measurement length on PUSCH PTRS.

Return type: Double

:FETch:NR:RESults<i>:MODacc<i>:CCARrier<i>:PUSCh:POWers:DATA
:FETch:NR:RESults<i>:MODacc<i>:CCARrier<i>:PUSCh:POWers:DATA:MEAN

Availability: Query Only

Default: N/A

Description: Returns the mean power value of PUSCH measurement in dBm.

Return type: Double

:FETch:NR:RESults<i>:MODacc<i>:CCARrier<i>:PUSCh:POWers:DMRS
:FETch:NR:RESults<i>:MODacc<i>:CCARrier<i>:PUSCh:POWers:DMRS:MEAN

Availability: Query Only

Default: N/A

Description: Returns the mean DMRS power value of PUSCH measurement in dBm.

Return type: Double

:FETch:NR:RESults<i>:MODacc<i>:CCARrier<i>:PUSCh:POWers:PTRS
:FETch:NR:RESults<i>:MODacc<i>:CCARrier<i>:PUSCh:POWers:PTRS:MEAN

Availability: Query Only

Default: N/A

Description: Returns the mean PTRS power value of PUSCH measurement in dBm.

Return type: Double

:FETch:NR:RESults<i>:MODacc<i>:CCARrier<i>:SFLatness

Availability: Query Only

Default: N/A

Description: Returns results for NRModAccCarrier Spectral Flatness measurement.

Return type: String

:FETch:NR:RESults<i>:MODacc<i>:CCARrier<i>:SPECTral:FMARgin:SLOT:INDex

Availability: Query Only

Default: -1

Description: Slot index with the worst ripple margin among all four ripple results defined in section 6.4.2.4.1 of 3GPP 38.101-1 specification and section 6.4.2.4.1 of 3GPP 38.101-2.

Return type: Int32

:FETch:NR:RESults<i>:MODacc<i>:CCARrier<i>:SPECTral:FRANge1:MAXimum

Availability: Query Only

Default: NaN

Description: Gets the maximum magnitude of the EVM equalizer coefficients within Range1 for the measurement unit with the worst ripple margin among all four ripple results defined in section 6.4.2.4.1 of 3GPP 38.101-1 specification and section 6.4.2.4.1 of 3GPP 38.101-2 specification. The value is expressed in dB.

Return type: Double

:FETch:NR:RESults<i>:MODacc<i>:CCARrier<i>:SPECtral:FRANge1:MAXimum:SUBCarrier:INDEX

Availability: Query Only

Default: -1

Description: Gets the maximum subcarrier index magnitude of EVM equalizer coefficients within Range1 for the measurement unit with the worst ripple margin among all four ripple results defined in section 6.4.2.4.1 of 3GPP 38.101-1 specification and section 6.4.2.4.1 of 3GPP 38.101-2 specification.

Return type: Int32

:FETch:NR:RESults<i>:MODacc<i>:CCARrier<i>:SPECtral:FRANge1:MINimum

Availability: Query Only

Default: NaN

Description: Gets the maximum magnitude of the EVM equalizer coefficients within Range1 for the measurement unit with the worst ripple margin among all four ripple results defined in section 6.4.2.4.1 of 3GPP 38.101-1 specification and section 6.4.2.4.1 of 3GPP 38.101-2 specification. The value is expressed in dB.

Return type: Double

:FETch:NR:RESults<i>:MODacc<i>:CCARrier<i>:SPECtral:FRANge1:MINimum:SUBCarrier:INDEX

Availability: Query Only

Default: -1

Description: Gets the minimum subcarrier index magnitude of EVM equalizer coefficients within Range1 for the measurement unit with the worst ripple margin among all four ripple results defined in section 6.4.2.4.1 of 3GPP 38.101-1 specification and section 6.4.2.4.1 of 3GPP 38.101-2 specification.

Return type: Int32

:FETch:NR:RESults<i>:MODacc<i>:CCARrier<i>:SPECtral:FRANge2:MAXimum

Availability: Query Only

Default: NaN

Description: Gets the maximum magnitude of the EVM equalizer coefficients within Range1 for the measurement unit with the worst ripple margin among all four ripple results defined in section 6.4.2.4.1 of 3GPP 38.101-1 specification and section 6.4.2.4.1 of 3GPP 38.101-2 specification. The value is expressed in dB.

Return type: Double

:FETch:NR:RESults<i>:MODacc<i>:CCARrier<i>:SPECtral:FRANge2:MAXimum:SUBCarrier:INDEX

Availability: Query Only

Default: -1

Description: Gets the maximum subcarrier index magnitude of EVM equalizer coefficients within Range1 for the measurement unit with the worst ripple margin among all four ripple results defined in section 6.4.2.4.1 of 3GPP 38.101-1 specification and section 6.4.2.4.1 of 3GPP 38.101-2 specification.

Return type: Int32

:FETch:NR:RESults<i>:MODacc<i>:CCARrier<i>:SPECtral:FRANge2:MINimum**Availability:** Query Only**Default:** NaN

Description: Gets the maximum magnitude of the EVM equalizer coefficients within Range1 for the measurement unit with the worst ripple margin among all four ripple results defined in section 6.4.2.4.1 of 3GPP 38.101-1 specification and section 6.4.2.4.1 of 3GPP 38.101-2 specification. The value is expressed in dB.

Return type: Double

:FETch:NR:RESults<i>:MODacc<i>:CCARrier<i>:SPECtral:FRANge2:MINimum:SUBCarrier:INDEX**Availability:** Query Only**Default:** -1

Description: Gets the minimum subcarrier index magnitude of EVM equalizer coefficients within Range1 for the measurement unit with the worst ripple margin among all four ripple results defined in section 6.4.2.4.1 of 3GPP 38.101-1 specification and section 6.4.2.4.1 of 3GPP 38.101-2 specification.

Return type: Int32

:FETch:NR:RESults<i>:MODacc<i>:CCARrier<i>:SSS:PEAK:EVM:MAXimum**Availability:** Query Only**Default:** NaN

Description: Gets the maximum value of EVMs calculated over measurement length on SSS symbols. When you set the SetEvmUnit(String, RFmxNRMXModAccEvmUnit) method to Percentage, the measurement returns this result as a percentage. When you set the ModAcc EVM Unit method to dB, the measurement returns this result in dB.

Return type: Double

:FETch:NR:RESults<i>:MODacc<i>:CCARrier<i>:SSS:RMS:EVM:MEAN**Availability:** Query Only**Default:** NaN

Description: Gets the mean value of EVMs calculated over measurement length on SSS symbols. When you set the SetEvmUnit(String, RFmxNRMXModAccEvmUnit) method to Percentage, the measurement returns this result as a percentage. When you set the ModAcc EVM Unit method to dB, the measurement returns this result in dB.

Return type: Double

:FETch:NR:RESults<i>:MODacc<i>:CCARrier<i>:TOFFset:MEAN**Availability:** Query Only**Default:** NaN

Description: Time difference between the detected slot or frame boundary depending on the sync mode and reference trigger location. This value is expressed in seconds.

Return type: Double

:FETch:NR:RESults<i>:OBW:SBLOCK<i>**Availability:** Query Only**Default:** N/A

Description: Set of parameters for NR obw sub block measurement results.

Return type: <SubBlockNumber: double>, <AverageTotalPower_dBm: double>, <OccupiedBandwidth_Hz: double>, <StartFrequency_Hz: double>, <StopFrequency_Hz: double>

:FETch:NR:RESults<i>:OBW:SBLock<i>:ALL**Availability:** Query Only**Default:** N/A**Description:** Returns string with results for NRModAccCarrier.**Return type:** <SubBlockNumber: double>, <AverageTotalPower_dBm: double>, <OccupiedBandwidth_Hz: double>, <StartFrequency_Hz: double>, <StopFrequency_Hz: double>

:FETch:NR:RESults<i>:OBW:SBLock<i>:BANDwidth**Availability:** Query Only**Default:** NaN**Description:** Contains the bandwidth that occupies 99 percentage of the total power of the signal within a carrier/subblock.**Return type:** Double

:FETch:NR:RESults<i>:OBW:SBLock<i>:FREQuency:START**Availability:** Query Only**Default:** NaN**Description:** Contains the start frequency of the subblock. The occupied bandwidth of a carrier/subblock is calculated using the following equation: Stop frequency - Start frequency = Occupied bandwidth.**Return type:** Double

:FETch:NR:RESults<i>:OBW:SBLock<i>:FREQuency:STOP**Availability:** Query Only**Default:** NaN**Description:** Contains the stop frequency of the subblock. The occupied bandwidth of a carrier/subblock is calculated using the following equation: Stop frequency - Start frequency = Occupied bandwidth.**Return type:** Double

:FETch:NR:RESults<i>:OBW:SBLock<i>:POWER:ABSolute**Availability:** Query Only**Default:** NaN**Description:** Contains the power measured over the integration bandwidth of the carrier/subblock.**Return type:** Double

:FETch:NR:RESults<i>:SEM:SBLock<i>:ALL**Availability:** Query Only**Default:** N/A**Description:** Returns all results for Sem measurement.**Return type:** String

:FETch:NR:RESults<i>:SEM:SBLock<i>:CCARrier<i>**Availability:** Query Only**Default:** N/A**Description:** Contains the results of the carrier measurements.**Return type:** SemCarrierMeasurementResults

:FETch:NR:RESults<i>:SEM:SBLock<i>:CCARrier<i>:FREQuency:PEAK**Availability:** Query Only**Default:** NaN**Description:** Peak frequency in Hz.**Return type:** Double

:FETch:NR:RESults<i></i>:SEM:SBLock<i></i>:CCARrier<i></i>:IPOWER:ABSolute**Availability:** Query Only**Default:** NaN

Description: Carrier power values. The carrier power is the integrated power of the RRC-filtered signal. The RRC filter uses a bandwidth of 3.84 MHz with a roll-off factor of 0.22. The carrier is centered at a frequency determined by the Center Frequency and methods. This value is expressed in dBm.

Return type: Double

:FETch:NR:RESults<i></i>:SEM:SBLock<i></i>:CCARrier<i></i>:IPOWER:RELative**Availability:** Query Only**Default:** NaN

Description: Carrier power values relative to the total carrier power of all enabled carriers. This value is expressed in dB.

Return type: Double

:FETch:NR:RESults<i></i>:SEM:SBLock<i></i>:CCARrier<i></i>:POWER:PEAK:ABS**Availability:** Query Only**Default:** N/A

Description: Absolute peak power in dBm.

Return type: Double

:FETch:NR:RESults<i></i>:SEM:SBLock<i></i>:MEAS**Availability:** Query Only**Default:** N/A

Description: Contains the results of the subblock measurements.

Return type: SubblockMeasurementResults

:FETch:NR:RESults<i></i>:SEM:SBLock<i></i>:MEAS:ALL**Availability:** Query Only**Default:** N/A

Description: Returns string with results for NRModAccCarrier.

Return type: String

:FETch:NR:RESults<i></i>:SEM:SBLock<i></i>:MEAS:FREquency**Availability:** Query Only**Default:** NaN

Description: Contains the absolute center frequency of the subblock. This value is the center of the subblock integration bandwidth.

Return type: Double

:FETch:NR:RESults<i></i>:SEM:SBLock<i></i>:MEAS:IBANDwidth**Availability:** Query Only**Default:** NaN

Description: Contains the integration bandwidth used in calculating the power of the subblock. Integration bandwidth is the span from left edge of the leftmost carrier to the right edge of the rightmost carrier within a subblock.

Return type: Double

:FETch:NR:RESults<i></i>:SEM:SBLock<i></i>:MEAS:POWER**Availability:** Query Only**Default:** NaN

Description: Contains the sum of powers of all the frequency bins over the integration bandwidth of the subblock.

Return type: Double

:FETch:NR:RESults<i>:SEM:SBLock<i>:OFFSet:MARGin**Availability:** Query Only**Default:** N/A**Description:** Builds the offset margin results.**Return type:** [<LowerOffsetMargins>,...], [<UpperOffsetMargins>,...]

:FETch:NR:RESults<i>:SEM:SBLock<i>:OFFSet:MARGin:LOWer<i>**Availability:** Query Only**Default:** N/A**Description:** Contains the results of the lower offset margin results.**Return type:** <Margin_dB>, <MarginFrequency_Hz>, <MarginAbsolutePower_dBm>, <MarginRelativePower_dB>, <StatusOfMeasurement>

:FETch:NR:RESults<i>:SEM:SBLock<i>:OFFSet:MARGin:LOWer<i>:FREQuency**Availability:** Query Only**Default:** N/A**Description:** Contains the array of frequency at which the margin occurs in the lower (negative) offset. For the intra-band noncontiguous type of carrier aggregation, the offset segment may be truncated or discarded based on offset overlap rules as defined in the 3GPP TS 36.521 specification. If the offset segment is truncated, the SEM results lower offset start frequency and SEM results lower offset stop frequency are updated, and the measurement is performed on the updated offset segment. If the offset segment is discarded, a NaN is returned.**Return type:** Double

:FETch:NR:RESults<i>:SEM:SBLock<i>:OFFSet:MARGin:LOWer<i>:MARGin**Availability:** Query Only**Default:** N/A**Description:** Contains the array of margins from the standard-defined absolute limit mask for the lower (negative) offset. Margin is defined as the minimum difference between the spectrum and the limit mask. For the intra-band noncontiguous type of carrier aggregation, the offset segment may be truncated or discarded based on offset overlap rules as defined in the 3GPP TS 36.521 specification. If the offset segment is truncated, the SEM results lower offset start frequency and SEM results lower offset stop frequency are updated, and the measurement is performed on the updated offset segment. If the offset segment is discarded, a NaN is returned.**Return type:** Double

:FETch:NR:RESults<i>:SEM:SBLock<i>:OFFSet:MARGin:LOWer<i>:POWER:ABSolute**Availability:** Query Only**Default:** N/A**Description:** Contains the array of power at which the margin occurs in the upper (positive) offset segment. For the intra-band noncontiguous type of carrier aggregation, the offset segment may be truncated or discarded based on offset overlap rules as defined in the 3GPP TS 36.521 specification. If the offset segment is truncated, the SEM results lower offset start frequency and SEM results lower offset stop frequency are updated, and the measurement is performed on the updated offset segment. If the offset segment is discarded, a NaN is returned.**Return type:** Double

:FETch:NR:RESults<i>:SEM:SBLock<i>:OFFSet:MARGin:LOWer<i>:POWer:RELative**Availability:** Query Only**Default:** N/A

Description: Contains the array of powers at which the margin occurs in the upper (positive) offset segment relative to the value of TotalAggregatedPower. For the intra-band noncontiguous type of carrier aggregation, the offset segment may be truncated or discarded based on offset overlap rules as defined in the 3GPP TS 36.521 specification. If the offset segment is truncated the measurement is performed on the updated offset segment. If the offset segment is discarded, a NaN is returned.

Return type: Double

:FETch:NR:RESults<i>:SEM:SBLock<i>:OFFSet:MARGin:LOWer<i>:STATus**Availability:** Query Only**Default:** N/A

Description: Contains the array of the measurement status indicating whether the power before and after the burst is within the standard defined limit.

Return type: Boolean

:FETch:NR:RESults<i>:SEM:SBLock<i>:OFFSet:MARGin:UPPer<i>**Availability:** Query Only**Default:** N/A

Description: Contains the results of the upper offset margin.

Return type: <Margin_dB>, <MarginFrequency_Hz>, <MarginAbsolutePower_dBm>, <MarginRelativePower_dB>, <StatusOfMeasurement>

:FETch:NR:RESults<i>:SEM:SBLock<i>:OFFSet:MARGin:UPPer<i>:FREQuency**Availability:** Query Only**Default:** N/A

Description: Contains the array of frequency at which the margin occurs in the lower (negative) offset. For the intra-band noncontiguous type of carrier aggregation, the offset segment may be truncated or discarded based on offset overlap rules as defined in the 3GPP TS 36.521 specification. If the offset segment is truncated, the SEM results lower offset start frequency and SEM results lower offset stop frequency are updated, and the measurement is performed on the updated offset segment. If the offset segment is discarded, a NaN is returned.

Return type: Double

:FETch:NR:RESults<i>:SEM:SBLock<i>:OFFSet:MARGin:UPPer<i>:MARGin**Availability:** Query Only**Default:** N/A

Description: Contains the array of margins from the standard-defined absolute limit mask for the lower (negative) offset. Margin is defined as the minimum difference between the spectrum and the limit mask. For the intra-band noncontiguous type of carrier aggregation, the offset segment may be truncated or discarded based on offset overlap rules as defined in the 3GPP TS 36.521 specification. If the offset segment is truncated, the SEM results lower offset start frequency and SEM results lower offset stop frequency are updated, and the measurement is performed on the updated offset segment. If the offset segment is discarded, a NaN is returned.

Return type: Double

:FETch:NR:RESults<i>:SEM:SBLock<i>:OFFSet:MARGin:UPPer<i>:POWer:ABSolute**Availability:** Query Only**Default:** N/A

Description: Contains the array of power at which the margin occurs in the upper (positive) offset segment. For the intra-band noncontiguous type of carrier aggregation, the offset segment may be truncated or discarded based on offset overlap rules as defined in the 3GPP TS 36.521 specification. If the offset segment is truncated, the SEM results lower offset start frequency and SEM results lower offset stop frequency are updated, and the measurement is performed on the updated offset segment. If the offset segment is discarded, a NaN is returned.

Return type: Double

:FETch:NR:RESults<i>:SEM:SBLock<i>:OFFSet:MARGin:UPPer<i>:POWer:RELative**Availability:** Query Only**Default:** N/A

Description: Contains the array of powers at which the margin occurs in the upper (positive) offset segment relative to the value of TotalAggregatedPower. For the intra-band noncontiguous type of carrier aggregation, the offset segment may be truncated or discarded based on offset overlap rules as defined in the 3GPP TS 36.521 specification. If the offset segment is truncated the measurement is performed on the updated offset segment. If the offset segment is discarded, a NaN is returned.

Return type: Double

:FETch:NR:RESults<i>:SEM:SBLock<i>:OFFSet:MARGin:UPPer<i>:STATus**Availability:** Query Only**Default:** N/A

Description: Contains the array of the measurement status indicating whether the power before and after the burst is within the standard defined limit.

Return type: Boolean

:FETch:NR:RESults<i>:SEM:SBLock<i>:OFFSet:POWer**Availability:** Query Only**Default:** N/A

Description: Builds the offset power results.

Return type: [<LowerOffsetPowers>,...], [<UpperOffsetPowers>,...]

:FETch:NR:RESults<i>:SEM:SBLock<i>:OFFSet:POWer:LOWer<i>**Availability:** Query Only**Default:** N/A

Description: Contains the results of the lower offset power measurements.

Return type: <PeakFrequency_Hz>, <RelativePeakPower_dBm
AbsolutePeakPower_dBm>, <RelativeIntegratedPower_dBm>,
<AbsoluteIntegratedPower_dBm>

:FETch:NR:RESults<i>:SEM:SBLock<i>:OFFSet:POWer:LOWer<i>:FREQuency**Availability:** Query Only**Default:** N/A

Description: Peak frequency in Hz.

Return type: Double

:FETch:NR:RESults<i>:SEM:SBLock<i>:OFFSet:POWer:LOWer<i>:IPOWer:ABSolute**Availability:** Query Only**Default:** N/A

Description: Contains the array of lower (negative) offset segment powers. For the intra-band noncontiguous type of carrier aggregation, the offset segment may be truncated or discarded based on offset overlap rules as defined in the 3GPP TS 36.521 specification. If the offset segment is truncated the measurement is performed on the updated offset segment. If the offset segment is discarded, a NaN is returned.

Return type: Double

:FETch:NR:RESults<i>:SEM:SBLock<i>:OFFSet:POWer:LOWer<i>:IPOWer:RELative**Availability:** Query Only**Default:** N/A

Description: Carrier power values relative to the total carrier power of all enabled carriers. This value is expressed in dB.

Return type: Double

:FETch:NR:RESults<i>:SEM:SBLock<i>:OFFSet:POWer:LOWer<i>:POWer:ABSolute**Availability:** Query Only**Default:** N/A

Description: Absolute peak power in dBm.

Return type: Double

:FETch:NR:RESults<i>:SEM:SBLock<i>:OFFSet:POWer:LOWer<i>:POWer:RELative**Availability:** Query Only**Default:** N/A

Description: Contains the array of peak power in the upper (positive) offset segment relative to the value returned by the SEM Results Total Aggregated Pwr method. For the intra-band noncontiguous type of carrier aggregation, the offset segment may be truncated or discarded based on offset overlap rules as defined in the 3GPP TS 36.521 specification. If the offset segment is truncated the measurement is performed on the updated offset segment. If the offset segment is discarded, a NaN is returned.

Return type: Double

:FETch:NR:RESults<i>:SEM:SBLock<i>:OFFSet:POWer:UPPer<i>**Availability:** Query Only**Default:** N/A

Description: Contains the results of the upper offset power results.

Return type: <PeakFrequency_Hz>, <RelativePeakPower_dBm
AbsolutePeakPower_dBm>, <RelativeIntegratedPower_dBm>,
<AbsoluteIntegratedPower_dBm>

:FETch:NR:RESults<i>:SEM:SBLock<i>:OFFSet:POWer:UPPer<i>:FREQuency**Availability:** Query Only**Default:** N/A

Description: Peak frequency in Hz.

Return type: Double

:FETch:NR:RESults<i>:SEM:SBLock<i>:OFFSet:POWer:UPPer<i>:IPOWer:ABSolute**Availability:** Query Only**Default:** N/A

Description: Contains the array of lower (negative) offset segment powers. For the intra-band noncontiguous type of carrier aggregation, the offset segment may be truncated or discarded based on offset overlap rules as defined in the 3GPP TS 36.521 specification. If the offset segment is truncated the measurement is performed on the updated offset segment. If the offset segment is discarded, a NaN is returned.

Return type: Double

:FETch:NR:RESults<i>:SEM:SBLock<i>:OFFSet:POWer:UPPer<i>:IPOWer:RELative**Availability:** Query Only**Default:** N/A

Description: Carrier power values relative to the total carrier power of all enabled carriers. This value is expressed in dB.

Return type: Double

:FETch:NR:RESults<i>:SEM:SBLock<i>:OFFSet:POWer:UPPer<i>:POWer:ABSolute**Availability:** Query Only**Default:** N/A

Description: Absolute peak power in dBm.

Return type: Double

:FETch:NR:RESults<i>:SEM:SBLock<i>:OFFSet:POWer:UPPer<i>:POWer:RELative**Availability:** Query Only**Default:** N/A

Description: Contains the array of peak power in the upper (positive) offset segment relative to the value returned by the SEM Results Total Aggregated Pwr method. For the intra-band noncontiguous type of carrier aggregation, the offset segment may be truncated or discarded based on offset overlap rules as defined in the 3GPP TS 36.521 specification. If the offset segment is truncated the measurement is performed on the updated offset segment. If the offset segment is discarded, a NaN is returned.

Return type: Double

:FETch:NR:RESults<i>:SEM:SBLock<i>:POWer:TOTal**Availability:** Query Only**Default:** NaN

Description: Contains the sum of powers of all the subblocks. This value includes the power in the inter-carrier gaps within a subblock, but it does not include the power in the subblock gaps.

Return type: Double

:FETch:NR:RESults<i>:SEM:SBLock<i>:STATus**Availability:** Query Only**Default:** 0

Description: Contains the measurement status indicating whether the power before and after the burst is within the standard defined limit.

Return type: Boolean

:FETch:NR:RESults<i>:TXP:SBLock<i>:ALL**Availability:** Query Only**Default:** N/A

Description: Returns string with results for NRTxpResults

Return type: String

:FETch:NR:RESults<i>:TXP:SBLock<i>:AVG:POWer:MEAN**Availability:** Query Only**Default:** NaN**Description:** Returns the average power of the acquired signal.**Return type:** Double

:FETch:NR:RESults<i>:TXP:SBLock<i>:NUMber**Availability:** Query Only**Default:** 0**Description:** Returns the number of sub block in the NR Txp measurement.**Return type:** Int32

:FETch:NR:RESults<i>:TXP:SBLock<i>:PEAK:POWer:MAXimum**Availability:** Query Only**Default:** NaN**Description:** Returns the peak power of the acquired signal.**Return type:** Double

:NR:INITiate <resultSpace>**Availability:** Command Only**Default:** N/A**Description:** Initiates the NR analyzer. Starts the measurement.**Parameters:** <resultSpace> Int32

:NR:MEASurement:STATe**Availability:** Query Only**Default:** N/A**Description:** Returns the current state of the measurement.**Return type:** READY | PROCESSING | OFF | PENDING | ACTIVE

:NR:RESet**Availability:** Command Only**Default:** N/A**Description:** Resets the NR analyzer parameters.

:TRIGger:NR:DELay <TriggerDelay_sec>**Availability:** Command and Query**Default:** N/A**Description:** Specifies the delay (in seconds) between the trigger onset and the start of data acquisition.**Parameters:** <TriggerDelay_sec> Double

:TRIGger:NR:EDGE <TriggerEdge>**Availability:** Command and Query**Default:** RISING**Description:** Specifies whether to trigger on the rising or falling edge for digital or power triggering.**Parameters:** <TriggerEdge> RISING | FALLING

:TRIGger:NR:MQTime <TriggerMinQuietDuration_sec>**Availability:** Command and Query**Default:** N/A**Description:** Specifies the Minimum Quiet Time between triggers. Negative value (e.g. -1) enables automatic duration.**Parameters:** <TriggerMinQuietDuration_sec> Double

:TRIGger:NR:SOURce <TriggerSource>**Availability:** Command and Query**Default:** IMMEDIATE**Description:** Specifies the trigger source.**Parameters:** <TriggerSource> IMM | RF0 | VIDEO | GENERATOR |
INTERNAL | IMMEDIATE

:TRIGger:NR:THReshold <TriggerThreshold>**Availability:** Command and Query**Default:** -20**Description:** Specifies the trigger threshold to use when power triggering. Absolute level type is in dBm, relative level type (to reference level) is in dB.**Parameters:** <TriggerThreshold> Double

:TRIGger:NR:TOUT <TriggerTimeout_sec>**Availability:** Command and Query**Default:** 10**Description:** Specifies the trigger timeout in seconds.**Parameters:** <TriggerTimeout_sec> Double

6. RFSG

:CONFigure:RFSG:FREQuency <Frequency_Hz>

Availability: Command and Query **Default:** 1950000000

Description: Specifies the frequency of the generated RF signal. For arbitrary waveform generation, this parameter specifies, in Hz, the center frequency of the signal.

Parameters: <Frequency_Hz> Double

:CONFigure:RFSG:POWer <PowerLevel_dBm>

Availability: Command and Query **Default:** 0

Description: Specifies the power level of the generated RF signal, expressed in dBm. By default, this parameter specifies the average power of the signal.

Parameters: <PowerLevel_dBm> Double

:CONFigure:RFSG:REPetition:CYCLes <RepetitionCycles>

Availability: Command and Query **Default:** 1

Description: Defines the number of the generation cycles in case of finite repetition mode.

Parameters: <RepetitionCycles> Int32

:CONFigure:RFSG:REPetition:MODE <Repetition>

Availability: Command and Query **Default:** Continuous

Description: Continuous or finite amount of generation cycles.

Parameters: <Repetition> Continuous | Finite

:CONFigure:RFSG:SCRIPT:TRIGger:DIGital:EDGE:SLOPe <ScriptTriggerDigitalEdgeSlope>

Availability: Command and Query **Default:** RISING

Description: Specifies if the falling or rising edge is used for trigger.

Parameters: <ScriptTriggerDigitalEdgeSlope> RISING | FALLING

:CONFigure:RFSG:SCRIPT:TRIGger:DIGital:EDGE:SOURce <ScriptTriggerDigitalEdgeSource>

Availability: Command and Query **Default:** PFI0

Description: Specifies for the digital edge trigger for the script0-source.

Parameters: <ScriptTriggerDigitalEdgeSource> PFI0 | PFI1 | PFI2 | PFI3 |
PxiTriggerLine0 | PxiTriggerLine1 |
PxiTriggerLine2 | PxiTriggerLine3 |
PxiTriggerLine4 | PxiTriggerLine5 |
PxiTriggerLine6 | PxiTriggerLine7 |
PxiStarLine

:CONFigure:RFSG:SCRIPT:TRIGger:DIGital:LEVel <ScriptTriggerDigitalLevel>

Availability: Command and Query **Default:** High

Description: Specifies the level is used for trigger.

Parameters: <ScriptTriggerDigitalLevel> ActiveHigh | ActiveLow

**:CONFigure:RFSG:SCRIPT:TRIGger:DIGital:LEVel:SOURce
<ScriptTriggerDigitalLevelSource>**

Availability: Command and Query **Default:** PF10

Description: Specifies for the digital level trigger for the script0-source.

Parameters: <ScriptTriggerDigitalLevelSource> PF10 | PF11 | PF12 | PF13 |
PxiTriggerLine0 | PxiTriggerLine1 |
PxiTriggerLine2 | PxiTriggerLine3 |
PxiTriggerLine4 | PxiTriggerLine5 |
PxiTriggerLine6 | PxiTriggerLine7 |
PxiStarLine

:CONFigure:RFSG:SCRIPT:TRIGger:TYPE <ScriptTriggerSetType>

Availability: Command and Query **Default:** IMM

Description: Specifies the trigger type. None (default) means no trigger.

Parameters: <ScriptTriggerSetType> None | DigitalEdge | DigitalLevel

:CONFigure:RFSG:WAVEform <Waveform>

Availability: Command and Query **Default:** N/A

Description: Filename of waveform to generated.

Parameters: <Waveform> String

:CONFigure:RFSG:WAVEforms:FOLDer

Availability: Query Only

Default:
C:\Users\Public\Documents\Noffz\UWT\Waveforms

Description: Folder where the waveforms have been loaded from. Read only. Waveform management on the API will be implemented later.

Return type: String

:OUTPut:TRIGger:SCRIPT:OUTPut:TERminal <ScriptTriggerExportedOutputTerminal>

Availability: Command and Query **Default:** None

Description: Specifies to which port the trigger is exposed.

Parameters: <ScriptTriggerExportedOutputTerminal> DoNotExport | PF10 | PF11 | PF14 | PF15
| PxiTriggerLine0 | PxiTriggerLine1 |
PxiTriggerLine2 | PxiTriggerLine3 |
PxiTriggerLine4 | PxiTriggerLine5 |
PxiTriggerLine6

:RFSG:ABORt

Availability: Command Only

Default: N/A

Description: Aborts the generation.

:RFSG:DB:UPDate**Availability:** Command Only**Default:** N/A**Description:** Updates the data base.

:RFSG:DB:VALidate**Availability:** Command and Query**Default:** N/A**Description:** Check the data in the data base.

:RFSG:GENerating**Availability:** Command and Query**Default:** N/A**Description:** Checks if the generation is ongoing.

:RFSG:INITiate**Availability:** Command Only**Default:** N/A**Description:** Starts the genention.

:RFSG:RESet**Availability:** Command Only**Default:** N/A**Description:** Resets the generator to its default state.

7. Wcdma

:CONFigure:WCDMA:ACP:AMPLitude:CORRection:TYPe <AcpAmplitudeCorrectionType>

Availability: Command and Query **Default:** RFCenterFrequency

Description: Sets whether the amplitude of the frequency bins, used in measurements, is corrected for external attenuation at the RF center frequency, or at the individual frequency bins. Use the RFmxInstr_CfgExternalAttenuation function to configure the external attenuation table.

Parameters: <AcpAmplitudeCorrectionType> RFCenterFrequency | SpectrumFrequencyBin

:CONFigure:WCDMA:ACP:AVG:COUNT <AcpAveragingCount>

Availability: Command and Query **Default:** 10

Description: Sets the number of acquisitions used for averaging when you set the to .

Parameters: <AcpAveragingCount> Int32

:CONFigure:WCDMA:ACP:AVG:ENABLE <AcpAveragingEnabled>

Availability: Command and Query **Default:** 0

Description: Sets whether to enable averaging for the ACP measurement.

Parameters: <AcpAveragingEnabled> Boolean

:CONFigure:WCDMA:ACP:AVG:TYPe <AcpAveragingType>

Availability: Command and Query **Default:** Log

Description: Sets the averaging type for averaging the spectrum of multiple acquisitions. The averaged spectrum is used for ACP measurement.

Parameters: <AcpAveragingType> Rms | Log | Scalar | Max | Min | Vector

:CONFigure:WCDMA:ACP:IF:OUTput:POWer:OFFSet:AUTO <AcpIFOutputPowerOffsetAuto>

Availability: Command and Query **Default:** 0

Description: Sets whether the measurement computes an IF output power level offset for the offset channels to improve the dynamic range of the ACP measurement.

Parameters: <AcpIFOutputPowerOffsetAuto> Boolean

:CONFigure:WCDMA:ACP:IF:OUTput:POWer:OFFSet:FAR <AcpFarIFOutputPowerOffset_dB>

Availability: Command and Query **Default:** 20

Description: Sets the power offset to use to adjust the IF output power level for offset channels that are far from the carrier channel. Adjusting the IF output power level improves the dynamic range.

Parameters: <AcpFarIFOutputPowerOffset_dB> Double

**:CONFigure:WCDMA:ACP:IF:OUTput:POWer:OFFSet:NEAR
<AcpNearIFOutputPowerOffset_dB>**

Availability: Command and Query **Default:** 10

Description: Sets the power offset to use to adjust the IF output power level for offset channels near the carrier channel. Adjusting the IF output power level improves the dynamic range.

Parameters: <AcpNearIFOutputPowerOffset_dB> Double

:CONFigure:WCDMA:ACP:MEASurement:ENABLE <AcpMeasurementEnabled>

Availability: Command and Query **Default:** 1

Description: Sets whether to enable the ACP measurement.

Parameters: <AcpMeasurementEnabled> Boolean

:CONFigure:WCDMA:ACP:METHod <AcpMeasurementMethod>

Availability: Command and Query **Default:** Normal

Description: Sets the method for performing the ACP measurement.

Parameters: <AcpMeasurementMethod> Normal | DynamicRange | SequentialFft

:CONFigure:WCDMA:ACP:NOFFset <AcpNumberOfOffsets>

Availability: Command and Query **Default:** 2

Description: Sets the number of offset channels.

Parameters: <AcpNumberOfOffsets> Int32

**:CONFigure:WCDMA:ACP:NOISe:COMPensation:ENABLE
<AcpNoiseCompensationEnabled>**

Availability: Command and Query **Default:** 0

Description: Sets whether to enable compensation of the channel powers for the inherent noise floor of the signal analyzer. Supported Devices: PXIe-5663/5665/5668R, PXIe-5830/5831.

Parameters: <AcpNoiseCompensationEnabled> Boolean

:CONFigure:WCDMA:ACP:NTHReads <AcpNumberOfAnalysisThreads>

Availability: Command and Query **Default:** 1

Description: Sets the maximum number of threads used for parallelism for the ACP measurement.

Parameters: <AcpNumberOfAnalysisThreads> Int32

**:CONFigure:WCDMA:ACP:OFFSet:POWer:REFerence:CARRier
<AcpOffsetPowerReferenceCarrier>**

Availability: Command and Query **Default:** Closest

Description: Sets the carrier used as the power reference to measure the offset channel relative power.

Parameters: <AcpOffsetPowerReferenceCarrier> Closest | Highest | Composite | Specific

**:CONFigure:WCDMA:ACP:OFFSet:POWer:REFeRence:SPECific
<AcpOffsetPowerReferenceSpecific>**

Availability: Command and Query **Default:** 0

Description: Sets the index of the reference carrier.

Parameters: <AcpOffsetPowerReferenceSpecific> Int32

:CONFigure:WCDMA:ACP:RBW:AUTO:BWIDth <AcpRbwAutoBandwidth>

Availability: Command and Query **Default:** 0

Description: Sets whether the measurement computes the RBW.

Parameters: <AcpRbwAutoBandwidth> Boolean

:CONFigure:WCDMA:ACP:RBW:FILTer:BWIDth <AcpRbwFilterBandwidth_Hz>

Availability: Command and Query **Default:** 38400

Description: Sets the bandwidth of the RBW filter used to sweep the acquired signal when you set the method to . This method is valid only if you set the method to or .

Parameters: <AcpRbwFilterBandwidth_Hz> Double

:CONFigure:WCDMA:ACP:RBW:FILTer:TYPE <AcpRbwFilterType>

Availability: Command and Query **Default:** Flat

Description: Sets the shape of the digital RBW filter.

Parameters: <AcpRbwFilterType> FftBased | Gaussian | Flat |
SynchTuned4 | SyncTunded5

:CONFigure:WCDMA:ACP:SEQuential:FFT:SIZE <AcpSequentialFftSize>

Availability: Command and Query **Default:** 512

Description: Sets the number of bins to use for FFT computation when the method is set to .

Parameters: <AcpSequentialFftSize> Int32

:CONFigure:WCDMA:ACP:SWEep:TIME:AUTO <AcpSweepTimeAuto>

Availability: Command and Query **Default:** 0

Description: Sets whether the measurement computes the sweep time.

Parameters: <AcpSweepTimeAuto> Boolean

:CONFigure:WCDMA:ACP:SWEep:TIME:INTerval <AcpSweepTimeInterval_s>

Availability: Command and Query **Default:** 0.00066667

Description: Sets the sweep time when you set the method to .

Parameters: <AcpSweepTimeInterval_s> Double

:CONFigure:WCDMA:ACP:TRACe:ENABle <AcpAllTracesEnabled>

Availability: Command and Query **Default:** 0

Description: Sets whether to enable the traces to be stored and retrieved after performing the ACP measurement.

Parameters: <AcpAllTracesEnabled> Boolean

:CONFigure:WCDMA:BAND <Band>

Availability: Command and Query **Default:** 1

Description: Configure the Universal Mobile Telecommunications System (UMTS) operation band.

Parameters: <Band> Int32

:CONFigure:WCDMA:BRANch <Branch>

Availability: Command and Query **Default:** I

Description: Configure the branch on which the data is modulated in the channel.

Parameters: <Branch> I | Q

:CONFigure:WCDMA:CARrier:FREQuency:CENTer <CenterCarrierFrequency_Hz>

Availability: Command and Query **Default:** 0

Description: Configure the center frequency of the carrier, relative to the RF.

Parameters: <CenterCarrierFrequency_Hz> Double

**:CONFigure:WCDMA:CDA:IQ:OFFSet:REMOval:ENABle
<CdaIQOffsetRemovalEnabled>**

Availability: Command and Query **Default:** 0

Description: Sets whether to remove the I/Q offset before the CDA measurement.

Parameters: <CdaIQOffsetRemovalEnabled> Boolean

**:CONFigure:WCDMA:CDA:MEASurement:CHANnel:BRANch
<CdaMeasurementChannelBranch>**

Availability: Command and Query **Default:** I

Description: Sets the branch of the measurement channel. This value is used to compute the symbol results of the CDA measurement.

Parameters: <CdaMeasurementChannelBranch> I | Q

**:CONFigure:WCDMA:CDA:MEASurement:CHANnel:MODulation:TYPE
<CdaMeasurementChannelModulationType>**

Availability: Command and Query **Default:** ModulationTypeBpskQpsk

Description: Sets the modulation type of the measurement channel. This value is used to compute the symbol results of the CDA measurement.

Parameters: <CdaMeasurementChannelModulationType> ModulationTypeBpskQpsk |
ModulationType4Pam16Qam

**:CONFigure:WCDMA:CDA:MEASurement:CHANnel:SPReading:CODE
<CdaMeasurementChannelSpreadingCode>**

Availability: Command and Query **Default:** 0

Description: Sets the spreading code of the measurement channel. This value is used to compute the symbol results of the CDA measurement.

Parameters: <CdaMeasurementChannelSpreadingCode> Int32

**:CONFigure:WCDMA:CDA:MEASurement:CHANnel:SPReading:FACTOR
<CdaMeasurementChannelSpreadingFactor>**

Availability: Command and Query **Default:** 256

Description: Sets the spreading factor of the measurement channel. This value is used to compute the symbol results of the CDA measurement.

Parameters: <CdaMeasurementChannelSpreadingFactor> Int32

:CONFigure:WCDMA:CDA:MEASurement:ENABLE <CdaMeasurementEnabled>

Availability: Command and Query **Default:** 0

Description: Sets whether to enable the CDA measurement.

Parameters: <CdaMeasurementEnabled> Boolean

:CONFigure:WCDMA:CDA:MEASurement:LENGth <CdaMeasurementLength>

Availability: Command and Query **Default:** 1

Description: Sets the duration of the code domain measurement. This value is expressed in slots.

Parameters: <CdaMeasurementLength> Int32

:CONFigure:WCDMA:CDA:MEASurement:OFFSet <CdaMeasurementOffset>

Availability: Command and Query **Default:** 0

Description: Sets the measurement offset to skip from the synchronization boundary. This value is expressed in slots. The synchronization boundary is specified by the method.

Parameters: <CdaMeasurementOffset> Int32

:CONFigure:WCDMA:CDA:POWER:UNIT <CdaPowerUnit>

Availability: Command and Query **Default:** dBm

Description: Sets the measurement unit of all power results, except .

Parameters: <CdaPowerUnit> dB | dBm

:CONFigure:WCDMA:CDA:RRC:FILTER:ENABLE <CdaRrcFilterEnabled>

Availability: Command and Query **Default:** 0

Description: Sets whether to enable the RRC filter. Use this method to disable the filter if the received signal is already RRC-filtered.

Parameters: <CdaRrcFilterEnabled> Boolean

:CONFigure:WCDMA:CDA:SPECTrum:INVerted <CdaSpectrumInverted>

Availability: Command and Query **Default:** 0

Description: Sets whether the spectrum of the signal is inverted.

Parameters: <CdaSpectrumInverted> Boolean

:CONFigure:WCDMA:CDA:SYNC <CdaSynchronizationMode>

Availability: Command and Query **Default:** Frame

Description: Sets whether the measurement is performed from the frame, slot, or symbol boundary.

Parameters: <CdaSynchronizationMode> Frame | Slot | Arbitrary

:CONFigure:WCDMA:CDA:TRACe:ENABle <CdaAllTracesEnabled>

Availability: Command and Query **Default:** 0

Description: Sets whether to enable the traces after performing the CDA measurement.

Parameters: <CdaAllTracesEnabled> Boolean

:CONFigure:WCDMA:CHANnel:CONFIguration:MODE <ChannelConfigurationMode>

Availability: Command and Query **Default:** AutoDetect

Description: Configure the channel configuration mode.

Parameters: <ChannelConfigurationMode> AutoDetect | UserDefined | TestModel

**:CONFigure:WCDMA:CHP:AMPLitude:CORRection:TYPE
<ChpAmplitudeCorrectionType>**

Availability: Command and Query **Default:** RFCenterFrequency

Description: Sets whether the amplitude of the frequency bins, used in measurements, is corrected for external attenuation at the RF center frequency, or at the individual frequency bins. Use the RFmxInstr_CfgExternalAttenuation function to configure the external attenuation table.

Parameters: <ChpAmplitudeCorrectionType> RFCenterFrequency |
SpectrumFrequencyBin

:CONFigure:WCDMA:CHP:AVG:COUNT <ChpAveragingCount>

Availability: Command and Query **Default:** 10

Description: Sets the number of acquisitions used for averaging when you set the method to .

Parameters: <ChpAveragingCount> Int32

:CONFigure:WCDMA:CHP:AVG:ENABle <ChpAveragingEnabled>

Availability: Command and Query **Default:** 1

Description: Sets whether to enable averaging for the CHP measurement.

Parameters: <ChpAveragingEnabled> Boolean

:CONFigure:WCDMA:CHP:AVG:TYPE <ChpAveragingType>

Availability: Command and Query **Default:** Rms

Description: Sets the averaging type for averaging the spectrum of multiple acquisitions.

Parameters: <ChpAveragingType> Rms | Log | Scalar | Max | Min | Vector

:CONFigure:WCDMA:CHP:MEASurement:ENABle <ChpMeasurementEnabled>

Availability: Command and Query **Default:** 1

Description: Sets whether to enable the CHP measurement.

Parameters: <ChpMeasurementEnabled> Boolean

:CONFigure:WCDMA:CHP:NTHReads <ChpNumberOfAnalysisThreads>

Availability: Command and Query **Default:** 1

Description: Sets the maximum number of threads used for parallelism for the CHP measurement.

Parameters: <ChpNumberOfAnalysisThreads> Int32

:CONFigure:WCDMA:CHP:RBW:AUTO:BWIDth <ChpRbwAutoBandwidth>

Availability: Command and Query **Default:** 0

Description: Sets whether the measurement computes the RBW.

Parameters: <ChpRbwAutoBandwidth> Boolean

:CONFigure:WCDMA:CHP:RBW:FILTer:BWIDth <ChpRbwFilterBandwidth_Hz>

Availability: Command and Query **Default:** 50000

Description: Sets the bandwidth of the RBW filter used to sweep the acquired signal when you set the method to . This method is valid only if you set the method to or .

Parameters: <ChpRbwFilterBandwidth_Hz> Double

:CONFigure:WCDMA:CHP:RBW:FILTer:TYPE <ChpRbwFilterType>

Availability: Command and Query **Default:** Flat

Description: Sets the shape of the digital RBW filter.

Parameters: <ChpRbwFilterType> FftBased | Gaussian | Flat |
SynchTuned4 | SynchTuned5

:CONFigure:WCDMA:CHP:SWEep:TIME:AUTO <ChpSweepTimeAuto>

Availability: Command and Query **Default:** 0

Description: Sets whether the measurement computes the sweep time.

Parameters: <ChpSweepTimeAuto> Boolean

:CONFigure:WCDMA:CHP:SWEep:TIME:INTerval <ChpSweepTimeInterval_s>

Availability: Command and Query **Default:** 0.00066667

Description: Sets the sweep time when you set the method to .

Parameters: <ChpSweepTimeInterval_s> Double

:CONFigure:WCDMA:CHP:TRACe:ENABle <ChpAllTracesEnabled>

Availability: Command and Query **Default:** 0

Description: Sets whether to enable the traces to be stored and retrieved after performing the CHP measurement.

Parameters: <ChpAllTracesEnabled> Boolean

:CONFigure:WCDMA:FREQuency:CENTer <CenterFrequency_Hz>

Availability: Command and Query **Default:** 1950000000

Description: For a single-carrier measurement, this method configure the center frequency of the acquired RF signal. For multi-carrier measurements, this method configure the reference frequency for the values in the method.

Parameters: <CenterFrequency_Hz> Double

**:CONFigure:WCDMA:MODacc:IQ:GAIN:IMBalance:REMOval:ENABle
<ModAccIQGainImbalanceRemovalEnabled>**

Availability: Command and Query **Default:** 0

Description: Sets whether to remove I/Q gain imbalance before the ModAcc Measurement.

Parameters: <ModAccIQGainImbalanceRemovalEnabled> Boolean

**:CONFigure:WCDMA:MODacc:IQ:OFFSet:REMOval:ENABLE
<ModAccIQOffsetRemovalEnabled>**

Availability: Command and Query **Default:** 0

Description: Sets whether to remove the I/Q offset before the ModAcc measurement.

Parameters: <ModAccIQOffsetRemovalEnabled> Boolean

**:CONFigure:WCDMA:MODacc:IQ:QERRorREMOval:ENABLE
<ModAccIQQuadratureErrorRemovalEnabled>**

Availability: Command and Query **Default:** 0

Description: Sets whether to remove the I/Q quadrature error before the ModAcc measurement.

Parameters: <ModAccIQQuadratureErrorRemovalEnabled> Boolean

:CONFigure:WCDMA:MODacc:MEASurement:ENABLE <ModAccMeasurementEnabled>

Availability: Command and Query **Default:** 1

Description: Sets whether to enable modulation accuracy (ModAcc) measurements on the acquired signal.

Parameters: <ModAccMeasurementEnabled> Boolean

:CONFigure:WCDMA:MODacc:MEASurement:LENGth <ModAccMeasurementLength>

Availability: Command and Query **Default:** 1

Description: Sets the duration of the ModAcc measurement. This value is expressed in slots.

Parameters: <ModAccMeasurementLength> Int32

:CONFigure:WCDMA:MODacc:MEASurement:OFFSet <ModAccMeasurementOffset>

Availability: Command and Query **Default:** 0

Description: Sets the measurement offset to skip from the synchronization boundary. This value is expressed in slots. The synchronization boundary is specified by the method.

Parameters: <ModAccMeasurementOffset> Int32

:CONFigure:WCDMA:MODacc:RRC:FILTer:ENABLE <ModAccRrcFilterEnabled>

Availability: Command and Query **Default:** 0

Description: Sets whether to enable the RRC filter. Use this method to disable the filter if the received signal is already RRC-filtered.

Parameters: <ModAccRrcFilterEnabled> Boolean

:CONFigure:WCDMA:MODacc:SPECTrum:INVerted <ModAccSpectrumInverted>

Availability: Command and Query **Default:** 0

Description: Sets whether the spectrum of the signal is inverted.

Parameters: <ModAccSpectrumInverted> Boolean

:CONFigure:WCDMA:MODacc:SYNC <ModAccSynchronizationMode>

Availability: Command and Query **Default:** Frame

Description: Sets whether the measurement is performed from the frame, slot, or symbol boundary.

Parameters: <ModAccSynchronizationMode> Frame | Slot | Arbitrary | Marker

:CONFigure:WCDMA:MODacc:TRACe:ENABLE <ModAccAllTracesEnabled>

Availability: Command and Query **Default:** 0

Description: Sets whether to enable the traces after performing the modulation accuracy (ModAcc) measurement.

Parameters: <ModAccAllTracesEnabled> Boolean

:CONFigure:WCDMA:MODacc:TRANSient:REMOval:ENABLE <ModAccTransientRemovalEnabled>

Availability: Command and Query **Default:** 0

Description: Sets whether the measurement excludes 25 microseconds from the start and end of each slot while computing the RMS EVM, peak EVM, RMS magnitude error and RMS phase error results.

Parameters: <ModAccTransientRemovalEnabled> Boolean

:CONFigure:WCDMA:MODulation:TYPE <ModulationType>

Availability: Command and Query **Default:** ModulationTypeBpskQpsk

Description: Configure the modulation type for the channel.

Parameters: <ModulationType> ModulationTypeBpskQpsk |
ModulationType4Pam16Qam

:CONFigure:WCDMA:NCARrier <NumberOfCarriers>

Availability: Command and Query **Default:** 1

Description: Configure the number of carriers.

Parameters: <NumberOfCarriers> Int32

:CONFigure:WCDMA:NCHannel <NumberOfChannels>

Availability: Command and Query **Default:** 1

Description: Configure the number of user-defined channels.

Parameters: <NumberOfChannels> Int32

:CONFigure:WCDMA:OBW:AMPLitude:CORRection:TYPE <ObwAmplitudeCorrectionType>

Availability: Command and Query **Default:** RFCenterFrequency

Description: Sets whether the amplitude of the frequency bins, used in measurements, is corrected for external attenuation at the RF center frequency, or at the individual frequency bins. Use the RFmxInstr_CfgExternalAttenuation function to configure the external attenuation table.

Parameters: <ObwAmplitudeCorrectionType> RFCenterFrequency |
SpectrumFrequencyBin

:CONFigure:WCDMA:OBW:AVG:COUNT <ObwAveragingCount>

Availability: Command and Query **Default:** 10

Description: Sets the number of acquisitions used for averaging when you set the method to .

Parameters: <ObwAveragingCount> Int32

:CONFigure:WCDMA:OBW:AVG:ENABLE <ObwAveragingEnabled>

Availability: Command and Query **Default:** 1

Description: Sets whether to enable averaging for the OBW measurement.

Parameters: <ObwAveragingEnabled> Boolean

:CONFigure:WCDMA:OBW:AVG:TYPE <ObwAveragingType>

Availability: Command and Query **Default:** Rms

Description: Sets the averaging type for averaging the spectrum of multiple acquisitions.

Parameters: <ObwAveragingType> Rms | Log | Scalar | Max | Min | Vector

:CONFigure:WCDMA:OBW:MEASurement:ENABLE <ObwMeasurementEnabled>

Availability: Command and Query **Default:** 1

Description: Sets whether to enable the Obw measurement.

Parameters: <ObwMeasurementEnabled> Boolean

:CONFigure:WCDMA:OBW:NTHReads <ObwNumberOfAnalysisThreads>

Availability: Command and Query **Default:** 1

Description: Sets the maximum number of threads used for parallelism for the Obw measurement.

Parameters: <ObwNumberOfAnalysisThreads> Int32

:CONFigure:WCDMA:OBW:RBW:AUTO:BWIDth <ObwRbwAutoBandwidth>

Availability: Command and Query **Default:** 0

Description: Sets whether the measurement computes the RBW.

Parameters: <ObwRbwAutoBandwidth> Boolean

:CONFigure:WCDMA:OBW:RBW:FILTer:BWIDth <ObwRbwFilterBandwidth_Hz>

Availability: Command and Query **Default:** 30000

Description: Sets the bandwidth of the RBW filter used to sweep the acquired signal when you set the method to . This method is valid only if you set the method to or .

Parameters: <ObwRbwFilterBandwidth_Hz> Double

:CONFigure:WCDMA:OBW:RBW:FILTer:TYPE <ObwRbwFilterType>

Availability: Command and Query **Default:** Flat

Description: Sets the shape of the digital RBW filter.

Parameters: <ObwRbwFilterType> FftBased | Gaussian | Flat |
SynchTuned4 | SynchTuned5

:CONFigure:WCDMA:OBW:SWEep:TIME:AUTO <ObwSweepTimeAuto>

Availability: Command and Query **Default:** 0

Description: Sets whether the measurement computes the sweep time.

Parameters: <ObwSweepTimeAuto> Boolean

:CONFigure:WCDMA:OBW:SWEep:TIME:INTErval <ObwSweepTimeInterval_s>

Availability: Command and Query **Default:** 0.00066667

Description: Sets the sweep time when you set the method to .

Parameters: <ObwSweepTimeInterval_s> Double

:CONFigure:WCDMA:OBW:TRACe:ENABle <ObwAllTracesEnabled>

Availability: Command and Query **Default:** 0

Description: Sets whether to enable the traces to be stored and retrieved after performing the Obw measurement.

Parameters: <ObwAllTracesEnabled> Boolean

:CONFigure:WCDMA:QEVm:AVG:COUnT <QevmAveragingCount>

Availability: Command and Query **Default:** 10

Description: Sets the number of acquisitions used for averaging when you set the method to .

Parameters: <QevmAveragingCount> Int32

:CONFigure:WCDMA:QEVm:AVG:ENABle <QevmAveragingEnabled>

Availability: Command and Query **Default:** 1

Description: Sets whether to enable averaging for the QEVm measurement.

Parameters: <QevmAveragingEnabled> Boolean

**:CONFigure:WCDMA:QEVm:IQ:OFFSet:REMOval:ENABle
<QevmIQOffsetRemovalEnabled>**

Availability: Command and Query **Default:** 0

Description: Sets whether to remove the I/Q offset before the QEVm measurement.

Parameters: <QevmIQOffsetRemovalEnabled> Boolean

:CONFigure:WCDMA:QEVm:MEASurement:ENABle <QevmMeasurementEnabled>

Availability: Command and Query **Default:** 0

Description: Sets whether to enable the QPSK EVM measurement.

Parameters: <QevmMeasurementEnabled> Boolean

:CONFigure:WCDMA:QEVm:MEASurement:LENGth <QevmMeasurementLength>

Availability: Command and Query **Default:** 2560

Description: Sets the duration of the QEVm measurement. This value is expressed in chips.

Parameters: <QevmMeasurementLength> Int32

:CONFigure:WCDMA:QEVm:NTHReads <QevmNumberOfAnalysisThreads>

Availability: Command and Query **Default:** 1

Description: Sets the maximum number of threads used for parallelism for the QEVm measurement.

Parameters: <QevmNumberOfAnalysisThreads> Int32

:CONFigure:WCDMA:QEVm:RRC:FILTER:ENABLE <QevmRrcFilterEnabled>

Availability: Command and Query **Default:** 0

Description: Sets whether to enable the RRC filter. Use this method to disable the filter if the received signal is already RRC-filtered.

Parameters: <QevmRrcFilterEnabled> Boolean

:CONFigure:WCDMA:QEVm:SPECTrum:INVERTed <QevmSpectrumInverted>

Availability: Command and Query **Default:** 0

Description: Sets whether the spectrum of the signal is inverted.

Parameters: <QevmSpectrumInverted> Boolean

:CONFigure:WCDMA:QEVm:TRACe:ENABLE <QevmAllTracesEnabled>

Availability: Command and Query **Default:** 0

Description: Sets whether to enable the traces to be stored and retrieved after performing the QEVm measurement.

Parameters: <QevmAllTracesEnabled> Boolean

:CONFigure:WCDMA:REFerence:AUTO:INITial <AutoLevelInitialReferenceLevel_dBm>

Availability: Command and Query **Default:** 30

Description: Configure the initial reference level that the function uses to estimate the peak power of the input signal.

Parameters: <AutoLevelInitialReferenceLevel_dBm> Double

:CONFigure:WCDMA:REFerence:LEVEL <ReferenceLevel_dBm>

Availability: Command and Query **Default:** 0

Description: Configure the reference level that represents the maximum expected power of the RF input signal.

Parameters: <ReferenceLevel_dBm> Double

:CONFigure:WCDMA:REFerence:LEVEL:UNITs <ReferenceLevelUnits>

Availability: Command and Query **Default:** dBm

Description: Configure reference level unit to Volts or dBm.

Parameters: <ReferenceLevelUnits> dBm | Volts

:CONFigure:WCDMA:SCRambling:CODE <ScramblingCode>

Availability: Command and Query **Default:** 0

Description: Configure the scrambling code for the uplink channel.

Parameters: <ScramblingCode> Int32

:CONFigure:WCDMA:SEM:AMPLitude:CORRection:TYPe
<SemAmplitudeCorrectionType>

Availability: Command and Query **Default:** RFCenterFrequency

Description: Sets whether the amplitude of the frequency bins, used in measurements, is corrected for external attenuation at the RF center frequency, or at the individual frequency bins. Use the RFmxInstr_CfgExternalAttenuation function to configure the external attenuation table.

Parameters: <SemAmplitudeCorrectionType> RFCenterFrequency | SpectrumFrequencyBin

:CONFigure:WCDMA:SEM:AVG:COUNT <SemAveragingCount>

Availability: Command and Query **Default:** 10

Description: Sets the number of acquisitions used for averaging when you set the method to .

Parameters: <SemAveragingCount> Int32

:CONFigure:WCDMA:SEM:AVG:ENABLE <SemAveragingEnabled>

Availability: Command and Query **Default:** 1

Description: Sets whether to enable averaging for the Sem measurement.

Parameters: <SemAveragingEnabled> Boolean

:CONFigure:WCDMA:SEM:AVG:TYPe <SemAveragingType>

Availability: Command and Query **Default:** Rms

Description: Sets the averaging type for averaging multiple spectrum acquisitions.

Parameters: <SemAveragingType> Rms | Log | Scalar | Max | Min | Vector

:CONFigure:WCDMA:SEM:MEASurement:ENABLE <SemMeasurementEnabled>

Availability: Command and Query **Default:** 1

Description: Sets whether to enable the Sem measurement.

Parameters: <SemMeasurementEnabled> Boolean

:CONFigure:WCDMA:SEM:NTHReads <SemNumberOfAnalysisThreads>

Availability: Command and Query **Default:** 1

Description: Sets the maximum number of threads used for parallelism for the Sem measurement.

Parameters: <SemNumberOfAnalysisThreads> Int32

:CONFigure:WCDMA:SEM:SWEep:TIME:AUTO <SemSweepTimeAuto>

Availability: Command and Query **Default:** 0

Description: Sets whether the measurement computes the sweep time.

Parameters: <SemSweepTimeAuto> Boolean

:CONFigure:WCDMA:SEM:SWEep:TIME:INTERval <SemSweepTimeInterval_s>

Availability: Command and Query **Default:** 0.00066667

Description: Sets the sweep time when you set the method to .

Parameters: <SemSweepTimeInterval_s> Double

:CONFigure:WCDMA:SEM:TRACe:ENABle <SemAllTracesEnabled>

Availability: Command and Query **Default:** 0

Description: Sets whether to enable the traces to be stored and retrieved after performing the SEM measurement.

Parameters: <SemAllTracesEnabled> Boolean

**:CONFigure:WCDMA:SLOT:PHASe:MEASurement:ENABle
<SlotPhaseMeasurementEnabled>**

Availability: Command and Query **Default:** 0

Description: Sets whether to enable the SlotPhase measurement.

Parameters: <SlotPhaseMeasurementEnabled> Boolean

**:CONFigure:WCDMA:SLOT:PHASe:MEASurement:LENGth
<SlotPhaseMeasurementLength>**

Availability: Command and Query **Default:** 15

Description: Sets the duration of the SlotPhase measurement. This value is expressed in slots.

Parameters: <SlotPhaseMeasurementLength> Int32

**:CONFigure:WCDMA:SLOT:PHASe:MEASurement:OFFSet
<SlotPhaseMeasurementOffset>**

Availability: Command and Query **Default:** 0

Description: Sets the measurement offset to skip from the synchronization boundary. This value is expressed in slots.

Parameters: <SlotPhaseMeasurementOffset> Int32

:CONFigure:WCDMA:SLOT:PHASe:RRC:FILTER:ENABle <SlotPhaseRrcFilterEnabled>

Availability: Command and Query **Default:** 0

Description: Sets whether to enable the RRC filter. Use this method to disable the filter if the received signal is already RRC-filtered.

Parameters: <SlotPhaseRrcFilterEnabled> Boolean

:CONFigure:WCDMA:SLOT:PHASe:SPECTrum:INVerted <SlotPhaseSpectrumInverted>

Availability: Command and Query **Default:** 0

Description: Sets whether the signal spectrum is inverted.

Parameters: <SlotPhaseSpectrumInverted> Boolean

:CONFigure:WCDMA:SLOT:PHASe:SYNC:Mode <SlotPhaseSynchronizationMode>

Availability: Command and Query **Default:** Frame

Description: Sets whether the measurement is performed from the frame or the slot boundary.

Parameters: <SlotPhaseSynchronizationMode> Frame | Slot

**:CONFigure:WCDMA:SLOT:PHASe:TransientREMOval:ENABLE
<SlotPhaseTransientRemovalEnabled>**

Availability: Command and Query **Default:** 0

Description: Sets whether the SlotPhase measurement excludes 25 microseconds from the start and end of each slot while computing the linear-fit chip phase error, which is used to compute phase discontinuities at the slot boundaries.

Parameters: <SlotPhaseTransientRemovalEnabled> Boolean

**:CONFigure:WCDMA:SLOT:POWER:MEASurement:ENABLE
<SlotPowerMeasurementEnabled>**

Availability: Command and Query **Default:** 0

Description: Sets whether to enable the SlotPower measurement.

Parameters: <SlotPowerMeasurementEnabled> Boolean

**:CONFigure:WCDMA:SLOT:POWER:MEASurement:LENGth
<SlotPowerMeasurementLength>**

Availability: Command and Query **Default:** 15

Description: Sets the duration of the SlotPower measurement. This value is expressed in slots.

Parameters: <SlotPowerMeasurementLength> Int32

**:CONFigure:WCDMA:SLOT:POWER:MEASurement:OFFSet
<SlotPowerMeasurementOffset>**

Availability: Command and Query **Default:** 0

Description: Sets the measurement offset to skip from the synchronization boundary. This value is expressed in slots.

Parameters: <SlotPowerMeasurementOffset> Int32

:CONFigure:WCDMA:SLOT:POWER:RRC:FILTer:ENABLE <SlotPowerRrcFilterEnabled>

Availability: Command and Query **Default:** 0

Description: Sets whether to enable the RRC filter.

Parameters: <SlotPowerRrcFilterEnabled> Boolean

:CONFigure:WCDMA:SLOT:POWER:SPECtrum:INVerted <SlotPowerSpectrumInverted>

Availability: Command and Query **Default:** 0

Description: Sets whether the signal spectrum is inverted.

Parameters: <SlotPowerSpectrumInverted> Boolean

:CONFigure:WCDMA:SLOT:POWER:SYNC <SlotPowerSynchronizationMode>

Availability: Command and Query **Default:** Frame

Description: Sets whether the measurement is performed from the frame or the slot boundary.

Parameters: <SlotPowerSynchronizationMode> Frame | Slot

:CONFigure:WCDMA:SlotPhaseAllTRACes:ENABle <SlotPhaseAllTracesEnabled>

Availability: Command and Query **Default:** 0

Description: Sets whether to enable the traces to be stored and retrieved after performing the SlotPhase measurement.

Parameters: <SlotPhaseAllTracesEnabled> Boolean

:CONFigure:WCDMA:SPReading:CODE <SpreadingCode>

Availability: Command and Query **Default:** 0

Description: Configure the spreading code of the channel.

Parameters: <SpreadingCode> Int32

:CONFigure:WCDMA:SPReading:FACTor <SpreadingFactor>

Availability: Command and Query **Default:** 256

Description: Configure the spreading factor of the channel.

Parameters: <SpreadingFactor> Int32

:CONFigure:WCDMA:UPLink:SCRambling:TYPE <UplinkScramblingType>

Availability: Command and Query **Default:** Long

Description: Configure the type of scrambling to use for the measurement.

Parameters: <UplinkScramblingType> Long | Short

:CONFigure:WCDMA:UPLink:TMODeI <UplinkTestModel>

Availability: Command and Query **Default:** R6C_2_1

Description: Configure the uplink test model when the user sets the method to .

Parameters: <UplinkTestModel> R6C_2_1 | R6C_2_2 | R6C_2_3 |
R6C_2_4 | R6C_2_5 |
R6C_10_1_4_Subtest1 |
R6C_10_1_4_Subtest2 |
R6C_10_1_4_Subtest3 |
R6C_10_1_4_Subtest4 |
R6C_10_1_4_Subtest5 |
R6C_10_1_4_Subtest6 |
R7C_10_1_4_Subtest1 |
R7C_10_1_4_Subtest2 |
R7C_10_1_4_Subtest3 |
R7C_10_1_4_Subtest4 |
R7C_11_1_3_Subtest1 |
R7C_11_1_3_Subtest2 |
R7C_11_1_3_Subtest3 |
R7C_11_1_3_Subtest4 |
R7C_11_1_3_Subtest5 |
R8C_11_1_3_Subtest1 |
R8C_11_1_3_Subtest2 |
R8C_11_1_3_Subtest3 |
R8C_11_1_3_Subtest4 |
R8C_11_1_3_Subtest5 |
R8C_11_1_4_Subtest1

:FETch:WCDMA:RESults<i>**Availability:** Query Only**Default:** N/A**Description:** Returns the results of the measurement on resultSpace = i.**Return type:** <ModAcc>, <Acp>, <Chp>, <Obw>, <Sem>, <SlotPhase>, <SlotPower>, <Qevm>, <Cda>

:FETch:WCDMA:RESults<i>:ACP**Availability:** Query Only**Default:** N/A**Description:** WCDMA Acp results**Return type:** <Carrier,...>, <Offset,...>

:FETch:WCDMA:RESults<i>:ACP:CARRier:POWER:TOTal**Availability:** Query Only**Default:** NaN**Description:** The sum of all active carrier powers, where each carrier power corresponds to the value of the method. This value is expressed in dBm. For a single-carrier measurement, total carrier power is the same as carrier absolute power.**Return type:** Double

:FETch:WCDMA:RESults<i>:ACP:CARRier<i>**Availability:** Query Only**Default:** N/A**Description:** WCDMA Adjacent Channel Power carrier measurement results.**Return type:** <AbsolutePower_dBm: double>, <RelativePower_dB: double>

:FETch:WCDMA:RESults<i>:ACP:CARRier<i>:POWER:ABSolute**Availability:** Query Only**Default:** NaN**Description:** Carrier power values. The carrier power is the integrated power of the RRC-filtered signal. The RRC filter uses a bandwidth of 3.84 MHz with a roll-off factor of 0.22. The carrier is centered at a frequency determined by the Center Frequency and methods.**Return type:** Double

:FETch:WCDMA:RESults<i>:ACP:CARRier<i>:POWER:RELative**Availability:** Query Only**Default:** NaN**Description:** The carrier power relative to the total carrier power. This value is expressed in dB.**Return type:** Double

:FETch:WCDMA:RESults<i>:ACP:OFFSet<i>**Availability:** Query Only**Default:** N/A**Description:** WCDMA Adjacent Channel Power offset measurement results.**Return type:** <LowerRelativePower_dB: double>, <UpperRelativePower_dB: double>, <LowerAbsolutePower_dBm: double>, <UpperAbsolutePower_dBm: double>

:FETch:WCDMA:RESults<i>:ACP:OFFSet<i>:POWER:LOWer:ABSolute**Availability:** Query Only**Default:** NaN**Description:** Lower offset channel power values.**Return type:** Double

:FETch:WCDMA:RESults<i>:ACP:OFFSet<i>:POWER:LOWer:RELative**Availability:** Query Only**Default:** NaN

Description: Lower offset channel power values measured relative to the power of the carrier(s) that you specify in the method. This value is expressed in dB.

Return type: Double

:FETch:WCDMA:RESults<i>:ACP:OFFSet<i>:POWER:UPPer:ABSolute**Availability:** Query Only**Default:** NaN

Description: Upper offset channel power values.

Return type: Double

:FETch:WCDMA:RESults<i>:ACP:OFFSet<i>:POWER:UPPer:RELative**Availability:** Query Only**Default:** NaN

Description: Upper offset channel power values measured relative to the power of the carrier(s) that you specify in the method. This value is expressed in dB.

Return type: Double

:FETch:WCDMA:RESults<i>:CDA**Availability:** Query Only**Default:** N/A

Description: WCDMA Cda results

Return type: <ChipRateError_ppm: double,...>, <IMeanActivePower_dBm: double,...>, <IPeakInactivePower_dBm: double,...>, <MeanActivePower_dBm: double,...>, <MeanInactivePower_dBm: double,...>, <MeanSymbolPower_dBm: double,...>, <PeakActivePower_dBm: double,...>, <PeakInactivePower_dBm: double,...>, <PeakSymbolEvm_pct: double,...>, <QMeanActivePower_dBm: double,...>, <QPeakInactivePower_dBm: double,...>, <RmsSymbolEvm_pct: double,...>, <RmsSymbolMagnitudeError_pct: double,...>, <RmsSymbolPhaseError_deg: double,...>, <TotalActivePower_dBm: double,...>, <TotalPower_dBm: double,...>

:FETch:WCDMA:RESults<i>:CDA:CRATe:ERRor<i>**Availability:** Query Only**Default:** NaN

Description: The chip rate error of the composite signal for a carrier. This value is expressed in ppm.

Return type: Double

:FETch:WCDMA:RESults<i>:CDA:POWER:ACTive:IMEAN<i>**Availability:** Query Only**Default:** NaN

Description: The average code power among the set of active in-phase channels in the code domain. If you set the method to , the measurement returns an absolute value

Return type: Double

:FETch:WCDMA:RESults<i>:CDA:POWER:ACTive:MEAN<i>**Availability:** Query Only**Default:** NaN

Description: The average of all the active channel powers. If you set the CDA Pwr Unit method to , the measurement returns an absolute value

Return type: Double

:FETch:WCDMA:RESults<i>:CDA:POWer:ACTive:PEAK<i>**Availability:** Query Only**Default:** NaN

Description: The largest code power among the set of active channels in the code domain. If you set the CDA Pwr Unit method to , the measurement returns an absolute value

Return type: Double

:FETch:WCDMA:RESults<i>:CDA:POWer:ACTive:QMEAN<i>**Availability:** Query Only**Default:** NaN

Description: The average code power among the set of active quadrature-phase channels in the code domain. If you set the CDA Pwr Unit method to , the measurement returns an absolute value

Return type: Double

:FETch:WCDMA:RESults<i>:CDA:POWer:ACTive:TOTal<i>**Availability:** Query Only**Default:** NaN

Description: The sum of all the active channel powers. If you set the method to , the measurement returns an absolute value

Return type: Double

:FETch:WCDMA:RESults<i>:CDA:POWer:INACTive:IPEAK<i>**Availability:** Query Only**Default:** NaN

Description: The largest code power among the set of inactive in-phase channels in the code domain. If you set the CDA Pwr Unit method to , the measurement returns an absolute value

Return type: Double

:FETch:WCDMA:RESults<i>:CDA:POWer:INACTive:MEAN<i>**Availability:** Query Only**Default:** NaN

Description: The average code power among the set of inactive channels in the code domain. If you set the CDA Pwr Unit method to , the measurement returns an absolute value

Return type: Double

:FETch:WCDMA:RESults<i>:CDA:POWer:INACTive:PEAK<i>**Availability:** Query Only**Default:** NaN

Description: The largest code power among the set of inactive channels in the code domain. If you set the CDA Pwr Unit method to , the measurement returns an absolute value

Return type: Double

:FETch:WCDMA:RESults<i>:CDA:POWer:INACTive:QPEAK<i>**Availability:** Query Only**Default:** NaN

Description: The largest code power among the set of inactive quadrature-phase channels in the code domain. If you set the CDA Pwr Unit method to , the measurement returns an absolute value

Return type: Double

:FETch:WCDMA:RESults<i>:CDA:POWer:TOTal<i>**Availability:** Query Only**Default:** NaN

Description: The mean power of the received signal, sampled at ideal inter-symbol-interference free points. This value is expressed in dBm.

Return type: Double

:FETch:WCDMA:RESults<i>:CDA:SYMBol:EVM:PEAK<i>**Availability:** Query Only**Default:** NaN

Description: The peak EVM for the measurement channel. This value is expressed as a percentage.

Return type: Double

:FETch:WCDMA:RESults<i>:CDA:SYMBol:EVM:RMS<i>**Availability:** Query Only**Default:** NaN

Description: The RMS EVM for the measurement channel. This value is expressed as a percentage.

Return type: Double

:FETch:WCDMA:RESults<i>:CDA:SYMBol:MAGNitude:ERRor:RMS<i>**Availability:** Query Only**Default:** NaN

Description: The RMS magnitude error for the measurement channel. This value is expressed as a percentage.

Return type: Double

:FETch:WCDMA:RESults<i>:CDA:SYMBol:PHASe:ERRor:RMS<i>**Availability:** Query Only**Default:** NaN

Description: The RMS phase error for the measurement channel. This value is expressed as a degrees.

Return type: Double

:FETch:WCDMA:RESults<i>:CDA:SYMBol:POWer:MEAN<i>**Availability:** Query Only**Default:** NaN

Description: The mean power of the symbols for the measurement channel. This value is expressed in dB or dBm.

Return type: Double

:FETch:WCDMA:RESults<i>:CHP**Availability:** Query Only**Default:** N/A

Description: WCDMA Chp results

Return type: <Chp,...>, <TotalCarrierPower_dBm: double>

:FETch:WCDMA:RESults<i>:CHP:CARRier:POWer:TOTal**Availability:** Query Only**Default:** NaN

Description: The sum of all active carrier powers, where each carrier power corresponds to the value of the method. This value is expressed in dBm. For a single-carrier measurement, total carrier power is the same as carrier absolute power.

Return type: Double

:FETch:WCDMA:RESults<i>:CHP:CARRier<i>**Availability:** Query Only**Default:** N/A**Description:** WCDMA Channel Power carrier measurement results.**Return type:** <AbsolutePower_dBm: double>, <RelativePower_dB: double>

:FETch:WCDMA:RESults<i>:CHP:CARRier<i>:POWer:ABSolute**Availability:** Query Only**Default:** NaN**Description:** Carrier power values. The carrier power is the integrated power of the RRC-filtered signal. The RRC filter uses a bandwidth of 3.84 MHz with a roll-off factor of 0.22. The carrier is centered at a frequency determined by the Center Frequency and methods.**Return type:** Double

:FETch:WCDMA:RESults<i>:CHP:CARRier<i>:POWer:RELative**Availability:** Query Only**Default:** NaN**Description:** The carrier power relative to the total carrier power. This value is expressed in dB.**Return type:** Double

:FETch:WCDMA:RESults<i>:MODacc**Availability:** Query Only**Default:** N/A**Description:** WCDMA ModAcc results**Return type:** <DetectedChannel,...>, <Evm,... CarrierMeasurement,...>, <NumberOfDetectedChannels>

:FETch:WCDMA:RESults<i>:MODacc:CARRier<i>**Availability:** Query Only**Default:** N/A**Description:** WCDMA Modulation Accuracy carrier measurement results.**Return type:** <IqOriginOffset_dB: double>, <IqGainImbalance_dB: double>, <IqQuadratureError_deg: double>, <PeakActiveCde_dB: double>, <PeakActiveCdeSpreadingFactor: double>, <PeakActiveCdeCode: double>, <PeakActiveCdeBranch: double>, <PeakCde_dB: double>, <PeakCdeCode: double>, <PeakCdeBranch: double>, <PeakRcde_dB: double>, <PeakRcdeSpreadingFactor: double>, <PeakRcdeCode: double>, <PeakRcdeBranch: double>

:FETch:WCDMA:RESults<i>:MODacc:CARRier<i>:CDE:ACTive:BRANch:PEAK**Availability:** Query Only**Default:** I**Description:** Branch values of the channel corresponding to the value of the peakActiveCDE parameter.**Return type:** I | Q

:FETch:WCDMA:RESults<i>:MODacc:CARRier<i>:CDE:ACTive:CODE:PEAK**Availability:** Query Only**Default:** 2147483647**Description:** Spreading codes of the channel corresponding to the value of the peakActiveCDE parameter.**Return type:** Int32

:FETch:WCDMA:RESults<i>:MODacc:CARRier<i>:CDE:ACTive:PEAK**Availability:** Query Only**Default:** NaN**Description:** Maximum values among the active code domain errors. This value is expressed in dB.**Return type:** Double

:FETch:WCDMA:RESults<i>:MODacc:CARRier<i>:CDE:ACTive:SPReading:FACTOR:PEAK**Availability:** Query Only**Default:** 2147483647**Description:** Spreading factors of the channel corresponding to the value of the peakActiveCDE parameter.**Return type:** Int32

:FETch:WCDMA:RESults<i>:MODacc:CARRier<i>:CDE:BRANCh:PEAK**Availability:** Query Only**Default:** I**Description:** Branches of the channel corresponding to the value of the peakCDE parameter.**Return type:** I | Q

:FETch:WCDMA:RESults<i>:MODacc:CARRier<i>:CDE:CODE:PEAK**Availability:** Query Only**Default:** 2147483647**Description:** Spreading codes corresponding to the value of the peakCDE parameter.**Return type:** Int32

:FETch:WCDMA:RESults<i>:MODacc:CARRier<i>:CDE:PEAK**Availability:** Query Only**Default:** NaN**Description:** Maximum CDE values. This value is expressed in dB.**Return type:** Double

:FETch:WCDMA:RESults<i>:MODacc:CARRier<i>:IQ:GAIN:IMBalance**Availability:** Query Only**Default:** NaN**Description:** I/Q gain imbalance values of the composite signal. This value is expressed in dB.**Return type:** Double

:FETch:WCDMA:RESults<i>:MODacc:CARRier<i>:IQ:ORIGin:OFFSet**Availability:** Query Only**Default:** NaN**Description:** I/Q origin offset values of the composite signal. This value is expressed in dB.**Return type:** Double

:FETch:WCDMA:RESults<i>:MODacc:CARRier<i>:IQ:QERRor**Availability:** Query Only**Default:** NaN**Description:** I/Q quadrature error values of the composite signal. This value is expressed in degrees.**Return type:** Double

:FETch:WCDMA:RESults<i>:MODacc:CARRier<i>:RCDE:BRANCh:PEAK**Availability:** Query Only**Default:** I**Description:** Branches of the channel corresponding to the value of the peakRCDE parameter.**Return type:** I | Q

:FETch:WCDMA:RESults<i>:MODacc:CARRier<i>:RCDE:CODE:PEAK**Availability:** Query Only**Default:** 2147483647**Description:** Spreading codes of the channel corresponding to the value of the peakRCDE parameter.**Return type:** Int32

:FETch:WCDMA:RESults<i>:MODacc:CARRier<i>:RCDE:PEAK**Availability:** Query Only**Default:** NaN**Description:** Maximum value among the relative code domain errors (RCDEs) for all active channels. This value is expressed in dB.**Return type:** Double

:FETch:WCDMA:RESults<i>:MODacc:CARRier<i>:RCDE:SPReading:FACTor:PEAK**Availability:** Query Only**Default:** 2147483647**Description:** Spreading factors of the channel corresponding to the value of the peakRCDE parameter.**Return type:** Int32

:FETch:WCDMA:RESults<i>:MODacc:DETected:CHANnel<i>**Availability:** Query Only**Default:** 2147483647, 2147483647, ModulationTypeBpskQpsk, I**Description:** WCDMA Modulation Accuracy detected channel results.**Return type:** <DetectedSpreadingFactor: int>, <DetectedSpreadingCode: int>, <ModulationTypeBpskQpsk | ModulationType4Pam16Qam>, <I | Q>

:FETch:WCDMA:RESults<i>:MODacc:DETected:CHANnel<i>:DETected:BRANCh**Availability:** Query Only**Default:** I**Description:** Branch of the detected channel**Return type:** I | Q

:FETch:WCDMA:RESults<i>:MODacc:DETected:CHANnel<i>:DETected:MODulation:TYPE**Availability:** Query Only**Default:** ModulationTypeBpskQpsk**Description:** Modulation type of the detected channel**Return type:** ModulationTypeBpskQpsk | ModulationType4Pam16Qam

:FETch:WCDMA:RESults<i>:MODacc:DETected:CHANnel<i>:DETected:SPReading:CODE**Availability:** Query Only**Default:** 2147483647**Description:** Spreading code of the detected channel**Return type:** Int32

:FETch:WCDMA:RESults<i>:MODacc:DETEcted:CHANnel<i>:DETEcted:SPReading:FACTor**Availability:** Query Only**Default:** 2147483647**Description:** Spreading factor of the detected channel**Return type:** Int32

:FETch:WCDMA:RESults<i>:MODacc:EVM<i>**Availability:** Query Only**Default:** N/A**Description:** WCDMA Modulation Accuracy Error Vector Magnitude results.**Return type:** <RmsEvm_pct: double>, <PeakEvm_pct: double>, <Rho: double>,
<FrequencyError_Hz: double>, <ChipRateError_ppm: double>,
<RmsMagnitudeError_pct: double>, <RmsPhaseError_deg: double>

:FETch:WCDMA:RESults<i>:MODacc:EVM<i>:CRATe:ERRor**Availability:** Query Only**Default:** NaN**Description:** The chip rate error of the composite signal for a carrier. This value is expressed in ppm.**Return type:** Double

:FETch:WCDMA:RESults<i>:MODacc:EVM<i>:FREQuency:ERRor**Availability:** Query Only**Default:** NaN**Description:** The frequency offset of the composite signal for a carrier. This value is expressed in Hz.**Return type:** Double

:FETch:WCDMA:RESults<i>:MODacc:EVM<i>:MAGNitude:ERRor:RMS**Availability:** Query Only**Default:** NaN**Description:** The RMS magnitude error of the composite signal for a carrier. This value is expressed in percentage.**Return type:** Double

:FETch:WCDMA:RESults<i>:MODacc:EVM<i>:PEAK**Availability:** Query Only**Default:** NaN**Description:** The peak EVM of the composite signal for a carrier. This value is expressed as a percentage.**Return type:** Double

:FETch:WCDMA:RESults<i>:MODacc:EVM<i>:PHASe:ERRor:RMS**Availability:** Query Only**Default:** NaN**Description:** The RMS phase error of the composite signal for a carrier. This value is expressed in degrees.**Return type:** Double

:FETch:WCDMA:RESults<i>:MODacc:EVM<i>:RHO**Availability:** Query Only**Default:** NaN**Description:** The correlation of the received signal with the reference signal normalized by the signal power for a carrier.**Return type:** Double

:FETch:WCDMA:RESults<i>:MODacc:EVM<i>:RMS**Availability:** Query Only**Default:** NaN**Description:** The RMS EVM of the composite signal for a carrier. This value is expressed as a percentage.**Return type:** Double

:FETch:WCDMA:RESults<i>:MODacc:NUMber:DEtected:CHANnel<i>**Availability:** Query Only**Default:** N/A**Description:** Number of detected channels.**Return type:** Int32

:FETch:WCDMA:RESults<i>:OBW**Availability:** Query Only**Default:** N/A**Description:** WCDMA Obw results**Return type:** <SubBlockNumber: double>, <AverageTotalPower_dBm: double>, <OccupiedBandwidth_Hz: double>, <StartFrequency_Hz: double>, <StopFrequency_Hz: double>

:FETch:WCDMA:RESults<i>:OBW:ALL**Availability:** Query Only**Default:** N/A**Description:** Returns string with results for NRModAccCarrier.**Return type:** <SubBlockNumber: double>, <AverageTotalPower_dBm: double>, <OccupiedBandwidth_Hz: double>, <StartFrequency_Hz: double>, <StopFrequency_Hz: double>

:FETch:WCDMA:RESults<i>:OBW:BANDwidth**Availability:** Query Only**Default:** NaN**Description:** Contains the bandwidth that occupies 99 percentage of the total power of the signal within a carrier/subblock.**Return type:** Double

:FETch:WCDMA:RESults<i>:OBW:FREquency:START**Availability:** Query Only**Default:** NaN**Description:** Contains the start frequency of the subblock. The occupied bandwidth of a carrier/subblock is calculated using the following equation: Stop frequency - Start frequency = Occupied bandwidth.**Return type:** Double

:FETch:WCDMA:RESults<i>:OBW:FREquency:STOP**Availability:** Query Only**Default:** NaN**Description:** Contains the stop frequency of the subblock. The occupied bandwidth of a carrier/subblock is calculated using the following equation: Stop frequency - Start frequency = Occupied bandwidth.**Return type:** Double

:FETch:WCDMA:RESults<i>:OBW:POWer:ABSolute**Availability:** Query Only**Default:** NaN

Description: Contains the power measured over the integration bandwidth of the carrier/subblock.

Return type: Double

:FETch:WCDMA:RESults<i>:QEVM**Availability:** Query Only**Default:** N/A

Description: WCDMA Qevm results

Return type: <MaximumIQGainImbalance_dB: double,...>,
<MaximumIQOriginOffset_dB: double,...>,
<MaximumIQQuadratureError_deg: double,...>, <MaximumPeakEvm_pct: double,...>,
<MeanChipRateError_ppm: double,...>,
<MeanFrequencyError_Hz: double,...>, <MeanIQGainImbalance_dB: double,...>,
<MeanIQOriginOffset_dB: double,...>,
<MeanIQQuadratureError_deg: double,...>, <MeanMagnitudeError_pct: double,...>,
<MeanPhaseError_pct: double,...>, <MeanRmsEvm_pct: double,...>

:FETch:WCDMA:RESults<i>:QEVM:CRATe:ERRor:MEAN<i>**Availability:** Query Only**Default:** NaN

Description: The mean of the chip rate errors for a QPSK signal. This value is expressed in ppm. This value is obtained by averaging the chip rate errors over all averaging acquisitions. The number of acquisitions is specified by the value of the method.

Return type: Double

:FETch:WCDMA:RESults<i>:QEVM:EVM:PEAK:MAXimum<i>**Availability:** Query Only**Default:** NaN

Description: The maximum value of the peak EVMs for a QPSK signal. This value is expressed as a percentage. This value is obtained over all averaging iterations. The number of acquisitions is specified by the value of the method.

Return type: Double

:FETch:WCDMA:RESults<i>:QEVM:EVM:RMS:MEAN<i>**Availability:** Query Only**Default:** NaN

Description: The mean of the RMS EVM values for a QPSK signal. This value is obtained by averaging the RMS EVMs over all averaging iterations. The number of acquisitions is specified by the value of the method. This value is expressed as a percentage.

Return type: Double

:FETch:WCDMA:RESults<i>:QEVM:FREQuency:ERRor:MEAN<i>**Availability:** Query Only**Default:** NaN

Description: The mean of the frequency errors for a QPSK signal. This value is expressed in Hz. This value is obtained by the mean of frequency errors obtained over all averaging acquisitions. The number of acquisitions is specified by the value of the method.

Return type: Double

:FETch:WCDMA:RESults<i>:QEVM:IQ:GAIN:IMBalance:MAXimum<i>**Availability:** Query Only**Default:** NaN

Description: The maximum value of I/Q gain imbalances for a QPSK signal. This value is expressed in dB. This value is obtained over all averaging iterations. The number of acquisitions is specified by the value of the method.

Return type: Double

:FETch:WCDMA:RESults<i>:QEVM:IQ:GAIN:IMBalance:MEAN<i>**Availability:** Query Only**Default:** NaN

Description: The mean of the I/Q gain imbalances for a QPSK signal. This value is expressed in dB. This value is obtained by the I/Q gain imbalances obtained over all averaging acquisitions. The number of acquisitions is specified by the value of the method.

Return type: Double

:FETch:WCDMA:RESults<i>:QEVM:IQ:ORIGin:OFFSet:MAXimum<i>**Availability:** Query Only**Default:** NaN

Description: The maximum I/Q origin offset for a QPSK signal. This value is expressed in dB.

Return type: Double

:FETch:WCDMA:RESults<i>:QEVM:IQ:ORIGin:OFFSet:MEAN<i>**Availability:** Query Only**Default:** NaN

Description: The mean of I/Q origin offsets for a QPSK signal. This value is expressed in dB. This value is obtained by averaging the I/Q origin offsets over all averaging acquisitions. The number of acquisitions is specified by the value of the method.

Return type: Double

:FETch:WCDMA:RESults<i>:QEVM:IQ:QERRor:MAXimum<i>**Availability:** Query Only**Default:** NaN

Description: The maximum value of I/Q quadrature errors for a QPSK signal. This value is expressed in degrees. This value is obtained over all averaging iterations. The number of acquisitions is specified by the value of the method. Quadrature error is a measure of the error in the phase between I and Q components of the signal being measured. This result is for future use

Return type: Double

:FETch:WCDMA:RESults<i>:QEVM:IQ:QERRor:MEAN<i>**Availability:** Query Only**Default:** NaN

Description: The mean of the I/Q quadrature errors for a QPSK signal. This value is expressed in degrees. This value is obtained by the mean of I/Q quadrature errors obtained over all averaging acquisitions. The number of acquisitions is specified by the value of the method.

Return type: Double

:FETch:WCDMA:RESults<i>:QEVM:MAGNitude:ERRor:MEAN<i>**Availability:** Query Only**Default:** NaN

Description: The mean of RMS magnitude errors for a QPSK signal. This value is expressed as a percentage. This value is obtained by averaging the RMS magnitude errors over all averaging acquisitions. The number of acquisitions is specified by the value of the method.

Return type: Double

:FETch:WCDMA:RESults<i>:QEVM:PHASe:ERRor:MEAN<i>**Availability:** Query Only**Default:** NaN

Description: The mean of the RMS phase error values for a QPSK signal. This value is expressed as a percentage. This value is obtained by averaging the RMS phase errors obtained over all averaging acquisitions. The number of acquisitions is specified by the value of the method.

Return type: Double

:FETch:WCDMA:RESults<i>:SEM**Availability:** Query Only**Default:** N/A

Description: WCDMA SEM results

Return type: <LowerOffsetMargin,...>, <LowerOffsetPower,...>, <UpperOffsetMargin,...>, <UpperOffsetPower,...>, <Carrier,...>, <TotalCarrierPower_dBm: double>, <MeasurementPassed: bool>

:FETch:WCDMA:RESults<i>:SEM:CARRier:POWER:TOTal**Availability:** Query Only**Default:** NaN

Description: The sum of all active carrier powers, where each carrier power corresponds to the value of the method. This value is expressed in dBm. For a single-carrier measurement, total carrier power is the same as carrier absolute power.

Return type: Double

:FETch:WCDMA:RESults<i>:SEM:CARRier<i>**Availability:** Query Only**Default:** N/A

Description: WCDMA SEM Carrier Measurement results.

Return type: SemCarrierMeasurementResults

:FETch:WCDMA:RESults<i>:SEM:CARRier<i>:FREQuency:PEAK**Availability:** Query Only**Default:** NaN

Description: Peak frequency in Hz.

Return type: Double

:FETch:WCDMA:RESults<i>:SEM:CARRier<i>:IPOWER:ABSolute**Availability:** Query Only**Default:** NaN

Description: Carrier power values. The carrier power is the integrated power of the RRC-filtered signal. The RRC filter uses a bandwidth of 3.84 MHz with a roll-off factor of 0.22. The carrier is centered at a frequency determined by the Center Frequency and methods. This value is expressed in dBm.

Return type: Double

:FETch:WCDMA:RESuLts<i>:SEM:CARRier<i>:IPOWER:RELative**Availability:** Query Only**Default:** NaN**Description:** Carrier power values relative to the total carrier power of all enabled carriers. This value is expressed in dB.**Return type:** Double

:FETch:WCDMA:RESuLts<i>:SEM:CARRier<i>:POWER:PEAK:ABS**Availability:** Query Only**Default:** N/A**Description:** Absolute peak power in dBm.**Return type:** Double

:FETch:WCDMA:RESuLts<i>:SEM:OFFSet:LOWer:MARGin<i>**Availability:** Query Only**Default:** N/A**Description:** WCDMA SEM Lower Offset Margin Measurement results.**Return type:** <Margin_dB>, <MarginFrequency_Hz>, <MarginAbsolutePower_dBm>, <MarginRelativePower_dB>, <StatusOfMeasurement>

:FETch:WCDMA:RESuLts<i>:SEM:OFFSet:LOWer:MARGin<i>:FREQuency**Availability:** Query Only**Default:** N/A**Description:** Contains the array of frequency at which the margin occurs in the lower (negative) offset. For the intra-band noncontiguous type of carrier aggregation, the offset segment may be truncated or discarded based on offset overlap rules as defined in the 3GPP TS 36.521 specification. If the offset segment is truncated, the SEM results lower offset start frequency and SEM results lower offset stop frequency are updated, and the measurement is performed on the updated offset segment. If the offset segment is discarded, a NaN is returned.**Return type:** Double

:FETch:WCDMA:RESuLts<i>:SEM:OFFSet:LOWer:MARGin<i>:MARGin**Availability:** Query Only**Default:** N/A**Description:** Contains the array of margins from the standard-defined absolute limit mask for the lower (negative) offset. Margin is defined as the minimum difference between the spectrum and the limit mask. For the intra-band noncontiguous type of carrier aggregation, the offset segment may be truncated or discarded based on offset overlap rules as defined in the 3GPP TS 36.521 specification. If the offset segment is truncated, the SEM results lower offset start frequency and SEM results lower offset stop frequency are updated, and the measurement is performed on the updated offset segment. If the offset segment is discarded, a NaN is returned.**Return type:** Double

:FETch:WCDMA:RESults<i>:SEM:OFFSet:LOWer:MARGin<i>:POWER:ABSolute**Availability:** Query Only**Default:** N/A

Description: Contains the array of power at which the margin occurs in the upper (positive) offset segment. For the intra-band noncontiguous type of carrier aggregation, the offset segment may be truncated or discarded based on offset overlap rules as defined in the 3GPP TS 36.521 specification. If the offset segment is truncated, the SEM results lower offset start frequency and SEM results lower offset stop frequency are updated, and the measurement is performed on the updated offset segment. If the offset segment is discarded, a NaN is returned.

Return type: Double

:FETch:WCDMA:RESults<i>:SEM:OFFSet:LOWer:MARGin<i>:POWER:RELative**Availability:** Query Only**Default:** N/A

Description: Contains the array of powers at which the margin occurs in the upper (positive) offset segment relative to the value of TotalAggregatedPower. For the intra-band noncontiguous type of carrier aggregation, the offset segment may be truncated or discarded based on offset overlap rules as defined in the 3GPP TS 36.521 specification. If the offset segment is truncated the measurement is performed on the updated offset segment. If the offset segment is discarded, a NaN is returned.

Return type: Double

:FETch:WCDMA:RESults<i>:SEM:OFFSet:LOWer:MARGin<i>:STATus**Availability:** Query Only**Default:** N/A

Description: Contains the array of the measurement status indicating whether the power before and after the burst is within the standard defined limit.

Return type: Boolean

:FETch:WCDMA:RESults<i>:SEM:OFFSet:LOWer:POWER<i>**Availability:** Query Only**Default:** N/A

Description: WCDMA SEM Lower Offset Power Measurement results.

Return type: <PeakFrequency_Hz>, <RelativePeakPower_dBm
AbsolutePeakPower_dBm>, <RelativeIntegratedPower_dBm>,
<AbsoluteIntegratedPower_dBm>

:FETch:WCDMA:RESults<i>:SEM:OFFSet:LOWer:POWER<i>:FREQuency**Availability:** Query Only**Default:** N/A

Description: Peak frequency in Hz.

Return type: Double

:FETch:WCDMA:RESults<i>:SEM:OFFSet:LOWer:POWER<i>:IPOWER:ABSolute**Availability:** Query Only**Default:** N/A

Description: Contains the array of lower (negative) offset segment powers. For the intra-band noncontiguous type of carrier aggregation, the offset segment may be truncated or discarded based on offset overlap rules as defined in the 3GPP TS 36.521 specification. If the offset segment is truncated the measurement is performed on the updated offset segment. If the offset segment is discarded, a NaN is returned.

Return type: Double

:FETch:WCDMA:RESults<i>:SEM:OFFSet:LOWer:POWer<i>:IPOWer:RELative**Availability:** Query Only**Default:** N/A

Description: Carrier power values relative to the total carrier power of all enabled carriers. This value is expressed in dB.

Return type: Double

:FETch:WCDMA:RESults<i>:SEM:OFFSet:LOWer:POWer<i>:POWer:ABSolute**Availability:** Query Only**Default:** N/A

Description: Absolute peak power in dBm.

Return type: Double

:FETch:WCDMA:RESults<i>:SEM:OFFSet:LOWer:POWer<i>:POWer:RELative**Availability:** Query Only**Default:** N/A

Description: Contains the array of peak power in the upper (positive) offset segment relative to the value returned by the SEM Results Total Aggregated Pwr method. For the intra-band noncontiguous type of carrier aggregation, the offset segment may be truncated or discarded based on offset overlap rules as defined in the 3GPP TS 36.521 specification. If the offset segment is truncated the measurement is performed on the updated offset segment. If the offset segment is discarded, a NaN is returned.

Return type: Double

:FETch:WCDMA:RESults<i>:SEM:OFFSet:UPPer:MARGIn<i>**Availability:** Query Only**Default:** N/A

Description: WCDMA SEM Upper Offset Margin Measurement results.

Return type: <Margin_dB>, <MarginFrequency_Hz>, <MarginAbsolutePower_dBm>, <MarginRelativePower_dB>, <StatusOfMeasurement>

:FETch:WCDMA:RESults<i>:SEM:OFFSet:UPPer:MARGIn<i>:FREQuency**Availability:** Query Only**Default:** N/A

Description: Contains the array of frequency at which the margin occurs in the lower (negative) offset. For the intra-band noncontiguous type of carrier aggregation, the offset segment may be truncated or discarded based on offset overlap rules as defined in the 3GPP TS 36.521 specification. If the offset segment is truncated, the SEM results lower offset start frequency and SEM results lower offset stop frequency are updated, and the measurement is performed on the updated offset segment. If the offset segment is discarded, a NaN is returned.

Return type: Double

:FETch:WCDMA:RESults<i>:SEM:OFFSet:UPPer:MARGin<i>:MARGin**Availability:** Query Only**Default:** N/A

Description: Contains the array of margins from the standard-defined absolute limit mask for the lower (negative) offset. Margin is defined as the minimum difference between the spectrum and the limit mask. For the intra-band noncontiguous type of carrier aggregation, the offset segment may be truncated or discarded based on offset overlap rules as defined in the 3GPP TS 36.521 specification. If the offset segment is truncated, the SEM results lower offset start frequency and SEM results lower offset stop frequency are updated, and the measurement is performed on the updated offset segment. If the offset segment is discarded, a NaN is returned.

Return type: Double

:FETch:WCDMA:RESults<i>:SEM:OFFSet:UPPer:MARGin<i>:POWer:ABSolute**Availability:** Query Only**Default:** N/A

Description: Contains the array of power at which the margin occurs in the upper (positive) offset segment. For the intra-band noncontiguous type of carrier aggregation, the offset segment may be truncated or discarded based on offset overlap rules as defined in the 3GPP TS 36.521 specification. If the offset segment is truncated, the SEM results lower offset start frequency and SEM results lower offset stop frequency are updated, and the measurement is performed on the updated offset segment. If the offset segment is discarded, a NaN is returned.

Return type: Double

:FETch:WCDMA:RESults<i>:SEM:OFFSet:UPPer:MARGin<i>:POWer:RELative**Availability:** Query Only**Default:** N/A

Description: Contains the array of powers at which the margin occurs in the upper (positive) offset segment relative to the value of TotalAggregatedPower. For the intra-band noncontiguous type of carrier aggregation, the offset segment may be truncated or discarded based on offset overlap rules as defined in the 3GPP TS 36.521 specification. If the offset segment is truncated the measurement is performed on the updated offset segment. If the offset segment is discarded, a NaN is returned.

Return type: Double

:FETch:WCDMA:RESults<i>:SEM:OFFSet:UPPer:MARGin<i>:STATus**Availability:** Query Only**Default:** N/A

Description: Contains the array of the measurement status indicating whether the power before and after the burst is within the standard defined limit.

Return type: Boolean

:FETch:WCDMA:RESults<i>:SEM:OFFSet:UPPer:POWer<i>**Availability:** Query Only**Default:** N/A

Description: WCDMA SEM Upper Offset Power Measurement results.

Return type: <PeakFrequency_Hz>, <RelativePeakPower_dBm
AbsolutePeakPower_dBm>, <RelativeIntegratedPower_dBm>,
<AbsoluteIntegratedPower_dBm>

:FETch:WCDMA:RESults<i>:SEM:OFFSet:UPPer:POWer<i>:FREQuency**Availability:** Query Only**Default:** N/A**Description:** Peak frequency in Hz.**Return type:** Double

:FETch:WCDMA:RESults<i>:SEM:OFFSet:UPPer:POWer<i>:IPOWer:ABSolute**Availability:** Query Only**Default:** N/A

Description: Contains the array of lower (negative) offset segment powers. For the intra-band noncontiguous type of carrier aggregation, the offset segment may be truncated or discarded based on offset overlap rules as defined in the 3GPP TS 36.521 specification. If the offset segment is truncated the measurement is performed on the updated offset segment. If the offset segment is discarded, a NaN is returned.

Return type: Double

:FETch:WCDMA:RESults<i>:SEM:OFFSet:UPPer:POWer<i>:IPOWer:RELative**Availability:** Query Only**Default:** N/A

Description: Carrier power values relative to the total carrier power of all enabled carriers. This value is expressed in dB.

Return type: Double

:FETch:WCDMA:RESults<i>:SEM:OFFSet:UPPer:POWer<i>:POWer:ABSolute**Availability:** Query Only**Default:** N/A

Description: Absolute peak power in dBm.

Return type: Double

:FETch:WCDMA:RESults<i>:SEM:OFFSet:UPPer:POWer<i>:POWer:RELative**Availability:** Query Only**Default:** N/A

Description: Contains the array of peak power in the upper (positive) offset segment relative to the value returned by the SEM Results Total Aggregated Pwr method. For the intra-band noncontiguous type of carrier aggregation, the offset segment may be truncated or discarded based on offset overlap rules as defined in the 3GPP TS 36.521 specification. If the offset segment is truncated the measurement is performed on the updated offset segment. If the offset segment is discarded, a NaN is returned.

Return type: Double

:FETch:WCDMA:RESults<i>:SEM:PASSed**Availability:** Query Only**Default:** 0

Description: Measurement status values based on the values of the method corresponding to each upper offset segment.

Return type: Boolean

:FETch:WCDMA:RESults<i>:SLOT:PHASe**Availability:** Query Only**Default:** , NaN, 2147483647, 2147483647, 2147483647**Description:** WCDMA Slot Phase results**Return type:** <SlotPhaseDiscontinuity: double,...>, <MaximumPhaseDiscontinuity: double,...>, <DiscontinuityCountGreaterThanLimit1: double,...>, <DiscontinuityCountGreaterThanLimit2: double,...>, <DiscontinuityMinimumDistance: int,...>

:FETch:WCDMA:RESults<i>:SLOT:PHASe:DISContinuity:COUNT:GRT:1LIMit<i>**Availability:** Query Only**Default:** 2147483647**Description:** The number of times the phase discontinuity values exceed the Limit 1 value for the acquired signal. Limit 1 is fixed at 36 degrees.**Return type:** Int32

:FETch:WCDMA:RESults<i>:SLOT:PHASe:DISContinuity:COUNT:GRT:2LIMit<i>**Availability:** Query Only**Default:** 2147483647**Description:** The number of times the phase discontinuity values exceed the Limit 2 value for the acquired signal. Limit 2 is fixed at 66 degrees.**Return type:** Int32

:FETch:WCDMA:RESults<i>:SLOT:PHASe:DISContinuity:MINimum:DISTance<i>**Availability:** Query Only**Default:** 2147483647**Description:** The minimum distance between two phase discontinuity measurements exceeding the Limit 1 value. Limit 1 is fixed at 36 degrees. This value is expressed in slots.**Return type:** Int32

:FETch:WCDMA:RESults<i>:SLOT:PHASe:MAXimum:PHASe:DISContinuity<i>**Availability:** Query Only**Default:** NaN**Description:** The maximum of all the measured phase discontinuity values at the slot boundaries. This value is expressed in degrees.**Return type:** Double

:FETch:WCDMA:RESults<i>:SLOT:POWER**Availability:** Query Only**Default:** ,**Description:** WCDMA Slot Power results**Return type:** <SlotPower_dBm: double,...>, <SlotPowerDelta_dB: double,...>

:TRIGger:WCDMA:DELay <TriggerDelay_sec>**Availability:** Command and Query**Default:** N/A**Description:** Specifies the delay (in seconds) between the trigger onset and the start of data acquisition.**Parameters:** <TriggerDelay_sec> Double

:TRIGger:WCDMA:EDGE <TriggerEdge>

Availability: Command and Query **Default:** RISING

Description: Specifies whether to trigger on the rising or falling edge for digital or power triggering.

Parameters: <TriggerEdge> RISING | FALLING

:TRIGger:WCDMA:MQTime <TriggerMinQuietDuration_sec>

Availability: Command and Query **Default:** N/A

Description: Specifies the Minimum Quiet Time between triggers. Negative value (e.g. -1) enables automatic duration.

Parameters: <TriggerMinQuietDuration_sec> Double

:TRIGger:WCDMA:SOURce <TriggerSource>

Availability: Command and Query **Default:** IMMEDIATE

Description: Specifies the trigger source.

Parameters: <TriggerSource> IMM | RF0 | VIDEO | GENERATOR |
INTERNAL | IMMEDIATE

:TRIGger:WCDMA:THReshold <TriggerThreshold>

Availability: Command and Query **Default:** -20

Description: Specifies the trigger threshold to use when power triggering. Absolute level type is in dBm, relative level type (to reference level) is in dB.

Parameters: <TriggerThreshold> Double

:TRIGger:WCDMA:TOUT <TriggerTimeout_sec>

Availability: Command and Query **Default:** 10

Description: Specifies the trigger timeout in seconds.

Parameters: <TriggerTimeout_sec> Double

:WCDMA:INITiate <resultSpace>

Availability: Command Only **Default:** N/A

Description: Initiates Gsm analyzer.

Parameters: <resultSpace> Int32

:WCDMA:MEASurement:STATe

Availability: Query Only **Default:** N/A

Description: Returns the current state of the measurement.

Return type: READY | PROCESSING | OFF | PENDING | ACTIVE

:WCDMA:RESet

Availability: Command Only **Default:** N/A

Description: Resets WCDMA analyzer.

8. Wlan

:CONFigure:WLAN:CHANnel:BANDwidth <ChannelBW>

Availability: Command and Query **Default:** BW20

Description: Configures the channel bandwidth.

Parameters: <ChannelBW> BW5 | BW10 | BW20 | BW40 | BW80 |
BW160 | BW80_80

:CONFigure:WLAN:FREQuency:BAND <FrequencyBand>

Availability: Command and Query **Default:** Band2_4GHz

Description: Sets the ISM frequency band. The SEM measurement uses this information to select an appropriate mask as defined in IEEE Standard 802.11n – 2009.

Parameters: <FrequencyBand> Band2_4GHz | Band5GHz

:CONFigure:WLAN:FREQuency:CENTer <CenterFrequency_Hz>

Availability: Command and Query **Default:** 5500000000

Description: Configures the expected carrier frequency of the RF signal to acquire. The signal analyzer tunes to this frequency.

Parameters: <CenterFrequency_Hz> Double

:CONFigure:WLAN:MODacc:DSSS:ACQUsition:LENGth <DsssModAccAcquisitionLength>

Availability: Command and Query **Default:** 1

Description: Sets the length of the waveform to be acquired for the DSSS ModAcc measurement, when user sets the DsssModAccAcquisitionLengthMode to Manual. This value is expressed in seconds.

Parameters: <DsssModAccAcquisitionLength> Double

:CONFigure:WLAN:MODacc:DSSS:ACQUsition:LENGth:MODE <DsssModAccAcquisitionLengthMode>

Availability: Command and Query **Default:** AUTO

Description: Sets whether the measurement automatically computes the acquisition length of the waveform based on DSSSModAcc properties.

Parameters: <DsssModAccAcquisitionLengthMode> AUTO | NORMAL

:CONFigure:WLAN:MODacc:DSSS:AVG:COUNT <DsssModAccAveragingCount>

Availability: Command and Query **Default:** 10

Description: Sets the number of acquisitions used for averaging when Dsss ModAcc averaging is enabled.

Parameters: <DsssModAccAveragingCount> Int32

:CONFigure:WLAN:MODacc:DSSS:AVG:ENABLE <DsssModAccAveragingEnabled>

Availability: Command and Query **Default:** 0

Description: Sets whether to enable averaging for DSSSModAcc measurement.

Parameters: <DsssModAccAveragingEnabled> Boolean

**:CONFigure:WLAN:MODacc:DSSS:BURSt:START:DETection:ENABLE
<DsssModAccBurstStartDetectionEnabled>**

Availability: Command and Query **Default:** 0

Description: Sets whether the measurement detects the rising edge of a burst in the acquired waveform.

Parameters: <DsssModAccBurstStartDetectionEnabled> Boolean

**:CONFigure:WLAN:MODacc:DSSS:CHIP:CERRor:CONNEction:ENABLE
<DsssModAccChipClockErrorConnectionEnabled>**

Availability: Command and Query **Default:** 1

Description: Sets whether to enable chip clock error correction.

Parameters: <DsssModAccChipClockErrorConnectionEnabled> Boolean

**:CONFigure:WLAN:MODacc:DSSS:DATA:DECoding:ENABLE
<DsssDataDecodingEnabled>**

Availability: Command and Query **Default:** 0

Description: Specifies whether to decode data bits and check for the validity of the cyclic redundancy check (CRC).

Parameters: <DsssDataDecodingEnabled> Boolean

**:CONFigure:WLAN:MODacc:DSSS:EQUalization:ENABLE
<DsssModAccEqualizationEnabled>**

Availability: Command and Query **Default:** 0

Description: Sets whether to enable equalization. The IEEE Standard 802.11-2016 does not allow equalization for computing EVM. If you enable equalization, the measurement does not support I/Q impairment estimation.

Parameters: <DsssModAccEqualizationEnabled> Boolean

:CONFigure:WLAN:MODacc:DSSS:EVM:UNIT <DsssModAccEvmUnit>

Availability: Command and Query **Default:** Percentage

Description: Sets the unit for the EVM results.

Parameters: <DsssModAccEvmUnit> Percentage | dB

**:CONFigure:WLAN:MODacc:DSSS:FERRor:CORREction:ENABLE
<DsssModAccFrequencyErrorCorrectionEnabled>**

Availability: Command and Query **Default:** 1

Description: Sets whether to enable frequency error correction.

Parameters: <DsssModAccFrequencyErrorCorrectionEnabled> Boolean

**:CONFigure:WLAN:MODacc:DSSS:IQ:ORIGin:OFFSet:CORRection:ENABLE
<DsssModAccIQOriginOffsetCorrectionEnabled>**

Availability: Command and Query **Default:** 1

Description: Sets whether to enable I/Q origin offset correction.

Parameters: <DsssModAccIQOriginOffsetCorrectionEnabled> Boolean

**:CONFigure:WLAN:MODacc:DSSS:MEASurement:ENABLE
<DsssModAccMeasurementEnabled>**

Availability: Command and Query **Default:** 0

Description: Sets whether to enable the DSSSModAcc measurement, which is a measurement of the modulation accuracy on signals conforming to the DSSS PHY defined in section 15 and the High Rate DSSS PHY defined in section 16 of IEEE Standard 802.11-2016.

Parameters: <DsssModAccMeasurementEnabled> Boolean

**:CONFigure:WLAN:MODacc:DSSS:MEASurement:LENGth:MAXimum
<DsssModAccMaxMeasurementLength>**

Availability: Command and Query **Default:** 1000

Description: Sets the maximum number of data chips that the measurement uses to compute EVM. This value is expressed in chips.

Parameters: <DsssModAccMaxMeasurementLength> Int32

**:CONFigure:WLAN:MODacc:DSSS:MEASurement:OFFSet
<DsssModAccMeasurementOffset>**

Availability: Command and Query **Default:** 0

Description: Sets the number of data chips to be ignored from the start of the data field for the EVM computation. This value is expressed in chips.

Parameters: <DsssModAccMeasurementOffset> Int32

**:CONFigure:WLAN:MODacc:DSSS:NTHReads
<DsssModAccNumberOfAnalysisThreads>**

Availability: Command and Query **Default:** 1

Description: Sets the maximum number of threads used for parallelism for DSSSModAcc measurement.

Parameters: <DsssModAccNumberOfAnalysisThreads> Int32

**:CONFigure:WLAN:MODacc:DSSS:POWER:CGATes:NUMBer
<DsssModAccPowerNumberOfCustomGates>**

Availability: Command and Query **Default:** 0

Description: Sets the number of custom gates used for power measurement.

Parameters: <DsssModAccPowerNumberOfCustomGates> Int32

:CONFigure:WLAN:MODacc:DSSS:POWer:CGATes:TiMe:STARt
<DsssModAccPowerCustomGateStartTime>

Availability: Command and Query **Default:** 0

Description: Sets the start time of the custom power gate. This value is expressed in seconds.

Parameters: <DsssModAccPowerCustomGateStartTime> Double

:CONFigure:WLAN:MODacc:DSSS:POWer:CGATes:TiMe:STOP
<DsssModAccPowerCustomGateStopTime>

Availability: Command and Query **Default:** 0

Description: Sets the stop time for the custom power gate. This value is expressed in seconds.

Parameters: <DsssModAccPowerCustomGateStopTime> Double

:CONFigure:WLAN:MODacc:DSSS:POWer:MEASurement:ENABLE
<DsssModAccPowerMeasurementEnabled>

Availability: Command and Query **Default:** 0

Description: Sets whether power measurement is performed. This measurement computes power of various fields in the PPDU.

Parameters: <DsssModAccPowerMeasurementEnabled> Boolean

:CONFigure:WLAN:MODacc:DSSS:PSFilter:PARAmeter
<DsssModAccPulseShapingFilterParameter>

Availability: Command and Query **Default:** 0

Description: Sets the value of the filter roll-off when user sets the Pulse Shaping Filter Type method to Raised Cosine or Root Raised Cosine. This method is ignored if you set the Pulse Shaping Filter Type method to Rectangular.

Parameters: <DsssModAccPulseShapingFilterParameter> Double

:CONFigure:WLAN:MODacc:DSSS:PSFilter:TYPE
<DsssModAccPulseShapingFilterType>

Availability: Command and Query **Default:** Rectangular

Description: Sets the type of pulse shaping filter used at the transmitter. This method is ignored when DsssModAccEqualizationEnabled is set to true.

Parameters: <DsssModAccPulseShapingFilterType> RaisedCosine | Rectangular | RootRaisedCosine

:CONFigure:WLAN:MODacc:DSSS:SPECTrum:INVerted:ENABLE
<DsssModAccSpectrumInvertedEnabled>

Availability: Command and Query **Default:** 0

Description: Sets whether the spectrum of the measured signal is inverted.

Parameters: <DsssModAccSpectrumInvertedEnabled> Boolean

:CONFigure:WLAN:MODacc:DSSS:TRACe:ENABle <DsssModAccAllTracesEnable>

Availability: Command and Query **Default:** 0

Description: Sets whether to enable all the traces computed by DSSSModAcc measurement.

Parameters: <DsssModAccAllTracesEnable> Boolean

**:CONFigure:WLAN:MODacc:OFDM:ACQuisition:LENGth
<OfdmModAccAcquisitionLength_s>**

Availability: Command and Query **Default:** 89

Description: Sets the length of the waveform to be acquired for the OFDMModAcc measurement, when user sets the OfdmModAccAcquisitionLengthMode to Manual. This value is expressed in seconds.

Parameters: <OfdmModAccAcquisitionLength_s> Double

**:CONFigure:WLAN:MODacc:OFDM:ACQuisition:LENGth:MODE
<OfdmModAccAcquisitionLengthMode>**

Availability: Command and Query **Default:** AUTO

Description: Sets whether the measurement automatically computes the acquisition length of the waveform based on OFDM ModAcc properties.

Parameters: <OfdmModAccAcquisitionLengthMode> AUTO | NORMAL

**:CONFigure:WLAN:MODacc:OFDM:AMPLitude:TRACking:ENABle
<OfdmModAccAmplitudeTrackingEnabled>**

Availability: Command and Query **Default:** 0

Description: Sets whether to enable pilot-based mean amplitude tracking per OFDM data symbol.

Parameters: <OfdmModAccAmplitudeTrackingEnabled> Boolean

:CONFigure:WLAN:MODacc:OFDM:AVG:COUNT <OfdmModAccAveragingCount>

Availability: Command and Query **Default:** 10

Description: Sets the number of acquisitions used for averaging when Ofdm ModAcc averaging is enabled.

Parameters: <OfdmModAccAveragingCount> Int32

:CONFigure:WLAN:MODacc:OFDM:AVG:ENABle <OfdmModAccAveragingEnabled>

Availability: Command and Query **Default:** 0

Description: Sets whether to enable averaging for OFDMModAcc measurements.

Parameters: <OfdmModAccAveragingEnabled> Boolean

:CONFigure:WLAN:MODacc:OFDM:AVG:TYPE <OfdmModAccAveragingType>

Availability: Command and Query **Default:** RMS

Description: Sets the averaging type for the OFDMModAcc measurement.

Parameters: <OfdmModAccAveragingType> RMS | VECTOR

**:CONFigure:WLAN:MODacc:OFDM:BURSt:STARt:DETection:ENABLE
<OfdmModAccBurstStartDetectionEnabled>**

Availability: Command and Query **Default:** 0

Description: Sets whether the measurement detects a rising edge of a burst in the acquired waveform.

Parameters: <OfdmModAccBurstStartDetectionEnabled> Boolean

**:CONFigure:WLAN:MODacc:OFDM:CHANnel:ESTimation:SMOothing:ENABLE
<OfdmModAccChannelEstimationSmoothingEnabled>**

Availability: Command and Query **Default:** 0

Description: Sets whether smoothing of the channel estimates is performed using a triangular-weighted moving average window across subcarriers.

Parameters: <OfdmModAccChannelEstimationSmoothingEnabled> Boolean

**:CONFigure:WLAN:MODacc:OFDM:CHANnel:ESTimation:SMOothing:LENGth
<OfdmModAccChannelEstimationSmoothingLength>**

Availability: Command and Query **Default:** 5

Description: Sets the length of the triangular-weighted moving window across subcarriers that is used for averaging the channel estimate.

Parameters: <OfdmModAccChannelEstimationSmoothingLength> Int32

**:CONFigure:WLAN:MODacc:OFDM:CHANnel:ESTimation:TYPE
<OfdmModAccChannelEstimationType>**

Availability: Command and Query **Default:** Reference

Description: Sets the fields in the PPDU used to estimate the channel frequency response.

Parameters: <OfdmModAccChannelEstimationType> Reference | ReferenceAndData

**:CONFigure:WLAN:MODacc:OFDM:COMMOn:CLOCK:SOURce:ENABLE
<OfdmModAccCommonClockSourceEnabled>**

Availability: Command and Query **Default:** 1

Description: Sets whether the transmitter uses the same reference clock signal for generating the RF carrier and the symbol clock.

Parameters: <OfdmModAccCommonClockSourceEnabled> Boolean

**:CONFigure:WLAN:MODacc:OFDM:DATAI:DECoding:ENABLE
<OfdmDataDecodingEnabled>**

Availability: Command and Query **Default:** 0

Description: Specifies whether to decode data bits and check for the validity of the cyclic redundancy check (CRC).

Parameters: <OfdmDataDecodingEnabled> Boolean

**:CONFigure:WLAN:MODacc:OFDM:EVM:DRANge:OPTimize:ENABLE
<OfdmModAccOptimizeDynamicRangeForEvmEnabled>**

Availability: Command and Query **Default:** 0

Description: Sets whether to optimize the analyzer's dynamic range for the EVM measurement. This method computes optimum attenuation settings for the analyzer based on the reference level you specify while still avoiding ADC or onboard signal processing (OSP) overflow. When you specify the reference level and you notice an overflow error, you can increase the reference level or specify a margin above the reference level by configuring the optimizeDynamicRangeForEvmMargin method.

Parameters: <OfdmModAccOptimizeDynamicRangeForEvmEnabled> Boolean

**:CONFigure:WLAN:MODacc:OFDM:EVM:DRANge:OPTimize:MARGin
<OfdmModAccOptimizeDynamicRangeForEvmMargin_dB>**

Availability: Command and Query **Default:** 0

Description: Sets the margin above the reference level you specify when user sets the optimizeDynamicRangeForEvmEnabled method to True. When the method's value is 0, the dynamic range is optimized. when user sets a positive value to the parameter, the dynamic range reduces from the optimized dynamic range. You can use this parameter to avoid ADC and onboard signal processing (OSP) overflows. This value is expressed in dB. The default value is 0 dB.

Parameters: <OfdmModAccOptimizeDynamicRangeForEvmMargin_dB> Double

:CONFigure:WLAN:MODacc:OFDM:EVM:UNIT <OfdmModAccEvmUnit>

Availability: Command and Query **Default:** dB

Description: Sets the unit for EVM results.

Parameters: <OfdmModAccEvmUnit> Percentage | dB

**:CONFigure:WLAN:MODacc:OFDM:FERRor:ESTimation:METHod
<OfdmModAccFrequencyErrorEstimationMethod>**

Availability: Command and Query **Default:** PreambleAndPilots

Description: Sets the PPDU fields that the measurement uses to estimate the carrier frequency error in the acquired signal.

Parameters: <OfdmModAccFrequencyErrorEstimationMethod> Disabled | InitialPreamble | Preamble | PreambleAndPilots | PreamblePilotsAndData

**:CONFigure:WLAN:MODacc:OFDM:IQ:GAIN:IMBalance:CORRection:ENABLE
<OfdmModAccIQGainImbalanceCorrectionEnabled>**

Availability: Command and Query **Default:** 0

Description: Sets whether to enable I/Q gain imbalance correction.

Parameters: <OfdmModAccIQGainImbalanceCorrectionEnabled> Boolean

**:CONFigure:WLAN:MODacc:OFDM:IQ:IMPairments:ESTimation:ENABLE
<OfdmModAccIQImpairmentsEstimationEnabled>**

Availability: Command and Query **Default:** 1

Description: Sets whether to enable the estimation of I/Q gain imbalance, I/Q quadrature error, and I/Q timing skew impairments.

Parameters: <OfdmModAccIQImpairmentsEstimationEnabled> Boolean

**:CONFigure:WLAN:MODacc:OFDM:IQ:IMPairments:MODEL
<OfdmModAccIQImpairmentsModel>**

Availability: Command and Query **Default:** TX

Description: Sets the I/Q impairments model used by the measurement for estimating I/Q impairments.

Parameters: <OfdmModAccIQImpairmentsModel> TX | RX

**:CONFigure:WLAN:MODacc:OFDM:IQ:IMPairments:PSCarrier:ENABLE
<OfdmModAccIQImpairmentsPerSubcarrierEnabled>**

Availability: Command and Query **Default:** 0

Description: Sets whether to return I/Q impairments independently for each subcarrier.

Parameters: <OfdmModAccIQImpairmentsPerSubcarrierEnabled> Boolean

**:CONFigure:WLAN:MODacc:OFDM:IQ:QERRor:CORRection:ENABLE
<OfdmModAccIQQuadratureErrorCorrectionEnabled>**

Availability: Command and Query **Default:** 0

Description: Sets whether to enable I/Q quadrature error correction.

Parameters: <OfdmModAccIQQuadratureErrorCorrectionEnabled> Boolean

**:CONFigure:WLAN:MODacc:OFDM:IQ:TIMing:SKEW:CORRection:ENABLE
<OfdmModAccIQTimingSkewCorrectionEnabled>**

Availability: Command and Query **Default:** 0

Description: Sets whether to enable I/Q timing skew correction.

Parameters: <OfdmModAccIQTimingSkewCorrectionEnabled> Boolean

**:CONFigure:WLAN:MODacc:OFDM:MEASurement:ENABLE
<OfdmModAccMeasurementEnabled>**

Availability: Command and Query **Default:** 1

Description: Sets whether to enable OFDMModAcc measurement.

Parameters: <OfdmModAccMeasurementEnabled> Boolean

**:CONFigure:WLAN:MODacc:OFDM:MEASurement:LENGth:MAXimum
<OfdmModAccMaxMeasurementLenght>**

Availability: Command and Query **Default:** 16

Description: Sets the maximum number of OFDM symbols that the measurement uses to compute EVM. This value is expressed in symbols.

Parameters: <OfdmModAccMaxMeasurementLenght> Int32

**:CONFigure:WLAN:MODacc:OFDM:MEASurement:MODE
<OfdmModAccMeasurementMode>**

Availability: Command and Query **Default:** Measure

Description: Sets whether the measurement calibrates the noise floor of analyzer or performs the ModAcc measurement.

Parameters: <OfdmModAccMeasurementMode> CalibrateNoiseFloor | Measure

**:CONFigure:WLAN:MODacc:OFDM:MEASurement:OFFSet
<OfdmModAccMeasurementOffset>**

Availability: Command and Query **Default:** 0

Description: Sets the number of data chips to be ignored from the start of the data field for the EVM computation. This value is expressed in chips.

Parameters: <OfdmModAccMeasurementOffset> Int32

**:CONFigure:WLAN:MODacc:OFDM:NOISe:COMPensation:ENABLE
<OfdmModAccNoiseCompensationEnabled>**

Availability: Command and Query **Default:** 0

Description: Sets whether the contribution of the instrument noise is compensated for EVM computation.

Parameters: <OfdmModAccNoiseCompensationEnabled> Boolean

**:CONFigure:WLAN:MODacc:OFDM:NOISe:COMPensation:INPut:POWEr:CHECK:ENABLE
<OfdmModAccNoiseCompensationInputPowerCheckEnabled>**

Availability: Command and Query **Default:** 1

Description: Sets whether the measurement checks if any high power signal is present at the RFIn port of the instrument while performing noise floor calibration.

Parameters: <OfdmModAccNoiseCompensationInputPowerCheckEnabled> Boolean

**:CONFigure:WLAN:MODacc:OFDM:NOISe:COMPensation:REFerence:LEVel:COERcion:LIMit
<OfdmModAccNoiseCompensationReferenceLevelCoercionLimit_dB>**

Availability: Command and Query **Default:** 0.5

Description: Sets the reference level coercion limit for noise compensation. This value is expressed in dB.

Parameters: <OfdmModAccNoiseCompensationReferenceLevelCoercionLimit_dB> Double

**:CONFigure:WLAN:MODacc:OFDM:NTHReads
<OfdmModAccNumberOfAnalysisThreads>**

Availability: Command and Query **Default:** 1

Description: Sets the maximum number of threads used for parallelism for the OFDMModAcc measurement.

Parameters: <OfdmModAccNumberOfAnalysisThreads> Int32

**:CONFigure:WLAN:MODacc:OFDM:PHASe:TRACking:ENABLE
<OfdmModAccPhaseTrackingEnabled>**

Availability: Command and Query **Default:** 1

Description: Sets whether to enable pilot-based common phase error correction per OFDM data symbol.

Parameters: <OfdmModAccPhaseTrackingEnabled> Boolean

**:CONFigure:WLAN:MODacc:OFDM:POWer:CGATes:NUMBer
<OfdmModAccPowerNumberOfCustomGates>**

Availability: Command and Query **Default:** 0

Description: Sets the number of custom gates for power measurement.

Parameters: <OfdmModAccPowerNumberOfCustomGates> Int32

**:CONFigure:WLAN:MODacc:OFDM:POWer:CGATes:TIME:START
<OfdmModAccPowerCustomGateStartTime>**

Availability: Command and Query **Default:** 0

Description: Sets the start time of the custom power gate. This value is expressed in seconds.

Parameters: <OfdmModAccPowerCustomGateStartTime> Double

**:CONFigure:WLAN:MODacc:OFDM:POWer:CGATes:TIME:STOP
<OfdmModAccPowerCustomGateStopTime>**

Availability: Command and Query **Default:** 0

Description: Sets the stop time of the custom power gate, and must be greater than the corresponding OFDMModAcc Pwr Custom Gate Start Time method. This value is expressed in seconds.

Parameters: <OfdmModAccPowerCustomGateStopTime> Double

**:CONFigure:WLAN:MODacc:OFDM:POWer:MEASurement:ENABLE
<OfdmModAccPowerMeasurementEnabled>**

Availability: Command and Query **Default:** 0

Description: Sets whether power averaging is performed.

Parameters: <OfdmModAccPowerMeasurementEnabled> Boolean

**:CONFigure:WLAN:MODacc:OFDM:SPECTrum:INVerted:ENABLE
<OfdmModAccSpectrumInvertedEnabled>**

Availability: Command and Query **Default:** 0

Description: Sets whether the spectrum of the measured signal is inverted. The inversion happens when the I and the Q components of the baseband complex signal are swapped.

Parameters: <OfdmModAccSpectrumInvertedEnabled> Boolean

**:CONFigure:WLAN:MODacc:OFDM:SYMBol:CERRor:CONNection:ENABLE
<OfdmModAccSymbolClockErrorConnectionEnabled>**

Availability: Command and Query **Default:** 1

Description: Sets whether to enable symbol clock error correction.

Parameters: <OfdmModAccSymbolClockErrorConnectionEnabled> Boolean

:CONFigure:WLAN:MODacc:OFDM:TRACe:ENABle <OfdmModAccAllTracesEnable>

Availability: Command and Query **Default:** 0

Description: Sets whether to enable all the traces computed by the OFDMModAcc measurement.

Parameters: <OfdmModAccAllTracesEnable> Boolean

**:CONFigure:WLAN:MODacc:OFDM:UNUSed:TERRor:MASK:REFerence
<OfdmModAccUnusedToneErrorMaskReference>**

Availability: Command and Query **Default:** Limit1

Description: Sets the reference used to create the unused tone error mask for the 802.11ax trigger-based PPDU signals.

Parameters: <OfdmModAccUnusedToneErrorMaskReference> Limit1 | Limit2

:CONFigure:WLAN:PWRRamp:ACQuisition:LENGth <PowerRampAcquisitionLength>

Availability: Command and Query **Default:** 1

Description: Sets the duration of the signal to be acquired for the PowerRamp measurement. This value is expressed in seconds.

Parameters: <PowerRampAcquisitionLength> Double

:CONFigure:WLAN:PWRRamp:AVG:COUNt <PowerRampAveragingCount>

Availability: Command and Query **Default:** 10

Description: Sets the number of acquisitions used for averaging when PowerRamp averaging is enabled.

Parameters: <PowerRampAveragingCount> Int32

:CONFigure:WLAN:PWRRamp:AVG:ENABle <PowerRampAveragingEnabled>

Availability: Command and Query **Default:** 0

Description: Sets if averaging is enabled for PowerRamp measurements.

Parameters: <PowerRampAveragingEnabled> Boolean

**:CONFigure:WLAN:PWRRamp:MEASurement:ENABle
<PowerRampMeasurementEnabled>**

Availability: Command and Query **Default:** 0

Description: Sets whether to enable PowerRamp measurement.

Parameters: <PowerRampMeasurementEnabled> Boolean

:CONFigure:WLAN:PWRRamp:NTHReads <PowerRampNumberOfAnalysisThreads>

Availability: Command and Query **Default:** 1

Description: Sets the maximum number of threads used for parallelism for PowerRamp measurement.

Parameters: <PowerRampNumberOfAnalysisThreads> Int32

:CONFigure:WLAN:PWRRamp:TRACe:ENABle <PowerRampAllTracesEnable>

Availability: Command and Query **Default:** 0

Description: Sets whether to enable all the traces computed by the PowerRamp measurement.

Parameters: <PowerRampAllTracesEnable> Boolean

:CONFigure:WLAN:REfERENCE:LEVel <ReferenceLevel_dBm>

Availability: Command and Query **Default:** 0

Description: Sets the reference level which represents the maximum expected power of the RF input signal. This value is expressed in dBm for RF devices and Vpk-pk for baseband devices.

Parameters: <ReferenceLevel_dBm> Double

:CONFigure:WLAN:RU:OFFSet <RUOffset>

Availability: Command and Query **Default:** 0

Description: Sets the location of RU for a user in terms of the index of a 26-tone RU, assuming the entire bandwidth is composed of 26-tone RUs.

Parameters: <RUOffset> Int32

:CONFigure:WLAN:RU:SIZE <RUSize>

Availability: Command and Query **Default:** 26

Description: Sets the RU size.

Parameters: <RUSize> Int32

**:CONFigure:WLAN:SEM:AMPLitude:CORRection:TYPE
<SemAmplitudeCorrectionType>**

Availability: Command and Query **Default:** RFCenterFreq

Description: Sets whether the amplitude of the frequency bins, used in the measurement, is corrected for external attenuation at the RF center frequency, or at the individual frequency bins. Use the RFmxInstr_CfgExternalAttenuationTable function to configure the external attenuation table.

Parameters: <SemAmplitudeCorrectionType> RFCenterFreq | SpectrumFrequencyBin

:CONFigure:WLAN:SEM:AVG:COUNt <SemAveragingCount>

Availability: Command and Query **Default:** 10

Description: Sets the number of acquisitions used for averaging when Sem averaging is enabled.

Parameters: <SemAveragingCount> Int32

:CONFigure:WLAN:SEM:AVG:ENABLE <SemAveragingEnabled>

Availability: Command and Query **Default:** 0

Description: Sets whether to enable averaging for the SEM measurement.

Parameters: <SemAveragingEnabled> Boolean

:CONFigure:WLAN:SEM:AVG:TYPE <SemAveragingType>

Availability: Command and Query **Default:** Rms

Description: Sets the averaging type for averaging multiple spectrum acquisitions. The averaged spectrum is used for SEM measurement.

Parameters: <SemAveragingType> Rms | Log | Scalar | Max | Min | Vector

:CONFigure:WLAN:SEM:MASK:TYPE <SemMaskType>

Availability: Command and Query **Default:** Standard

Description: Sets whether the mask used for the SEM measurement is defined either as per the standard or as specified by you.

Parameters: <SemMaskType> Custom | Standard

:CONFigure:WLAN:SEM:MEASurement:ENABLE <SemMeasurementEnabled>

Availability: Command and Query **Default:** 1

Description: Sets whether to enable the SEM measurement.

Parameters: <SemMeasurementEnabled> Boolean

:CONFigure:WLAN:SEM:NTHReads <SemNumberOfAnalysisThreads>

Availability: Command and Query **Default:** 1

Description: Sets the maximum number of threads used for parallelism for SEM measurement.

Parameters: <SemNumberOfAnalysisThreads> Int32

:CONFigure:WLAN:SEM:OFFSet:FREQuency:START <SemOffsetStartFrequency_Hz>

Availability: Command and Query **Default:** 9000000

Description: Sets the start frequency of the offset segment relative to the carrier frequency. This value is expressed in Hz.

Parameters: <SemOffsetStartFrequency_Hz> Double

:CONFigure:WLAN:SEM:OFFSet:FREQuency:STOP <SemOffsetStopFrequency_Hz>

Availability: Command and Query **Default:** 11000000

Description: Sets the stop frequency of the offset segment relative to carrier frequency. This value is expressed in Hz.

Parameters: <SemOffsetStopFrequency_Hz> Double

:CONFigure:WLAN:SEM:OFFSet:RLIMit:START <SemOffsetRelativeLimitStart>

Availability: Command and Query **Default:** 0

Description: Sets the relative power limit corresponding to the start of the offset segment. This value is expressed in dB.

Parameters: <SemOffsetRelativeLimitStart> Double

:CONFigure:WLAN:SEM:OFFSet:RLIMit:STOP <SemOffsetRelativeLimitStop>

Availability: Command and Query **Default:** -20

Description: Sets the relative power limit corresponding to the end of the offset segment. This value is expressed in dB.

Parameters: <SemOffsetRelativeLimitStop> Double

:CONFigure:WLAN:SEM:OFFSet:SIDE:BAND <SemOffsetSideband>

Availability: Command and Query **Default:** BOTH

Description: Sets whether the offset segment is present on one side or on both sides of the carrier.

Parameters: <SemOffsetSideband> NEG | POS | BOTH

:CONFigure:WLAN:SEM:OFFSets:NUMBer <SemNumberOfOffsets>

Availability: Command and Query **Default:** 4

Description: Sets the number of offset segments.

Parameters: <SemNumberOfOffsets> Int32

:CONFigure:WLAN:SEM:SPAN <SemSpan>

Availability: Command and Query **Default:** 66000000

Description: Sets the frequency range of the spectrum used for the SEM measurement. This value is expressed in Hz.

Parameters: <SemSpan> Double

:CONFigure:WLAN:SEM:SPAN:AUTO <SemSpanAuto>

Availability: Command and Query **Default:** 1

Description: Sets whether the frequency range of the spectrum used for SEM measurement is computed automatically by the measurement or is configured by you.

Parameters: <SemSpanAuto> Boolean

:CONFigure:WLAN:SEM:SWEep:TIME:AUTO <SemSweepTimeAuto>

Availability: Command and Query **Default:** 1

Description: Sets whether the sweep time for the SEM measurement is computed automatically or is configured by you.

Parameters: <SemSweepTimeAuto> Boolean

:CONFigure:WLAN:SEM:SWEep:TIME:INTerval <SemSweepTimeInterval_s>

Availability: Command and Query **Default:** 0.001

Description: Sets the sweep time for the SEM measurement. This value is expressed in seconds.

Parameters: <SemSweepTimeInterval_s> Double

:CONFigure:WLAN:SEM:TRACe:ENABle <SemAllTracesEnable>

Availability: Command and Query **Default:** 0

Description: Sets whether to enable the traces to be stored and retrieved after performing the SEM measurement.

Parameters: <SemAllTracesEnable> Boolean

:CONFigure:WLAN:STANdard <Standard>

Availability: Command and Query **Default:** A_G

Description: Sets the signal under analysis as defined in IEEE Standard 802.11.

Parameters: <Standard> A_G | B | J | P | N | AC |
G_DSSS_OFDM | AX

:CONFigure:WLAN:TRACe:ENABle <TraceEnable>

Availability: Command and Query **Default:** 0

Description: Enables traces for all measurements.

Parameters: <TraceEnable> Boolean

:CONFigure:WLAN:TX:POWer:CLASs <TxPowerClass>

Availability: Command and Query **Default:** A

Description: Sets the STA transmit power classification as defined in annexure D.2.2 of IEEE Standard 802.11 – 2016, if you set the Standard to Standard802_11p.

Parameters: <TxPowerClass> A | B | C | D

:CONFigure:WLAN:TXP:AVG:COUNT <TxpAveragingCount>

Availability: Command and Query **Default:** 10

Description: Sets the number of acquisitions used for averaging when Txp averaging is enabled.

Parameters: <TxpAveragingCount> Int32

:CONFigure:WLAN:TXP:AVG:ENABLE <TxpAveragingEnabled>

Availability: Command and Query **Default:** 0

Description: Sets whether to enable averaging for the TXP measurement.

Parameters: <TxpAveragingEnabled> Boolean

:CONFigure:WLAN:TXP:BURSt:DETection:ENABLE <TxpBurstDetectionEnabled>

Availability: Command and Query **Default:** 1

Description: Sets whether the measurement detects the start and the end of a WLAN packet automatically.

Parameters: <TxpBurstDetectionEnabled> Boolean

:CONFigure:WLAN:TXP:MEASurement:ENABLE <TxpMeasurementEnabled>

Availability: Command and Query **Default:** 1

Description: Sets whether to enable the TXP measurement.

Parameters: <TxpMeasurementEnabled> Boolean

**:CONFigure:WLAN:TXP:MEASurement:INTERval:MAXimum
<TxpMaxMeasurementInterval_s>**

Availability: Command and Query **Default:** 0.001

Description: Sets the maximum measurement interval. This value is expressed in seconds.

Parameters: <TxpMaxMeasurementInterval_s> Double

:CONFigure:WLAN:TXP:NTHReads <TxpNumberOfAnalysisThreads>

Availability: Command and Query **Default:** 1

Description: Sets the maximum number of threads used for parallelism for TXP measurement.

Parameters: <TxpNumberOfAnalysisThreads> Int32

:CONFigure:WLAN:TXP:TRACe:ENABLE <TxpAllTracesEnable>

Availability: Command and Query **Default:** 0

Description: Sets whether to enable the traces to be stored and retrieved after performing the TXP measurement.

Parameters: <TxpAllTracesEnable> Boolean

:CONFigure:WLAN:USERS:NUMBER <NumberOfUsers>**Availability:** Command and Query **Default:** 1**Description:** Sets the number of users in a multi-user (MU) PPDU.**Parameters:** <NumberOfUsers> Int32

:FETch:WLAN:RESults<i>:MODacc:DSSS:CHIP:CERRor:MEAN**Availability:** Query Only **Default:** NaN**Description:** Contains chip clock error result of the transmitter. This value is expressed in parts per million (ppm). When averaging is enabled, this result returns the mean of the chip clock error computed for each averaging count.**Return type:** Double

:FETch:WLAN:RESults<i>:MODacc:DSSS:CHIP:NUMBER**Availability:** Query Only **Default:** 0**Description:** Contains the number of chips used for the DSSSModAcc measurement.**Return type:** Int32

:FETch:WLAN:RESults<i>:MODacc:DSSS:DATA:POWer:AVG:MEAN**Availability:** Query Only **Default:** NaN**Description:** Contains the average power of the data field of the PPDU. When averaging is enabled, this method returns the mean of the data field average power results computed for each averaging count. This value is expressed in dBm.**Return type:** Double

:FETch:WLAN:RESults<i>:MODacc:DSSS:DATA:POWer:PEAK:MAXimum**Availability:** Query Only **Default:** NaN**Description:** Contains the peak power of the data field of the PPDU. When averaging is enabled, this result returns the maximum of the peak data field power results computed for each averaging count. This value is expressed as a percentage or in dB.**Return type:** Double

:FETch:WLAN:RESults<i>:MODacc:DSSS:EVM:PEAK1999:MAXimum**Availability:** Query Only **Default:** NaN**Description:** Contains the peak EVM results of the burst. This value is expressed as a percentage or in dB. This measurement is performed in accordance with section 16.3.7.9 of IEEE Standard 802.11-2016. When averaging is enabled, this result returns the maximum of the peak EVM computed for each averaging count.**Return type:** Double

:FETch:WLAN:RESults<i>:MODacc:DSSS:EVM:PEAK2007:MAXimum**Availability:** Query Only **Default:** NaN**Description:** Contains the peak EVM results of the burst. This value is expressed as a percentage or in dB. This measurement is performed in accordance with section 16.3.7.9 of IEEE Standard 802.11-2016. When averaging is enabled, this result returns the maximum of the peak EVM computed for each averaging count.**Return type:** Double

:FETch:WLAN:RESults<i>:MODacc:DSSS:EVM:PEAK2016:MAXimum**Availability:** Query Only**Default:** NaN

Description: Contains the peak EVM results of the burst. This value is expressed as a percentage or in dB. This measurement is performed in accordance with section 16.3.7.9 of IEEE Standard 802.11-2016. When averaging is enabled, this result returns the maximum of the peak EVM computed for each averaging count.

Return type: Double

:FETch:WLAN:RESults<i>:MODacc:DSSS:FERRor:MEAN**Availability:** Query Only**Default:** NaN

Description: Contains the carrier frequency error of the transmitter. This value is expressed in Hz. When averaging is enabled, this result returns the mean of the carrier frequency error results computed for each averaging count.

Return type: Double

:FETch:WLAN:RESults<i>:MODacc:DSSS:HEADer:BITS:TRACe:DECoded<i>**Availability:** Query Only**Default:** N/A

Description: Fetches the decoded Header bits.

Return type: Int32

:FETch:WLAN:RESults<i>:MODacc:DSSS:HEADer:POWER:AVG:MEAN**Availability:** Query Only**Default:** NaN

Description: Contains the average power of the header field of the PPDU. When averaging is enabled, this result returns the mean of the average header field power computed for each averaging count. This value is expressed in dBm.

Return type: Double

:FETch:WLAN:RESults<i>:MODacc:DSSS:HEADer:POWER:PEAK:MAXimum**Availability:** Query Only**Default:** NaN

Description: Contains the peak power of the header field of the PPDU. When averaging is enabled, this result returns the maximum of the peak header field power results computed for each averaging count. This value is expressed as a percentage or in dB.

Return type: Double

:FETch:WLAN:RESults<i>:MODacc:DSSS:IQ:GAIN:IMBalance:MEAN**Availability:** Query Only**Default:** NaN

Description: Contains the I/Q gain imbalance results. This value is expressed in dB. I/Q gain imbalance is the ratio of the mean amplitude of the in-phase (I) signal to the mean amplitude of the quadrature-phase (Q) signal. When user sets the DSSSModAcc Averaging Enabled method to True, this parameter returns the mean of the I/Q gain imbalance results computed for each averaging count.

Return type: Double

:FETch:WLAN:RESults<i>:MODacc:DSSS:IQ:ORIGin:OFFSet:MEAN**Availability:** Query Only**Default:** NaN

Description: Contains the I/Q origin offset. This value is expressed in dB. I/Q origin offset is the ratio of the mean value of the signal to the RMS value of the signal. When averaging is enabled, this parameter returns the mean of the I/Q origin offset results computed for each averaging count.

Return type: Double

:FETch:WLAN:RESults<i>:MODacc:DSSS:IQ:QERRor:MEAN**Availability:** Query Only**Default:** NaN

Description: Contains the peak EVM results of the burst. This value is expressed as a percentage or in dB. This measurement is performed in accordance with section 18.4.7.8 of IEEE Standard 802.11b-1999. When averaging is enabled, this result returns the maximum of the peak EVM computed for each averaging count.

Return type: Double

:FETch:WLAN:RESults<i>:MODacc:DSSS:PAYLoad:LENGth**Availability:** Query Only**Default:** 0

Description: Contains the payload length of the acquired burst. This value is expressed in bytes.

Return type: Int32

:FETch:WLAN:RESults<i>:MODacc:DSSS:PPDU:POWer:AVG:MEAN**Availability:** Query Only**Default:** NaN

Description: Contains the average power of the PPDU. When averaging is enabled, this parameter returns the mean of the average PPDU power results computed for each averaging count. This value is expressed in dBm.

Return type: Double

:FETch:WLAN:RESults<i>:MODacc:DSSS:PPDU:POWer:PEAK:MAXimum**Availability:** Query Only**Default:** NaN

Description: Contains the peak power of the PPDU. When averaging is enabled, this parameter returns the maximum of the peak PPDU power results computed for each averaging count. This value is expressed as a percentage or in dB.

Return type: Double

:FETch:WLAN:RESults<i>:MODacc:DSSS:PREamble:POWer:AVG:MEAN**Availability:** Query Only**Default:** NaN

Description: Contains the average power of the preamble field of the PPDU. When averaging is enabled, this result returns the mean of the average preamble field power computed for each averaging count. This value is expressed in dBm.

Return type: Double

:FETch:WLAN:RESults<i>:MODacc:DSSS:PREamble:POWER:PEAK:MAXimum**Availability:** Query Only**Default:** NaN

Description: Contains the peak power of the preamble field of the PPDU. When averaging is enabled, this result returns the maximum of the peak preamble field power results computed for each averaging count. This value is expressed as a percentage or in dB.

Return type: Double

:FETch:WLAN:RESults<i>:MODacc:DSSS:PSDU:BITS:TRACe:DECoded<i>**Availability:** Query Only**Default:** N/A

Description: Fetches the decoded PLCP service data unit (PSDU) bits.

Return type: Int32

:FETch:WLAN:RESults<i>:MODacc:DSSS:PSDU:CRC:STATus**Availability:** Query Only**Default:** FAIL

Description: Indicates whether the cyclic redundancy check (CRC) of the received decoded PLCP service data unit (PSDU) has passed.

Return type: FAIL | PASS

:FETch:WLAN:RESults<i>:MODacc:DSSS:RMS:EVM:MEAN**Availability:** Query Only**Default:** NaN

Description: Contains the RMS EVM results of the burst. When averaging is enabled, this result returns the mean of the RMS EVM computed for each averaging count. This value is expressed as a percentage or in dB.

Return type: Double

:FETch:WLAN:RESults<i>:MODacc:DSSS:RMS:MERRor:MEAN**Availability:** Query Only**Default:** NaN

Description: Gets the RMS magnitude error of the received constellation, which is the RMS level of the one minus the magnitude of the received constellation symbols. This value is expressed as a percentage.

Return type: Double

:FETch:WLAN:RESults<i>:MODacc:DSSS:RMS:PERRor:MEAN**Availability:** Query Only**Default:** NaN

Description: Gets the RMS phase error of the received constellation, which is the RMS level of difference between the ideal and the actual values of the phase of the received constellation symbols. This value is expressed in degrees.

Return type: Double

:FETch:WLAN:RESults<i>:MODacc:OFDM:AVG:TYPE**Availability:** Query Only**Default:** RMS

Description: Gets the averaging type for the OFDMModAcc measurement.

Return type: RMS | VECTOR

:FETch:WLAN:RESults<i>:MODacc:OFDM:CHAI:n:DATA:RMS:EVM:MEAN**Availability:** Query Only**Default:** NaN

Description: Gets the chain RMS EVM of data subcarriers in all OFDM symbols. This value is expressed as a percentage or in dB.

Return type: Double

:FETch:WLAN:RESults<i>:MODacc:OFDM:CHAI:n:PILot:RMS:EVM:MEAN**Availability:** Query Only**Default:** NaN

Description: Gets the chain RMS EVM of pilot subcarriers in all OFDM symbols. This value is expressed as a percentage or in dB.

Return type: Double

:FETch:WLAN:RESults<i>:MODacc:OFDM:CHAI:n:RMS:EVM:MAXimum**Availability:** Query Only**Default:** NaN

Description: Gets the chain RMS EVM of all subcarriers in all OFDM symbols. This value is expressed as a percentage or in dB.

Return type: Double

:FETch:WLAN:RESults<i>:MODacc:OFDM:CHAI:n:RMS:EVM:MEAN**Availability:** Query Only**Default:** NaN

Description: Gets the chain RMS EVM of all subcarriers in all OFDM symbols. This value is expressed as a percentage or in dB.

Return type: Double

:FETch:WLAN:RESults<i>:MODacc:OFDM:CHAI:n:RMS:EVM:MINimum**Availability:** Query Only**Default:** NaN

Description: Gets the chain RMS EVM of all subcarriers in all OFDM symbols. This value is expressed as a percentage or in dB.

Return type: Double

:FETch:WLAN:RESults<i>:MODacc:OFDM:CROSS:POWER:MEAN**Availability:** Query Only**Default:** NaN

Description: Gets the cross power. The cross power for chain x is the power contribution from streams other than stream x in the chain. This value is expressed in dB.

Return type: Double

:FETch:WLAN:RESults<i>:MODacc:OFDM:DATA:POWER:AVG:MEAN**Availability:** Query Only**Default:** NaN

Description: Contains the average power of the data field of the PPDU. When averaging is enabled, this method returns the mean of the data field average power results computed for each averaging count. This value is expressed in dBm.

Return type: Double

:FETch:WLAN:RESults<i>:MODacc:OFDM:DATA:POWer:PEAK:MAXimum**Availability:** Query Only**Default:** NaN

Description: Contains the peak power of the data field of the PPDU. When averaging is enabled, this result returns the maximum of the peak data field power results computed for each averaging count. This value is expressed as a percentage or in dB.

Return type: Double

:FETch:WLAN:RESults<i>:MODacc:OFDM:FECCoding:TYPE**Availability:** Query Only**Default:** BCC

Description: Gets the type of forward error correction (FEC) coding used.

Return type: BCC | LDPC

:FETch:WLAN:RESults<i>:MODacc:OFDM:FERRor:CCDF:PERCents10**Availability:** Query Only**Default:** NaN

Description: Fetches the frequency error CCDF 10% result.

Return type: Double

:FETch:WLAN:RESults<i>:MODacc:OFDM:FERRor:MAXimum**Availability:** Query Only**Default:** NaN

Description: Gets the carrier frequency error of the transmitter. This value is expressed in Hz.

Return type: Double

:FETch:WLAN:RESults<i>:MODacc:OFDM:FERRor:MEAN**Availability:** Query Only**Default:** NaN

Description: Contains the carrier frequency error of the transmitter. This value is expressed in Hz. When averaging is enabled, this result returns the mean of the carrier frequency error results computed for each averaging count.

Return type: Double

:FETch:WLAN:RESults<i>:MODacc:OFDM:FERRor:MINimum**Availability:** Query Only**Default:** NaN

Description: Gets the carrier frequency error of the transmitter. This value is expressed in Hz.

Return type: Double

:FETch:WLAN:RESults<i>:MODacc:OFDM:HE:LTF:POWer:AVG:MEAN**Availability:** Query Only**Default:** NaN

Description: Contains the average power of the HE-LTF field. When averaging is enabled, this parameter returns the mean of the HE-LTF average power results computed for each averaging count. This value is expressed in dBm.

Return type: Double

:FETch:WLAN:RESults<i>:MODacc:OFDM:HE:LTF:POWer:PEAK:MAXimum**Availability:** Query Only**Default:** NaN

Description: Contains the peak power of the HE-LTF field. When averaging is enabled, this parameter returns the maximum of the HE-LTF peak power results computed for each averaging count. This value is expressed in dBm.

Return type: Double

:FETch:WLAN:RESults<i>:MODacc:OFDM:HE:SIGa:POWer:AVG:MEAN**Availability:** Query Only**Default:** NaN

Description: Contains the average power of the HE-SIG-A field. When averaging is enabled, this parameter returns the mean of the HE-SIG-A field average power results computed for each averaging count. This value is expressed in dBm.

Return type: Double

:FETch:WLAN:RESults<i>:MODacc:OFDM:HE:SIGa:POWer:PEAK:MAXimum**Availability:** Query Only**Default:** NaN

Description: Contains the peak power of the HE-SIG-A field. When averaging is enabled, this parameter returns the maximum of the HE-SIG-A field peak power results computed for each averaging count. This value is expressed in dBm.

Return type: Double

:FETch:WLAN:RESults<i>:MODacc:OFDM:HE:SIGb:POWer:AVG:MEAN**Availability:** Query Only**Default:** NaN

Description: Contains the average power of the HE-SIG-B field. When averaging is enabled, this parameter returns the mean of the HE-SIG-B field average power results computed for each averaging count. This value is expressed in dBm.

Return type: Double

:FETch:WLAN:RESults<i>:MODacc:OFDM:HE:SIGb:POWer:PEAK:MAXimum**Availability:** Query Only**Default:** NaN

Description: Contains the peak power of the HE-SIG-B field. When averaging is enabled, this parameter returns the maximum of the HE-SIG-B field peak power results computed for each averaging count. This value is expressed in dBm.

Return type: Double

:FETch:WLAN:RESults<i>:MODacc:OFDM:HE:SIGb:SYMBols:NUMBER**Availability:** Query Only**Default:** 0

Description: Fetches the number of HE-SIG-B symbols.

Return type: Int32

:FETch:WLAN:RESults<i>:MODacc:OFDM:HE:STF:POWer:AVG:MEAN**Availability:** Query Only**Default:** NaN

Description: Contains the average power of the HE-STF field. When averaging is enabled, this parameter returns the mean of the HE-STF average power results computed for each averaging count. This value is expressed in dBm.

Return type: Double

:FETch:WLAN:RESults<i>:MODacc:OFDM:HE:STF:POWer:PEAK:MAXimum**Availability:** Query Only**Default:** NaN

Description: Contains the peak power of the HE-STF field. When averaging is enabled, this parameter returns the maximum of the HE-STF peak power results computed for each averaging count. This value is expressed in dBm.

Return type: Double

:FETch:WLAN:RESults<i>:MODacc:OFDM:HT:DLTF:POWer:AVG:MEAN**Availability:** Query Only**Default:** NaN

Description: Contains the average power of the HT-DLTF. When averaging is enabled, this parameter returns the mean of the HT-DLTF average power results computed for each averaging count. This value is expressed in dBm.

Return type: Double

:FETch:WLAN:RESults<i>:MODacc:OFDM:HT:DLTF:POWer:PEAK:MAXimum**Availability:** Query Only**Default:** NaN

Description: Contains the peak power of the HT-DLTF field. When averaging is enabled, this parameter returns the maximum of the HT-DLTF peak power results computed for each averaging count. This value is expressed in dBm.

Return type: Double

:FETch:WLAN:RESults<i>:MODacc:OFDM:HT:ELTF:POWer:AVG:MEAN**Availability:** Query Only**Default:** NaN

Description: Contains the average power of the HT-ELTF field. When averaging is enabled, this parameter returns the mean of the HT-ELTF average power results computed for each averaging count. This value is expressed in dBm.

Return type: Double

:FETch:WLAN:RESults<i>:MODacc:OFDM:HT:ELTF:POWer:PEAK:MAXimum**Availability:** Query Only**Default:** NaN

Description: Contains the peak power of the HT-ELTF field. When averaging is enabled, this parameter returns the maximum of the HT-ELTF peak power results computed for each averaging count. This value is expressed in dBm.

Return type: Double

:FETch:WLAN:RESults<i>:MODacc:OFDM:HT:SIG:POWer:AVG:MEAN**Availability:** Query Only**Default:** NaN

Description: Contains the average power of the HT-SIG field. When averaging is enabled, this parameter returns the mean of the HT-SIG field average power results computed for each averaging count. This value is expressed in dBm.

Return type: Double

:FETch:WLAN:RESults<i>:MODacc:OFDM:HT:SIG:POWer:PEAK:MAXimum**Availability:** Query Only**Default:** NaN

Description: Contains the peak power of the HT-SIG field. When averaging is enabled, this parameter returns the maximum of the HT-SIG field peak power results computed for each averaging count. This value is expressed in dBm.

Return type: Double

:FETch:WLAN:RESults<i>:MODacc:OFDM:HT:STF:POWer:AVG:MEAN**Availability:** Query Only**Default:** NaN

Description: Contains the average power of the HT-STF field. When averaging is enabled, this parameter returns the mean of the HT-STF average power results computed for each averaging count. This value is expressed in dBm.

Return type: Double

:FETch:WLAN:RESults<i>:MODacc:OFDM:HT:STF:POWer:PEAK:MAXimum**Availability:** Query Only**Default:** NaN

Description: Contains the peak power of the HT-STF field. When averaging is enabled, this parameter returns the maximum of the HT-STF peak power results computed for each averaging count. This value is expressed in dBm.

Return type: Double

:FETch:WLAN:RESults<i>:MODacc:OFDM:INTerval:GUARd:TYPE**Availability:** Query Only**Default:** OneByFour

Description: Fetches the guard interval type.

Return type: OneByFour | OneByEight | OneBySixteen

:FETch:WLAN:RESults<i>:MODacc:OFDM:IQ:GAIN:IMBalance:MAXimum**Availability:** Query Only**Default:** NaN

Description: Gets the I/Q gain imbalance maximum. This value is expressed in dB.

Return type: Double

:FETch:WLAN:RESults<i>:MODacc:OFDM:IQ:GAIN:IMBalance:MEAN**Availability:** Query Only**Default:** NaN

Description: Contains the I/Q gain imbalance results. This value is expressed in dB. I/Q gain imbalance is the ratio of the mean amplitude of the in-phase (I) signal to the mean amplitude of the quadrature-phase (Q) signal. When user sets the DSSSMoAcc Averaging Enabled method to True, this parameter returns the mean of the I/Q gain imbalance results computed for each averaging count.

Return type: Double

:FETch:WLAN:RESults<i>:MODacc:OFDM:IQ:GAIN:IMBalance:MINimum**Availability:** Query Only**Default:** NaN**Description:** Gets the I/Q gain imbalance Minimum. This value is expressed in dB.**Return type:** Double

:FETch:WLAN:RESults<i>:MODacc:OFDM:IQ:ORIGin:OFFSer:RELative:MEAN**Availability:** Query Only**Default:** NaN**Description:** Contains the relative I/Q origin offset, which is the ratio of the power of the DC subcarrier to the total power of all the subcarriers. When averaging is enabled, this method returns the mean of the relative I/Q origin offset computed for each averaging count. This value is expressed in dB.**Return type:** Double

:FETch:WLAN:RESults<i>:MODacc:OFDM:IQ:ORIGin:OFFSet:ABSolute:MEAN**Availability:** Query Only**Default:** NaN**Description:** Contains the absolute I/Q origin offset, which is the power of the DC subcarrier. When averaging is enabled, this method returns the mean of the absolute I/Q origin offset computed for each averaging count. This value is expressed in dBm.**Return type:** Double

:FETch:WLAN:RESults<i>:MODacc:OFDM:IQ:QERRor:MAXimum**Availability:** Query Only**Default:** NaN**Description:** Gets the I/Q quadrature error maximum. This value is expressed in dB.**Return type:** Double

:FETch:WLAN:RESults<i>:MODacc:OFDM:IQ:QERRor:MEAN**Availability:** Query Only**Default:** NaN**Description:** Contains the peak EVM results of the burst. This value is expressed as a percentage or in dB. This measurement is performed in accordance with section 18.4.7.8 of IEEE Standard 802.11b-1999. When averaging is enabled, this result returns the maximum of the peak EVM computed for each averaging count.**Return type:** Double

:FETch:WLAN:RESults<i>:MODacc:OFDM:IQ:QERRor:MINimum**Availability:** Query Only**Default:** NaN**Description:** Gets the I/Q quadrature error minimum. This value is expressed in dB.**Return type:** Double

:FETch:WLAN:RESults<i>:MODacc:OFDM:IQ:TIMing:SKEW:MEAN**Availability:** Query Only**Default:** NaN**Description:** Contains the I/Q timing skew, which is the difference between the group delay of the in-phase (I) and quadrature (Q) components of the signal. When averaging is enabled, this method returns the mean of the I/Q timing skew computed for each averaging count. This value is expressed in seconds.**Return type:** Double

:FETch:WLAN:RESults<i>:MODacc:OFDM:L:LTF:POWer:AVG:MEAN**Availability:** Query Only**Default:** NaN

Description: Contains the average power of the L-LTF or LTF field. When averaging is enabled, this parameter returns the mean of the L-LTF or LTF average power results computed for each averaging count. This value is expressed in dBm.

Return type: Double

:FETch:WLAN:RESults<i>:MODacc:OFDM:L:LTF:POWer:PEAK:MAXimum**Availability:** Query Only**Default:** NaN

Description: Contains the peak power of the L-LTF or LTF field. When averaging is enabled, this parameter returns the maximum of the L-LTF or LTF peak power results computed for each averaging count. This value is expressed in dBm.

Return type: Double

:FETch:WLAN:RESults<i>:MODacc:OFDM:L:SIG:POWer:AVG:MEAN**Availability:** Query Only**Default:** NaN

Description: Contains the average power of the L-SIG or SIGNAL field. When averaging is enabled, this parameter returns the mean of the L-SIG or SIGNAL field average power results computed for each averaging count. This value is expressed in dBm.

Return type: Double

:FETch:WLAN:RESults<i>:MODacc:OFDM:L:SIG:POWer:PEAK:MAXimum**Availability:** Query Only**Default:** NaN

Description: Contains the peak power of the L-SIG or SIGNAL field. When averaging is enabled, this parameter returns the maximum of the L-SIG or SIGNAL field peak power results computed for each averaging count. This value is expressed in dBm.

Return type: Double

:FETch:WLAN:RESults<i>:MODacc:OFDM:L:STF:POWer:AVG:MEAN**Availability:** Query Only**Default:** NaN

Description: Contains the average power of the L-STF or STF field. When averaging is enabled, this parameter returns the mean of the L-STF or STF average power results computed for each averaging count. This value is expressed in dBm.

Return type: Double

:FETch:WLAN:RESults<i>:MODacc:OFDM:L:STF:POWer:PEAK:MAXimum**Availability:** Query Only**Default:** NaN

Description: Contains the peak power of the L-STF or STF field. When averaging is enabled, this parameter returns the maximum of the L-STF or STF peak power results computed for each averaging count. This value is expressed in dBm.

Return type: Double

:FETch:WLAN:REsults<i>:MODacc:OFDM:MODacc:OFDM:DECodEd:EHTSig:BITS:TRACe<i>		
	Availability: Query Only	Default: N/A
Description:	Fetches the decoded Eht-Sig bits trace.	
Return type:	Int32	
:FETch:WLAN:REsults<i>:MODacc:OFDM:MODacc:OFDM:DECodEd:LSIG:BITS:TRACe<i>		
	Availability: Query Only	Default: N/A
Description:	Fetches the decoded L-Sig bits trace.	
Return type:	Int32	
:FETch:WLAN:REsults<i>:MODacc:OFDM:MODacc:OFDM:DECodEd:PSDU:BITS:TRACe<i>		
	Availability: Query Only	Default: N/A
Description:	Fetches the decoded PLCP service data unit (PSDU) bits.	
Return type:	Int32	
:FETch:WLAN:REsults<i>:MODacc:OFDM:MODacc:OFDM:DECodEd:SERVice:BITS:TRACe<i>		
	Availability: Query Only	Default: N/A
Description:	Fetches the decoded Service bits.	
Return type:	Int32	
:FETch:WLAN:REsults<i>:MODacc:OFDM:MODacc:OFDM:DECodEd:SIG:BITS:TRACe<i>		
	Availability: Query Only	Default: N/A
Description:	Fetches the decoded Sig bits trace.	
Return type:	Int32	
:FETch:WLAN:REsults<i>:MODacc:OFDM:MODacc:OFDM:DECodEd:SIGB:BITS:TRACe<i>		
	Availability: Query Only	Default: N/A
Description:	Fetches the decoded Sig-B bits trace.	
Return type:	Int32	
:FETch:WLAN:REsults<i>:MODacc:OFDM:MODacc:OFDM:DECodEd:USIG:BITS:TRACe<i>		
	Availability: Query Only	Default: N/A
Description:	Fetches the decoded U-Sig bits trace.	
Return type:	Int32	
:FETch:WLAN:REsults<i>:MODacc:OFDM:MSC:INDEx		
	Availability: Query Only	Default: 0
Description:	Fetches the MCS index.	
Return type:	Int32	
:FETch:WLAN:REsults<i>:MODacc:OFDM:PE:DURation		
	Availability: Query Only	Default: NaN
Description:	Fetches the duration of the packet extension field.	
Return type:	Double	

:FETch:WLAN:RESults<i>:MODacc:OFDM:PE:POWer:AVG:MEAN**Availability:** Query Only**Default:** NaN**Description:** Fetches the average power of the packet extension field.**Return type:** Double

:FETch:WLAN:RESults<i>:MODacc:OFDM:PE:POWer:POWer:MAXimum**Availability:** Query Only**Default:** NaN**Description:** Fetches the peak power of the packet extension field.**Return type:** Double

:FETch:WLAN:RESults<i>:MODacc:OFDM:PPDU:POWer:AVG:MEAN**Availability:** Query Only**Default:** NaN**Description:** Contains the average power of the PPDU. When averaging is enabled, this parameter returns the mean of the average PPDU power results computed for each averaging count. This value is expressed in dBm.**Return type:** Double

:FETch:WLAN:RESults<i>:MODacc:OFDM:PPDU:POWer:POWer:MAXimum**Availability:** Query Only**Default:** NaN**Description:** Contains the peak power of the PPDU. When averaging is enabled, this parameter returns the maximum of the peak PPDU power results computed for each averaging count. This value is expressed as a percentage or in dB.**Return type:** Double

:FETch:WLAN:RESults<i>:MODacc:OFDM:PSDU:CRC:STATus**Availability:** Query Only**Default:** FAIL**Description:** Indicates whether the cyclic redundancy check (CRC) of the received decoded PLCP service data unit (PSDU) has passed.**Return type:** FAIL | PASS

:FETch:WLAN:RESults<i>:MODacc:OFDM:RELative:IQ:ORIGin:OFFSet:MAXimum**Availability:** Query Only**Default:** NaN**Description:** Gets the relative I/Q origin offset, which is the ratio of the power of the DC subcarrier to the total power of all the subcarriers. This value is expressed in dB.**Return type:** Double

:FETch:WLAN:RESults<i>:MODacc:OFDM:RELative:IQ:ORIGin:OFFSet:MINimum**Availability:** Query Only**Default:** NaN**Description:** Gets the relative I/Q origin offset, which is the ratio of the power of the DC subcarrier to the total power of all the subcarriers. This value is expressed in dB.**Return type:** Double

:FETch:WLAN:RESults<i>:MODacc:OFDM:RI:SIG:POWer:AVG:MEAN**Availability:** Query Only**Default:** NaN

Description: Contains the average power of the RL-SIG field. When averaging is enabled, this parameter returns the mean of the RL-SIG field average power results computed for each averaging count. This value is expressed in dBm.

Return type: Double

:FETch:WLAN:RESults<i>:MODacc:OFDM:RI:SIG:POWer:PEAK:MAXimum**Availability:** Query Only**Default:** NaN

Description: Contains the peak power of the RL-SIG field. When averaging is enabled, this parameter returns the maximum of the RL-SIG field peak power results computed for each averaging count. This value is expressed in dBm.

Return type: Double

:FETch:WLAN:RESults<i>:MODacc:OFDM:RMS:COMMon:PERRor:MEAN**Availability:** Query Only**Default:** NaN

Description: Contains the RMS common phase error.

Return type: Double

:FETch:WLAN:RESults<i>:MODacc:OFDM:RMS:EVM:CHAI:n:DATA:MEAN**Availability:** Query Only**Default:** NaN

Description: Contains the Data Rms Evm results.

Return type: Double

:FETch:WLAN:RESults<i>:MODacc:OFDM:RMS:EVM:CHAI:n:MEAN**Availability:** Query Only**Default:** NaN

Description: Contains the Chain Rms Evm results.

Return type: Double

:FETch:WLAN:RESults<i>:MODacc:OFDM:RMS:EVM:CHAI:n:PILOt:MEAN**Availability:** Query Only**Default:** NaN

Description: Contains the Pilot Rms Evm results.

Return type: Double

:FETch:WLAN:RESults<i>:MODacc:OFDM:RMS:EVM:COMPosite:DATA:MEAN**Availability:** Query Only**Default:** NaN

Description: Contains the RMS EVM of data-subcarriers in all OFDM symbols. This value is expressed as a percentage or in dB.

Return type: Double

:FETch:WLAN:RESults<i>:MODacc:OFDM:RMS:EVM:COMPosite:MEAN**Availability:** Query Only**Default:** NaN

Description: Contains the RMS EVM of all subcarriers in all OFDM symbols. This value is expressed as a percentage or in dB.

Return type: Double

:FETch:WLAN:RESults<i>:MODacc:OFDM:RMS:EVM:COMPOSITE:PILOT:MEAN**Availability:** Query Only**Default:** NaN

Description: Contains the RMS EVM of pilot-subcarriers in all OFDM symbols. This value is expressed as a percentage or in dB.

Return type: Double

:FETch:WLAN:RESults<i>:MODacc:OFDM:RMS:EVM:STREAM:DATA:MEAN**Availability:** Query Only**Default:** NaN

Description: Contains the Stream Data Rms Evm results.

Return type: Double

:FETch:WLAN:RESults<i>:MODacc:OFDM:RMS:EVM:STREAM:MEAN**Availability:** Query Only**Default:** NaN

Description: Contains the Stream Rms Evm results.

Return type: Double

:FETch:WLAN:RESults<i>:MODacc:OFDM:RMS:EVM:STREAM:PILOT:MEAN**Availability:** Query Only**Default:** NaN

Description: Contains the Stream Pilot Rms Evm results.

Return type: Double

:FETch:WLAN:RESults<i>:MODacc:OFDM:RMS:EVM:STREAM:USER:DATA:MEAN**Availability:** Query Only**Default:** NaN

Description: Contains the RMS EVM of data-subcarriers in all OFDM symbols for the specified user. This value is expressed as a percentage or in dB.

Return type: Double

:FETch:WLAN:RESults<i>:MODacc:OFDM:RMS:EVM:STREAM:USER:MEAN**Availability:** Query Only**Default:** NaN

Description: Contains the RMS EVM of all subcarriers in all OFDM symbols for the specified user. This value is expressed as a percentage or in dB.

Return type: Double

:FETch:WLAN:RESults<i>:MODacc:OFDM:RMS:EVM:STREAM:USER:PILOT:MEAN**Availability:** Query Only**Default:** NaN

Description: Contains the RMS EVM of pilot-subcarriers in all OFDM symbols for the specified user. This value is expressed as a percentage or in dB.

Return type: Double

:FETch:WLAN:RESults<i>:MODacc:OFDM:RU:OFFSET**Availability:** Query Only**Default:** 0

Description: Contains the location of RU for a user in terms of the index of a 26-tone RU, assuming the entire bandwidth is composed of 26-tone RUs.

Return type: Int32

:FETch:WLAN:RESults<i>:MODacc:OFDM:RU:SIZE**Availability:** Query Only**Default:** 0**Description:** Contains the RU size for a user**Return type:** Int32

:FETch:WLAN:RESults<i>:MODacc:OFDM:SPACE:TIME:STReams:NUMBer**Availability:** Query Only**Default:** 0**Description:** Fetches the number of space time streams.**Return type:** Int32

:FETch:WLAN:RESults<i>:MODacc:OFDM:SPECTral:FLATness:MARGIn**Availability:** Query Only**Default:** NaN

Description: Contains the spectral flatness margin, which is the minimum of the upper and lower spectral flatness margins. The upper spectral flatness margin is the minimum difference between the upper mask and the spectral flatness across subcarriers. The lower spectral flatness margin is the minimum difference between the spectral flatness and the lower mask across subcarriers. When averaging is enabled, the spectral flatness is computed using the mean of the channel frequency response magnitude computed for each averaging count. This value is expressed in dB.

Return type: Double

:FETch:WLAN:RESults<i>:MODacc:OFDM:SPECTral:FLATness:MARGIn:SCARrier:INDEX**Availability:** Query Only**Default:** 0

Description: Contains the subcarrier index corresponding to the spectralFlatnessMargin parameter.

Return type: Int32

:FETch:WLAN:RESults<i>:MODacc:OFDM:SPECTral:FMARgin1:MAXimum**Availability:** Query Only**Default:** NaN

Description: Gets the spectral flatness margin, which is the minimum of the upper and lower spectral flatness margins. This value is expressed in dB.

Return type: Double

:FETch:WLAN:RESults<i>:MODacc:OFDM:SPECTral:FMARgin1:MINimum**Availability:** Query Only**Default:** NaN

Description: Gets the spectral flatness margin, which is the minimum of the upper and lower spectral flatness margins. This value is expressed in dB.

Return type: Double

:FETch:WLAN:RESults<i>:MODacc:OFDM:STReam:DATA:RMS:EVM:MEAN**Availability:** Query Only**Default:** NaN

Description: Gets the stream RMS EVM of data subcarriers in all OFDM symbols. This value is expressed as a percentage or in dB.

Return type: Double

:FETch:WLAN:RESults<i>:MODacc:OFDM:STReam:PILot:RMS:EVM:MEAN**Availability:** Query Only**Default:** NaN

Description: Gets the stream RMS EVM of pilot subcarriers in all OFDM symbols. This value is expressed as a percentage or in dB.

Return type: Double

:FETch:WLAN:RESults<i>:MODacc:OFDM:STReam:RMS:EVM:MAXimum**Availability:** Query Only**Default:** NaN

Description: Gets the stream RMS EVM of all subcarriers in all OFDM symbols. This value is expressed as a percentage or in dB.

Return type: Double

:FETch:WLAN:RESults<i>:MODacc:OFDM:STReam:RMS:EVM:MEAN**Availability:** Query Only**Default:** NaN

Description: Gets the stream RMS EVM of all subcarriers in all OFDM symbols. This value is expressed as a percentage or in dB.

Return type: Double

:FETch:WLAN:RESults<i>:MODacc:OFDM:STReam:RMS:EVM:MINimum**Availability:** Query Only**Default:** NaN

Description: Gets the stream RMS EVM of all subcarriers in all OFDM symbols. This value is expressed as a percentage or in dB.

Return type: Double

:FETch:WLAN:RESults<i>:MODacc:OFDM:SYMBol:CERRor:MAXimum**Availability:** Query Only**Default:** NaN

Description: Gets the symbol clock error maximum of the transmitter.

Return type: Double

:FETch:WLAN:RESults<i>:MODacc:OFDM:SYMBol:CERRor:MEAN**Availability:** Query Only**Default:** NaN

Description: Fetches the symbol clock error of the transmitter.

Return type: Double

:FETch:WLAN:RESults<i>:MODacc:OFDM:SYMBol:CERRor:MINimum**Availability:** Query Only**Default:** NaN

Description: Gets the symbol clock error minimum of the transmitter.

Return type: Double

:FETch:WLAN:RESults<i>:MODacc:OFDM:SYMBol:NUMBER**Availability:** Query Only**Default:** 0

Description: Fetches the number of OFDM symbols used for EVM measurement.

Return type: Int32

:FETch:WLAN:RESults<i>:MODacc:OFDM:USER:POWER:MAXimum**Availability:** Query Only**Default:** NaN

Description: Gets the user power. User power is the frequency domain power measured over subcarriers occupied by a given user. This value is expressed in dBm.

Return type: Double

:FETch:WLAN:RESults<i>:MODacc:OFDM:USER:POWER:MEAN**Availability:** Query Only**Default:** NaN

Description: Gets the user power. User power is the frequency domain power measured over subcarriers occupied by a given user. This value is expressed in dBm.

Return type: Double

:FETch:WLAN:RESults<i>:MODacc:OFDM:USER:POWER:MINimum**Availability:** Query Only**Default:** NaN

Description: Gets the user power. User power is the frequency domain power measured over subcarriers occupied by a given user. This value is expressed in dBm.

Return type: Double

:FETch:WLAN:RESults<i>:MODacc:OFDM:USER:STReam:RMS:EVM:MAXimum**Availability:** Query Only**Default:** NaN

Description: Gets the RMS EVM of all subcarriers in all OFDM symbols for the specified user. This value is expressed as a percentage or in dB.

Return type: Double

:FETch:WLAN:RESults<i>:MODacc:OFDM:USER:STReam:RMS:EVM:MINimum**Availability:** Query Only**Default:** NaN

Description: Gets the RMS EVM of all subcarriers in all OFDM symbols for the specified user. This value is expressed as a percentage or in dB.

Return type: Double

:FETch:WLAN:RESults<i>:MODacc:OFDM:USERS:NUMBER**Availability:** Query Only**Default:** 0

Description: Fetches the number of users.

Return type: Int32

:FETch:WLAN:RESults<i>:MODacc:OFDM:UTONe:ERROR:MARGIN**Availability:** Query Only**Default:** NaN

Description: Contains the unused tone error margin, which is the minimum difference between the unused tone error mask and the unused tone error across 26-tone RUs. This value is expressed in dB.

Return type: Double

:FETch:WLAN:RESults<i>:MODacc:OFDM:UTONe:ERROR:MARGIN:RU:INDEX**Availability:** Query Only**Default:** 0

Description: Contains the 26-tone RU index corresponding to the unusedToneErrorMargin parameter.

Return type: Int32

:FETch:WLAN:RESults<i>:MODacc:OFDM:VHT:LTF:POWer:AVG:MEAN**Availability:** Query Only**Default:** NaN

Description: Contains the average power of the VHT-LTF field. When averaging is enabled, this parameter returns the mean of the VHT-LTF average power results computed for each averaging count. This value is expressed in dBm.

Return type: Double

:FETch:WLAN:RESults<i>:MODacc:OFDM:VHT:LTF:POWer:PEAK:MAXimum**Availability:** Query Only**Default:** NaN

Description: Contains the peak power of the VHT-LTF field. When averaging is enabled, this parameter returns the maximum of the VHT-LTF peak power results computed for each averaging count. This value is expressed in dBm.

Return type: Double

:FETch:WLAN:RESults<i>:MODacc:OFDM:VHT:SIGa:POWer:AVG:MEAN**Availability:** Query Only**Default:** NaN

Description: Contains the average power of the VHT-SIG-A field. When averaging is enabled, this parameter returns the mean of the VHT-SIG-A field average power results computed for each averaging count. This value is expressed in dBm.

Return type: Double

:FETch:WLAN:RESults<i>:MODacc:OFDM:VHT:SIGa:POWer:PEAK:MAXimum**Availability:** Query Only**Default:** NaN

Description: Contains the peak power of the VHT-SIG-A field. When averaging is enabled, this method returns the maximum of the VHT-SIG-A field peak power results computed for each averaging count. This value is expressed in dBm.

Return type: Double

:FETch:WLAN:RESults<i>:MODacc:OFDM:VHT:SIGb:POWer:AVG:MEAN**Availability:** Query Only**Default:** NaN

Description: Contains the average power of the VHT-SIG-B field. When averaging is enabled, this parameter returns the mean of the VHT-SIG-B field average power results computed for each averaging count. This value is expressed in dBm.

Return type: Double

:FETch:WLAN:RESults<i>:MODacc:OFDM:VHT:SIGb:POWer:PEAK:MAXimum**Availability:** Query Only**Default:** NaN

Description: Contains the peak power of the VHT-SIG-B field. When averaging is enabled, this parameter returns the maximum of the VHT-SIG-B field peak power results computed for each averaging count. This value is expressed in dBm.

Return type: Double

:FETch:WLAN:RESults<i>:MODacc:OFDM:VHT:STF:POWer:AVG:MEAN**Availability:** Query Only**Default:** NaN

Description: Contains the average power of the VHT-STF field. When averaging is enabled, this parameter returns the mean of the VHT-STF average power results computed for each averaging count. This value is expressed in dBm.

Return type: Double

:FETch:WLAN:RESults<i>:MODacc:OFDM:VHT:STF:POWer:PEAK:MAXimum**Availability:** Query Only**Default:** NaN

Description: Contains the peak power of the VHT-STF field. When averaging is enabled, this parameter returns the maximum of the VHT-STF peak power results computed for each averaging count. This value is expressed in dBm.

Return type: Double

:FETch:WLAN:RESults<i>:SEM:ALL**Availability:** Query Only**Default:** N/A

Description: Returns all results for Sem measurement.

Return type: String

:FETch:WLAN:RESults<i>:SEM:CCARrier<i>**Availability:** Query Only**Default:** N/A

Description: Contains the results of the carrier measurements.

Return type: SemCarrierMeasurementResults

:FETch:WLAN:RESults<i>:SEM:CCARrier<i>:FREQuency:PEAK**Availability:** Query Only**Default:** NaN

Description: Peak frequency in Hz.

Return type: Double

:FETch:WLAN:RESults<i>:SEM:CCARrier<i>:IPOWER:ABSolute**Availability:** Query Only**Default:** NaN

Description: Carrier power values. The carrier power is the integrated power of the RRC-filtered signal. The RRC filter uses a bandwidth of 3.84 MHz with a roll-off factor of 0.22. The carrier is centered at a frequency determined by the Center Frequency and methods. This value is expressed in dBm.

Return type: Double

:FETch:WLAN:RESults<i>:SEM:CCARrier<i>:IPOWER:RELative**Availability:** Query Only**Default:** NaN

Description: Carrier power values relative to the total carrier power of all enabled carriers. This value is expressed in dB.

Return type: Double

:FETch:WLAN:RESults<i>:SEM:CCARrier<i>:POWER:PEAK:ABS**Availability:** Query Only**Default:** N/A

Description: Absolute peak power in dBm.

Return type: Double

:FETch:WLAN:RESults<i>:SEM:MEAS**Availability:** Query Only**Default:** N/A**Description:** Contains the results of the subblock measurements.**Return type:** SubblockMeasurementResults

:FETch:WLAN:RESults<i>:SEM:MEAS:ALL**Availability:** Query Only**Default:** N/A**Description:** Returns string with results for NRModAccCarrier.**Return type:** String

:FETch:WLAN:RESults<i>:SEM:MEAS:FREQuency**Availability:** Query Only**Default:** NaN**Description:** Contains the absolute center frequency of the subblock. This value is the center of the subblock integration bandwidth.**Return type:** Double

:FETch:WLAN:RESults<i>:SEM:MEAS:IBANDwidth**Availability:** Query Only**Default:** NaN**Description:** Contains the integration bandwidth used in calculating the power of the subblock. Integration bandwidth is the span from left edge of the leftmost carrier to the right edge of the rightmost carrier within a subblock.**Return type:** Double

:FETch:WLAN:RESults<i>:SEM:MEAS:POWer**Availability:** Query Only**Default:** NaN**Description:** Contains the sum of powers of all the frequency bins over the integration bandwidth of the subblock.**Return type:** Double

:FETch:WLAN:RESults<i>:SEM:OFFSet:MARGIn**Availability:** Query Only**Default:** N/A**Description:** Builds the offset margin results.**Return type:** [<LowerOffsetMargins>,...], [<UpperOffsetMargins>,...]

:FETch:WLAN:RESults<i>:SEM:OFFSet:MARGIn:LOWer<i>**Availability:** Query Only**Default:** N/A**Description:** Contains the results of the lower offset margin results.**Return type:** <Margin_dB>, <MarginFrequency_Hz>, <MarginAbsolutePower_dBm>, <MarginRelativePower_dB>, <StatusOfMeasurement>

:FETch:WLAN:RESults<i>:SEM:OFFSet:MARGin:LOWer<i>:FREQuency**Availability:** Query Only**Default:** N/A

Description: Contains the array of frequency at which the margin occurs in the lower (negative) offset. For the intra-band noncontiguous type of carrier aggregation, the offset segment may be truncated or discarded based on offset overlap rules as defined in the 3GPP TS 36.521 specification. If the offset segment is truncated, the SEM results lower offset start frequency and SEM results lower offset stop frequency are updated, and the measurement is performed on the updated offset segment. If the offset segment is discarded, a NaN is returned.

Return type: Double

:FETch:WLAN:RESults<i>:SEM:OFFSet:MARGin:LOWer<i>:MARGin**Availability:** Query Only**Default:** N/A

Description: Contains the array of margins from the standard-defined absolute limit mask for the lower (negative) offset. Margin is defined as the minimum difference between the spectrum and the limit mask. For the intra-band noncontiguous type of carrier aggregation, the offset segment may be truncated or discarded based on offset overlap rules as defined in the 3GPP TS 36.521 specification. If the offset segment is truncated, the SEM results lower offset start frequency and SEM results lower offset stop frequency are updated, and the measurement is performed on the updated offset segment. If the offset segment is discarded, a NaN is returned.

Return type: Double

:FETch:WLAN:RESults<i>:SEM:OFFSet:MARGin:LOWer<i>:POWER:ABSolute**Availability:** Query Only**Default:** N/A

Description: Contains the array of power at which the margin occurs in the upper (positive) offset segment. For the intra-band noncontiguous type of carrier aggregation, the offset segment may be truncated or discarded based on offset overlap rules as defined in the 3GPP TS 36.521 specification. If the offset segment is truncated, the SEM results lower offset start frequency and SEM results lower offset stop frequency are updated, and the measurement is performed on the updated offset segment. If the offset segment is discarded, a NaN is returned.

Return type: Double

:FETch:WLAN:RESults<i>:SEM:OFFSet:MARGin:LOWer<i>:POWER:RELative**Availability:** Query Only**Default:** N/A

Description: Contains the array of powers at which the margin occurs in the upper (positive) offset segment relative to the value of TotalAggregatedPower. For the intra-band noncontiguous type of carrier aggregation, the offset segment may be truncated or discarded based on offset overlap rules as defined in the 3GPP TS 36.521 specification. If the offset segment is truncated the measurement is performed on the updated offset segment. If the offset segment is discarded, a NaN is returned.

Return type: Double

:FETch:WLAN:RESults<i>:SEM:OFFSet:MARGin:LOWer<i>:STATus**Availability:** Query Only**Default:** N/A**Description:** Contains the array of the measurement status indicating whether the power before and after the burst is within the standard defined limit.**Return type:** Boolean

:FETch:WLAN:RESults<i>:SEM:OFFSet:MARGin:UPPer<i>**Availability:** Query Only**Default:** N/A**Description:** Contains the results of the upper offset margin.**Return type:** <Margin_dB>, <MarginFrequency_Hz>, <MarginAbsolutePower_dBm>, <MarginRelativePower_dB>, <StatusOfMeasurement>

:FETch:WLAN:RESults<i>:SEM:OFFSet:MARGin:UPPer<i>:FREQuency**Availability:** Query Only**Default:** N/A**Description:** Contains the array of frequency at which the margin occurs in the lower (negative) offset. For the intra-band noncontiguous type of carrier aggregation, the offset segment may be truncated or discarded based on offset overlap rules as defined in the 3GPP TS 36.521 specification. If the offset segment is truncated, the SEM results lower offset start frequency and SEM results lower offset stop frequency are updated, and the measurement is performed on the updated offset segment. If the offset segment is discarded, a NaN is returned.**Return type:** Double

:FETch:WLAN:RESults<i>:SEM:OFFSet:MARGin:UPPer<i>:MARGin**Availability:** Query Only**Default:** N/A**Description:** Contains the array of margins from the standard-defined absolute limit mask for the lower (negative) offset. Margin is defined as the minimum difference between the spectrum and the limit mask. For the intra-band noncontiguous type of carrier aggregation, the offset segment may be truncated or discarded based on offset overlap rules as defined in the 3GPP TS 36.521 specification. If the offset segment is truncated, the SEM results lower offset start frequency and SEM results lower offset stop frequency are updated, and the measurement is performed on the updated offset segment. If the offset segment is discarded, a NaN is returned.**Return type:** Double

:FETch:WLAN:RESults<i>:SEM:OFFSet:MARGin:UPPer<i>:POWER:ABSolute**Availability:** Query Only**Default:** N/A**Description:** Contains the array of power at which the margin occurs in the upper (positive) offset segment. For the intra-band noncontiguous type of carrier aggregation, the offset segment may be truncated or discarded based on offset overlap rules as defined in the 3GPP TS 36.521 specification. If the offset segment is truncated, the SEM results lower offset start frequency and SEM results lower offset stop frequency are updated, and the measurement is performed on the updated offset segment. If the offset segment is discarded, a NaN is returned.**Return type:** Double

:FETch:WLAN:RESults<i>:SEM:OFFSet:MARGin:UPPer<i>:POWER:RELative**Availability:** Query Only**Default:** N/A

Description: Contains the array of powers at which the margin occurs in the upper (positive) offset segment relative to the value of TotalAggregatedPower. For the intra-band noncontiguous type of carrier aggregation, the offset segment may be truncated or discarded based on offset overlap rules as defined in the 3GPP TS 36.521 specification. If the offset segment is truncated the measurement is performed on the updated offset segment. If the offset segment is discarded, a NaN is returned.

Return type: Double

:FETch:WLAN:RESults<i>:SEM:OFFSet:MARGin:UPPer<i>:STATus**Availability:** Query Only**Default:** N/A

Description: Contains the array of the measurement status indicating whether the power before and after the burst is within the standard defined limit.

Return type: Boolean

:FETch:WLAN:RESults<i>:SEM:OFFSet:POWer**Availability:** Query Only**Default:** N/A

Description: Builds the offset power results.

Return type: [<LowerOffsetPowers>,...], [<UpperOffsetPowers>,...]

:FETch:WLAN:RESults<i>:SEM:OFFSet:POWer:LOWer<i>**Availability:** Query Only**Default:** N/A

Description: Contains the results of the lower offset power measurements.

Return type: <PeakFrequency_Hz>, <RelativePeakPower_dBm
AbsolutePeakPower_dBm>, <RelativeIntegratedPower_dBm>,
<AbsoluteIntegratedPower_dBm>

:FETch:WLAN:RESults<i>:SEM:OFFSet:POWer:LOWer<i>:FREQuency**Availability:** Query Only**Default:** N/A

Description: Peak frequency in Hz.

Return type: Double

:FETch:WLAN:RESults<i>:SEM:OFFSet:POWer:LOWer<i>:IPOWER:ABSolute**Availability:** Query Only**Default:** N/A

Description: Contains the array of lower (negative) offset segment powers. For the intra-band noncontiguous type of carrier aggregation, the offset segment may be truncated or discarded based on offset overlap rules as defined in the 3GPP TS 36.521 specification. If the offset segment is truncated the measurement is performed on the updated offset segment. If the offset segment is discarded, a NaN is returned.

Return type: Double

:FETch:WLAN:RESults<i>:SEM:OFFSet:POWer:LOWer<i>:IPOWER:RELative**Availability:** Query Only**Default:** N/A

Description: Carrier power values relative to the total carrier power of all enabled carriers. This value is expressed in dB.

Return type: Double

:FETch:WLAN:RESults<i>:SEM:OFFSet:POWer:LOWer<i>:POWer:ABSolute**Availability:** Query Only**Default:** N/A**Description:** Absolute peak power in dBm.**Return type:** Double

:FETch:WLAN:RESults<i>:SEM:OFFSet:POWer:LOWer<i>:POWer:RELative**Availability:** Query Only**Default:** N/A

Description: Contains the array of peak power in the upper (positive) offset segment relative to the value returned by the SEM Results Total Aggregated Pwr method. For the intra-band noncontiguous type of carrier aggregation, the offset segment may be truncated or discarded based on offset overlap rules as defined in the 3GPP TS 36.521 specification. If the offset segment is truncated the measurement is performed on the updated offset segment. If the offset segment is discarded, a NaN is returned.

Return type: Double

:FETch:WLAN:RESults<i>:SEM:OFFSet:POWer:UPPer<i>**Availability:** Query Only**Default:** N/A**Description:** Contains the results of the upper offset power results.

Return type: <PeakFrequency_Hz>, <RelativePeakPower_dBm
AbsolutePeakPower_dBm>, <RelativeIntegratedPower_dBm>,
<AbsoulteIntegratedPower_dBm>

:FETch:WLAN:RESults<i>:SEM:OFFSet:POWer:UPPer<i>:FREQuency**Availability:** Query Only**Default:** N/A**Description:** Peak frequency in Hz.**Return type:** Double

:FETch:WLAN:RESults<i>:SEM:OFFSet:POWer:UPPer<i>:IPOWER:ABSolute**Availability:** Query Only**Default:** N/A

Description: Contains the array of lower (negative) offset segment powers. For the intra-band noncontiguous type of carrier aggregation, the offset segment may be truncated or discarded based on offset overlap rules as defined in the 3GPP TS 36.521 specification. If the offset segment is truncated the measurement is performed on the updated offset segment. If the offset segment is discarded, a NaN is returned.

Return type: Double

:FETch:WLAN:RESults<i>:SEM:OFFSet:POWer:UPPer<i>:IPOWER:RELative**Availability:** Query Only**Default:** N/A

Description: Carrier power values relative to the total carrier power of all enabled carriers. This value is expressed in dB.

Return type: Double

:FETch:WLAN:RESults<i>:SEM:OFFSet:POWer:UPPer<i>:POWer:ABSolute**Availability:** Query Only**Default:** N/A**Description:** Absolute peak power in dBm.**Return type:** Double

:FETch:WLAN:RESults<i>:SEM:OFFSet:POWer:UPPer<i>:POWer:RELative**Availability:** Query Only**Default:** N/A

Description: Contains the array of peak power in the upper (positive) offset segment relative to the value returned by the SEM Results Total Aggregated Pwr method. For the intra-band noncontiguous type of carrier aggregation, the offset segment may be truncated or discarded based on offset overlap rules as defined in the 3GPP TS 36.521 specification. If the offset segment is truncated the measurement is performed on the updated offset segment. If the offset segment is discarded, a NaN is returned.

Return type: Double

:FETch:WLAN:RESults<i>:SEM:POWer:TOTal**Availability:** Query Only**Default:** NaN

Description: Contains the sum of powers of all the subblocks. This value includes the power in the inter-carrier gaps within a subblock, but it does not include the power in the subblock gaps.

Return type: Double

:FETch:WLAN:RESults<i>:SEM:STATus**Availability:** Query Only**Default:** 0

Description: Contains the measurement status indicating whether the power before and after the burst is within the standard defined limit.

Return type: Boolean

:FETch:WLAN:RESults<i>:TXP:AVG:POWer:MAXimum**Availability:** Query Only**Default:** NaN

Description: Returns the average power maximum in dBm.

Return type: Double

:FETch:WLAN:RESults<i>:TXP:AVG:POWer:MINimum**Availability:** Query Only**Default:** 0

Description: Returns the average power minimum in dBm.

Return type: Double

:FETch:WLAN:RESults<i>:TXP:PAPR**Availability:** Query Only**Default:** NaN

Description: Returns the peak to average ratio considering the results in dB.

Return type: Double

:FETch:WLAN:RESults<i>:TXP:PEAK:POWer:MEAN**Availability:** Query Only**Default:** NaN

Description: Returns the peak power mean in dBm.

Return type: Double

:FETch:WLAN:RESults<i>:TXP:PEAK:POWer:MINimum**Availability:** Query Only**Default:** NaN

Description: Returns the peak power minimum in dBm.

Return type: Double

:FETch:WLAN:RESults<i>:TXP:POWer:AVG:MEAN**Availability:** Query Only**Default:** NaN

Description: Contains the average power of the acquired signal. This value is expressed in dBm. When averaging is enabled, this parameter returns the mean of the average power computed for each averaging count.

Return type: Double

:FETch:WLAN:RESults<i>:TXP:POWer:MAXimum**Availability:** Query Only**Default:** NaN

Description: Contains the peak power of the acquired signal. This value is expressed in dBm. When averaging is enabled, this parameter returns the maximum of the peak power computed for each averaging count.

Return type: Double

:FETch:WLAN:RESults<i>:TXP:POWer:MINimum**Availability:** Query Only**Default:** NaN

Description: Minimum power of the result.

Return type: Double

:TRIGger:WLAN:DElay <TriggerDelay_sec>**Availability:** Command and Query**Default:** N/A

Description: Specifies the delay (in seconds) between the trigger onset and the start of data acquisition.

Parameters: <TriggerDelay_sec> Double

:TRIGger:WLAN:EDGE <TriggerEdge>**Availability:** Command and Query**Default:** RISING

Description: Specifies whether to trigger on the rising or falling edge for digital or power triggering.

Parameters: <TriggerEdge> RISING | FALLING

:TRIGger:WLAN:MQTime <TriggerMinQuietDuration_sec>**Availability:** Command and Query**Default:** N/A

Description: Specifies the Minimum Quiet Time between triggers. Negative value (e.g. -1) enables automatic duration.

Parameters: <TriggerMinQuietDuration_sec> Double

:TRIGger:WLAN:SOURce <TriggerSource>**Availability:** Command and Query**Default:** IMMEDIATE

Description: Specifies the trigger source.

Parameters: <TriggerSource> IMM | RF0 | VIDEO | GENERATOR | INTERNAL | IMMEDIATE

:TRIGger:WLAN:THReshold <TriggerThreshold>**Availability:** Command and Query**Default:** -20

Description: Specifies the trigger threshold to use when power triggering. Absolute level type is in dBm, relative level type (to reference level) is in dB.

Parameters: <TriggerThreshold> Double

:TRIGger:WLAN:TOUT <TriggerTimeout_sec>

Availability: Command and Query **Default:** 10

Description: Specifies the trigger timeout in seconds.

Parameters: <TriggerTimeout_sec> Double

:WLAN:INITiate <resultSpace>

Availability: Command Only **Default:** N/A

Description: Initiates Wlan analyzer. Starts the measurement.

Parameters: <resultSpace> Int32

:WLAN:MEASurement:STATe

Availability: Query Only **Default:** N/A

Description: Returns the current state of the measurement.

Return type: READY | PROCESSING | OFF | PENDING | ACTIVE

:WLAN:RESet

Availability: Command Only **Default:** N/A

Description: Resets the Wlan analyzer configuratoins.