

SensorSentinel — Telegram Quick Reference

Boat & jetty monitoring · @sensorsentinelchatbot · type  in the chat for this list on your phone

CHECKING ON THINGS

<code>/status</code> <code>[device]</code>	Last reading from each device, with signal and age
<code>/sensors</code> <code>[device]</code>	Every channel and what it reads — named or not
<code>/info</code>	What you own and how it is configured
<code>/help</code>	The command list, in the chat

Only what you own. Every view is scoped to your own devices. With one device you can leave its name out of any command.

WATCHING LIVE

<code>/watch</code> <code>[device]</code> <code>[mins]</code>	Every reading as it arrives, ~1 per 30 s
<code>/unwatch</code> <code>[device]</code>	Stop feeds — all of them, or one

Feeds expire. 30 minutes by default, then they stop by themselves — the catch for when you have walked out of signal. **Stop** on a feed stops that device; **Another 30m** resets it to 30 from now rather than adding.

TAKING ON A DEVICE

<code>/claim</code> <code><code></code> <code>[name]</code>	Make it yours, and name it
<code>/rename</code> <code><code></code> <code><name></code>	Give it a proper name
<code>/release</code> <code><device></code>	Hand it to someone else

The code is on the screen. Press **PRG** on the device and it shows six characters for ten seconds. Claiming works even if the bot has never met you — no email, no invitation. **A claimed device cannot be claimed.** Its owner must `/release` it first, so a code alone can never take a boat off someone.

SETTING UP SENSORS

<code>/sensorname</code> <code><ch></code> <code><name></code>	Name a channel so it appears elsewhere
<code>/sensoralert</code> <code><Dn></code> <code><when></code>	When a switch matters
<code>/limits</code> <code><ch></code> <code><low></code> <code>[high]</code>	Alert outside a range
<code>/limits</code> <code><ch></code> <code>off</code>	Stop it alerting
CHANNEL WHAT IT IS	
bus0–bus7	I ² C sensors — battery monitors and the like
A0–A3	Analog inputs, raw ADC counts
D0–D7	Switch inputs — float switches, contacts

Naming is not arming. A named channel shows up in `/status` and stays silent until you give it a trigger or a limit.

SWITCH TRIGGERS

WORD	ALERTS WHEN
open	the contact opens — resolves when it closes
closed	the contact closes — resolves when it opens
change	either way, neither called an alarm
off	never

1 means open. Inputs read **1** when nothing is pulling them down and **0** when closed to ground — so an unconnected input looks exactly like a switch sitting open. **To find which input something is on:** toggle it, run `/sensors` again, and see which digit moved.

WHERE ALERTS GO

<code>/alerts</code>	Telegram, email, or both
<code>/email</code> <code>on off</code>	Turn email on or off
<code>/mute</code> <code>[2h]</code>	Silence everything, every channel
<code>/unmute</code>	Start telling you again

You cannot leave yourself unreachable. `/email off` is refused while email is the only way to reach you. **A mute with a duration un-mutes itself.** Without one it lasts until you say otherwise — and a muted account hears nothing at all, including a device going offline.

SETTING UP A NEW DEVICE

1. Power it up in range of a jetty gateway. It registers itself.
2. Press **PRG** — note the six characters on the screen.
3. `/claim` 676358 Renko
4. `/sensors` to see what it is reading.
5. `/sensorname` bus0 Boat battery then `/limits` bus0 12000 14500.

Check the units. `/limits` shows the live reading next to the limit you set, and says so if what you typed is already outside the range. A battery reading 12680 in millivolts needs 12000, not 12.

WHAT THE NUMBERS MEAN

SHOWN	MEANING
rssi -34	Signal strength. Closer to zero is stronger; -120 is marginal
snr 14.3	Signal above noise. Higher is better
12s ago	Age of the reading, not the time now
** QUIET **	Nothing heard for a while — treat every figure below it as stale
not alerting	Named, but nothing set to make it speak up

HOW IT REACHES YOU

boat → LoRa → jetty gateway → Tailscale → home
Readings travel **one way only**. The bot cannot ask a device anything, so every view is the most recent message it sent — usually under a minute old, and older if it has gone quiet. That is why the age sits beside the name.

Silence is the normal state. You hear when a reading crosses a limit, and again when it returns to normal. A device that stops reporting raises an alert of its own — a silent sensor otherwise looks identical to one saying all is well.