

Inverter – Battery Compatibility List 01 (Updated to Dec. 2024)

Note: All of the above inverters are not compatible with the Low Voltage Battery Series.
Blue text indicates the number of batteries connectable to a single battery port.

* Heating function available

! Firmware must be updated to the latest version

		X1 HYBRID-G4 (FIT)	X3 HYBRID-G4 (FIT)	X3 HYBRID-G4 LV	X1 HYBRID-G3 (FIT)	X1 AC	X3 ULTRA	X3 HYB-G4 PRO	X1 VAST
High Voltage Battery Series	T45/63	1, 2, 3	2, 3, 4	2, 3, 4	1, 2, 3	1, 2, 3			
	T58 V1 (V1master+V2slave)	1, 2, 3	2, 3, 4	2, 3, 4	1, 2, 3	1, 2, 3	2 – 8 2 – 4	2 – 8 2 – 4	
	T58 (V2, V2.1, V2.2)	1, 2, 3	2, 3, 4	2, 3, 4		1, 2, 3	2 – 8 2 – 4	2 – 8 2 – 4	1 – 6 1 – 3
	T30 V1	1, 2, 3, 4*	2, 3, 4*	2, 3, 4	1, 2, 3	1, 2, 3	2 – 8* 2 – 4	2 – 8* 2 – 4	1 – 8 1 – 4
	T30 V2	1, 2, 3, 4*	2, 3, 4*	2, 3, 4	1, 2, 3	1, 2, 3	2 – 8* 2 – 4	2 – 8* 2 – 4	1 – 8 1 – 4
	HR25	2 – 8	4 – 13	4 – 11			3 – 26 3 – 13		
	HS25	2 – 8*	3 – 13*	3 – 11*			3 – 26* 3 – 13	3 – 26 3 – 13	2 – 16 2 – 8
	HR36	2 – 8	4 – 13	4 – 11			3 – 26 3 – 13		
	HS36	2 – 8*	3 – 13*	3 – 11*			3 – 26* 3 – 13	3 – 26 3 – 13	2 – 16 2 – 8
	HS51						3 – 26* 3 – 13		
	HS50E-D							2 – 12 2 – 6	
	HS50E		2 – 6*						
High Voltage Battery Box Series	Battery Parallel Box (Battery parallel box, only supports T58 V1 slave battery only)	1,2,3/2,4,6 !	2,3,4/4,6,8 !	2,3,4/4,6,8 !					
	Battery Parallel Box V2 (Battery parallel box, only supports T58 V1&V2 slave battery)	1,2,3/2,4,6	2,3,4/4,6,8	2,3,4/4,6,8					
	Battery Parallel Box G2 (Battery parallel box, supports T58 V1&V2)	2,4,6	4,6,8	4,6,8			4,6,8		
	Battery Parallel Box G2 (Battery parallel box, supports T30)	2,4,6,8*	4,6,8*	4,6,8*			4,6,8		
	TCBox-70 (Battery Combiner Box, supports HS25/36/51)						3~39 3-13 (single cluster, up to three clusters)		
	TCBox-70 (Battery Combiner Box, supports HS50E-D)								

Inverter – Battery Compatibility List 02 (Updated to Dec. 2024)

Note: Blue text indicates the number of batteries connectable to a single battery port.

		A1 HYBRID-G2 (FIT)	A1 HYBRID-G1 (FIT)	J1 ESS 3.0	J1 ESS 5.9	J3-ULTRA	J1ESS-HB-2	X1-SPT 3.0 X1-SPT 3.6	X1-SPT 6.0 X1-SPT 7.0
High Voltage Battery Series	T45/63		1, 2, 3						
	T58 V1 (V1master+V2slave)		1, 2, 3	1, 2	1, 2, 3			1, 2	1, 2, 3
	T58 (V2、V2.1、V2.2)							1, 2	1, 2, 3
	T30 V1				2, 3, 4				
	T30 V2								
	HR25					3-16 3-8			
	HS25					3-16 3-8			
	HR36					3-16 3-8			
	HS36					3-16 3-8			2-7
	T50	2, 3, 4							
	HS51					3-16 3-8			
	HS50E-D								
	HS50E								
	HS50J-D								

Inverter – Battery Compatibility List 03 (Updated to Dec. 2024)

	X3-IES X3-IES-A	X1-IES X1-IES-A	X3 IES-P	X1-HYB -3-6-LV	X1-Lite -8-12-LV	X3-NEO -5-15K-LV
HS50E	2 – 6	1 – 4	2 – 6			
LR25					1 – 16	
LR36				1 – 16	1 – 16	
LD53				1 – 16	1 – 16	1 – 16
LD150						1 – 16