

The battery is not working - load power is low

Author: 胡维
Reviewer: Eason

FAQ\ Hybrid INV

Issue introduction

No battery output when the loads are working with low power

Confirmation of basic information

[Photo] SN numbers of inverters.

[Photo] 'HotStandby Set' function should be disabled.

Guidance for installer

Step1: Set HotStandby Disable.

Settings path: *Setting→Advanced setting→HotStandby Setting*

HotStandby Setting

HotStandby Setting

Disable

Save

Information check list

If you have completed the above <Guidance for installer>, and the problem is still not solved, please collect the following troubleshooting information and send them to the R&D.

1.[Photo] SN number of the inverter, which should clearly display the registration number.



2.[Photo] 'HotStandby Set' function should be disabled.