

Operating Mode of X1-Hybrid-LV Without Battery



1. X1-Hybrid-LV Operating Mode Without Battery

When no battery is connected, the X1-Hybrid-LV will operate as a traditional string inverter. In this mode, the inverter no longer involves battery storage functions and instead directly outputs the power generated by the photovoltaic system to the load or the grid.

It is important to note that, in the configuration without a battery, the selection of modes such as sub mode has no practical significance. These modes are based on energy storage functions, and since the system without a battery cannot perform energy storage management, these modes will not be functional.

2. System Settings

In the absence of a battery, functions such as sub mode cannot be enabled, so the system settings for grid export will be adjusted according to different requirements:

2.1 Grid Export Settings

If you wish to feed the power generated by the photovoltaic system into the grid, it is recommended to set the export power to 100% to ensure maximum power output.

System ON/OFF	▼
Work Mode	▼
Export Control	^
Export Control	
Export	
Export Power (%)	
100	Save
Max Utility/Gen Charge Current (A)	
20	Save
Battery Settings	▼
Gen Port	▼
Setting	>

2.2 Zero Export Settings

If you wish to achieve zero export in the system, set the export control to zero export to ensure that the photovoltaic power matches the load power.

System ON/OFF	▼
Work Mode	▼
Export Control	▲
Export Control	
zero Export	Save
Device bias Power (%)	
0	Save
Max Utility/Gen Charge Current (A)	
20	Save
Battery Settings	▼
Gen Port	▼
Setting	>