

ARM Parallel Communication Fault

Alarm Attribute

Alarm name	Alarm Severity	Alarm Category
ARM Parallel Communication Fault	General	Communication alarm

Possible Cause

Cause ID	Possible Cause
1	ARM parallel fault: In a parallel system, the ARM of the slave device hasn't received the signal from the Master ARM for a long time.

Suggestion

- 1.Ensure the baud rate settings are consistent, preferably using the default baud rate.
- 2.If the master is not connected to the Datahub, do not select Datahub in the Modbus or Internal 485 settings of the master.
- 3.Confirm that all firmware versions are consistent, or upgrade them uniformly to the latest version.
- 4.If the issue remains, provide the completed troubleshooting results to SolaX technical support team through video or images.Including but not limited to:
 - 1) SN number of the inverter.
 - 2)Baud rate settings.
 - 3)Modbus or Internal 485 settings.