

Arc Hardware Fault

Alarm Attribute

Alarm name	Alarm Severity	Alarm Category
Arc Hardware Fault	General	Communication alarm

Possible Cause

Cause ID	Possible Cause
1	Arc board communication loss: No communication was established between ARM and Arc board for a certain time

Suggestion

- 1.Disconnect the PV switch, turn off the battery, restart the inverter, and upgrade the firmware to the latest version.
- 2.Disable ArcCheck function.
- 3.If the issue remains, provide the completed troubleshooting results to SolaX technical support team through video or images.Including but not limited to:
 - 1) SN number of the inverter.