

BMS 536. Fault

Alarm Attribute

Alarm name	Alarm Severity	Alarm Category
BMS 536. Fault	General	Battery alarm

Possible Cause

Cause ID	Possible Cause
1	Battery Analog Front End Failure.
2	There is a battery analog front end (AFE) failure.

Suggestion

- 1.Update both the inverter and battery firmware to the latest version, then restart the inverter and battery.
- 2.If the issue remains, disconnect all slave batteries and connect each battery to the inverter one at a time with the master battery to identify the faulty battery and remove it from the system.
- 3.If all batteries trigger an error, provide the completed troubleshooting results to SolaX technical support team through video or images.Including but not limited to:
 - 1) SN number of the inverter.
 - 2)The error messages displayed on the inverter screen when each battery is connected individually.(Tips:Please ensure that the battery voltage connected to the inverter meets the minimum startup voltage requirement of the inverter.)