

BMS AirSwitch Break

Alarm Attribute

Alarm name	Alarm Severity	Alarm Category
BMS AirSwitch Break	General	Battery alarm

Possible Cause

Cause ID	Possible Cause
1	Battery circuit breaker disconnection failure.

Suggestion

1. Turn off the circuit breaker on the battery. If the error persists, update both the inverter and battery to the latest firmware. Restart the inverter and battery.
2. If the issue remains, provide the completed troubleshooting results to SolaX technical support team through video or images. Including but not limited to:
 - 1) SN number of the inverter and battery.
 - 2) The status of the battery switch.