

BMS Discharge Overcurrent

Alarm Attribute

Alarm name	Alarm Severity	Alarm Category
BMS Discharge Overcurrent	General	Battery alarm

Possible Cause

Cause ID	Possible Cause
1	Battery discharge overcurrent fault: The current of the battery discharging is too high

Suggestion

- 1.If the error persists, upgrade the inverter firmware to the latest version.
- 2.If the error continues for a period and the battery stops working, Record a video of this phenomenon and send it to the SolaX technical support team.
- 3.If other battery errors occur, such as circuit fault or current sensor fault, provide the completed troubleshooting results to SolaX technical support team through video or images.Including but not limited to:
 - 1) SN number of the inverter.