

BMS External Error

Alarm Attribute

Alarm name	Alarm Severity	Alarm Category
BMS External Error	General	Battery alarm

Possible Cause

Cause ID	Possible Cause
1	BMS External Communication Error: The communication between the battery and inverter has problems

Suggestion

- 1.Check the communication cable and communication ports between the inverter and the battery for any damage.
- 2.Replace the communication cable and restart both the battery and inverter.
- 3.If the issue remains, provide the completed troubleshooting results to SolaX technical support team through video or images.Including but not limited to:
 - 1) SN number of the inverter.
 - 2)The front photo of all communication ports on the battery, without any communication cables connected, showing whether the ports are damaged internally.
 - 3)The photo of the BMS port on the inverter.