

BMS Hardware Protect

Alarm Attribute

Alarm name	Alarm Severity	Alarm Category
BMS Hardware Protect	General	Battery alarm

Possible Cause

Cause ID	Possible Cause
1	Slave battery hardware fault: the hardware of the slave battery has problem

Suggestion

- 1.The fault commonly occurs during the battery charging and discharging process, and is usually accompanied by errors related to the cell temperature or voltage. First, let the battery sit for 30 minutes. Then, Based on the accompanying error, use the T-BAT-Charger to check the detailed cell voltage and temperature information of each battery, Identify the faulty battery.
- 2.If the T-BAT-Charger is unavailable, provide the SN number of the inverter to SolaX technical support team.