

BMS Lost

Alarm Attribute

Alarm name	Alarm Severity	Alarm Category
BMS Lost	General Alarm	Inverter alarm

Possible Cause

Cause ID	Possible Cause
1	BMS communication loss fault: The communication between the ARM and the BMS has not been established.

Suggestion

- 1.Check if the communication cable between the BMS and inverter is connected correctly and tightly.
2. Upgrade the firmware to the latest version.
- 3.If the issue remains, provide the completed troubleshooting results to SolaX technical support team through video or images.Including but not limited to:
 - 1) SN number of the inverter.
 - 2)The front photo of the BMS port and BMS communication port located at the bottom of the inverter. If there are any abnormalities or damage, please take a photo.
 - 3)The terminals on both ends of the communication cable between the inverter and the BMS. If there is any damage, please take a photo.