

BMS Precharge Fault

Alarm Attribute

Alarm name	Alarm Severity	Alarm Category
BMS Precharge Fault	General	Battery alarm

Possible Cause

Cause ID	Possible Cause
1	BMS Pre-charge Fault.
2	The master battery has pre-charge fault.

Suggestion

- 1.Disconnect the power cable between the inverter and the battery. Perform a black start on the battery and check if the status light is normal. Remove any battery with an abnormal status light from the system.
- 2.Inspect all battery connections to ensure no port damage or reversed polarity. Update the firmware to the latest version.
- 3.If the issue remains, provide the completed troubleshooting results to SolaX technical support team through video or images.Including but not limited to:
 - 1) SN number of the inverter.
 - 2)A video of the battery status lights showing abnormal behavior.
 - 3)If the battery has any damaged ports, please take a photo.