

Battery Voltage Fault

Alarm Attribute

Alarm name	Alarm Severity	Alarm Category
Battery Voltage Fault	General Alarm	Inverter alarm

Possible Cause

Cause ID	Possible Cause
1	Battery voltage fault: The battery voltage exceeds the range for normal operation.

Suggestion

- 1.Measure the total battery voltage to ensure it is within the inverter's operating range.
- 2.If the total battery voltage is normal, update the firmware of both the inverter and the battery to the latest version, then restart the battery.
- 3.If the issue remains, provide the completed troubleshooting results to SolaX technical support team through video or images.Including but not limited to:
 - 1) SN number of the inverter.