

Earth Relay Fault

Alarm Attribute

Alarm name	Alarm Severity	Alarm Category
Earth Relay Fault	General	Inverter alarm

Possible Cause

Cause ID	Possible Cause
1	Earth relay malfunction
2	Relay self-check failed

Suggestion

- 1.Try to disconnect the AC, DC switches, and battery switch. Then, restart the inverter.
- 2.Upgrade the firmware to the latest version.If the issue remains, provide the inverter's SN number to the SolaX technical support team for further analysis.