

FAN 2 Fault

Alarm Attribute

Alarm name	Alarm Severity	Alarm Category
Fan 2 Fault	General	Communication alarm

Possible Cause

Cause ID	Possible Cause
1	Fan 22 Fault: The Fan 2 doesn't pass the check

Suggestion

1. Upgrade the firmware to latest version.
2. Observe the external fan; if it keeps running, remove the fan and replug it.
3. If the fan does not run at all, remove the fan and clean it with a brush.
4. If the issue remains, provide the completed troubleshooting results to SolaX technical support team through video or images. Including but not limited to:
 - 1) SN number of the inverter.
 - 2) A video of the fan's working status while the inverter is running. If there are any unusual noises, please record the sound as well.