

Meter Fault

Alarm Attribute

Alarm name	Alarm Severity	Alarm Category
Meter Fault	General	Communication alarm

Possible Cause

Cause ID	Possible Cause
1	Meter Communication fault: No communication established between the ARM and the meter.

Suggestion

- 1.Check the inverter settings. If the meter is not connected, do not select the meter in the settings.
- 2.Verify that the communication cable between the inverter and the meter is correctly connected.
- 3.Check the settings on both the meter and inverter, including baud rate, address, and communication protocol.
- 4.If the issue remains, provide the completed troubleshooting results to SolaX technical support team through video or images.Including but not limited to:
 - 1) SN number of the inverter.
 - 2)The sampling devices actually used in the system.
 - 3)The connection status of the communication cable from the meter to the inverter. The wiring at the ports should be clearly displayed.
 - 4)Baud rate and address settings on inverter and Meter.