

NTC Sample Invalid

Alarm Attribute

Alarm name	Alarm Severity	Alarm Category
NTC Sample Invalid	General	Communication alarm

Possible Cause

Cause ID	Possible Cause
1	Lead-acid battery temperature sampling fault
2	External NTC unable to read temperature

Suggestion

- 1.Check if the battery type in the inverter settings is incorrectly set to lead-acid batteries.
- 2.Check if the external NTC of the lead-acid battery is properly connected.
- 3.Check if the wiring of the NTC communication interface conforms to the requirements in the manual.
- 4.If the issue remains, provide the completed troubleshooting results to SolaX technical support team through video or images.Including but not limited to:
 - 1) SN number of the inverter.
 - 2) Battery type settings.
 - 2)A photo of the NTC communication port, clearly showing the wiring details.