



\* Flost and Last Link

Convertion: Qo= Qn=0 k Qo= Qn=0

D) For O Rd, Set the Constant parameters to Zero'

d, on 0,=0 & dnor On=0

=> The parameters (x; a; d; ,0;) associated with each link is called:

OH parameter on Denavit Mantenberg Parameter

L> Three parametes are fixed.

\* Frame Attachment

1 Z-axis along the joint axis

English and allowed Translate Williams

@ Origin et intersection of common normali

3 X- axis toward common normal.

(9) Y-axis using sight hand thumb sale.

\* Summary

121-1

Axis

Axis

(1)


a; > distance (Z:, Zite) along X:

X; > angle (Zi, Ziri) about X;

d: > distance (Xin, Xi) along Zi

0; => congle (Xi, Xi) chot Zi

i | X:-, a:-, d: 0;



Date Page Cor -So: O di-1-1 So: Cx: - Co: Cx: - Sx. - Sx. d: So: Sa: - Co: Ca: - Ca: => Foonward Kimmatics: OTN = 071 172 -- N-2 1V-1 TN