

gcm D (Д) - Installation Guide



gcm D (Д) comes on a memory card inserted into the hard lock's plug. Both the software and the tutorial, as well as the drivers, are on this card.

1. INSTALLING HARD-LOCK DRIVER

GCM D is protected by using Sentinel HASP HL, or simply Sentinel HL, hard-lock. Before starting GCM D, you must install the hard-lock driver. Copy folder GCM-HASP from GCM memory card to your hard disc. Go to GCM-HASP. The driver is installed by running HASPUserSetup.EXE.

You can find the latest on Sentinel HL technology on: <https://cpl.thalesgroup.com/software-monetization/all-products/sentinel-hasp>

2. INSTALLING **gcm D** SOFTWARE

GCM D runs on AutoCAD®. There are two versions (folders) of GCM D software on memory card:

- GCM-D-Software-for-AutoCAD2019-AutoCAD2020
- GCM-D-Software-for-AutoCAD2021-AutoCAD2022-AutoCAD2023-AutoCAD2024

- Copy the folder you need from the GCM memory card to your hard disc.
- Start AutoCAD® and call command PREFERENCES (or OPTIONS). Add new "Support file search path", pointing to the appropriate GCM D software folder on your hard disc.
- Add GCM D software folder to "Trusted Locations".

Next time you start AutoCAD®, GCM D will be loaded automatically. But, do not leave AutoCAD® yet.

- Call CUILOAD command and, when asked for the menu file, select GAVRAN-Civil-Modeller.cuix from folder GCM D software folder. GCM D toolbars will appear.

Now, you can leave AutoCAD®. Next time you enter AutoCAD®, GCM D and the appropriate toolbars will be loaded automatically.

3. INSTALLING AND VIEWING GCM TUTORIAL

GCM tutorial contains almost 27 hours of video files (AVI files). There are six folders with AVI files on GCM memory card:

- | | |
|----------------|--|
| GCM-TUTOR | - AVI files from GCM2000 era |
| GCM-TUTOR-2004 | - AVI files explaining what was new in GCM2004 |
| GCM-TUTOR-2006 | - AVI files explaining what was new in GCM2006 |
| GCM-TUTOR-2009 | - AVI files explaining what is new in GCMx64 (GCM2009) |
| GCM++TUTOR | - AVI files explaining what is new in GCM++ (GCM2013) |
| GCM-D-TUTORIAL | - AVI files explaining what is new in GCM D |

You should copy all these folders to your hard disc and start AVI files from there. You can view AVI files by using standard media players.

But, before viewing these files, you must start TSCC.EXE driver. This driver is placed at the top level of GCM-TUTOR folder (and in TSCC folder). GCM tutorial is recorded and produced with Camtasia software, by using very high degree of compression (Camtasia is trademark of TechSmith Corporation). Therefore, before starting the media player, you must install specific TSCC.EXE driver.

Older AVI files (GCM2000 and GCM2004) run too fast with some media players. Therefore, you should slow them down, by using "Play speed" options.

Electronic documentation for GavranSTL module (3D printing) is organized as a four part Microsoft Office PowerPoint® slide show and is stored in folder GCMx64-STL-TUTORIAL. Each slide show is automatically linked to tens of instruction movies explaining how to prepare 3D model for 3D printing.

4. KNOWN PROBLEMS

You may have already noticed that, while inserting blocks in later releases of AutoCAD, some of the inserted blocks are unexpectedly small. For example, in GCM, you might get too small labeling blocks, when calling LBLDET command. This is because some of the system variables dealing with the insertion scale are set, by default, to comply with inches, rather than meters. Therefore, you should set INSUNITS, INSUNITSDEFSOURCE and INSUNITSDEFTARGET to 0.

Because of rather conservative GCM conventions, names of the layers used with GCM must not contain empty spaces (blanks). The same applies to the names of *.DWG files created with GCM and even to the names of folders in which these *.DWG files reside.

For proper insertion of blocks containing attributes, system variable ATTREQ must be set to 1.

Try not to define blocks with "Scale uniformly" option turned on. In some versions of AutoCAD, after defining such a block, all subsequent block insertions are executed with the equal scale along all three X,Y,Z vectors. As the drain, curb and similar blocks used in cross sections must be ready for the insertion with different scales (in vertically exaggerated cross sections), such handling of blocks leads to improper scales and rotations of the inserted blocks.

To bring AutoCAD back to a state where the blocks could be inserted with different X,Y,Z scales again, all you should do is to create a new block with "Scale uniformly" turned off.

Try not to have 3DOSNAP constantly turned on.