Sea-Doo / Rotax Diagnostic Trouble Codes (DTC) - Full Database

Ova lista sadrži sve jedinstvene bazne kodove izvučene direktno iz video materijala. Tekst je ostavljen u originalu radi preciznosti pri mapiranju softwarea.

DTC	Description	Possible Causes	Service Actions
P0008	Engine phase detection fault	Engine timing chain stretch, Sensor alignment, Internal engine mechanical problem.	Check engine timing alignment, check for loose or damaged engine timing components.
P0030	Heater Power Stage for lambda sensor (Upstream)	Fuse for the lambda sensor heater blown, open circuit, faulty lambda sensor.	Check fuse, wiring and lambda sensor. Measure resistance of the heater.
P0031	Heater Power Stage for lambda sensor (Upstream) - shorted to ground	Wiring shorted to ground, faulty lambda sensor, faulty ECM.	Check wiring for short to ground. Replace lambda sensor if necessary.
P0032	Heater Power Stage for lambda sensor (Upstream) - shorted to V+	Wiring shorted to battery voltage, faulty lambda sensor, faulty ECM.	Check wiring for short to B+. Replace lambda sensor if necessary.
P0038	Heater Power Stage for lambda sensor (Downstream)	Open circuit or shorted to ground/V+ in the downstream heater circuit.	Check downstream lambda sensor wiring and connector.
P004A	Catalyst control trim integrator limit	Air leak in intake or exhaust, faulty fuel pressure, faulty lambda sensor.	Check for air leaks. Check fuel pressure. Check lambda sensor operation.
P00B6	Lambda sensor downstream signal shorted to ground	Damaged wiring, faulty sensor, connector moisture.	Inspect downstream sensor harness and pins.
P00B7	Lambda sensor downstream signal shorted to V+	Damaged wiring, faulty sensor, internal sensor short.	Inspect downstream sensor harness and pins.
P0106	Manifold Intake pressure out of range	Faulty MAP sensor, intake manifold leak, vacuum hose damaged.	Check MAP sensor and vacuum lines. Check for intake leaks.

P0107	Manifold absolute pressure - shorted to ground	Open circuit or short to ground, sensor disconnected.	Check wiring for continuity and 5V reference.
P0108	Manifold absolute pressure - shorted to V+	Signal shorted to V+ or faulty sensor.	Check sensor output voltage. Replace MAP if necessary.
P0112	Intake manifold temperature - shorted to ground	IAT sensor internal short or wiring shorted to ground.	Measure sensor resistance. Check wiring.
P0113	Intake manifold temperature - shorted to V+	Open circuit or sensor disconnected, wiring shorted to V+.	Check IAT connector and wiring integrity.
P0116	Engine coolant temperature signal not plausible	Faulty thermostat, faulty ECT sensor, low coolant level.	Check cooling system, check ECT sensor resistance vs temperature.
P0117	Engine coolant temperature - shorted to ground	Wiring short to ground, faulty ECT sensor.	Check ECT wiring harness.
P0118	Engine coolant temperature - shorted to V+	Open circuit, sensor disconnected or shorted to B+.	Check ECT sensor connector pins and wires.
P0122	TAS (Throttle Accelerator Sensor) 1 signal low	Open circuit or shorted to ground, faulty TAS, faulty ECM.	Check wiring for TAS 1. Verify 5V supply and signal.
P0123	TAS (Throttle Accelerator Sensor) 1 signal high	Signal shorted to V+ or faulty TAS.	Check for short to B+ in signal wire.
P0131	Lambda sensor upstream signal low voltage	Lean condition, exhaust leak, faulty sensor.	Check for exhaust leaks before the sensor.
P0132	Lambda sensor upstream signal high voltage	Rich condition, contaminated sensor, faulty wiring.	Check fuel injectors and fuel pressure.
P0134	Lambda sensor upstream no activity	Sensor heater not working, sensor contaminated, open circuit.	Check heater circuit and sensor response.

P0135	Lambda sensor heating fault (Upstream)	Faulty lambda sensor heater, open circuit.	Replace upstream lambda sensor.
P0136	Lambda sensor fault (Downstream)	Problem with the downstream oxygen sensor signal.	Inspect downstream sensor and connector.
P0137	Lambda sensor downstream voltage low	Exhaust leak near sensor, lean condition.	Check exhaust system for leaks.
P0138	Lambda sensor downstream voltage high	Rich condition, faulty downstream sensor.	Check for rich running conditions.
P013B	Oxygen sensor downstream lean to rich reaction time	Sensor aging, contaminated sensor.	Check sensor performance, replace if slow.
P013E	Oxygen sensor downstream maximum error	Deviation of the sensor signal beyond limits.	Check fuel system and sensor condition.
P013F	Oxygen sensor downstream minimum error	Deviation of the sensor signal below limits.	Check fuel system and sensor condition.
P0141	Lambda sensor heating fault (Downstream)	Faulty downstream heater, wiring problem.	Replace downstream lambda sensor.
P0201	Injector 1 circuit fault	Open circuit or short to ground/V+ in injector 1.	Check injector 1 resistance and wiring.
P0202	Injector 2 circuit fault	Open circuit or short to ground/V+ in injector 2.	Check injector 2 resistance and wiring.
P0203	Injector 3 circuit fault	Open circuit or short to ground/V+ in injector 3.	Check injector 3 resistance and wiring.
P0222	TAS (Throttle Accelerator Sensor) 2 signal low	Open circuit or short to ground, faulty TAS.	Check wiring for TAS 2.
P0223	TAS (Throttle Accelerator Sensor) 2 signal high	Signal shorted to V+ or faulty TAS.	Check wiring for TAS 2.

P0231	Fuel pump relay shorted to ground	Wiring short to ground, faulty relay.	Check fuel pump relay and harness.
P0232	Fuel pump relay shorted to V+	Wiring short to battery voltage.	Check fuel pump relay and harness.
P0261	Injector 1 open circuit or shorted to ground	Wiring fault or injector internal failure.	Inspect harness and test injector.
P0262	Injector 1 shorted to battery voltage	Signal wire shorted to B+.	Inspect harness and test injector.
P0264	Injector 2 open circuit or shorted to ground	Wiring fault or injector internal failure.	Inspect harness and test injector.
P0265	Injector 2 shorted to battery voltage	Signal wire shorted to B+.	Inspect harness and test injector.
P0335	Crankshaft Position Sensor (CKP) fault	Faulty sensor, sensor gap incorrect, damaged trigger wheel.	Check CKP sensor and trigger wheel condition.
P0336	Crankshaft Position Sensor signal out of range	Interference, loose sensor, faulty sensor.	Check sensor mounting and shield wiring.
P0351	Ignition Coil 1 fault	Faulty ignition coil, wiring fault, faulty ECM.	Test ignition coil 1 and wiring.
P0352	Ignition Coil 2 fault	Faulty ignition coil, wiring fault, faulty ECM.	Test ignition coil 2 and wiring.
P0353	Ignition Coil 3 fault	Faulty ignition coil, wiring fault, faulty ECM.	Test ignition coil 3 and wiring.
P0354	Ignition Power Stage fault (Cylinder 1)	Internal ECM fault or shorted coil.	Check coil resistance and ECM outputs.
P0357	Ignition Power Stage fault (Cylinder 2)	Internal ECM fault or shorted coil.	Check coil resistance and ECM outputs.
P0360	Ignition Power Stage fault (Cylinder 3)	Internal ECM fault or shorted coil.	Check coil resistance and ECM outputs.

P0362	Ignition Power Stage max error	Current limit reached on ignition output.	Check spark plug and coil.
P0363	Misfire detected - fuel disabled	Severe misfire, faulty coil, injector or spark plug.	Diagnose specific cylinder misfire.
P0390	Ignition Power Stage false detection	Interference or internal ECM logic error.	Check for electrical noise/interference.
P0420	Catalyst conversion insufficient	Faulty catalyst, faulty upstream/downstream sensors.	Inspect catalyst and compare sensor readings.
P0444	EVAP Purge Valve open circuit	Valve disconnected, wiring open circuit.	Check EVAP valve and connector.
P0445	EVAP Purge Valve shorted to ground/V+	Wiring shorted, faulty valve.	Check EVAP valve and connector.
P0500	Vehicle Speed Sensor (VSS) fault	Faulty VSS, wiring fault, cluster problem.	Check VSS signal in monitoring.
P0505	Idle Control System fault	Faulty idle air valve, throttle body dirty/faulty.	Check throttle body and idle air passages.
P0512	Starter power stage high current	Faulty starter, seized engine, wiring short.	Check starter motor and main cables.
P0513	Invalid DESS key	Key not programmed, dirty key, faulty DESS post.	Clean key and post. Re-program key.
P0520	Oil pressure switch functional problem	Switch stuck open or closed, low oil pressure.	Check oil pressure with mechanical gauge.
P0522	Oil pressure sensor low voltage	Shorted to ground or faulty sensor.	Replace oil pressure sensor.
P0523	Oil pressure sensor high voltage	Open circuit or short to V+.	Check sensor wiring and connector.
P0524	Low oil pressure condition	Actual low oil pressure, worn engine.	Check oil level and pump.
P0544	Exhaust gas temperature sensor functional	EGT sensor signal out of range.	Check EGT sensor and exhaust temp.

P0545	Exhaust gas temperature shorted to ground	Shorted wiring or faulty EGT sensor.	Inspect EGT sensor wiring.
P0546	Exhaust gas temperature shorted to V+	Open circuit or shorted to B+.	Inspect EGT sensor wiring.
P0562	System Voltage Low	Low battery, faulty alternator, excessive load.	Check battery and charging system.
P0563	System Voltage High	Faulty voltage regulator, jump starting.	Check alternator/regulator output.
P0601	ECM Checksum error	Internal ECM memory failure.	Replace ECM.
P0602	ECM Programming error	ECM not programmed or interrupted flash.	Re-program ECM.
P0604	ECM RAM error	Internal ECM hardware failure.	Replace ECM.
P0605	ECM ROM error	Internal ECM hardware failure.	Replace ECM.
P0606	ECM Microprocessor fault	Internal ECM processor failure.	Replace ECM.
P0616	Starter Relay shorted to ground	Relay coil or wiring shorted to ground.	Inspect starter relay circuit.
P0617	Starter Relay shorted to V+	Relay coil or wiring shorted to B+.	Inspect starter relay circuit.
P0627	Fuel Pump Power Stage open circuit	Fuel pump disconnected, wiring fault.	Check fuel pump harness and relay.
P1102	TPS (Throttle Position Sensor) adaptation fault	Adaptation limits reached, dirty throttle.	Clean throttle body and perform adaptation.
P1201	Cylinder 1 Injector shorted to B+	Injector harness shorted to battery.	Inspect injector 1 wiring.
P1505	T.O.P.S. (Tip-Over) switch fault	Switch signal not plausible, vehicle flipped.	Check sensor orientation and reset.

P1506	T.O.P.S. (Tip-Over) switch open circuit	Switch disconnected or wiring broken.	Check T.O.P.S. wiring.
P1614	DESS key not recognized	Communication error with DESS key.	Clean DESS post and key.
P1657	DESS line electrical fault	Short or open in the DESS circuit.	Inspect DESS post wiring.
P1658	DESS key communication fault	Data error from the key.	Replace DESS key if cleaning fails.
P1659	DESS key password error	Wrong key programmed for this vehicle.	Use correct key or re-program.
P1661	IBR malfunction	Internal error in the IBR module.	Check IBR actuator and harness.
P1662	IBR torque request not plausible	Communication or logic error for IBR torque.	Calibrate IBR system.
P1679	Main Relay Sticking	Main relay contacts stuck closed.	Replace main relay.
P16B6	ECU Fast ADC fault (Knock)	Internal ECM error for knock detection.	Replace ECM or check knock sensor.
P16B7	ECU Fast ADC fault (MAP)	Internal ECM error for MAP processing.	Replace ECM or check MAP sensor.
P16B8	ECU Fast ADC fault (TPS)	Internal ECM error for TPS processing.	Replace ECM or check TPS sensor.
P16C0	Fault of ECM ADC	General analog-to-digital converter fault.	Replace ECM.
P1700	Pedestal seat sensor fault	Seat sensor shorted or open circuit.	Check wiring under the seat.
P1914	IBR reverse position not reached	Actuator jammed, mechanical obstruction.	Check for debris in the IBR gate.
P2122	TAS 1 (Throttle Accelerator Sensor) voltage too low	Wiring short to ground or open circuit.	Check TAS 1 harness.

P2123	TAS 1 (Throttle Accelerator Sensor) voltage too high	Wiring short to B+.	Check TAS 1 harness.
P2620	TPS (Throttle Position Sensor) output circuit	Faulty throttle body, internal gear failure.	Replace throttle body assembly.
P2621	TPS 1 Electrical lower range violation	Signal below minimum limit.	Check throttle body wiring.
P2622	TPS 2 Electrical lower range violation	Signal below minimum limit.	Check throttle body wiring.
U0100	Lost Communication with ECM	CAN bus timeout with Engine Control Module.	Check CAN wires and ECM power/ground.
U0121	Lost Communication with ABS	CAN bus timeout with ABS module.	Check ABS module power and CAN lines.
U0155	Lost Communication with Instrument Cluster	CAN bus timeout with the display.	Check display connector and CAN lines.
U16AA	Cluster CAN Timeout (ID 410h)	Communication loss with cluster on ID 410h.	Check wiring between ECM and Cluster.