
## **Betriebsanleitung • Operating Instructions**

## Turbopumpen

mit Antriebselektronik TC 750-E74

## **Turbopumps**

with electronic drive unit TC 750-E74



Ergänzende Informationen zu Betriebsanleitungen für Turbopumpen mit TC 750

Supplementary information to operating instructions for turbopumps with TC 750

TC 750 mit 15-poligem Remote-Anschluss TC 750 with 15-pole remote connection



### Gültigkeit

Diese ergänzende Information beschreibt wichtige Abweichungen gegenüber dem Standardprodukt und hat nur Gültigkeit im Zusammenhang mit den geltenden Betriebsanleitungen.

- Turbopumpen mit Antriebselektronik TC 750-E74 und 15-poligem Remote-Anschluss
  - Pfeiffer Vacuum Artikelnummer TC 750-E74: PM C01 712

## Fernbedienung anschließen




#### **HINWEIS**

Geänderte Kontaktbelegung der Remote-Anschlussverbindung bei Turbopumpen mit TC 750-E74 (PM C01 712)

Fernbedienung für verschiedene Funktionen ist über den Anschluss mit der Bezeichnung "REMOTE" am TC 750-E74 über die 15-polige Steckverbindung möglich.

→ Abgeschirmtes Kabel verwenden.


#### **Pin-Belegung**



Pin	Belegung	Pin	Belegung
1	start/stop (+)	9	start/stop (-)
2	n.c.	10	n.c.
3	acceleration status (+)	11	acceleration status (-)
4	normal status (+)	12	normal status (-)
5	deceleration status (+)	13	deceleration status (-)
6	alarm status (+)	14	alarm status (-)
7	remote/local status (+)	15	remote/local status (-)
8	~alarm status (+)	14	

#### **Anschluss "E74"**

Der Anschluss "REMOTE" an der TC 750-E74 mit 15-poliger Anschlussbuchse entspricht den Anforderungen der Richtlinie SEMI E74-0301 für ein zusätzliches invertiertes Alarmsignal bei Turbomolekularpumpen.



Die Signal(-)-Leitungen des "alarm status (+)" und "~alarm status (+) sind zusammen gefasst zum Signal "alarm status (-)".


# Signalbeschreibung

Signal	(+) Pin	(-) Pin	Funktion beim Schließen	Funktion beim Öffnen
start / stop	1	9	Pumpe startet / Reset	Pumpe stoppt

Signal	(+) Pin	(-) Pin	Bedeutung wenn geschlossen	Bedeutung wenn geöffnet
acceleration status	3	11	Pumpe beschleunigt	Pumpe beschleunigt nicht
normal status	4	12	Schaltpunkt erreicht	Schaltpunkt nicht erreicht
deceleration status	5	13	Pumpe bremst	Pumpe bremst nicht
alarm status	6	14	kein Fehler	Fehler
remote / local status	7	15	Gerät fernbedient	Gerät nicht fernbedient
~alarm status	8	14	Fehler	kein Fehler

#### **Anschlussplan**

TC 750 - E 74



### **Validity**

This supplementary information describes important variations to the standard product and is only valid together with the revailing operating instructions.

- Turbopumps with electronic drive unit TC 750-E74 and 15-pole remote connection
  - Pfeiffer Vacuum product number TC 750-E74: PM C01 712

### Connecting the remote control unit




#### **NOTE**

Modified pin arrangement of the remote connection for turbopumps with TC 750-E74 (PM C01 712)

Remote control for various functions is provided by the connection "REMOTE" on the TC 750-E74 via the 15-pole D-Sub-connection.

→ Shielded cable must be used.


#### Pin arrangement



function	Pin	fuction
start/stop (+)	9	start/stop (-)
n.c.	10	n.c.
acceleration status (+)	11	acceleration status (-)
normal status (+)	12	normal status (-)
deceleration status (+)	13	deceleration status (-)
alarm status (+)	14	alarm status (-)
remote/local status (+)	15	remote/local status (-)
~alarm status (+)	14	
	start/stop (+) n.c. acceleration status (+) normal status (+) deceleration status (+) alarm status (+) remote/local status (+)	start/stop (+) 9 n.c. 10 acceleration status (+) 11 normal status (+) 12 deceleration status (+) 13 alarm status (+) 14 remote/local status (+) 15

## Connection "E74"

The connection "REMOTE" on the TC 750-E74 with 15-pole female plug complies with the requirements for an additional inverted alarm signal on turbomolecular pumps as described in the Standard SEMI E74-0301.




The signal (-) leads of the "alarm status (+)" and "~alarm status (+)" are combined in the signal "alarm status (-)".

#### Signal definition

Signal	(+) Pin	(-) Pin	Function if closed	Function if open
start / stop	1	9	Pump starts / reset	Pump stops


Signal	(+) Pin	(-) Pin	Meaning if closed	Meaning if closed
acceleration status	3	11	Pump accelerates	Pump does not accelerate
normal status	4	12	Switch point attained	Switch point not attained
deceleration status	5	13	Pump decelerates	Pump does not decelerate
alarm status	6	14	No malfunction	Malfunction
remote / local status	7	15	Unit remote controlled	Unit locally controlled
~alarm status	8	14	Malfunction	no malfunction

# Connection diagram



Notizen / Notes:

### Vacuum is nothing, but everything to us!



Rotary vane pumps

Roots pumps

Dry compressing pumps

Leak detectors

**Valves** 

Components and feedthroughs

Vacuum measurement

© ⊕ ⊖ Gas analysis

System engineering

Service

