

GENERAL INFORMATION

DIAGNOSTIC TROUBLE CODE INDEX - DTC:
DRIVER/PASSENGER DOOR MODULE [DDM/PDM]

[G2006795]

DESCRIPTION AND OPERATION

DRIVER DOOR MODULE/PASSENGER DOOR MODULE [DDM/PDM]

CAUTIONS:

- Diagnosis by substitution from a donor vehicle is **NOT** acceptable. Substitution of control modules does not guarantee confirmation of a fault, and may also cause additional faults in the vehicle being tested and/or the donor vehicle.
- The vehicle latches are non-serviceable. Lubrication must not be sprayed into or around the door latches. Care should be taken when washing the vehicle to not spray water at or into the latches

NOTES:

- If a control module or a component is not to specification and the vehicle remains under manufacturer warranty, refer to the Warranty Policy and Procedures manual, or determine if any prior approval program is in operation, prior to the installation of a new module/component.
- Generic scan tools may not read the codes listed, or may read only 5-digit codes. Match the 5 digits from the scan tool to the first 5 digits of the 7-digit code listed to identify the fault (the last 2 digits give extra information read by the manufacturer-approved diagnostic system).
- When performing voltage or resistance tests, always use a digital multimeter that has the resolution ability to view 3 decimal places. For example, on the 2 volts range can measure 1mV or 2 K Ohm range can measure 1 Ohm. When testing resistance always take the resistance of the digital multimeter leads into account.
- Check and rectify basic faults before beginning diagnostic routines involving pinpoint tests.
- Inspect connectors for signs of water ingress, and pins for damage and/or corrosion.
- If DTCs are recorded and, after performing the pinpoint tests, a fault is not present, an intermittent concern may be the cause. Always inspect for loose connections and corroded terminals.
- Check JLR claims submission system for open campaigns. Refer to the corresponding bulletins and SSMs which may be valid for the specific customer complaint and complete the recommendations as required.

The table below lists all diagnostic trouble codes (DTCs) that could be set in the Driver Door Module/Passenger Door Module (DDM/PDM). For additional diagnosis and testing information refer to the relevant diagnosis and testing section. For additional information, refer to: [Driver Door Module](#) (419-10 Multifunction Electronic Modules, Diagnosis and Testing).

DTC	DESCRIPTION	POSSIBLE CAUSES	ACTION
B1087-83	LIN Bus "A" - Value of signal protection calculation incorrect	■ Door switchpack internal failure	■ Using the Jaguar Land Rover approved diagnostic equipment, clear the DTCs and retest. If the fault persists, install a new door switchpack

DTC	DESCRIPTION	POSSIBLE CAUSES	ACTION
B1087-86	LIN Bus "A " - Signal invalid	Door switchpack internal failure	Using the Jaguar Land Rover approved diagnostic equipment, clear the DTCs and retest. If the fault persists, install a new door switchpack
B1087-87	LIN Bus "A" - Missing message	- Door switchpack power or ground circuit open circuit, high resistance - LIN bus circuit short circuit to ground, short circuit to power, open circuit, high resistance - Door modules are not configured correctly - Door switchpack internal failure	- Refer to the electrical circuit diagrams and check the door switchpack power and ground circuits for open circuit, high resistance - Refer to the electrical circuit diagrams and check the LIN bus circuit for short circuit to ground, short circuit to power, open circuit, high resistance - Using the Jaguar Land Rover approved diagnostic equipment, reconfigure all the door modules with the latest level software. Clear the DTCs and retest - Using the Jaguar Land Rover approved diagnostic equipment, clear the DTCs and retest. If the fault persists, install a new door switchpack
B1087-88	LIN Bus "A" - Bus off	LIN bus circuit short circuit to ground, short circuit to power, open circuit, high resistance	Refer to the electrical circuit diagrams and check the LIN bus circuit for short circuit to ground, short circuit to power, open circuit, high resistance
B1207-12	Crash Input Hardwired Signal - Circuit short to battery	Crash event circuit short circuit to power	Refer to the electrical circuit diagrams and check the crash event circuit for short circuit to power
B1207-14	Crash Input Hardwired Signal - Circuit short to ground or open	Crash event circuit short circuit to ground, open circuit, high resistance	Refer to the electrical circuit diagrams and check the crash event circuit for short circuit to ground, open circuit, high resistance
B1207-29	Crash Input Hardwired Signal - Signal invalid	Crash event circuit short circuit to ground, short circuit to power, open circuit, high resistance	Refer to the electrical circuit diagrams and check the crash event circuit for short circuit to ground, short circuit to power, open circuit, high resistance
B12BC-11	Mirror Position Sensor Supply - Circuit short to ground	Door mirror position sensor power circuit short circuit to ground	Refer to the electrical circuit diagrams and check the door mirror position sensor power circuit for short circuit to ground
B12C4-11	Mirror Turn Indicator - Circuit short to ground	Side repeater lamp circuit short circuit to ground	Refer to the electrical circuit diagrams and check the side repeater lamp circuit for short circuit to ground
B12C4-15	Mirror Turn Indicator - Circuit short to battery or open	Side repeater lamp circuit short circuit to power, open circuit, high resistance	Refer to the electrical circuit diagrams and check the side repeater lamp circuit for short circuit to power, open circuit, high resistance
B12D4-51	Rolling Code Synchronization - Not programmed	- The rolling encryption code received during a central door locking request is out of synchronization with the master code sequence - Door modules are not configured correctly	NOTE: Do NOT install a new Door module as this will NOT rectify the fault - Using the Jaguar Land Rover approved diagnostic equipment, perform routine - Immobilisation. Clear the DTCs and retest - Using the Jaguar Land Rover approved diagnostic equipment, reconfigure all the door modules with the latest level software. Clear the DTCs and retest

DTC	DESCRIPTION	POSSIBLE CAUSES	ACTION
B12D8-11	Mirror Heater Output - Circuit short to ground	Door mirror heater circuit short circuit to ground	Refer to the electrical circuit diagrams and check the door mirror heater circuit for short circuit to ground
B12D8-15	Mirror Heater Output - Circuit short to battery or open	Door mirror heater circuit short circuit to power, open circuit, high resistance	Refer to the electrical circuit diagrams and check the door mirror heater circuit for short circuit to power, open circuit, high resistance
B12DA-11	Blind Spot Warning Indicator - Circuit short to ground	Side object detection system alert/status LED circuit short circuit to ground	Refer to the electrical circuit diagrams and check the side object detection system alert/status LED circuit for short circuit to ground
B12DA-15	Blind Spot Warning Indicator - Circuit short to battery or open	Side object detection system alert/status LED circuit short circuit to power, open circuit, high resistance	Refer to the electrical circuit diagrams and check the side object detection system alert/status LED circuit for short circuit to power, open circuit, high resistance
B1326-11	External Door Handle LED - Circuit short to ground	Exterior door handle LED circuit short circuit to ground	Refer to the electrical circuit diagrams and check the exterior door handle LED circuit for short circuit to ground
B1326-15	External Door Handle LED - Circuit short to battery or open	Exterior door handle LED circuit short circuit to power, open circuit, high resistance	Refer to the electrical circuit diagrams and check the exterior door handle LED circuit for short circuit to power, open circuit, high resistance
B1378-12	Mirror Horizontal Position Sensor - Circuit short to battery	Door mirror position sensor X axis signal circuit short circuit to power	Refer to the electrical circuit diagrams and check the door mirror position sensor X axis signal circuit for short circuit to power
B1378-14	Mirror Horizontal Position Sensor - Circuit short to ground or open	Door mirror position sensor X axis signal circuit short circuit to ground, open circuit, high resistance	Refer to the electrical circuit diagrams and check the door mirror position sensor X axis signal circuit for short circuit to ground, open circuit, high resistance
B137C-12	Mirror Vertical Position Sensor - Circuit short to battery	Door mirror position sensor Y axis signal circuit short circuit to power	Refer to the electrical circuit diagrams and check the door mirror position sensor Y axis signal circuit for short circuit to power
B137C-14	Mirror Vertical Position Sensor - Circuit short to ground or open	Door mirror position sensor Y axis signal circuit short circuit to ground, open circuit, high resistance	Refer to the electrical circuit diagrams and check the door mirror position sensor Y axis signal circuit for short circuit to ground, open circuit, high resistance
B147F-07	Power Window Motor - Mechanical failures	Window movement obstructed	Check the open/close operation of the window. Inspect the installation of the window seal. Calibrate the window and re-test. If the fault persists, install a new window seal and re-test. If the fault persists, install a new window regulator
B147F-11	Power Window Motor - Circuit short to ground	Window regulator motor circuit short circuit to ground	Refer to the electrical circuit diagrams and check the window regulator motor circuit for short circuit to power
B147F-12	Power Window Motor - Circuit short to battery	Window regulator motor circuit short circuit to power	Refer to the electrical circuit diagrams and check the window regulator motor circuit for short circuit to power

DTC	DESCRIPTION	POSSIBLE CAUSES	ACTION
B147F-92	Power Window Motor - Performance or incorrect operation	Window movement obstructed	Check the open/close operation of the window. Inspect the installation of the window seal. Calibrate the window and re-test. If the fault persists, install a new window seal and re-test. If the fault persists, install a new window regulator
B147F-97	Power Window Motor - Component or system operation obstructed or blocked	- Window regulator motor circuit open circuit, high resistance - Window regulator motor position sensor circuit short circuit to ground, short circuit to power, open circuit, high resistance	- Refer to the electrical circuit diagrams and check the window regulator motor circuit for open circuit, high resistance - Refer to the electrical circuit diagrams and check the window regulator motor position sensor circuit for short circuit to ground, short circuit to power, open circuit, high resistance
B1480-29	Window Position Sensor - Signal invalid	- Window regulator motor circuit open circuit, high resistance - Window regulator motor position sensor circuit short circuit to ground, short circuit to power, open circuit, high resistance	- Refer to the electrical circuit diagrams and check the window regulator motor circuit for open circuit, high resistance - Refer to the electrical circuit diagrams and check the window regulator motor position sensor circuit for short circuit to ground, short circuit to power, open circuit, high resistance
B1482-11	Door Double Locking Motor - Circuit short to ground	- Double locking motor circuit short circuit to ground - Door modules are not configured correctly	- Refer to the electrical circuit diagrams and check the double locking motor circuit for short circuit to ground. Clear the DTCs and retest - Using the Jaguar Land Rover approved diagnostic equipment, reconfigure al the door modules with the latest level software. Clear the DTCs and retest
B1482-15	Door Double Locking Motor - Circuit short to battery or open	Double locking motor circuit short circuit to power, open circuit, high resistance	Refer to the electrical circuit diagrams and check the double locking motor circuit for short circuit to power, open circuit, high resistance
B1483-11	Door Central Locking Motor - Circuit short to ground	Central door locking motor circuit short circuit to ground	Refer to the electrical circuit diagrams and check the central door locking motor circuit for short circuit to ground
B1483-15	Door Central Locking Motor - Circuit short to battery or open	Central door locking motor circuit short circuit to power, open circuit, high resistance	Refer to the electrical circuit diagrams and check the central door locking motor circuit for short circuit to power, open circuit, high resistance
B1484-11	Lock Status LED - Circuit short to ground	Lock status LED circuit short circuit to ground	Refer to the electrical circuit diagrams and check the lock status LED circuit for short circuit to ground
B1484-15	Lock Status LED - Circuit short to battery or open	Lock status LED circuit short circuit to power, open circuit, high resistance	Refer to the electrical circuit diagrams and check the lock status LED circuit for short circuit to power, open circuit, high resistance
B1488-11	Up/Down Mirror Motor - Circuit short to ground	Door mirror vertical adjustment actuator circuit short circuit to ground	Refer to the electrical circuit diagrams and check the door mirror vertical adjustment actuator circuit for short circuit to ground

DTC	DESCRIPTION	POSSIBLE CAUSES	ACTION
B1488-15	Up/Down Mirror Motor - Circuit short to battery or open	Door mirror vertical adjustment actuator circuit short circuit to power, open circuit, high resistance	Refer to the electrical circuit diagrams and check the door mirror vertical adjustment actuator circuit for short circuit to power, open circuit, high resistance
B1489-11	Left/Right Mirror Motor - Circuit short to ground	Door mirror horizontal adjustment actuator circuit short circuit to ground	Refer to the electrical circuit diagrams and check the door mirror horizontal adjustment actuator circuit for short circuit to ground
B1489-15	Left/Right Mirror Motor - Circuit short to battery or open	Door mirror horizontal adjustment actuator circuit short circuit to power, open circuit, high resistance	Refer to the electrical circuit diagrams and check the door mirror horizontal adjustment actuator circuit for short circuit to power, open circuit, high resistance
B148A-11	Deployable Door Handle Motor - Circuit short to ground	Deployable door handle actuator circuit short circuit to ground	NOTE: Disconnect the startup battery prior to performing circuit checks - Refer to the electrical circuit diagrams and check the front door module circuit for short circuit to ground - Check the front door module circuit for short circuit to ground reconnect startup battery and repeatedly lock and unlock door while ignition is in the off position and see if DTC sets - If the fault persists, install a new deployable door handle as required
B148A-15	Deployable Door Handle Motor - Circuit short to battery or open	Deployable door handle actuator circuit short circuit to power, open circuit, high resistance	NOTE: Disconnect the battery prior to performing circuit checks - Refer to the electrical circuit diagrams and check the deployable door handle actuator circuit for short circuit to power, open circuit, high resistance - Check the front door module circuit for short circuit to ground reconnect startup battery and repeatedly lock and unlock door while ignition is in the off position and see if DTC sets - If the fault persists, install a new deployable door handle as required
B148B-11	Folding Mirror Motor - Circuit short to ground	Door mirror power fold actuator circuit short circuit to ground	Refer to the electrical circuit diagrams and check the door mirror power fold actuator circuit for short circuit to ground
B148B-15	Folding Mirror Motor - Circuit short to battery or open	Door mirror power fold actuator circuit short circuit to power, open circuit, high resistance	Refer to the electrical circuit diagrams and check the door mirror power fold actuator circuit for short circuit to power, open circuit, high resistance
B148C-11	Approach Lamp - Circuit short to ground	Approach lamp circuit short circuit to ground	Refer to the electrical circuit diagrams and check the approach lamp circuit for short circuit to ground

DTC	DESCRIPTION	POSSIBLE CAUSES	ACTION
B148D-11	Memory Status LED - Circuit short to ground	Seat switchpack memory status LED circuit short circuit to ground	Refer to the electrical circuit diagrams and check the seat switchpack memory status LED circuit for short circuit to ground
B148D-15	Memory Status LED - Circuit short to battery or open	Seat switchpack memory status LED circuit short circuit to power, open circuit, high resistance	Refer to the electrical circuit diagrams and check the seat switchpack memory status LED circuit for short circuit to power, open circuit, high resistance
B1DD7-11	Deployable Door Handle Retract Switch - Circuit short to ground	- Deployable door handle retract switch circuit short circuit to ground - Deployable door handle retract switch internal failure	NOTES: - Make sure deployable door handle is fully retracted. Handle can be retracted using PID - Door Handle(420F). Alternatively affected door can be manually latched while open (drive latch to fully closed position with door open) and vehicle centrally locked through interior lock switch. This will retract the handle and still allow access to interior door trim - To prevent possible damage to striker assembly make sure vehicle is unlocked and door is unlatched through interior/exterior door handle prior to closing door - Disconnect the startup battery ground cable. Refer to the electrical circuit diagrams and check continuity between door module Pin 18 (connector A) of harness and ground. If open circuit, replace deployable door handle. If closed circuit using the Jaguar Land Rover approved diagnostic equipment, clear the DTCs and retest
B1DD7-15	Deployable Door Handle Retract Switch - Circuit short to battery or open	- Deployable door handle retract switch circuit short circuit to power, open circuit, high resistance - Deployable door handle retract switch internal failure	NOTES: - Make sure deployable door handle is fully retracted. Handle can be retracted using PID - Door Handle(420F). Alternatively affected door can be manually latched while open (drive latch to fully closed position with door open) and vehicle centrally locked through interior lock switch. This will retract the handle and still allow access to interior door trim - To prevent possible damage to striker assembly make sure vehicle is unlocked and door is unlatched through interior/exterior door handle prior to closing door - Disconnect the startup battery ground cable. Refer to the electrical circuit diagrams and check continuity between door module Pin 18 (connector A) of harness and ground. If open circuit, replace deployable door handle. If closed circuit using the Jaguar Land Rover approved diagnostic equipment, clear the DTCs and retest
B1DD8-11	Deployable Door Handle Deploy Switch - Circuit short to ground	- Deployable door handle deploy switch circuit short circuit to ground - Deployable door handle deploy switch internal failure	NOTE: Make sure deployable door handle is fully deployed. Handle can be deployed using PID - Door Handle(420F). Alternatively make sure vehicle is unlocked with door open and handle will remain deployed Disconnect the startup battery ground cable. Refer to the electrical circuit diagrams and check continuity between door module Pin 24 (connector B) of harness and ground. If open circuit, replace deployable door handle. If closed circuit using the Jaguar Land Rover approved diagnostic equipment, clear the DTCs and retest

DTC	DESCRIPTION	POSSIBLE CAUSES	ACTION
B1DD8-15	Deployable Door Handle Deploy Switch - Circuit short to battery or open	- Deployable door handle deploy switch circuit short circuit to power, open circuit, high resistance - Deployable door handle deploy switch internal failure	NOTE: Make sure deployable door handle is fully deployed. Handle can be deployed using PID - Door Handle(420F). Alternatively make sure vehicle is unlocked with door open and handle will remain deployed Disconnect the startup battery ground cable. Refer to the electrical circuit diagrams and check continuity between door module Pin 24 (connector B) of harness and ground. If open circuit, replace deployable door handle. If closed circuit using the Jaguar Land Rover approved diagnostic equipment, clear the DTCs and retest
P0604-42	Internal Control Module Random Access Memory (RAM) Error - General memory failure	Door module internal failure	Using the Jaguar Land Rover approved diagnostic equipment, clear the DTCs and retest. If the fault persists, install a new door module
P0605-42	Internal Control Module Read Only Memory (ROM) Error - General memory failure	Door module internal failure	Using the Jaguar Land Rover approved diagnostic equipment, clear the DTCs and retest. If the fault persists, install a new door module
P1603-44	EEPROM Malfunction - Data memory failure	Door module internal failure	Using the Jaguar Land Rover approved diagnostic equipment, clear the DTCs and retest. If the fault persists, install a new door module
U0046-81	Vehicle Communication Bus C - Invalid serial data received	Invalid data received from another control module through the Medium Speed CAN bus (body)	Using the Jaguar Land Rover approved diagnostic equipment, check the snapshot data to determine the invalid data source control module. Check the relevant control module for related DTCs and refer to the relevant DTC index
U0046-82	Vehicle Communication Bus C - Alive / sequence counter incorrect / not updated	Invalid data received from another control module through the Medium Speed CAN bus (body)	Using the Jaguar Land Rover approved diagnostic equipment, check the snapshot data to determine the invalid data source control module. Check the relevant control module for related DTCs and refer to the relevant DTC index
U0046-88	Vehicle Communication Bus C - Bus off	Medium Speed CAN bus (body) circuit short circuit to ground, short circuit to power, open circuit, high resistance	Using the Jaguar Land Rover approved diagnostic equipment, perform a CAN network integrity test. Refer to the electrical circuit diagrams and check the Medium Speed CAN bus (body) circuit for short circuit to ground, short circuit to power, open circuit, high resistance
U0300-00	Internal Control Module Software Incompatibility - No sub type information	Door module is not configured correctly	Using the Jaguar Land Rover approved diagnostic equipment, reconfigure the door module with the latest level software
U200D-11	Control Module Output Power A - Circuit short to ground	Door switchpack circuit short circuit to ground	Refer to the electrical circuit diagrams and check the door switchpack power circuit for short circuit to ground
U2010-11	Switch Illumination - Circuit short to ground	Door switchpack illumination circuit short circuit to ground	Refer to the electrical circuit diagrams and check the door switchpack illumination circuit for short circuit to ground
U2010-15	Switch Illumination - Circuit short to battery or open	Door switchpack illumination circuit short circuit to power, open circuit, high resistance	Refer to the electrical circuit diagrams and check the door switchpack illumination circuit for short circuit to power, open circuit, high resistance

DTC	DESCRIPTION	POSSIBLE CAUSES	ACTION
U201A-56	Control Module Main Calibration Data - Invalid/incomplete configuration	■ Car configuration file mismatch with vehicle specification	NOTES: ■ Do NOT install a new Door module as this will NOT rectify the fault ■ After updating the car configuration file, set the ignition to on and wait 30 seconds before clearing the DTCs ■ Using the Jaguar Land Rover approved diagnostic equipment, check and update the car configuration file as necessary. Clear the DTCs and retest

cmVIX2FZzsyMDiILTEyLTESVDA2OjUjOjA5LjkzNVo7MjA3LjE4MS4zLjEzMt1TQUpERDFHWD RMQ0s2NzO5Nw==