

GENERAL INFORMATION

DIAGNOSTIC TROUBLE CODE INDEX - DTC:
GATEWAY MODULE [GWM] [G2044759]

DESCRIPTION AND OPERATION

GATEWAY MODULE [GWM]

CAUTION:

Diagnosis by substitution from a donor vehicle is **NOT** acceptable. Substitution of control modules does not guarantee confirmation of a fault, and may also cause additional faults in the vehicle being tested and/or the donor vehicle

NOTES:

- Guided Diagnostics must be followed and the repair advised by the process completed. Failure to do so may result in the rejection of any warranty claim made.
- If the control module or a component is at fault or may be at fault and the vehicle remains under manufacturer warranty, refer to the warranty policy and procedures manual, or determine if any prior approval program is in operation, prior to the installation of a new module/component
- Generic scan tools may not read the codes listed, or may read only 5-digit codes. Match the 5 digits from the scan tool to the first 5 digits of the 7-digit code listed to identify the fault (the last 2 digits give extra information read by the manufacturer-approved diagnostic system)
- When performing voltage or resistance tests, always use a digital multimeter that has the resolution ability to view 3 decimal places. For example, on the 2 volts range can measure 1mV or 2 K Ohm range can measure 1 Ohm. When testing resistance always take the resistance of the digital multimeter leads into account
- Check and rectify basic faults before beginning diagnostic routines involving pinpoint tests
- Inspect connectors for signs of water ingress, and pins for damage and/or corrosion
- If Diagnostic Trouble Code(s) are recorded and, after performing the pinpoint tests, a fault is not present, an intermittent concern may be the cause. Always check for loose connections and corroded terminals
- Where an 'on demand self-test' is referred to, this can be accessed through the 'diagnostic trouble code monitor' tab on the manufacturers approved diagnostic system
- Check the JLR claims submission system for open campaigns. Refer to the corresponding bulletins and SSMS which may be valid for the specific customer complaint and complete the recommendations as required.

The table below lists all Diagnostic Trouble Code(s) that could be set in the gateway module, for additional diagnosis and testing information refer to the relevant diagnosis and testing section. For additional information, refer to: [Battery](#) (414-01 Battery, Mounting and Cables, Removal and Installation).

DTC	DESCRIPTION	POSSIBLE CAUSES	ACTION
B11DB-49	Battery Monitoring Module A - Internal electronic failure	Battery monitoring system control module - Internal failure	Using the Jaguar Land Rover approved diagnostic equipment, refer to the "Auto Stop system" Guided Diagnostic. This test can be found by navigating to Guided Diagnostics, Powertrain, Engine, Auto Stop-Start system
B11DB-87	Battery Monitoring Module A - Missing message	NOTE: Circuit reference - LIN_1_GWM - - Battery monitoring system control module wiring connector fault - Battery monitoring system control module circuit short circuit to ground, open circuit, high resistance - LIN 1 bus circuit fault - Battery monitoring control module internal failure	Using the Jaguar Land Rover approved diagnostic equipment, refer to the "Auto Stop system" Guided Diagnostic. This test can be found by navigating to Guided Diagnostics, Powertrain, Engine, Auto Stop-Start system
B12CD-16	Voltage Quality Module - Circuit voltage below threshold	NOTE: Circuit reference - LIN_2_GWM - - Voltage quality module connector fault - Voltage quality module power or ground circuit short circuit to ground, open circuit, high resistance - LIN 2 bus circuit short circuit to ground, short circuit to power, open circuit, high resistance - Voltage quality module internal failure	- Refer to the electrical circuit diagrams and check the integrity of the voltage quality module circuit connections at both ends. Rectify as required - Refer to the electrical circuit diagrams and check the voltage quality module power and ground circuits for short circuit to ground, open circuit, high resistance. Repair circuit as required. Clear DTC and retest - Refer to the electrical circuit diagrams and check the LIN 2 bus circuit between the gateway module and the voltage quality module (at central junction box connector C, pin 58) for short circuit to ground, short circuit to power, open circuit, high resistance. Repair circuit as required. Clear DTC and retest - If the fault persists, clear the Diagnostic Trouble Code(s) lock the vehicle and wait 4 minutes. Unlock the vehicle and retest. If the fault persists, raise a Technical Assistance (TA)
B12CD-19	Voltage Quality Module - Circuit current above threshold	NOTE: Circuit reference - LIN_2_GWM - - Voltage quality module connector fault - Voltage quality module power or ground circuit open circuit, high resistance - LIN 2 bus circuit short circuit to ground, short circuit to power, open circuit, high resistance - Voltage quality module internal failure	- Refer to the electrical circuit diagrams and check the integrity of the voltage quality module circuit connections at both ends. Rectify as required - Refer to the electrical circuit diagrams and check the voltage quality module power and ground circuits for open circuit, high resistance. Repair circuit as required. Clear DTC and retest - Refer to the electrical circuit diagrams and check the LIN 2 bus circuit between the gateway module and the voltage quality module (at central junction box connector C, pin 58) for short circuit to ground, short circuit to power, open circuit, high resistance. Repair circuit as required. Clear DTC and retest - If the fault persists, clear the Diagnostic Trouble Code(s) lock the vehicle and wait 4 minutes. Unlock the vehicle and retest. If the fault persists, raise a Technical Assistance (TA)

DTC	DESCRIPTION	POSSIBLE CAUSES	ACTION
B12CD-87	Voltage Quality Module - Missing message	NOTE: Circuit reference - LIN_2_GWM - - Gateway module has not received expected signals from the voltage quality module - Voltage quality module power or ground circuit short circuit to ground, open circuit, high resistance - LIN 2 bus circuit short circuit to ground, short circuit to power, open circuit, high resistance - Voltage quality module internal failure	- Check the integrity of the voltage quality module circuit connectors. Rectify as required - Refer to the electrical circuit diagrams and check the voltage quality module power and ground circuits for short circuit to ground, open circuit, high resistance. Repair the circuit as required. Clear the Diagnostic Trouble Code(s) and retest - Refer to the electrical circuit diagrams and check the LIN 2 bus circuit between the gateway module and the voltage quality module (at central junction box connector C, pin 58) for short circuit to ground, short circuit to power, open circuit, high resistance. Repair circuit as required - Clear the Diagnostic Trouble Code(s) lock the vehicle and wait 4 minutes. Unlock the vehicle and retest. If the fault persists, raise a Technical Assistance (TA)
B12CD-92	Voltage Quality Module - Performance or incorrect operation	NOTE: Circuit reference - LIN_2_GWM - - Gateway module has not received expected signals from the voltage quality module - Voltage quality module power or ground circuit short circuit to ground, open circuit, high resistance - LIN 2 bus circuit short circuit to ground, short circuit to power, open circuit, high resistance - Voltage quality module internal failure	- Refer to the electrical circuit diagrams and check the integrity of the voltage quality module circuit connections at both ends. Rectify as required - Refer to the electrical circuit diagrams and check the voltage quality module power and ground circuits for short circuit to ground, open circuit, high resistance. Repair the wiring harness as required. Clear the Diagnostic Trouble Code(s) and retest - Refer to the electrical circuit diagrams and check the LIN 2 bus circuit between the gateway module and the voltage quality module (at central junction box connector C, pin 58) for short circuit to ground, short circuit to power, open circuit, high resistance. Repair circuit as required - Using the Jaguar Land Rover approved diagnostic equipment; clear the Diagnostic Trouble Code(s) lock the vehicle and wait 4 minutes. Unlock the vehicle and retest. If the fault persists, raise a Technical Assistance (TA)
B12CD-96	Voltage Quality Module - Component internal failure	NOTE: Circuit reference - LIN_2_GWM - - Voltage quality module power or ground circuit open circuit, high resistance - LIN 2 bus circuit short circuit to ground, short circuit to power, open circuit, high resistance - Voltage quality module internal failure	- Refer to the electrical circuit diagrams and check the integrity of the voltage quality module circuit connections at both ends. Rectify as required - Refer to the electrical circuit diagrams and check the voltage quality module power and ground circuits for short circuit to ground, open circuit, high resistance. Repair circuit as required. Clear the Diagnostic Trouble Code(s) and retest - Refer to the electrical circuit diagrams and check the LIN 2 bus circuit between the gateway module and the voltage quality module (at central junction box connector C, pin 58) for short circuit to ground, short circuit to power, open circuit, high resistance. Repair circuit as required - Using the Jaguar Land Rover approved diagnostic equipment, clear the Diagnostic Trouble Code(s) and retest. If the fault persists, clear the Diagnostic Trouble Code(s) lock the vehicle and wait 4 minutes. Unlock the vehicle and retest. If the fault persists, raise a Technical Assistance (TA)

DTC	DESCRIPTION	POSSIBLE CAUSES	ACTION
B1404-13	Charging System - Circuit open	■ Battery/charging system fault ■ Generator internal failure	■ Using the Jaguar Land Rover approved diagnostic equipment, perform routine - Power Supply Service Mode (0x2027), to confirm the correct mode is operational . Clear the Diagnostic Trouble Code(s) and retest ■ If the fault persists, check and install a new generator as required
B1412-09	Quiescent Relay Box - Component failures	NOTE: Circuit reference - LIN_1_GWM - ■ Quiescent current control module power or ground circuit(s) open circuit, high resistance ■ LIN 1 bus circuit short circuit to ground, short circuit to power, open circuit, high resistance ■ Quiescent current control module internal failure	■ Refer to the electrical circuit diagrams and check the quiescent current control module power and ground circuits for open circuit, high resistance. Repair circuit as required ■ If fault persists, refer to the electrical circuit diagrams and check the LIN 1 bus circuit between the gateway module and the quiescent current control module (at central junction box connector C, pin 57) for short circuit to ground, short circuit to power, open circuit, high resistance. Repair circuit as required ■ Using the Jaguar Land Rover approved diagnostic equipment, clear the Diagnostic Trouble Code(s) and retest. If the fault persists, install a new quiescent current control module
B1412-87	Quiescent Relay Box - Missing message	NOTE: Circuit reference - LIN_1_GWM - ■ LIN 1 bus circuit short circuit to ground, short circuit to power, open circuit, high resistance ■ Quiescent current control module internal failure	■ If fault persists, refer to the electrical circuit diagrams and check the LIN 1 bus circuit between the gateway module and the quiescent current control module (at central junction box connector C, pin 57) for short circuit to ground, short circuit to power, open circuit, high resistance. Repair circuit as required. Clear DTC and retest ■ If the fault persists, install a new quiescent current control module as required
B1412-96	Quiescent Relay Box - Component internal failure	■ Quiescent current control module internal failure	■ Using the Jaguar Land Rover approved diagnostic equipment, run application - GWM Quiescent Relay Contact Clean. Clear the DTCs and retest. If the fault persists, install a new quiescent current control module
B1479-08	Power Supply Distribution Box - Bus signal/message failures	NOTE: Circuit reference - LIN_2_GWM - ■ Auxiliary battery wiring harness connector fault ■ LIN 2 bus circuit short circuit to ground, short circuit to power, open circuit, high resistance ■ Power supply distribution box circuit short circuit to ground, open circuit, high resistance ■ Power supply distribution box internal failure	■ Refer to the electrical circuit diagrams and check the integrity of the auxiliary battery circuit connections at the battery terminals and at the power supply distribution box. Rectify as required ■ Refer to the electrical circuit diagrams and check the LIN 2 bus circuit between the gateway module and the power supply distribution box (at central junction box connector C, pin 58) for short circuit to ground, short circuit to power, open circuit, high resistance. Repair circuit as required ■ Refer to the electrical circuit diagrams and check the power supply distribution box circuit for short circuit to ground, short circuit to power, open circuit, high resistance. Repair the wiring harness as necessary ■ Using the Jaguar Land Rover approved diagnostic equipment; clear the Diagnostic Trouble Code(s) lock the vehicle and wait 2 minutes. Unlock the vehicle and retest. If the fault persists, raise a Technical Assistance (TA)

DTC	DESCRIPTION	POSSIBLE CAUSES	ACTION
B1479-14	Power Supply Distribution Box - Circuit short to ground or open	NOTE: Circuit reference - VBATT_2 - - Auxiliary battery wiring harness connector fault - Power supply distribution box circuit short circuit to ground, open circuit, high resistance - Power supply distribution box internal failure	- Refer to the electrical circuit diagrams and check the integrity of the auxiliary battery circuit connections at the battery terminals and at the power supply distribution box. Rectify as required - Refer to the electrical circuit diagrams and check the power supply distribution box circuit between the gateway module and the power supply distribution box (at central junction box connector F, pin 1) for short circuit to ground, open circuit, high resistance. Repair circuit as required - Using the Jaguar Land Rover approved diagnostic equipment; clear the Diagnostic Trouble Code(s) lock the vehicle and wait 2 minutes. Unlock the vehicle and retest. If the fault still persists, raise a Technical Assistance (TA)
B1479-72	Power Supply Distribution Box - Actuator stuck open	NOTE: Circuit reference - VBATT_2 - - Auxiliary battery wiring harness connector fault - Power supply distribution box circuit short circuit to ground, open circuit, high resistance - Power supply distribution box internal failure	- Refer to the electrical circuit diagrams and check the integrity of the auxiliary battery circuit connections at the battery terminals and at the power supply distribution box. Rectify as required - Refer to the electrical circuit diagrams and check the power supply distribution box circuit between the gateway module and the power supply distribution box (at central junction box connector F, pin 1) for short circuit to ground, open circuit, high resistance. Repair circuit as required - Using the Jaguar Land Rover approved diagnostic equipment; clear the Diagnostic Trouble Code(s) lock the vehicle and wait 2 minutes. Unlock the vehicle and retest. If the fault still persists, raise a Technical Assistance (TA)
B1479-73	Power Supply Distribution Box - Actuator stuck closed	NOTE: Circuit reference - VBATT_2 - - Auxiliary battery wiring harness connector fault - Power supply distribution box circuit short circuit to ground, open circuit, high resistance - Power supply distribution box internal failure	- Refer to the electrical circuit diagrams and check the integrity of the auxiliary battery circuit connections at the battery terminals and at the power supply distribution box. Rectify as required - Refer to the electrical circuit diagrams and check the power supply distribution box circuit between the gateway module and the power supply distribution box (at central junction box connector F, pin 1) for short circuit to ground, open circuit, high resistance. Repair circuit as required - Using the Jaguar Land Rover approved diagnostic equipment, clear the Diagnostic Trouble Code(s), lock the vehicle and wait 2 minutes. Unlock the vehicle and retest. If the fault still persists, raise a Technical Assistance (TA)
B1479-96	Power Supply Distribution Box - Component internal failure	NOTE: Circuit reference - VBATT_2 - - Auxiliary battery wiring harness connector fault - Power supply distribution box circuit short circuit to ground, open circuit, high resistance - Power supply distribution box internal failure	- Refer to the electrical circuit diagrams and check the integrity of the auxiliary battery circuit connections at the battery terminals and at the power supply distribution box. Rectify as required - Refer to the electrical circuit diagrams and check the power supply distribution box circuit between the gateway module and the power supply distribution box (at central junction box connector F, pin 1) for short circuit to ground, open circuit, high resistance. Repair circuit as required - Using the Jaguar Land Rover approved diagnostic equipment, clear the Diagnostic Trouble Code(s), lock the vehicle and wait 2 minutes. Unlock the vehicle and retest. If the fault still persists, install a new power supply distribution box as required

DTC	DESCRIPTION	POSSIBLE CAUSES	ACTION
B1479-98	Power Supply Distribution Box - Component or system over temperature	■ Auxiliary battery wiring harness connector fault ■ Power supply distribution box circuit short circuit to ground, open circuit, high resistance ■ Power supply distribution box - Over temperature event	■ Refer to the electrical circuit diagrams and check the integrity of the auxiliary battery circuit connections at the battery terminals and at the power supply distribution box. Rectify as required ■ Refer to the electrical circuit diagrams and check the power supply distribution box circuit between the gateway module and the power supply distribution box (at central junction box connector F, pin 1) for short circuit to ground, open circuit, high resistance. Repair circuit as required ■ Allow the vehicle to cool. Using the Jaguar Land Rover approved diagnostic equipment; clear the Diagnostic Trouble Code(s) lock the vehicle and wait 2 minutes. Unlock the vehicle and run the engine for 5 minutes with all electrical loads on. If the fault persists, raise a Technical Assistance (TA)
P0620-00	Generator Control Circuit - No sub type information	NOTE: Circuit reference - LIN_3_GWM - ■ Accessory drive belt incorrect tension ■ Generator wiring harness connector fault ■ Generator power circuit short circuit to ground, open circuit, high resistance ■ LIN 3 bus circuit short circuit to ground, short circuit to power, open circuit, high resistance ■ Generator internal failure	■ Check the accessory drive belt tension and rectify as required ■ Check with the integrity of the generator circuit connectors. Rectify as required ■ Refer to the electrical circuit diagrams and check the generator power circuit for short circuit to ground, open circuit, high resistance. Repair the wiring harness as necessary ■ Refer to the electrical circuit diagrams and check the LIN 3 bus circuit between the gateway module and the generator (at central junction box connector H, pin 41) for short circuit to ground, short circuit to power, open circuit, high resistance. Repair circuit as required ■ Using the Jaguar Land Rover Approved Diagnostic Equipment, perform routine - Power Supply Service Mode, to confirm the correct mode is operational. Clear the Diagnostic Trouble Code(s) and retest ■ If the fault persists, check and install a new generator as required
P065B-16	Generator Control Circuit Range/Performance - Circuit voltage below threshold	NOTE: Circuit reference - LIN_3_GWM - ■ Startup battery discharged ■ Startup battery wiring harness connector fault ■ Generator wiring harness connector fault ■ Generator power circuit short circuit to ground, open circuit, high resistance ■ LIN 3 bus circuit short circuit to ground, short circuit to power, open circuit, high resistance ■ Generator internal failure	NOTE: If P620-00, P065C-01, P0A1A-87 or P0A3B-68 are also set, perform the relevant corrective actions for these Diagnostic Trouble Code(s) first and retest. ■ Refer to the relevant section of the workshop manual and test the startup battery ■ Check the integrity of the startup battery connectors and rectify as required ■ Check the integrity of the generator circuit connectors. Rectify as required ■ Refer to the electrical circuit diagrams and check the generator power circuit for short circuit to ground, open circuit, high resistance. Repair the wiring harness as necessary ■ Refer to the electrical circuit diagrams and check the LIN 3 bus circuit between the gateway module and the generator (at central junction box connector H, pin 41) for short circuit to ground, short circuit to power, open circuit, high resistance. Repair circuit as required. Clear DTC and retest ■ If the fault persists, install a new generator as required

DTC	DESCRIPTION	POSSIBLE CAUSES	ACTION
P065B-17	Generator Control Circuit Range/Performance - Circuit voltage above threshold	NOTE: Circuit reference - LIN_3_GWM - - Startup battery wiring harness connector fault - Generator wiring harness connector fault - LIN 3 bus circuit short circuit to ground, short circuit to power, open circuit, high resistance - Generator internal failure	NOTES: - This DTC may be induced by boost starting or battery charging. - If P620-00, P065C-01, P0A1A-87 or P0A3B-68 are also set, perform the relevant corrective actions for these Diagnostic Trouble Code(s) first and retest. - Check the integrity of the startup battery connectors and rectify as required - Check the integrity of the generator connectors and rectify as required - Refer to the electrical circuit diagrams and check the LIN 3 bus circuit between the gateway module and the generator (at central junction box connector H, pin 41) for short circuit to ground, short circuit to power, open circuit, high resistance. Repair circuit as required. Clear DTC and retest - If the fault persists, install a new generator as required
P065C-01	Generator Mechanical Performance - General electrical failure	- Accessory drive belt incorrect tension - Generator wiring harness connector fault - Generator power circuit short circuit to ground, open circuit, high resistance - LIN 3 bus circuit short circuit to ground, short circuit to power, open circuit, high resistance - Generator internal failure	- Check the accessory drive belt tension and rectify as required - Check the integrity of the generator circuit connectors. Rectify as required - Refer to the electrical circuit diagrams and check the generator power circuit for short circuit to ground, open circuit, high resistance. Repair the wiring harness as necessary - Refer to the electrical circuit diagrams and check the LIN 3 bus circuit between the gateway module and the generator (at the central junction box connector H, pin 41) for short circuit to ground, short circuit to power, open circuit, high resistance. Repair the wiring harness as required. Clear the Diagnostic Trouble Code(s) and retest - If the fault persists, install a new generator as required
P0A0F-71	Engine Failed To Start - Actuator stuck	- Powertrain system fault - Starter motor circuit (including starter relays) short circuit to ground, short circuit to power, open circuit, high resistance - Startup battery/charging system fault - Starter motor mechanical failure	- Using the Jaguar Land Rover approved diagnostic equipment, check the powertrain control module for related Diagnostic Trouble Code(s) and refer to the relevant DTC index - Refer to the electrical circuit diagrams and check the starter motor circuit (including starter relays) for short circuit to ground, short circuit to power, open circuit, high resistance. Repair as necessary - Refer to the relevant section of the workshop manual and check the startup battery and charging system. Rectify as necessary - Check the starter motor for mechanical failure. Replace as necessary. Using the Jaguar Land Rover approved diagnostic equipment, clear the Diagnostic Trouble Code(s) and retest

DTC	DESCRIPTION	POSSIBLE CAUSES	ACTION
POA1A-87	Generator Control Module - Missing message	NOTE: Circuit reference - LIN_3_GWM - - Startup battery wiring harness connector fault - Generator wiring harness connector fault - LIN 3 bus circuit short circuit to ground, short circuit to power, open circuit, high resistance - Generator internal failure	- Check the integrity of the startup battery connectors and rectify as required - Check the integrity of the generator connectors and rectify as required - Refer to the electrical circuit diagrams and check the LIN 3 bus circuit between the gateway module and the generator (at central junction box connector H, pin 41) for short circuit to ground, short circuit to power, open circuit, high resistance. Repair circuit as required. Clear DTC and retest - If the fault persists, install a new generator as required. Clear DTC and retest
POA3B-68	Generator Over Temperature - Event information	- Generator over temperature event - Generator internal failure	- Check generator wiring and connectors for evidence of heat damage. Investigate the cause of generator over temperature event. Using the Jaguar Land Rover approved diagnostic equipment, clear the Diagnostic Trouble Code(s) and retest - If the fault persists install a new generator as required
U0028-81	Vehicle Communication Bus A - Invalid serial data received	Invalid data received from another control module through the high speed CAN bus (powertrain)	Using the Jaguar Land Rover approved diagnostic equipment, check the snapshot data to determine the invalid data source control module. Check the relevant control module for related Diagnostic Trouble Code(s) and refer to the relevant DTC index
U0028-87	Vehicle Communication Bus A - Missing message	Missing message from another control module through the high speed CAN bus (powertrain)	Using the Jaguar Land Rover approved diagnostic equipment, check the snapshot data to determine the missing message source control module. Check the relevant control module for related Diagnostic Trouble Code(s) and refer to the relevant DTC index
U0028-88	Vehicle Communication Bus A - Bus off	High speed CAN bus (powertrain) circuit - Short circuit to ground, short circuit to power, open circuit, high resistance	Using the Jaguar Land Rover approved diagnostic equipment, perform a CAN network integrity test. Refer to the electrical circuit diagrams and check the high speed CAN bus (powertrain) circuit for short circuit to ground, short circuit to power, open circuit, high resistance
U0037-81	Vehicle Communication Bus B - Invalid serial data received	Invalid data received from another control module through the high speed CAN bus (chassis)	Using the Jaguar Land Rover approved diagnostic equipment, check the snapshot data to determine the invalid data source control module. Check the relevant control module for related Diagnostic Trouble Code(s) and refer to the relevant DTC index
U0037-87	Vehicle Communication Bus B - Missing message	Missing message from another control module through the high speed CAN bus (chassis)	Using the Jaguar Land Rover approved diagnostic equipment, check the snapshot data to determine the missing message source control module. Check the relevant control module for related Diagnostic Trouble Code(s) and refer to the relevant DTC index
U0037-88	Vehicle Communication Bus B - Bus off	High speed CAN bus (chassis) circuit - Short circuit to ground, short circuit to power, open circuit, high resistance	Using the Jaguar Land Rover approved diagnostic equipment, perform a CAN network integrity test. Refer to the electrical circuit diagrams and check the high speed CAN bus (chassis) circuit for short circuit to ground, short circuit to power, open circuit, high resistance

DTC	DESCRIPTION	POSSIBLE CAUSES	ACTION
U0046-87	Vehicle Communication Bus C - Missing message	Missing message from another control module through the high speed CAN bus (hybrid)	Using the Jaguar Land Rover approved diagnostic equipment, check the snapshot data to determine the missing message source control module. Check the relevant control module for related Diagnostic Trouble Code(s) and refer to the relevant DTC index
U0046-88	Vehicle Communication Bus C - Bus off	High speed CAN bus (hybrid) circuit short circuit to ground, short circuit to power, open circuit, high resistance	Using the Jaguar Land Rover approved diagnostic equipment, perform a CAN network integrity test. Refer to the electrical circuit diagrams and check the high speed CAN bus (hybrid) circuit for short circuit to ground, short circuit to power, open circuit, high resistance
U0055-87	Vehicle Communication Bus D - Missing message	Missing message from another control module through the medium speed CAN bus (body)	Using the Jaguar Land Rover approved diagnostic equipment, check the snapshot data to determine the missing message source control module. Check the relevant control module for related Diagnostic Trouble Code(s) and refer to the relevant DTC index
U0055-88	Vehicle Communication Bus D - Bus off	- Medium speed CAN bus (body) circuit short circuit to ground, short circuit to power, open circuit, high resistance - Missing message from another control module through the medium speed CAN bus (body)	- Using the Jaguar Land Rover approved diagnostic equipment, perform a CAN network integrity test. Refer to the electrical circuit diagrams and check the medium speed CAN bus (body) circuit for short circuit to ground, short circuit to power, open circuit, high resistance - Using the Jaguar Land Rover approved diagnostic equipment, check the snapshot data to determine the missing message source control module. Check the relevant control module for related Diagnostic Trouble Code(s) and refer to the relevant DTC index
U0064-87	Vehicle Communication Bus E - Missing message	Missing message from another control module through the medium speed CAN bus (comfort)	Using the Jaguar Land Rover approved diagnostic equipment, check the snapshot data to determine the missing message source control module. Check the relevant control module for related Diagnostic Trouble Code(s) and refer to the relevant DTC index
U0064-88	Vehicle Communication Bus E - Bus off	Medium speed CAN bus (comfort) circuit short circuit to ground, short circuit to power, open circuit, high resistance	Using the Jaguar Land Rover approved diagnostic equipment, perform a CAN network integrity test. Refer to the electrical circuit diagrams and check the medium speed CAN bus (comfort) circuit for short circuit to ground, short circuit to power, open circuit, high resistance
U0300-46	Internal Control Module Software Incompatibility - Calibration/parameter memory failure	Gateway module is not configured correctly	Using the Jaguar Land Rover approved diagnostic equipment, reconfigure the gateway module with the latest level software. Clear the Diagnostic Trouble Code(s) and retest. If the fault persists, clear the Diagnostic Trouble Code(s), lock the vehicle and wait 2 minutes. Unlock the vehicle and retest. If the fault persists, install a new central junction box

DTC	DESCRIPTION	POSSIBLE CAUSES	ACTION
U1A14-00	CAN Initialisation Failure - No sub type information	- Gateway module power or ground circuit open circuit, high resistance - High speed CAN bus (chassis or powertrain) circuit short circuit to ground, short circuit to power, open circuit, high resistance - Medium speed CAN bus (body or comfort) circuit short circuit to ground, short circuit to power, open circuit, high resistance - Gateway module internal failure	- Refer to the electrical circuit diagrams and check the gateway module power and ground circuits for open circuit, high resistance - Using the Jaguar Land Rover approved diagnostic equipment, perform a CAN network integrity test. Refer to the electrical circuit diagrams and check the high speed CAN bus (chassis and powertrain) circuit for short circuit to ground, short circuit to power, open circuit, high resistance - Using the Jaguar Land Rover approved diagnostic equipment, perform a CAN network integrity test. Refer to the electrical circuit diagrams and check the medium speed CAN bus (body and comfort) circuit for short circuit to ground, short circuit to power, open circuit, high resistance - Using the Jaguar Land Rover approved diagnostic equipment, clear the Diagnostic Trouble Code(s) and retest. If the fault persists, install a new central junction box
U2100-00	Initial Configuration Not Complete - No sub type information	- Body control module is not configured correctly - Gateway module is not configured correctly	- Using the Jaguar Land Rover approved diagnostic equipment, reconfigure the body control module with the latest level software - Using the Jaguar Land Rover approved diagnostic equipment, reconfigure the gateway module with the latest level software
U2300-41	Central Configuration - General checksum failure	Car configuration file mismatch with vehicle specification	Using the Jaguar Land Rover approved diagnostic equipment, check and update the car configuration file as necessary
U2300-51	Central Configuration - Not programed	Car configuration file mismatch with vehicle specification	Using the Jaguar Land Rover approved diagnostic equipment, check and update the car configuration file as necessary
U2300-54	Central Configuration - Missing calibration	Car configuration file mismatch with vehicle specification	Using the Jaguar Land Rover approved diagnostic equipment, check and update the car configuration file as necessary
U2300-56	Central Configuration - Invalid/incomplete configuration	Car configuration file mismatch with vehicle specification	Using the Jaguar Land Rover approved diagnostic equipment, check and update the car configuration file as necessary
U2300-57	Central Configuration - Invalid/incomplete software component	Car configuration file mismatch with vehicle specification	Using the Jaguar Land Rover approved diagnostic equipment, check and update the car configuration file as necessary
U2300-64	Central Configuration - Signal plausibility failure	Car configuration file mismatch with vehicle specification	Using the Jaguar Land Rover approved diagnostic equipment, check and update the car configuration file as necessary
U3000-04	Control Module - System internal failures	Gateway module internal failure	Using the Jaguar Land Rover approved diagnostic equipment, reconfigure the gateway module with the latest level software. Clear the Diagnostic Trouble Code(s), lock the vehicle and wait 2 minutes. Unlock the vehicle and retest. If the fault persists, install a new gateway module