

GENERAL INFORMATION

DIAGNOSTIC TROUBLE CODE INDEX - DTC:  
INFOTAINMENT MASTER CONTROLLER (IMC)

[G2008131]

DESCRIPTION AND OPERATION

INFOTAINMENT MASTER CONTROLLER (IMC)

CAUTION:

Diagnosis by substitution from a donor vehicle is **NOT** acceptable. Substitution of control modules does not guarantee confirmation of a fault, and may also cause additional faults in the vehicle being tested and/or the donor vehicle.

NOTES:

- Guided Diagnostics must be followed and the repair advised by the process completed. Failure to do so may result in the rejection of any warranty claim made.
- If a control module or a component is not to specification and the vehicle remains under manufacturer warranty, refer to the Warranty Policy and Procedures manual, or determine if any prior approval program is in operation, prior to the installation of a new module/component.
- Generic scan tools may not read the codes listed, or may read only 5-digit codes. Match the 5 digits from the scan tool to the first 5 digits of the 7-digit code listed to identify the fault (the last 2 digits give extra information read by the manufacturer-approved diagnostic system).
- When performing voltage or resistance tests, always use a digital multimeter that has the resolution ability to view 3 decimal places. For example, on the 2 volts range can measure 1mV or 2 K Ohm range can measure 1 Ohm. When testing resistance always take the resistance of the digital multimeter leads into account.
- Inspect and rectify basic faults before beginning diagnostic routines involving pinpoint tests.
- Inspect connectors for signs of water ingress, and pins for damage and/or corrosion.
- If DTCs are recorded and, after performing the pinpoint tests, a fault is not present, an intermittent concern may be the cause. Always inspect for loose connections and corroded terminals.
- Check JLR claims submission system for open campaigns. Refer to the corresponding bulletins and SSMs which may be valid for the specific customer complaint and complete the recommendations as required.

The table below lists all Diagnostic Trouble Codes (DTCs) that could be set in the Infotainment Master Controller (IMC). For additional diagnosis and testing information, refer to the relevant Diagnosis and Testing section in the workshop manual.

| DTC      | DESCRIPTION                                                    | POSSIBLE CAUSES                                                                                                                                                                                                                    | ACTION                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                    |
|----------|----------------------------------------------------------------|------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------|---------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------|
| B1087-83 | LIN Bus "A" - Value of signal protection calculation incorrect | <ul style="list-style-type: none"> <li>Infotainment master controller is not configured correctly</li> </ul>                                                                                                                       | <ul style="list-style-type: none"> <li>Using the Jaguar Land Rover approved diagnostic equipment, reconfigure the infotainment master controller with the latest level software</li> <li>If the fault persists, do not replace the infotainment master controller. Contact the Jaguar Land Rover service desk for further assistance</li> </ul>                                                                                                                                                                                                                           |
| B1087-86 | LIN Bus "A" - Signal invalid                                   | <ul style="list-style-type: none"> <li>Steering wheel switchpack power or ground circuit open circuit, high resistance</li> <li>Infotainment master controller is not configured correctly</li> </ul>                              | <ul style="list-style-type: none"> <li>Refer to the electrical circuit diagrams and check the steering wheel switchpack power and ground circuits for open circuit, high resistance. Repair the wiring harness as necessary</li> <li>Using the Jaguar Land Rover approved diagnostic equipment, reconfigure the infotainment master controller with the latest level software</li> <li>If the fault persists, do not replace the infotainment master controller. Contact the Jaguar Land Rover service desk for further assistance</li> </ul>                             |
| B1087-87 | LIN Bus "A" - Missing message                                  | <ul style="list-style-type: none"> <li>Steering wheel switchpack power or ground circuit, intermittent short circuit, open circuit, high resistance</li> <li>Infotainment master controller is not configured correctly</li> </ul> | <ul style="list-style-type: none"> <li>Refer to the electrical circuit diagrams and check the steering wheel switchpack power and ground circuits for intermittent short circuit, open circuit, high resistance. Repair the wiring harness as necessary</li> <li>Using the Jaguar Land Rover approved diagnostic equipment, reconfigure the infotainment master controller with the latest level software</li> <li>If the fault persists, do not replace the infotainment master controller. Contact the Jaguar Land Rover service desk for further assistance</li> </ul> |
| B1087-88 | LIN Bus "A" - Bus off                                          | <ul style="list-style-type: none"> <li>Steering wheel switchpack power or ground circuit open circuit, high resistance</li> <li>Infotainment master controller is not configured correctly</li> </ul>                              | <ul style="list-style-type: none"> <li>Refer to the electrical circuit diagrams and check the steering wheel switchpack power and ground circuits for open circuit, high resistance. Repair the wiring harness as necessary</li> <li>Using the Jaguar Land Rover approved diagnostic equipment, reconfigure the infotainment master controller with the latest level software</li> <li>If the fault persists, do not replace the infotainment master controller. Contact the Jaguar Land Rover service desk for further assistance</li> </ul>                             |
| B119F-11 | GPS Antenna - Circuit short to ground                          | <ul style="list-style-type: none"> <li>Global positioning system antenna circuit short circuit to ground</li> </ul>                                                                                                                | <ul style="list-style-type: none"> <li>Refer to the electrical circuit diagrams and check the global positioning system antenna circuit for short circuit to ground</li> </ul>                                                                                                                                                                                                                                                                                                                                                                                            |
| B119F-15 | GPS Antenna - Circuit short to battery or open                 | <ul style="list-style-type: none"> <li>Global positioning system antenna circuit short circuit to power, open circuit, high resistance</li> </ul>                                                                                  | <ul style="list-style-type: none"> <li>Refer to the electrical circuit diagrams and check the global positioning system antenna circuit for short circuit to power, open circuit, high resistance</li> </ul>                                                                                                                                                                                                                                                                                                                                                              |
| B11A4-11 | L-Band Antenna - Circuit short to ground                       | <ul style="list-style-type: none"> <li>Digital radio L-band antenna circuit short circuit to ground</li> </ul>                                                                                                                     | <ul style="list-style-type: none"> <li>Refer to the electrical circuit diagrams and check the digital radio L-band antenna circuit for short circuit to ground</li> </ul>                                                                                                                                                                                                                                                                                                                                                                                                 |
| B11A4-12 | L-Band Antenna - Circuit short to battery                      | <ul style="list-style-type: none"> <li>Digital radio L-band antenna circuit short circuit to power</li> </ul>                                                                                                                      | <ul style="list-style-type: none"> <li>Refer to the electrical circuit diagrams and check the digital radio L-band antenna circuit for short circuit to power</li> </ul>                                                                                                                                                                                                                                                                                                                                                                                                  |

| DTC      | DESCRIPTION                                          | POSSIBLE CAUSES                                                                                                                                                                                                                                                                                                                                                                                                                   | ACTION                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                    |
|----------|------------------------------------------------------|-----------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------|---------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------|
| B11A4-13 | L-Band Antenna - Circuit open                        | <ul style="list-style-type: none"> <li>Digital radio L-band antenna circuit open circuit, high resistance</li> </ul>                                                                                                                                                                                                                                                                                                              | <ul style="list-style-type: none"> <li>Refer to the electrical circuit diagrams and check the digital radio L-band antenna circuit for open circuit, high resistance</li> </ul>                                                                                                                                                                                                                                                                                                                                                                                                                                           |
| B11A5-11 | Band 3 Antenna - Circuit short to ground             | <ul style="list-style-type: none"> <li>Digital radio band 3 antenna circuit short circuit to ground</li> </ul>                                                                                                                                                                                                                                                                                                                    | <ul style="list-style-type: none"> <li>Refer to the electrical circuit diagrams and check the digital radio band 3 antenna circuit for short circuit to ground</li> </ul>                                                                                                                                                                                                                                                                                                                                                                                                                                                 |
| B11A5-12 | Band 3 Antenna - Circuit short to battery            | <ul style="list-style-type: none"> <li>Digital radio band 3 antenna circuit short circuit to power</li> </ul>                                                                                                                                                                                                                                                                                                                     | <ul style="list-style-type: none"> <li>Refer to the electrical circuit diagrams and check the digital radio band 3 antenna circuit for short circuit to power</li> </ul>                                                                                                                                                                                                                                                                                                                                                                                                                                                  |
| B11A5-13 | Band 3 Antenna - Circuit open                        | <ul style="list-style-type: none"> <li>Digital radio band 3 antenna circuit open circuit, high resistance</li> </ul>                                                                                                                                                                                                                                                                                                              | <ul style="list-style-type: none"> <li>Refer to the electrical circuit diagrams and check the digital radio band 3 antenna circuit for open circuit, high resistance</li> </ul>                                                                                                                                                                                                                                                                                                                                                                                                                                           |
| B121C-93 | Hard Drive - No operation                            | <ul style="list-style-type: none"> <li>Infotainment master controller hard drive internal failure</li> </ul>                                                                                                                                                                                                                                                                                                                      | <ul style="list-style-type: none"> <li>Using the Jaguar Land Rover approved diagnostic equipment, reconfigure the infotainment master controller with the latest level software and retest</li> <li>If the fault persists, do not replace the infotainment master controller. Contact the Jaguar Land Rover service desk for further assistance</li> </ul>                                                                                                                                                                                                                                                                |
| B137F-31 | Steering Wheel Left Switch Pack - No signal          | <ul style="list-style-type: none"> <li>Steering wheel left switchpack power or ground circuit open circuit, high resistance</li> <li>LIN bus circuit short circuit to ground, short circuit to power, open circuit, high resistance</li> <li>Steering wheel left switchpack internal failure</li> </ul>                                                                                                                           | <ul style="list-style-type: none"> <li>Refer to the electrical circuit diagrams and check the steering wheel left switchpack power and ground circuits for open circuit, high resistance. Repair the wiring harness as necessary</li> <li>Refer to the electrical circuit diagrams and check the LIN bus circuit for short circuit to ground, short circuit to power, open circuit, high resistance. Repair the wiring harness as necessary</li> <li>Using the Jaguar Land Rover approved diagnostic equipment, clear the DTCs and retest. If the fault persists, install a new steering wheel left switchpack</li> </ul> |
| B1492-11 | Microphone #1 Input Signal - Circuit short to ground | <div> <p><b>NOTE:</b></p> <p>There are two different types of microphone installed to the vehicle. One type of microphone has one inner circuit and an outer screen while the other type has two inner circuits and an outer screen. Make sure all circuits are tested where appropriate</p> </div> <ul style="list-style-type: none"> <li>Infotainment master controller microphone 1 circuit short circuit to ground</li> </ul> | <div> <p><b>NOTE:</b></p> <p>If this DTC is set simultaneously with a number of DTCs including U200F-11, check symptoms for U200F-11 first, rectify the fault, clear DTCs and retest</p> </div> <ul style="list-style-type: none"> <li>Refer to the electrical circuit diagrams and check the infotainment master controller microphone 1 circuit for short circuit to ground. Repair the wiring harness as necessary</li> </ul>                                                                                                                                                                                          |

| DTC      | DESCRIPTION                                                           | POSSIBLE CAUSES                                                                                                                                                                                                                                                                                                | ACTION                                                                                                                                                                                                                                                                                                                                                                                                                                              |
|----------|-----------------------------------------------------------------------|----------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------|-----------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------|
| B1492-12 | Microphone #1 Input Signal - Circuit short to battery                 | <ul style="list-style-type: none"> <li>Infotainment master controller microphone 1 circuit short circuit to power</li> </ul>                                                                                                                                                                                   | <p><b>NOTE:</b></p> <p>If this DTC is set simultaneously with a number of DTCs including U200F-11, check symptoms for U200F-11 first, rectify the fault, clear DTCs and retest</p> <ul style="list-style-type: none"> <li>Refer to the electrical circuit diagrams and check the infotainment master controller microphone 1 circuit for short circuit to power. Repair the wiring harness as necessary</li> </ul>                                  |
| B1492-13 | Microphone #1 Input Signal - Circuit open                             | <ul style="list-style-type: none"> <li>Infotainment master controller microphone 1 circuit open circuit, high resistance</li> </ul>                                                                                                                                                                            | <p><b>NOTE:</b></p> <p>If this DTC is set simultaneously with a number of DTCs including U200F-11, check symptoms for U200F-11 first, rectify the fault, clear DTCs and retest</p> <ul style="list-style-type: none"> <li>Refer to the electrical circuit diagrams and check the infotainment master controller microphone 1 circuit for open circuit, high resistance. Repair the wiring harness as necessary</li> </ul>                           |
| B1492-15 | Microphone #1 Input Signal - Circuit short to battery or open circuit | <p><b>NOTE:</b></p> <p>The microphone has two inner circuits and an outer screen. Make sure both inner circuits are tested</p> <ul style="list-style-type: none"> <li>Infotainment master controller microphone 1 circuit open circuit, high resistance or short circuit to power</li> </ul>                   | <p><b>NOTE:</b></p> <p>If this DTC is set simultaneously with a number of DTCs including U200F-11, check symptoms for U200F-11 first, rectify the fault, clear DTCs and retest</p> <ul style="list-style-type: none"> <li>Refer to the electrical circuit diagrams and check the infotainment master controller microphone 1 circuit for open circuit, high resistance or short circuit to power. Repair the wiring harness as necessary</li> </ul> |
| B1492-1A | Microphone #1 Input Signal - Circuit Resistance Below Threshold       | <p><b>NOTE:</b></p> <p>The microphone has two inner circuits and an outer screen. Make sure both inner circuits are tested</p> <ul style="list-style-type: none"> <li>Infotainment master controller microphone 1 circuit low resistance or short circuit between the two inner microphone circuits</li> </ul> | <p><b>NOTE:</b></p> <p>If this DTC is set simultaneously with a number of DTCs including U200F-11, check symptoms for U200F-11 first, rectify the fault, clear DTCs and retest</p> <ul style="list-style-type: none"> <li>Refer to the electrical circuit diagrams and check the infotainment master controller microphone 1 circuit(s) for a low resistance or short circuit between the two inner microphone circuits</li> </ul>                  |
| B14A3-02 | APIX Display Link - User Interface Panel - General signal failure     | <ul style="list-style-type: none"> <li>See note</li> </ul>                                                                                                                                                                                                                                                     | <p><b>NOTE:</b></p> <p>This DTC is for event information only and does not indicate a fault.</p> <ul style="list-style-type: none"> <li>Ignore this DTC</li> </ul>                                                                                                                                                                                                                                                                                  |

| DTC      | DESCRIPTION                                                               | POSSIBLE CAUSES                                                                                                                                                                                                 | ACTION                                                                                                                                                                                                                                                                                                                                                          |
|----------|---------------------------------------------------------------------------|-----------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------|-----------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------|
| B14A3-31 | APIX Display Link - User Interface Panel - No signal                      | <ul style="list-style-type: none"> <li>Infotainment master controller portable audio interface panel APIX link active with no video</li> </ul>                                                                  | <ul style="list-style-type: none"> <li>Using the Jaguar Land Rover approved diagnostic equipment, update the infotainment master controller to the latest level software and retest</li> <li>If the fault persists, replace the portable audio interface panel and retest</li> <li>If the fault persists, replace the infotainment master controller</li> </ul> |
| B14A4-02 | APIX Display Link - Instrument Pack - General signal failure              | <ul style="list-style-type: none"> <li>Instrument Panel Cluster (IPC) APIX circuit open circuit, high resistance</li> </ul>                                                                                     | <ul style="list-style-type: none"> <li>Refer to the electrical circuit diagrams and check the Instrument Panel Cluster (IPC) APIX circuit for open circuit, high resistance. Repair the wiring harness as necessary</li> </ul>                                                                                                                                  |
| B14A5-08 | BroadR-Reach Link - Amplifier (+) - Bus signal/message failures           | <ul style="list-style-type: none"> <li>Audio amplifier module BroadR-Reach® circuit short circuit between positive and negative</li> </ul>                                                                      | <ul style="list-style-type: none"> <li>Refer to the electrical circuit diagrams and check the audio amplifier module BroadR-Reach® circuit for short circuit across BroadR-Reach® positive and negative pins</li> </ul>                                                                                                                                         |
| B14A5-13 | BroadR-Reach Link - Amplifier (+) - Circuit open                          | <ul style="list-style-type: none"> <li>Audio amplifier module BroadR-Reach® circuit open circuit, high resistance</li> </ul>                                                                                    | <ul style="list-style-type: none"> <li>Refer to the electrical circuit diagrams and check the audio amplifier module BroadR-Reach® circuit for open circuit, high resistance. Repair the wiring harness as necessary</li> </ul>                                                                                                                                 |
| B14A9-08 | BroadR-Reach Link - Telematics (+) - Bus signal/message failures          | <ul style="list-style-type: none"> <li>Telematics control module BroadR-Reach® circuit short circuit between positive and negative</li> </ul>                                                                   | <ul style="list-style-type: none"> <li>Refer to the electrical circuit diagrams and check the telematics control module BroadR-Reach® for short circuit across BroadR-Reach® positive and negative pins</li> </ul>                                                                                                                                              |
| B14A9-13 | BroadR-Reach Link - Telematics (+) - Circuit open                         | <ul style="list-style-type: none"> <li>Telematics control module BroadR-Reach® circuit open circuit, high resistance</li> </ul>                                                                                 | <ul style="list-style-type: none"> <li>Refer to the electrical circuit diagrams and check the telematics control module BroadR-Reach® circuit for open circuit, high resistance. Repair the wiring harness as necessary</li> </ul>                                                                                                                              |
| B14AC-11 | Audio Amplifier Wake-up/Enable Control - Circuit short to ground          | <div> <b>NOTE:</b><br/> Circuit reference - AMP WAKE UP - </div> <ul style="list-style-type: none"> <li>Audio amplifier module wake up circuit short circuit to ground</li> </ul>                               | <ul style="list-style-type: none"> <li>Refer to the electrical circuit diagrams and check the audio amplifier module wake up circuit for short circuit to ground. Repair the wiring harness as necessary</li> </ul>                                                                                                                                             |
| B14AC-15 | Audio Amplifier Wake-up/Enable Control - Circuit short to battery or open | <div> <b>NOTE:</b><br/> Circuit reference - AMP WAKE UP - </div> <ul style="list-style-type: none"> <li>Audio amplifier module wake up circuit short circuit to power, open circuit, high resistance</li> </ul> | <ul style="list-style-type: none"> <li>Refer to the electrical circuit diagrams and check the audio amplifier module wake up circuit for short circuit to power, open circuit, high resistance. Repair the wiring harness as necessary</li> </ul>                                                                                                               |

| DTC      | DESCRIPTION                                                              | POSSIBLE CAUSES                                                                                                                                                                                                                                                                             | ACTION                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                         |
|----------|--------------------------------------------------------------------------|---------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------|----------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------|
| B14AC-19 | Audio Amplifier Wake-up/Enable Control - Circuit current above threshold | <div> <b>NOTE:</b><br/> Circuit reference - AMP WAKE UP - </div> <ul style="list-style-type: none"> <li>Audio amplifier module wake up circuit short circuit to ground</li> <li>Audio amplifier module internal failure</li> <li>Infotainment master controller internal failure</li> </ul> | <ul style="list-style-type: none"> <li>Refer to the electrical circuit diagrams and check the audio amplifier module wake up circuit for short circuit to ground. Repair the wiring harness as necessary</li> <li>If the speakers do not function normally, using the Jaguar Land Rover approved diagnostic equipment, clear the DTCs and retest. If the fault persists, install a new audio amplifier module</li> <li>If the speakers function normally, using the Jaguar Land Rover approved diagnostic equipment, update the infotainment master controller to the latest level software and retest. If the fault persists, do not replace the infotainment master controller. Contact the Jaguar Land Rover service desk for further assistance</li> </ul> |
| B14AD-02 | Front Display Screen - General signal failure                            | <ul style="list-style-type: none"> <li>Touchscreen APIX circuit short circuit to ground, short circuit to power, open circuit, high resistance</li> </ul>                                                                                                                                   | <div> <b>NOTE:</b><br/> If this DTC is set simultaneously with a number of DTCs including U200F-11, check symptoms for U200F-11 first, rectify the fault, clear DTCs and retest </div> <ul style="list-style-type: none"> <li>Refer to the electrical circuit diagrams and check the touchscreen APIX circuit for short circuit to ground, short circuit to power, open circuit, high resistance. Repair the wiring harness as necessary</li> </ul>                                                                                                                                                                                                                                                                                                            |
| B14AD-05 | Front Display Screen - System programming failures                       | <ul style="list-style-type: none"> <li>Touchscreen programming failure</li> <li>Touchscreen internal failure</li> </ul>                                                                                                                                                                     | <ul style="list-style-type: none"> <li>Refer to the electrical circuit diagrams and check the integrity of the touchscreen power and ground circuits. Connect the manufacturer approved diagnostic tool and inspect to make sure the connections are secure before reconfiguring the touchscreen. Clear DTCs and retest</li> <li>If fault persists, replace the touchscreen</li> </ul>                                                                                                                                                                                                                                                                                                                                                                         |
| B14AD-16 | Front Display Screen - Circuit voltage below threshold                   | <ul style="list-style-type: none"> <li>Touchscreen power circuit short circuit to ground</li> <li>Battery/charging system fault</li> </ul>                                                                                                                                                  | <ul style="list-style-type: none"> <li>Refer to the electrical circuit diagrams and check the touchscreen power circuit for short circuit to ground. Repair the wiring harness as necessary</li> <li>Refer to the relevant section of the workshop manual and inspect the battery and charging system</li> </ul>                                                                                                                                                                                                                                                                                                                                                                                                                                               |
| B14AD-17 | Front Display Screen - Circuit voltage above threshold                   | <ul style="list-style-type: none"> <li>Touchscreen ground circuit short circuit to power</li> <li>Battery/charging system fault</li> </ul>                                                                                                                                                  | <ul style="list-style-type: none"> <li>Refer to the electrical circuit diagrams and check the touchscreen ground circuit for short circuit to power. Repair the wiring harness as necessary</li> <li>Refer to the relevant section of the workshop manual and inspect the battery and charging system</li> </ul>                                                                                                                                                                                                                                                                                                                                                                                                                                               |
| B14AD-31 | Front Display Screen - No signal                                         | <ul style="list-style-type: none"> <li>See note</li> </ul>                                                                                                                                                                                                                                  | <div> <b>NOTE:</b><br/> This DTC is for event information only and does not indicate a fault </div> <ul style="list-style-type: none"> <li>Ignore this DTC</li> </ul>                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                          |
| B14AD-49 | Front Display Screen - Internal electronic failure                       | <ul style="list-style-type: none"> <li>Touchscreen internal failure</li> </ul>                                                                                                                                                                                                              | <ul style="list-style-type: none"> <li>Using the Jaguar Land Rover approved diagnostic equipment, clear the DTCs and retest. If the fault persists, install a new touchscreen</li> </ul>                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                       |

| DTC      | DESCRIPTION                                                     | POSSIBLE CAUSES                                                                                    | ACTION                                                                                                                                                                                                             |
|----------|-----------------------------------------------------------------|----------------------------------------------------------------------------------------------------|--------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------|
| B14AD-96 | Front Display Screen - Component internal failure               | <ul style="list-style-type: none"> <li>See note</li> </ul>                                         | <div> <b>NOTE:</b><br/>           This DTC is for event information only and does not indicate a fault         </div> <ul style="list-style-type: none"> <li>Ignore this DTC</li> </ul>                            |
| B14AD-98 | Front Display Screen - Component or system over temperature     | <ul style="list-style-type: none"> <li>Touchscreen internal temperature above threshold</li> </ul> | <ul style="list-style-type: none"> <li>Allow the system to cool. Using the Jaguar Land Rover approved diagnostic equipment, clear the DTCs and retest. If the fault persists, install a new touchscreen</li> </ul> |
| B14AD-9A | Front Display Screen - Component or system operating conditions | <ul style="list-style-type: none"> <li>See note</li> </ul>                                         | <div> <b>NOTE:</b><br/>           This DTC is for event information only and does not indicate a fault         </div> <ul style="list-style-type: none"> <li>Ignore this DTC</li> </ul>                            |
| B14B0-11 | Television Antenna #1 - Circuit short to ground                 | <ul style="list-style-type: none"> <li>TV antenna circuit short circuit to ground</li> </ul>       | <ul style="list-style-type: none"> <li>Refer to the electrical circuit diagrams and check the TV antenna circuit for short circuit to ground</li> </ul>                                                            |
| B14B0-12 | Television Antenna #1 - Circuit short to battery                | <ul style="list-style-type: none"> <li>TV antenna circuit short circuit to power</li> </ul>        | <ul style="list-style-type: none"> <li>Refer to the electrical circuit diagrams and check the TV antenna circuit for short circuit to power</li> </ul>                                                             |
| B14B0-13 | Television Antenna #1 - Circuit open                            | <ul style="list-style-type: none"> <li>TV antenna circuit open circuit, high resistance</li> </ul> | <ul style="list-style-type: none"> <li>Refer to the electrical circuit diagrams and check the TV antenna circuit for open circuit, high resistance</li> </ul>                                                      |
| B14B1-11 | Television Antenna #2 - Circuit short to ground                 | <ul style="list-style-type: none"> <li>TV antenna circuit short circuit to ground</li> </ul>       | <ul style="list-style-type: none"> <li>Refer to the electrical circuit diagrams and check the TV antenna circuit for short circuit to ground</li> </ul>                                                            |
| B14B1-12 | Television Antenna #2 - Circuit short to battery                | <ul style="list-style-type: none"> <li>TV antenna circuit short circuit to power</li> </ul>        | <ul style="list-style-type: none"> <li>Refer to the electrical circuit diagrams and check the TV antenna circuit for short circuit to power</li> </ul>                                                             |
| B14B1-13 | Television Antenna #2 - Circuit open                            | <ul style="list-style-type: none"> <li>TV antenna circuit open circuit, high resistance</li> </ul> | <ul style="list-style-type: none"> <li>Refer to the electrical circuit diagrams and check the TV antenna circuit for open circuit, high resistance</li> </ul>                                                      |
| B14B2-11 | Television Antenna #3 - Circuit short to ground                 | <ul style="list-style-type: none"> <li>TV antenna circuit short circuit to ground</li> </ul>       | <ul style="list-style-type: none"> <li>Refer to the electrical circuit diagrams and check the TV antenna circuit for short circuit to ground</li> </ul>                                                            |
| B14B2-12 | Television Antenna #3 - Circuit short to battery                | <ul style="list-style-type: none"> <li>TV antenna circuit short circuit to power</li> </ul>        | <ul style="list-style-type: none"> <li>Refer to the electrical circuit diagrams and check the TV antenna circuit for short circuit to power</li> </ul>                                                             |
| B14B2-13 | Television Antenna #3 - Circuit open                            | <ul style="list-style-type: none"> <li>TV antenna circuit open circuit, high resistance</li> </ul> | <ul style="list-style-type: none"> <li>Refer to the electrical circuit diagrams and check the TV antenna circuit for open circuit, high resistance</li> </ul>                                                      |
| B14B3-11 | Television Antenna #4 - Circuit short to ground                 | <ul style="list-style-type: none"> <li>TV antenna circuit short circuit to ground</li> </ul>       | <ul style="list-style-type: none"> <li>Refer to the electrical circuit diagrams and check the TV antenna circuit for short circuit to ground</li> </ul>                                                            |
| B14B3-12 | Television Antenna #4 - Circuit short to battery                | <ul style="list-style-type: none"> <li>TV antenna circuit short circuit to power</li> </ul>        | <ul style="list-style-type: none"> <li>Refer to the electrical circuit diagrams and check the TV antenna circuit for short circuit to power</li> </ul>                                                             |

| DTC      | DESCRIPTION                                             | POSSIBLE CAUSES                                                                                                                                                                                                                                                                                                                      | ACTION                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                         |
|----------|---------------------------------------------------------|--------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------|--------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------|
| B14B3-13 | Television Antenna #4 - Circuit open                    | <ul style="list-style-type: none"> <li>TV antenna circuit open circuit, high resistance</li> </ul>                                                                                                                                                                                                                                   | <ul style="list-style-type: none"> <li>Refer to the electrical circuit diagrams and check the TV antenna circuit for open circuit, high resistance</li> </ul>                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                  |
| B14B4-15 | Bluetooth Antenna #1 - Circuit short to battery or open | <ul style="list-style-type: none"> <li>Infotainment master controller front Bluetooth® antenna circuit short circuit to power, open circuit, high resistance</li> </ul>                                                                                                                                                              | <div> <b>NOTE:</b><br/>           If this DTC is set simultaneously with a number of DTCs including U200F-11, check symptoms for U200F-11 first, rectify the fault, clear DTCs and retest         </div> <ul style="list-style-type: none"> <li>Refer to the electrical circuit diagrams and check the infotainment master controller front Bluetooth® antenna circuit for short circuit to power, open circuit, high resistance</li> </ul>                                                                                                                                                                                                                                                                                    |
| B14B5-15 | WiFi Antenna #1 - Circuit short to battery or open      | <ul style="list-style-type: none"> <li>WiFi antenna circuit short circuit to power, open circuit, high resistance</li> </ul>                                                                                                                                                                                                         | <div> <b>NOTE:</b><br/>           If this DTC is set simultaneously with a number of DTCs including U200F-11, check symptoms for U200F-11 first, rectify the fault, clear DTCs and retest         </div> <ul style="list-style-type: none"> <li>Refer to the electrical circuit diagrams and check the WiFi antenna circuit for short circuit to power, open circuit, high resistance</li> </ul>                                                                                                                                                                                                                                                                                                                               |
| B14B6-13 | USB Port #1 - Circuit open                              | <div> <b>NOTE:</b><br/>           Circuit reference - UIPUSB 2.0 D+ / UIPUSB 2.0 D- / UIP USB 3.0 SSTX+ / UIP USB 3.0 SSTX- / UIP USB 3.0 SSRX+ / UIP USB 3.0 SSRX- -         </div> <ul style="list-style-type: none"> <li>Infotainment master controller USB repeater module data circuit open circuit, high resistance</li> </ul> | <div> <b>NOTE:</b><br/>           This DTC will only be set if the link between the infotainment master controller and the connecting module is severed. The connecting module could be the USB repeater module (where installed), or the portable audio interface panel. Where a USB repeater module is installed, and the link between the USB repeater module and the portable audio interface panel is severed, then DTC B14A3-02 will be raised instead         </div> <ul style="list-style-type: none"> <li>Refer to the electrical circuit diagrams and check the infotainment master controller USB repeater module data circuit for open circuit, high resistance. Repair the wiring harness as necessary</li> </ul> |
| B14B6-19 | USB Port #1 - Circuit current above threshold           | <div> <b>NOTE:</b><br/>           Circuit reference - UIP VBUS -         </div> <ul style="list-style-type: none"> <li>Infotainment master controller USB repeater module power circuit short circuit to ground, short circuit to power</li> </ul>                                                                                   | <ul style="list-style-type: none"> <li>Refer to the electrical circuit diagrams and check the infotainment master controller USB repeater module power circuit for short circuit to ground, short circuit to power. Repair the wiring harness as necessary</li> <li>Using the Jaguar Land Rover approved diagnostic equipment, clear the DTCs and retest. If the fault persists, install a new USB repeater module</li> </ul>                                                                                                                                                                                                                                                                                                  |
| B14B7-13 | USB Hub #1 - Circuit open                               | <div> <b>NOTE:</b><br/>           Circuit reference - USB HUB 2.0 D+ / USB HUB 2.0 D- -         </div> <ul style="list-style-type: none"> <li>USB hub module data circuit open circuit, high resistance</li> </ul>                                                                                                                   | <ul style="list-style-type: none"> <li>Refer to the electrical circuit diagrams and check the USB hub module data circuit for open circuit, high resistance. Repair the wiring harness as necessary</li> </ul>                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                 |



| DTC      | DESCRIPTION                                                 | POSSIBLE CAUSES                                                                                                                                                                 | ACTION                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                       |
|----------|-------------------------------------------------------------|---------------------------------------------------------------------------------------------------------------------------------------------------------------------------------|--------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------|
| B14B7-19 | USB Hub #1 - Circuit current above threshold                | <div> <b>NOTE:</b><br/> Circuit reference - USB HUB VBUS<br/> - </div> <ul style="list-style-type: none"> <li>■ USB hub module power circuit short circuit to ground</li> </ul> | <ul style="list-style-type: none"> <li>■ Refer to the electrical circuit diagrams and check the USB hub module power circuit for short circuit to ground. Repair the wiring harness as necessary</li> <li>■ Using the Jaguar Land Rover approved diagnostic equipment, clear the DTCs and retest. If the fault persists, install a new USB hub #1 module</li> </ul>                                                                                                                                                                                          |
| B14D1-05 | SDARS (Satellite Radio) Tuner - System programming failures | <ul style="list-style-type: none"> <li>■ Infotainment master controller is not configured correctly</li> </ul>                                                                  | <ul style="list-style-type: none"> <li>■ Using the Jaguar Land Rover approved diagnostic equipment, reconfigure the infotainment master controller with the latest level software</li> </ul>                                                                                                                                                                                                                                                                                                                                                                 |
| B14D1-96 | SDARS (Satellite Radio) Tuner - Component internal failure  | <ul style="list-style-type: none"> <li>■ Infotainment master controller hardware/software incompatibility</li> <li>■ Infotainment master controller internal failure</li> </ul> | <div> <b>NOTE:</b><br/> This DTC may set as a result of hardware/software incompatibility and may not indicate a fault in the vehicle </div> <ul style="list-style-type: none"> <li>■ Using the Jaguar Land Rover approved diagnostic equipment, reconfigure the infotainment master controller with the latest level software</li> <li>■ If the fault persists or the customer continues to report problems with the radio, do not replace the infotainment master controller. Contact the Jaguar Land Rover service desk for further assistance</li> </ul> |
| B14D2-05 | TV (Television) - System programming failures               | <ul style="list-style-type: none"> <li>■ Infotainment master controller is not configured correctly</li> </ul>                                                                  | <ul style="list-style-type: none"> <li>■ Using the Jaguar Land Rover approved diagnostic equipment, reconfigure the infotainment master controller with the latest level software</li> </ul>                                                                                                                                                                                                                                                                                                                                                                 |
| B14D2-56 | TV (Television) - Invalid/incomplete configuration          | <ul style="list-style-type: none"> <li>■ Infotainment master controller is not configured correctly</li> </ul>                                                                  | <ul style="list-style-type: none"> <li>■ Using the Jaguar Land Rover approved diagnostic equipment, reconfigure the infotainment master controller with the latest level software</li> </ul>                                                                                                                                                                                                                                                                                                                                                                 |
| B14D2-57 | TV (Television) - Invalid/incomplete software component     | <ul style="list-style-type: none"> <li>■ Infotainment master controller is not configured correctly</li> </ul>                                                                  | <ul style="list-style-type: none"> <li>■ Using the Jaguar Land Rover approved diagnostic equipment, reconfigure the infotainment master controller with the latest level software</li> </ul>                                                                                                                                                                                                                                                                                                                                                                 |
| B14D2-96 | TV (Television) - Component internal failure                | <ul style="list-style-type: none"> <li>■ Infotainment master controller hardware/software incompatibility</li> <li>■ Infotainment master controller internal failure</li> </ul> | <div> <b>NOTE:</b><br/> This DTC may set as a result of hardware/software incompatibility and may not indicate a fault in the vehicle </div> <ul style="list-style-type: none"> <li>■ Using the Jaguar Land Rover approved diagnostic equipment, reconfigure the infotainment master controller with the latest level software</li> <li>■ If the fault persists or the customer continues to report problems with the TV, do not replace the infotainment master controller. Contact the Jaguar Land Rover service desk for further assistance</li> </ul>    |
| B14D3-05 | Radio Tuner - System programming failures                   | <ul style="list-style-type: none"> <li>■ Infotainment master controller is not configured correctly</li> </ul>                                                                  | <ul style="list-style-type: none"> <li>■ Using the Jaguar Land Rover approved diagnostic equipment, reconfigure the infotainment master controller with the latest level software</li> </ul>                                                                                                                                                                                                                                                                                                                                                                 |

| DTC      | DESCRIPTION                                                                           | POSSIBLE CAUSES                                                                                                                                                             | ACTION                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                              |
|----------|---------------------------------------------------------------------------------------|-----------------------------------------------------------------------------------------------------------------------------------------------------------------------------|-----------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------|
| B14D3-56 | Radio Tuner - Invalid/incomplete configuration                                        | <ul style="list-style-type: none"> <li>Infotainment master controller is not configured correctly</li> </ul>                                                                | <ul style="list-style-type: none"> <li>Using the Jaguar Land Rover approved diagnostic equipment, reconfigure the infotainment master controller with the latest level software</li> </ul>                                                                                                                                                                                                                                                                                                                                                          |
| B14D3-96 | Radio Tuner - Component internal failure                                              | <ul style="list-style-type: none"> <li>Infotainment master controller hardware/software incompatibility</li> <li>Infotainment master controller internal failure</li> </ul> | <div> <b>NOTE:</b><br/> This DTC may set as a result of hardware/software incompatibility and may not indicate a fault in the vehicle </div> <ul style="list-style-type: none"> <li>Using the Jaguar Land Rover approved diagnostic equipment, update the infotainment master controller with the latest level software</li> <li>If the fault persists or the customer continues to report problems with the radio, do not replace the infotainment master controller. Contact the Jaguar Land Rover service desk for further assistance</li> </ul> |
| B14D9-11 | Dedicated Short Range Communication (DRSC) Antenna - Circuit short to ground          | <ul style="list-style-type: none"> <li>Dedicated short range communication module antenna circuit short circuit to ground</li> </ul>                                        | <ul style="list-style-type: none"> <li>Refer to the electrical circuit diagrams and check the dedicated short range communication module antenna circuit for short circuit to ground. Repair the wiring harness as necessary</li> </ul>                                                                                                                                                                                                                                                                                                             |
| B14D9-13 | Dedicated Short Range Communication (DRSC) Antenna - Circuit open                     | <ul style="list-style-type: none"> <li>Dedicated short range communication module antenna circuit open circuit, high resistance</li> </ul>                                  | <ul style="list-style-type: none"> <li>Refer to the electrical circuit diagrams and check the dedicated short range communication module antenna circuit for open circuit, high resistance. Repair the wiring harness as necessary</li> </ul>                                                                                                                                                                                                                                                                                                       |
| B14DA-11 | Vehicle Information and Communication System (VICS) Antenna - Circuit short to ground | <ul style="list-style-type: none"> <li>Vehicle information and communication system module antenna circuit short circuit to ground</li> </ul>                               | <ul style="list-style-type: none"> <li>Refer to the electrical circuit diagrams and check the vehicle information and communication system module antenna circuit for short circuit to ground. Repair the wiring harness as necessary</li> </ul>                                                                                                                                                                                                                                                                                                    |
| B14DA-13 | Vehicle Information and Communication System (VICS) Antenna - Circuit open            | <ul style="list-style-type: none"> <li>Vehicle information and communication system module antenna circuit open circuit, high resistance</li> </ul>                         | <ul style="list-style-type: none"> <li>Refer to the electrical circuit diagrams and check the vehicle information and communication system module antenna circuit for open circuit, high resistance</li> </ul>                                                                                                                                                                                                                                                                                                                                      |
| B14DB-56 | Optical Disk Drive (ODD) Region Code - Invalid/incomplete configuration               | <ul style="list-style-type: none"> <li>Digital disc player region code incorrect for region</li> </ul>                                                                      | <ul style="list-style-type: none"> <li>Set region code to current region</li> </ul>                                                                                                                                                                                                                                                                                                                                                                                                                                                                 |
| B14DC-13 | Electronic Toll Collection Module - Circuit open                                      | <ul style="list-style-type: none"> <li>Electronic toll collection module connection not available</li> </ul>                                                                | <ul style="list-style-type: none"> <li>Refer to the electrical circuit diagrams and check the electronic toll collection module power and ground circuits for open circuit, high resistance. Repair the wiring harness as necessary</li> <li>Using the Jaguar Land Rover approved diagnostic equipment, clear the DTCs and retest</li> </ul>                                                                                                                                                                                                        |
| B14DC-96 | Electronic Toll Collection Module - Component internal failure                        | <ul style="list-style-type: none"> <li>Electronic toll collection module internal failure</li> </ul>                                                                        | <ul style="list-style-type: none"> <li>Using the Jaguar Land Rover approved diagnostic equipment, clear the DTCs and retest. If the fault persists, install a new electronic toll collection module</li> </ul>                                                                                                                                                                                                                                                                                                                                      |

| DTC      | DESCRIPTION                                                | POSSIBLE CAUSES                                                                                                                                                                                                                                | ACTION                                                                                                                                                                                                                                                                                                                                                                                                    |
|----------|------------------------------------------------------------|------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------|-----------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------|
| B151F-09 | Auxiliary Cooling Fan - Component failure                  | <ul style="list-style-type: none"> <li>Infotainment cooling fan circuit open circuit, high resistance</li> <li>Infotainment cooling fan duct obstructed or installed incorrectly</li> <li>Infotainment cooling fan internal failure</li> </ul> | <ul style="list-style-type: none"> <li>Refer to the electrical circuit diagrams and check the infotainment cooling fan circuit for open circuit, high resistance. Repair the wiring harness as necessary</li> <li>Inspect the integrity of the infotainment cooling fan duct</li> <li>Check the operation of the infotainment cooling fan. Install a new infotainment cooling fan as necessary</li> </ul> |
| B1520-11 | Auxiliary Fan Relay Control Line - Circuit short to ground | <ul style="list-style-type: none"> <li>Infotainment cooling fan relay circuit short circuit to ground</li> </ul>                                                                                                                               | <ul style="list-style-type: none"> <li>Refer to the electrical circuit diagrams and check the infotainment cooling fan relay circuit for short circuit to ground. Repair the wiring harness as necessary</li> </ul>                                                                                                                                                                                       |
| B1520-13 | Auxiliary Fan Relay Control Line - Circuit open            | <div> <b>NOTE:</b><br/> This DTC will set in Service 19 Only after on demand self test is run </div> <ul style="list-style-type: none"> <li>Infotainment cooling fan relay circuit open circuit, high resistance</li> </ul>                    | <ul style="list-style-type: none"> <li>Refer to the electrical circuit diagrams and check the infotainment cooling fan relay circuit for open circuit, high resistance. Repair the wiring harness as necessary</li> </ul>                                                                                                                                                                                 |
| B1A56-11 | Antenna - Circuit short to ground                          | <ul style="list-style-type: none"> <li>AM/FM antenna circuit short circuit to ground</li> </ul>                                                                                                                                                | <ul style="list-style-type: none"> <li>Refer to the electrical circuit diagrams and check the AM/FM antenna circuit for short circuit to ground</li> </ul>                                                                                                                                                                                                                                                |
| B1A56-12 | Antenna - Circuit short to battery                         | <ul style="list-style-type: none"> <li>AM/FM antenna circuit short circuit to power</li> </ul>                                                                                                                                                 | <ul style="list-style-type: none"> <li>Refer to the electrical circuit diagrams and check the AM/FM antenna circuit for short circuit to power</li> </ul>                                                                                                                                                                                                                                                 |
| B1A56-13 | Antenna - Circuit open                                     | <ul style="list-style-type: none"> <li>AM/FM antenna circuit open circuit, high resistance</li> </ul>                                                                                                                                          | <ul style="list-style-type: none"> <li>Refer to the electrical circuit diagrams and check the AM/FM antenna circuit for open circuit, high resistance</li> </ul>                                                                                                                                                                                                                                          |
| B1A89-11 | Satellite Antenna - Circuit short to ground                | <ul style="list-style-type: none"> <li>Satellite radio antenna circuit short circuit to ground</li> </ul>                                                                                                                                      | <ul style="list-style-type: none"> <li>Refer to the electrical circuit diagrams and check the satellite radio antenna circuit for short circuit to ground</li> </ul>                                                                                                                                                                                                                                      |
| B1A89-13 | Satellite Antenna - Circuit open                           | <ul style="list-style-type: none"> <li>Satellite radio antenna circuit open circuit, high resistance</li> </ul>                                                                                                                                | <ul style="list-style-type: none"> <li>Refer to the electrical circuit diagrams and check the satellite radio antenna circuit for open circuit, high resistance</li> </ul>                                                                                                                                                                                                                                |
| B1D55-11 | Antenna #2 - Circuit short to ground                       | <ul style="list-style-type: none"> <li>FM antenna circuit short circuit to ground</li> </ul>                                                                                                                                                   | <ul style="list-style-type: none"> <li>Refer to the electrical circuit diagrams and check the FM antenna circuit for short circuit to ground</li> </ul>                                                                                                                                                                                                                                                   |
| B1D55-12 | Antenna #2 - Circuit short to battery                      | <ul style="list-style-type: none"> <li>FM antenna circuit short circuit to power</li> </ul>                                                                                                                                                    | <ul style="list-style-type: none"> <li>Refer to the electrical circuit diagrams and check the FM antenna circuit for short circuit to power</li> </ul>                                                                                                                                                                                                                                                    |
| B1D55-13 | Antenna #2 - Circuit open                                  | <ul style="list-style-type: none"> <li>FM antenna circuit open circuit, high resistance</li> </ul>                                                                                                                                             | <ul style="list-style-type: none"> <li>Refer to the electrical circuit diagrams and check the FM antenna circuit for open circuit, high resistance</li> </ul>                                                                                                                                                                                                                                             |
| B1D99-19 | Solid State Drive - Circuit current above threshold        | <ul style="list-style-type: none"> <li>Infotainment master controller hard drive internal failure</li> </ul>                                                                                                                                   | <ul style="list-style-type: none"> <li>Using the Jaguar Land Rover approved diagnostic equipment, clear the DTCs and retest. If the fault persists, install a new infotainment master controller</li> </ul>                                                                                                                                                                                               |

| DTC      | DESCRIPTION                                                            | POSSIBLE CAUSES                                                                                                                                                                                                                                                                  | ACTION                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                            |
|----------|------------------------------------------------------------------------|----------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------|-----------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------|
| B1D99-98 | Solid State Drive - Component or system over temperature               | <ul style="list-style-type: none"> <li>■ Infotainment master controller hard drive over temperature</li> <li>■ Infotainment master controller hard drive internal failure</li> </ul>                                                                                             | <ul style="list-style-type: none"> <li>■ Allow the system to cool. Using the Jaguar Land Rover approved diagnostic equipment, make sure the infotainment master controller is configured with the latest level software level</li> <li>■ If the fault persists, do not replace the infotainment master controller. Contact the Jaguar Land Rover service desk for further assistance</li> </ul>                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                   |
| B1DE3-2F | Multimedia Link - Driver Assistance Domain Controller - Signal erratic | <ul style="list-style-type: none"> <li>■ Infotainment master controller signal circuit short circuit to ground, short circuit to power, open circuit, high resistance</li> <li>■ Infotainment master controller power or ground circuit open circuit, high resistance</li> </ul> | <ul style="list-style-type: none"> <li>■ Inspect for loose/damaged connectors, corroded or backed out terminals. Refer to the electrical circuit diagrams and check the infotainment master controller signal circuit for short circuit to ground, short circuit to power, open circuit, high resistance</li> <li>■ Refer to the electrical circuit diagrams and check the cable continuity for both cables between the infotainment master controller to image processing module B and image processing module B to camera module. Replace cables as required</li> <li>■ If the fault persists, do not replace the infotainment master controller. Contact the Jaguar Land Rover service desk for further assistance</li> <li>■ Inspect for loose/damaged connectors, corroded or backed out terminals. Refer to the electrical circuit diagrams and check the infotainment master controller power and ground circuit for open circuit, high resistance</li> <li>■ Refer to the electrical circuit diagrams and check the cable continuity for both cables between the infotainment master controller to image processing module B and image processing module B to camera module. Replace cables as required</li> <li>■ If the fault persists, do not replace the infotainment master controller. Contact the Jaguar Land Rover service desk for further assistance</li> </ul> |
| B1DE3-31 | Multimedia Link - Driver Assistance Domain Controller - No signal      | <ul style="list-style-type: none"> <li>■ Infotainment master controller signal circuit short circuit to ground, short circuit to power, open circuit, high resistance</li> <li>■ Infotainment master controller power or ground circuit open circuit, high resistance</li> </ul> | <ul style="list-style-type: none"> <li>■ Inspect for loose/damaged connectors, corroded or backed out terminals. Refer to the electrical circuit diagrams and check the infotainment master controller signal circuit for short circuit to ground, short circuit to power, open circuit, high resistance</li> <li>■ Refer to the electrical circuit diagrams and check the cable continuity for both cables between the infotainment master controller to image processing module B and image processing module B to camera module. Replace cables as required</li> <li>■ If the fault persists, do not replace the infotainment master controller. Contact the Jaguar Land Rover service desk for further assistance</li> <li>■ Inspect for loose/damaged connectors, corroded or backed out terminals. Refer to the electrical circuit diagrams and check the infotainment master controller power and ground circuit for open circuit, high resistance</li> <li>■ Refer to the electrical circuit diagrams and check the cable continuity for both cables between the infotainment master controller to image processing module B and image processing module B to camera module. Replace cables as required</li> <li>■ If the fault persists, do not replace the infotainment master controller. Contact the Jaguar Land Rover service desk for further assistance</li> </ul> |

| DTC      | DESCRIPTION                                                                          | POSSIBLE CAUSES                                                                                                                                                                                                                                                                  | ACTION                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                            |
|----------|--------------------------------------------------------------------------------------|----------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------|-----------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------|
| B1DE3-67 | Multimedia Link - Driver Assistance Domain Controller - Signal incorrect after event | <ul style="list-style-type: none"> <li>■ Infotainment master controller signal circuit short circuit to ground, short circuit to power, open circuit, high resistance</li> <li>■ Infotainment master controller power or ground circuit open circuit, high resistance</li> </ul> | <ul style="list-style-type: none"> <li>■ Inspect for loose/damaged connectors, corroded or backed out terminals. Refer to the electrical circuit diagrams and check the infotainment master controller signal circuit for short circuit to ground, short circuit to power, open circuit, high resistance</li> <li>■ Refer to the electrical circuit diagrams and check the cable continuity for both cables between the infotainment master controller to image processing module B and image processing module B to camera module. Replace cables as required</li> <li>■ If the fault persists, do not replace the infotainment master controller. Contact the Jaguar Land Rover service desk for further assistance</li> <li>■ Inspect for loose/damaged connectors, corroded or backed out terminals. Refer to the electrical circuit diagrams and check the infotainment master controller power and ground circuit for open circuit, high resistance</li> <li>■ Refer to the electrical circuit diagrams and check the cable continuity for both cables between the infotainment master controller to image processing module B and image processing module B to camera module. Replace cables as required</li> <li>■ If the fault persists, do not replace the infotainment master controller. Contact the Jaguar Land Rover service desk for further assistance</li> </ul> |
| U0001-82 | High Speed CAN Communication Bus - Alive/sequence counter incorrect/not updated      | <ul style="list-style-type: none"> <li>■ Invalid data received from another control module through the high speed CAN bus (comfort)</li> </ul>                                                                                                                                   | <ul style="list-style-type: none"> <li>■ Using the Jaguar Land Rover approved diagnostic equipment, check the snapshot data to determine the invalid data source control module. Check the relevant control module for related DTCs and refer to the relevant DTC index</li> </ul>                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                |
| U0001-87 | High Speed CAN Communication Bus - Missing message                                   | <ul style="list-style-type: none"> <li>■ Missing message from another control module through the high speed CAN bus (comfort)</li> </ul>                                                                                                                                         | <ul style="list-style-type: none"> <li>■ Using the Jaguar Land Rover approved diagnostic equipment, inspect the snapshot data to determine the missing message source control module. Check the relevant control module for related DTCs and refer to the relevant DTC index</li> </ul>                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                           |
| U0001-88 | High Speed CAN Communication Bus - Bus off                                           | <ul style="list-style-type: none"> <li>■ High speed CAN bus (comfort) circuit short circuit to ground, short circuit to power, open circuit, high resistance</li> </ul>                                                                                                          | <ul style="list-style-type: none"> <li>■ Using the Jaguar Land Rover approved diagnostic equipment, perform a CAN network integrity test. Refer to the electrical circuit diagrams and check the high speed CAN bus (comfort) circuit for short circuit to ground, short circuit to power, open circuit, high resistance</li> </ul>                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                               |
| U0184-00 | Lost Communication With Radio - No sub type information                              | <ul style="list-style-type: none"> <li>■ Infotainment master controller hardware/software incompatibility</li> </ul>                                                                                                                                                             | <div> <p><b>NOTE:</b></p> <p>This DTC may set as a result of hardware/software incompatibility and may not indicate a fault in the vehicle</p> </div> <ul style="list-style-type: none"> <li>■ Using the Jaguar Land Rover approved diagnostic equipment, reconfigure the infotainment master controller with the latest level software</li> <li>■ If the fault persists, do not replace the infotainment master controller. Contact the Jaguar Land Rover service desk for further assistance</li> </ul>                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                         |

| DTC      | DESCRIPTION                                                                | POSSIBLE CAUSES                                                                                                                                                                                                                                                  | ACTION                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                      |
|----------|----------------------------------------------------------------------------|------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------|-----------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------|
| U0300-00 | Internal Control Module Software Incompatibility - No sub type information | <ul style="list-style-type: none"> <li>Car Configuration file mismatch with vehicle specification</li> </ul>                                                                                                                                                     | <p><b>NOTE:</b></p> <p>After updating the Car Configuration file, set the ignition to on and wait 30 seconds before clearing the DTCs</p> <ul style="list-style-type: none"> <li>Using the Jaguar Land Rover approved diagnostic equipment, check and update the Car Configuration file as necessary. Clear the DTCs and retest</li> </ul>                                                                                                                                                                                                                                  |
| U1011-13 | Optical Disk Drive - Circuit open                                          | <ul style="list-style-type: none"> <li>Digital disc player power or ground circuit open circuit, high resistance</li> <li>Digital disc player internal failure</li> </ul>                                                                                        | <p><b>NOTE:</b></p> <p>If this DTC is set simultaneously with a number of DTCs including U200F-11, check symptoms for U200F-11 first, rectify the fault, clear DTCs and retest</p> <ul style="list-style-type: none"> <li>Refer to the electrical circuit diagrams and check the digital disc player power and ground circuits for open circuit, high resistance. Repair the wiring harness as necessary</li> <li>Using the Jaguar Land Rover approved diagnostic equipment, clear the DTCs and retest. If the fault persists, install a new digital disc player</li> </ul> |
| U200E-11 | Control Module Output Power B - Circuit short to ground                    | <p><b>NOTE:</b></p> <p>Infotainment master controller circuit reference - USB HUB PWR / USB HUB GND -</p> <ul style="list-style-type: none"> <li>Infotainment master controller USB hub circuit short circuit to ground</li> </ul>                               | <ul style="list-style-type: none"> <li>Refer to the electrical circuit diagrams and check the infotainment master controller USB hub circuit for short circuit to ground. Repair the wiring harness as necessary</li> </ul>                                                                                                                                                                                                                                                                                                                                                 |
| U200E-15 | Control Module Output Power B - Circuit short to battery or open           | <p><b>NOTE:</b></p> <p>Infotainment master controller circuit reference - USB HUB PWR / USB HUB GND -</p> <ul style="list-style-type: none"> <li>Infotainment master controller USB hub circuit short circuit to power, open circuit, high resistance</li> </ul> | <ul style="list-style-type: none"> <li>Refer to the electrical circuit diagrams and check the infotainment master controller USB hub circuit for short circuit to power, open circuit, high resistance. Repair the wiring harness as necessary</li> </ul>                                                                                                                                                                                                                                                                                                                   |
| U200F-11 | Control Module Output Power C - Circuit short to ground                    | <p><b>NOTE:</b></p> <p>Infotainment master controller circuit reference - HLDF APIX2 12V -</p> <ul style="list-style-type: none"> <li>Touchscreen power circuit short circuit to ground</li> </ul>                                                               | <p><b>NOTE:</b></p> <p>This fault may also cause a number of other DTCs to set (B1492-11, B1492-12, B1492-13, B14AD-02, B14B4-15, B14B5-15, U1011-13). If this DTC is set simultaneously with a number of other DTCs, check symptoms for U200F-11 first, rectify the fault, clear DTCs and retest</p> <ul style="list-style-type: none"> <li>Refer to the electrical circuit diagrams and check the touchscreen power circuit for short circuit to ground. Repair the wiring harness as necessary</li> </ul>                                                                |

| DTC      | DESCRIPTION                                                      | POSSIBLE CAUSES                                                                                                                                                                                                                    | ACTION                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                        |
|----------|------------------------------------------------------------------|------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------|-----------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------|
| U200F-15 | Control Module Output Power C - Circuit short to battery or open | <p><b>NOTE:</b></p> <p>Infotainment master controller circuit reference - HLDF APIX2 12V -</p> <ul style="list-style-type: none"> <li>■ Touchscreen power circuit short circuit to power, open circuit, high resistance</li> </ul> | <ul style="list-style-type: none"> <li>■ Refer to the electrical circuit diagrams and check the touchscreen power circuit for short circuit to power, open circuit, high resistance. Repair the wiring harness as necessary</li> </ul>                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                        |
| U2016-68 | Control Module Main Software - Event information                 | <ul style="list-style-type: none"> <li>■ Infotainment master controller internal software event</li> </ul>                                                                                                                         | <p><b>NOTES:</b></p> <ul style="list-style-type: none"> <li>■ If DTCs B14B4-15, B14B5-15 and B1492-11 are set in the infotainment master controller alongside this DTC, this does not indicate a fault with the associated DTCs</li> <li>■ This DTC may set as a result of hardware/software incompatibility and may not indicate a fault in the vehicle</li> </ul> <ul style="list-style-type: none"> <li>■ Using the Jaguar Land Rover approved diagnostic equipment, update the infotainment master controller with the latest level software. Clear the DTCs and retest</li> <li>■ If the fault persists, do not replace the infotainment master controller. Contact the Jaguar Land Rover service desk for further assistance</li> </ul> |
| U2100-55 | Initial Configuration Not Complete - Not configured              | <ul style="list-style-type: none"> <li>■ Infotainment master controller is not configured correctly</li> </ul>                                                                                                                     | <ul style="list-style-type: none"> <li>■ Using the Jaguar Land Rover approved diagnostic equipment, reconfigure the infotainment master controller with the latest level software</li> </ul>                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                  |
| U2300-51 | Central Configuration - Not programmed                           | <ul style="list-style-type: none"> <li>■ Car Configuration file mismatch with vehicle specification</li> <li>■ Infotainment master controller is not configured correctly</li> </ul>                                               | <p><b>NOTE:</b></p> <p>This DTC will be set if the Car Configuration file in the vehicle has been changed</p> <ul style="list-style-type: none"> <li>■ Using the Jaguar Land Rover approved diagnostic equipment, reconfigure the infotainment master controller with the latest level software</li> <li>■ Clear the DTCs, cycle ignition twice, wait for 3 minutes and retest</li> <li>■ If the fault persists, do not replace the infotainment master controller. Contact the Jaguar Land Rover service desk for further assistance</li> </ul>                                                                                                                                                                                              |
| U2300-54 | Central Configuration - Missing calibration                      | <ul style="list-style-type: none"> <li>■ Infotainment master controller is not configured correctly</li> </ul>                                                                                                                     | <p><b>NOTE:</b></p> <p>This DTC will occur if the routine to clear the Car Configuration has been performed and subsequent correct steps are not complete. It will also occur if the Car Configuration has been partly updated</p> <ul style="list-style-type: none"> <li>■ Using the Jaguar Land Rover approved diagnostic equipment, make sure the process to reconfigure the module is complete. Clear the DTCs, then read DTCs in the next ignition cycle</li> </ul>                                                                                                                                                                                                                                                                      |

| DTC      | DESCRIPTION                                              | POSSIBLE CAUSES                                                                                                       | ACTION                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                        |
|----------|----------------------------------------------------------|-----------------------------------------------------------------------------------------------------------------------|-------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------|
| U2300-55 | Central Configuration - Not configured                   | <ul style="list-style-type: none"> <li>Infotainment master controller is not configured correctly</li> </ul>          | <div> <b>NOTE:</b><br/>           This DTC will occur if the routine to clear the Car Configuration has been performed and subsequent correct steps are not complete. It will also occur if the Car Configuration has been partly updated         </div> <ul style="list-style-type: none"> <li>Using the Jaguar Land Rover approved diagnostic equipment, make sure the process to reconfigure the module is complete. Clear the DTCs, then read DTCs in the next ignition cycle</li> </ul>                                                                                  |
| U2300-56 | Central Configuration - Invalid/incomplete configuration | <ul style="list-style-type: none"> <li>See note</li> </ul>                                                            | <div> <b>NOTE:</b><br/>           This DTC is for event information only and does not indicate a fault         </div> <ul style="list-style-type: none"> <li>Ignore this DTC</li> </ul>                                                                                                                                                                                                                                                                                                                                                                                       |
| U2300-64 | Central Configuration - Signal plausibility failure      | <ul style="list-style-type: none"> <li>Infotainment master controller is not configured correctly</li> </ul>          | <ul style="list-style-type: none"> <li>Using the Jaguar Land Rover approved diagnostic equipment, reconfigure the infotainment master controller with the latest level software</li> </ul>                                                                                                                                                                                                                                                                                                                                                                                    |
| U3000-04 | Control Module - System internal failures                | <ul style="list-style-type: none"> <li>Infotainment master controller internal failure</li> </ul>                     | <div> <b>NOTE:</b><br/>           If DTCs B14B4-15, B14B5-15 and B1492-11 are set in the infotainment master controller alongside this DTC, this does <b>not</b> indicate a fault with the associated DTCs         </div> <ul style="list-style-type: none"> <li>Using the Jaguar Land Rover approved diagnostic equipment, update the infotainment master controller to the latest level software and retest</li> <li>If the fault persists, do not replace the infotainment master controller. Contact the Jaguar Land Rover service desk for further assistance</li> </ul> |
| U3000-98 | Control Module - Component or system over temperature    | <ul style="list-style-type: none"> <li>Infotainment master controller internal temperature above threshold</li> </ul> | <ul style="list-style-type: none"> <li>Allow the system to cool. Using the Jaguar Land Rover approved diagnostic equipment, make sure the infotainment master controller is configured with the latest level software level</li> <li>If the fault persists, do not replace the infotainment master controller. Contact the Jaguar Land Rover service desk for further assistance</li> </ul>                                                                                                                                                                                   |