

GENERAL INFORMATION

DIAGNOSTIC TROUBLE CODE INDEX - DTC:
REMOTE FUNCTION ACTUATOR [RFA] [G2353832]

DESCRIPTION AND OPERATION

REMOTE FUNCTION ACTUATOR [RFA]

CAUTION:

Diagnosis by substitution from a donor vehicle is **NOT** acceptable. Substitution of control modules does not guarantee confirmation of a fault, and may also cause additional faults in the vehicle being tested and/or the donor vehicle.

NOTES:

- If a control module or a component failure is suspected and the vehicle remains under manufacturer warranty, refer to the Warranty Policy and Procedures manual, or determine if any prior approval program is in operation, prior to the installation of a new module/component.
- If a fault is suspected or is reported by the customer then the TOPIx Cloud guided diagnostic should be followed. This gives the most reliable route to a right first time repair. The diagnostic may include investigation of other linked systems and software.
- Generic scan tools may not read the codes listed, or may read only 5-digit codes. Match the 5 digits from the scan tool to the first 5 digits of the 7-digit code listed to identify the fault (the last 2 digits give extra information read by the Jaguar Land Rover approved diagnostic equipment).
- When performing voltage or resistance tests, always use a digital multimeter that has the resolution ability to view 3 decimal places. For example, on the 2 volts range can measure 1 mV or 2 kΩ range can measure 1 Ω. When testing resistance always take the resistance of the digital multimeter leads into account.
- Check and rectify basic faults before beginning diagnostic routines involving pinpoint tests.
- Inspect connectors for signs of water ingress, and pins for damage and/or corrosion.
- If DTCs are recorded and, after performing the pinpoint tests, a fault is not present, an intermittent concern may be the cause. Always check for loose connections and corroded terminals.
- Check the JLR claims submission system for open campaigns. Refer to the corresponding bulletins and SSMs which may be valid for the specific customer complaint and perform the recommendations as required.

The table below lists all Diagnostic Trouble Codes (DTCs) that could be set in the Remote Function Actuator (RFA). For additional diagnosis and testing information, refer to the relevant Diagnosis and Testing section in the workshop manual. For additional information, refer to:

[Locks, Latches and Entry Systems](#) (501-14 Handles, Locks, Latches and Entry Systems, Diagnosis and Testing),
[Anti-Theft - Active](#) (419-01A Anti-Theft - Active, Diagnosis and Testing).

DTC	DESCRIPTION	POSSIBLE CAUSES	ACTION
B102B-00	Passive Key - No sub type information	NOTE: This DTC is set if an invalid smart key is detected when the ignition switch is operated. Invalid smart key detected	Using the Jaguar Land Rover approved diagnostic equipment, run application - ECU Diagnostics / Remote Function Actuator (RFA) / Clear DTCs. Retest. If the fault persists, run application - ECU Diagnostics / Remote Function Actuator (RFA) / ECU Functions / Recover Programed Keys
B10A9-00	Remote Keyless Entry Less Than 2 Keys Programmed - No sub type information	Less than 2 smart keys have been programed	Using the Jaguar Land Rover approved diagnostic equipment, run application - ECU Diagnostics / Remote Function Actuator (RFA) / ECU Functions / Recover Programed Keys
B10C1-15	Left Front Unlock Pull Switch - Circuit short to battery or open	Left exterior door handle unlock switch circuit short circuit to power, open circuit, high resistance	Refer to the electrical circuit diagrams and check the left exterior door handle unlock switch circuit for short circuit to power, open circuit, high resistance. Repair the wiring harness as necessary
B10C1-23	Left Front Unlock Pull Switch - Signal stuck low	Left exterior door handle unlock switch circuit short circuit to ground	Refer to the electrical circuit diagrams and check the left exterior door handle unlock switch circuit for short circuit to ground. Repair the wiring harness as necessary
B10C3-15	Right Front Unlock Pull Switch - Circuit short to battery or open	Right exterior door handle unlock switch circuit short circuit to power, open circuit, high resistance	Refer to the electrical circuit diagrams and check the right exterior door handle unlock switch circuit for short circuit to power, open circuit, high resistance. Repair the wiring harness as necessary
B10C3-23	Right Front Unlock Pull Switch - Signal stuck low	Right exterior door handle unlock switch circuit short circuit to ground	Refer to the electrical circuit diagrams and check the right exterior door handle unlock switch circuit for short circuit to ground. Repair the wiring harness as necessary
B10C5-23	Trunk Unlock Pull Switch - Signal stuck low	Luggage compartment lid release switch signal circuit short circuit to ground	Refer to the electrical circuit diagrams and check the luggage compartment lid release switch signal circuit for short circuit to ground. Repair the wiring harness as necessary
B10C6-00	Exterior Trunk Antenna - No sub type information	Luggage compartment lid exterior low frequency antenna circuit short circuit to ground, short circuit to power	NOTE: If any other low frequency antenna short circuit to power DTC is also set, perform the relevant corrective action(s) first. Using the Jaguar Land Rover approved diagnostic equipment, run application - ECU Diagnostics / Remote Function Actuator (RFA) / Clear DTCs. Run application - ECU Diagnostics / Remote Function Actuator (RFA) / ECU Functions / On Demand Self Test. If the fault persists, refer to the electrical circuit diagrams and check the luggage compartment lid exterior low frequency antenna circuit for short circuit to ground, short circuit to power. Repair the wiring harness as necessary

DTC	DESCRIPTION	POSSIBLE CAUSES	ACTION
B10C6-11	Exterior Trunk Antenna - Circuit short to ground	Luggage compartment lid exterior low frequency antenna circuit short circuit to ground, short circuit between positive and negative	NOTE: If any other low frequency antenna short circuit to power DTC is also set, perform the relevant corrective action(s) first. Using the Jaguar Land Rover approved diagnostic equipment, run application - ECU Diagnostics / Remote Function Actuator (RFA) / Clear DTCs. Run application - ECU Diagnostics / Remote Function Actuator (RFA) / ECU Functions / On Demand Self Test. If the fault persists, refer to the electrical circuit diagrams and check the luggage compartment lid exterior low frequency antenna circuit for short circuit to ground, short circuit between positive and negative. Repair the wiring harness as necessary
B10C6-12	Exterior Trunk Antenna - Circuit short to battery	Luggage compartment lid exterior low frequency antenna circuit short circuit to power	Using the Jaguar Land Rover approved diagnostic equipment, run application - ECU Diagnostics / Remote Function Actuator (RFA) / Clear DTCs. Run application - ECU Diagnostics / Remote Function Actuator (RFA) / ECU Functions / On Demand Self Test. If the fault persists, refer to the electrical circuit diagrams and check the luggage compartment lid exterior low frequency antenna circuit for short circuit to power. Repair the wiring harness as necessary
B10C6-13	Exterior Trunk Antenna - Circuit open	Luggage compartment lid exterior low frequency antenna circuit open circuit, high resistance	NOTE: If any other low frequency antenna short circuit to power DTC is also set, perform the relevant corrective action(s) first. Using the Jaguar Land Rover approved diagnostic equipment, run application - ECU Diagnostics / Remote Function Actuator (RFA) / Clear DTCs. Run application - ECU Diagnostics / Remote Function Actuator (RFA) / ECU Functions / On Demand Self Test. If the fault persists, refer to the electrical circuit diagrams and check the luggage compartment lid exterior low frequency antenna circuit for open circuit, high resistance. Repair the wiring harness as necessary
B10C7-00	Interior Trunk Antenna - No sub type information	Luggage compartment left low frequency antenna circuit short circuit to ground, short circuit to power	NOTE: If any other low frequency antenna short circuit to power DTC is also set, perform the relevant corrective action(s) first. Using the Jaguar Land Rover approved diagnostic equipment, run application - ECU Diagnostics / Remote Function Actuator (RFA) / Clear DTCs. Run application - ECU Diagnostics / Remote Function Actuator (RFA) / ECU Functions / On Demand Self Test. If the fault persists, refer to the electrical circuit diagrams and check the luggage compartment left low frequency antenna circuit for short circuit to ground, short circuit to power. Repair the wiring harness as necessary

DTC	DESCRIPTION	POSSIBLE CAUSES	ACTION
B10C7-11	Interior Trunk Antenna - Circuit short to ground	Luggage compartment left low frequency antenna circuit short circuit to ground, short circuit between positive and negative	NOTE: If any other low frequency antenna short circuit to power DTC is also set, perform the relevant corrective action(s) first. Using the Jaguar Land Rover approved diagnostic equipment, run application - ECU Diagnostics / Remote Function Actuator (RFA) / Clear DTCs. Run application - ECU Diagnostics / Remote Function Actuator (RFA) / ECU Functions / On Demand Self Test. If the fault persists, refer to the electrical circuit diagrams and check the luggage compartment left low frequency antenna circuit for short circuit to ground, short circuit between positive and negative. Repair the wiring harness as necessary
B10C7-12	Interior Trunk Antenna - Circuit short to battery	Luggage compartment left low frequency antenna circuit short circuit to power	Using the Jaguar Land Rover approved diagnostic equipment, run application - ECU Diagnostics / Remote Function Actuator (RFA) / Clear DTCs. Run application - ECU Diagnostics / Remote Function Actuator (RFA) / ECU Functions / On Demand Self Test. If the fault persists, refer to the electrical circuit diagrams and check the luggage compartment left low frequency antenna circuit for short circuit to power. Repair the wiring harness as necessary
B10C7-13	Interior Trunk Antenna - Circuit open	Luggage compartment left low frequency antenna circuit open circuit, high resistance	NOTE: If any other low frequency antenna short circuit to power DTC is also set, perform the relevant corrective action(s) first. Using the Jaguar Land Rover approved diagnostic equipment, run application - ECU Diagnostics / Remote Function Actuator (RFA) / Clear DTCs. Run application - ECU Diagnostics / Remote Function Actuator (RFA) / ECU Functions / On Demand Self Test. If the fault persists, refer to the electrical circuit diagrams and check the luggage compartment left low frequency antenna circuit for open circuit, high resistance. Repair the wiring harness as necessary
B10C8-00	Interior Centre Antenna - No sub type information	Passenger compartment rear low frequency antenna circuit short circuit to ground, short circuit to power	NOTE: If any other low frequency antenna short circuit to power DTC is also set, perform the relevant corrective action(s) first. Using the Jaguar Land Rover approved diagnostic equipment, run application - ECU Diagnostics / Remote Function Actuator (RFA) / Clear DTCs. Run application - ECU Diagnostics / Remote Function Actuator (RFA) / ECU Functions / On Demand Self Test. If the fault persists, refer to the electrical circuit diagrams and check the passenger compartment rear low frequency antenna circuit for short circuit to ground, short circuit to power. Repair the wiring harness as necessary

DTC	DESCRIPTION	POSSIBLE CAUSES	ACTION
B10C8-11	Interior Centre Antenna - Circuit short to ground	Passenger compartment rear low frequency antenna circuit short circuit to ground, short circuit between positive and negative	NOTE: If any other low frequency antenna short circuit to power DTC is also set, perform the relevant corrective action(s) first. Using the Jaguar Land Rover approved diagnostic equipment, run application - ECU Diagnostics / Remote Function Actuator (RFA) / Clear DTCs. Run application - ECU Diagnostics / Remote Function Actuator (RFA) / ECU Functions / On Demand Self Test. If the fault persists, refer to the electrical circuit diagrams and check the passenger compartment rear low frequency antenna circuit for short circuit to ground, short circuit between positive and negative. Repair the wiring harness as necessary
B10C8-12	Interior Centre Antenna - Circuit short to battery	Passenger compartment rear low frequency antenna circuit short circuit to power	Using the Jaguar Land Rover approved diagnostic equipment, run application - ECU Diagnostics / Remote Function Actuator (RFA) / Clear DTCs. Run application - ECU Diagnostics / Remote Function Actuator (RFA) / ECU Functions / On Demand Self Test. If the fault persists, refer to the electrical circuit diagrams and check the passenger compartment rear low frequency antenna circuit for short circuit to power. Repair the wiring harness as necessary
B10C8-13	Interior Centre Antenna - Circuit open	Passenger compartment rear low frequency antenna circuit open circuit, high resistance	NOTE: If any other low frequency antenna short circuit to power DTC is also set, perform the relevant corrective action(s) first. Using the Jaguar Land Rover approved diagnostic equipment, run application - ECU Diagnostics / Remote Function Actuator (RFA) / Clear DTCs. Run application - ECU Diagnostics / Remote Function Actuator (RFA) / ECU Functions / On Demand Self Test. If the fault persists, refer to the electrical circuit diagrams and check the passenger compartment rear low frequency antenna circuit for open circuit, high resistance. Repair the wiring harness as necessary
B10C9-00	Interior Front Antenna - No sub type information	Passenger compartment front low frequency antenna circuit short circuit to ground, short circuit to power	NOTE: If any other low frequency antenna short circuit to power DTC is also set, perform the relevant corrective action(s) first. Using the Jaguar Land Rover approved diagnostic equipment, run application - ECU Diagnostics / Remote Function Actuator (RFA) / Clear DTCs. Run application - ECU Diagnostics / Remote Function Actuator (RFA) / ECU Functions / On Demand Self Test. If the fault persists, refer to the electrical circuit diagrams and check the passenger compartment front low frequency antenna circuit for short circuit to ground, short circuit to power. Repair the wiring harness as necessary

DTC	DESCRIPTION	POSSIBLE CAUSES	ACTION
B10C9-11	Interior Front Antenna - Circuit short to ground	Passenger compartment front low frequency antenna circuit short circuit to ground, short circuit between positive and negative	NOTE: If any other low frequency antenna short circuit to power DTC is also set, perform the relevant corrective action(s) first. Using the Jaguar Land Rover approved diagnostic equipment, run application - ECU Diagnostics / Remote Function Actuator (RFA) / Clear DTCs. Run application - ECU Diagnostics / Remote Function Actuator (RFA) / ECU Functions / On Demand Self Test. If the fault persists, refer to the electrical circuit diagrams and check the passenger compartment front low frequency antenna circuit for short circuit to ground, short circuit between positive and negative. Repair the wiring harness as necessary
B10C9-12	Interior Front Antenna - Circuit short to battery	Passenger compartment front low frequency antenna circuit short circuit to power	Using the Jaguar Land Rover approved diagnostic equipment, run application - ECU Diagnostics / Remote Function Actuator (RFA) / Clear DTCs. Run application - ECU Diagnostics / Remote Function Actuator (RFA) / ECU Functions / On Demand Self Test. If the fault persists, refer to the electrical circuit diagrams and check the passenger compartment front low frequency antenna circuit for short circuit to power. Repair the wiring harness as necessary
B10C9-13	Interior Front Antenna - Circuit open	Passenger compartment front low frequency antenna circuit open circuit, high resistance	NOTE: If any other low frequency antenna short circuit to power DTC is also set, perform the relevant corrective action(s) first. Using the Jaguar Land Rover approved diagnostic equipment, run application - ECU Diagnostics / Remote Function Actuator (RFA) / Clear DTCs. Run application - ECU Diagnostics / Remote Function Actuator (RFA) / ECU Functions / On Demand Self Test. If the fault persists, refer to the electrical circuit diagrams and check the passenger compartment front low frequency antenna circuit for open circuit, high resistance. Repair the wiring harness as necessary
B10CC-23	Left Front Latch Clutch Switch - Signal stuck low	Left door latch clutch switch circuit short circuit to ground	Refer to the electrical circuit diagrams and check the left door latch clutch switch circuit for short circuit to ground. Repair the wiring harness as necessary
B10CE-23	Right Front Latch Clutch Switch - Signal stuck low	Right door latch clutch switch circuit short circuit to ground	Refer to the electrical circuit diagrams and check the right door latch clutch switch circuit for short circuit to ground. Repair the wiring harness as necessary
B10D1-23	Left Front Lock Button - Signal stuck low	Left exterior door handle lock switch circuit short circuit to ground	Refer to the electrical circuit diagrams and check the left exterior door handle lock switch circuit for short circuit to ground. Repair the wiring harness as necessary
B10D3-23	Right Front Lock Button - Signal stuck low	Right exterior door handle lock switch circuit short circuit to ground	Refer to the electrical circuit diagrams and check the right exterior door handle lock switch circuit for short circuit to ground. Repair the wiring harness as necessary

DTC	DESCRIPTION	POSSIBLE CAUSES	ACTION
B12D5-16	Door Handle Proximity Sensor - Circuit voltage below threshold	- Door handle proximity sensor circuit short circuit to ground - Remote function actuator power or ground circuit open circuit, high resistance - Remote function actuator internal failure	- Refer to the electrical circuit diagrams and check the door handle proximity sensor circuit for short circuit to ground. Repair the wiring harness as necessary - Using the Jaguar Land Rover approved diagnostic equipment, run application - ECU Diagnostics / Remote Function Actuator (RFA) / Live Data - and select parameter - ECU Power Supply Voltage (0xD111). Refer to the electrical circuit diagrams and check the remote function actuator power and ground circuits for open circuit, high resistance. Repair the wiring harness as necessary - Using the Jaguar Land Rover approved diagnostic equipment, run application - ECU Diagnostics / Remote Function Actuator (RFA) / Clear DTCs. Retest. If the fault persists, install a new remote function actuator
B12D6-11	Fast Door Unlock/Open Actuator - Circuit short to ground	Door latch actuator circuit(s) short circuit to ground	NOTE: Faults on individual terminals cannot be detected. A short circuit on any one output terminal will be detected as a short circuit on all terminals Refer to the electrical circuit diagrams and check the door latch actuator circuits for short circuit to ground. Repair the wiring harness as necessary
B12D6-12	Fast Door Unlock/Open Actuator - Circuit short to battery	Door latch actuator circuit(s) short circuit to power	NOTE: Faults on individual terminals cannot be detected. A short circuit on any one output terminal will be detected as a short circuit on all terminals Refer to the electrical circuit diagrams and check the door latch actuator circuits for short circuit to power. Repair the wiring harness as necessary
B12EA-96	Radio Frequency (RF) Receiver - Component internal failure	Radio frequency receiver internal failure	Using the Jaguar Land Rover approved diagnostic equipment, run application - ECU Diagnostics / Remote Function Actuator (RFA) / Clear DTCs. Retest. If the fault persists, install a new radio frequency receiver
B1334-23	Tailgate Glass Release Switch - Signal stuck low	- Tailgate glass switch circuit short circuit to ground - Tailgate glass switch stuck active	- Refer to the electrical circuit diagrams and check the tailgate glass switch circuit for short circuit to ground. Repair the wiring harness as necessary - Check the operation of the tailgate glass switch. Free the stuck switch or install a new tailgate glass switch as necessary

DTC	DESCRIPTION	POSSIBLE CAUSES	ACTION
B1335-00	Front Triangulation / Loadspace Antenna - No sub type information	Floor console front low frequency antenna circuit short circuit to ground, short circuit to power	NOTE: If any other low frequency antenna short circuit to power DTC is also set, perform the relevant corrective action(s) first. Using the Jaguar Land Rover approved diagnostic equipment, run application - ECU Diagnostics / Remote Function Actuator (RFA) / Clear DTCs. Run application - ECU Diagnostics / Remote Function Actuator (RFA) / ECU Functions / On Demand Self Test. If the fault persists, refer to the electrical circuit diagrams and check the floor console front low frequency antenna circuit for short circuit to ground, short circuit to power. Repair the wiring harness as necessary
B1335-11	Front Triangulation / Loadspace Antenna - Circuit short to ground	Floor console front low frequency antenna circuit short circuit to ground, short circuit between positive and negative	NOTE: If any other low frequency antenna short circuit to power DTC is also set, perform the relevant corrective action(s) first. Using the Jaguar Land Rover approved diagnostic equipment, run application - ECU Diagnostics / Remote Function Actuator (RFA) / Clear DTCs. Run application - ECU Diagnostics / Remote Function Actuator (RFA) / ECU Functions / On Demand Self Test. If the fault persists, refer to the electrical circuit diagrams and check the floor console front low frequency antenna circuit for short circuit to ground, short circuit between positive and negative. Repair the wiring harness as necessary
B1335-12	Front Triangulation / Loadspace Antenna - Circuit short to battery	Floor console front low frequency antenna circuit short circuit to power	Using the Jaguar Land Rover approved diagnostic equipment, run application - ECU Diagnostics / Remote Function Actuator (RFA) / Clear DTCs. Run application - ECU Diagnostics / Remote Function Actuator (RFA) / ECU Functions / On Demand Self Test. If the fault persists, refer to the electrical circuit diagrams and check the floor console front low frequency antenna circuit for short circuit to power. Repair the wiring harness as necessary
B1335-13	Front Triangulation / Loadspace Antenna - Circuit open	Floor console front low frequency antenna circuit open circuit, high resistance	NOTE: If any other low frequency antenna short circuit to power DTC is also set, perform the relevant corrective action(s) first. Using the Jaguar Land Rover approved diagnostic equipment, run application - ECU Diagnostics / Remote Function Actuator (RFA) / Clear DTCs. Run application - ECU Diagnostics / Remote Function Actuator (RFA) / ECU Functions / On Demand Self Test. If the fault persists, refer to the electrical circuit diagrams and check the floor console front low frequency antenna circuit for open circuit, high resistance. Repair the wiring harness as necessary

DTC	DESCRIPTION	POSSIBLE CAUSES	ACTION
B1336-00	Left Front Door External Antenna - No sub type information	Front left exterior door handle low frequency antenna circuit short circuit to ground, short circuit to power	NOTE: If any other low frequency antenna short circuit to power DTC is also set, perform the relevant corrective action(s) first. Using the Jaguar Land Rover approved diagnostic equipment, run application - ECU Diagnostics / Remote Function Actuator (RFA) / Clear DTCs. Run application - ECU Diagnostics / Remote Function Actuator (RFA) / ECU Functions / On Demand Self Test. If the fault persists, refer to the electrical circuit diagrams and check the front left exterior door handle low frequency antenna circuit for short circuit to ground, short circuit to power. Repair the wiring harness as necessary
B1336-11	Left Front Door External Antenna - Circuit short to ground	Front left exterior door handle low frequency antenna circuit short circuit to ground, short circuit between positive and negative	NOTE: If any other low frequency antenna short circuit to power DTC is also set, perform the relevant corrective action(s) first. Using the Jaguar Land Rover approved diagnostic equipment, run application - ECU Diagnostics / Remote Function Actuator (RFA) / Clear DTCs. Run application - ECU Diagnostics / Remote Function Actuator (RFA) / ECU Functions / On Demand Self Test. If the fault persists, refer to the electrical circuit diagrams and check the front left exterior door handle low frequency antenna circuit for short circuit to ground, short circuit between positive and negative. Repair the wiring harness as necessary
B1336-12	Left Front Door External Antenna - Circuit short to battery	Front left exterior door handle low frequency antenna circuit short circuit to power	Using the Jaguar Land Rover approved diagnostic equipment, run application - ECU Diagnostics / Remote Function Actuator (RFA) / Clear DTCs. Run application - ECU Diagnostics / Remote Function Actuator (RFA) / ECU Functions / On Demand Self Test. If the fault persists, refer to the electrical circuit diagrams and check the front left exterior door handle low frequency antenna circuit for short circuit to power. Repair the wiring harness as necessary
B1336-13	Left Front Door External Antenna - Circuit open	Front left exterior door handle low frequency antenna circuit open circuit, high resistance	NOTE: If any other low frequency antenna short circuit to power DTC is also set, perform the relevant corrective action(s) first. Using the Jaguar Land Rover approved diagnostic equipment, run application - ECU Diagnostics / Remote Function Actuator (RFA) / Clear DTCs. Run application - ECU Diagnostics / Remote Function Actuator (RFA) / ECU Functions / On Demand Self Test. If the fault persists, refer to the electrical circuit diagrams and check the front left exterior door handle low frequency antenna circuit for open circuit, high resistance. Repair the wiring harness as necessary

DTC	DESCRIPTION	POSSIBLE CAUSES	ACTION
B1337-00	Right Front Door External Antenna - No sub type information	Front right exterior door handle low frequency antenna circuit short circuit to ground, short circuit to power	NOTE: If any other low frequency antenna short circuit to power DTC is also set, perform the relevant corrective action(s) first. Using the Jaguar Land Rover approved diagnostic equipment, run application - ECU Diagnostics / Remote Function Actuator (RFA) / Clear DTCs. Run application - ECU Diagnostics / Remote Function Actuator (RFA) / ECU Functions / On Demand Self Test. If the fault persists, refer to the electrical circuit diagrams and check the front right exterior door handle low frequency antenna circuit for short circuit to ground, short circuit to power. Repair the wiring harness as necessary
B1337-11	Right Front Door External Antenna - Circuit short to ground	Front right exterior door handle low frequency antenna circuit short circuit to ground, short circuit between positive and negative	NOTE: If any other low frequency antenna short circuit to power DTC is also set, perform the relevant corrective action(s) first. Using the Jaguar Land Rover approved diagnostic equipment, run application - ECU Diagnostics / Remote Function Actuator (RFA) / Clear DTCs. Run application - ECU Diagnostics / Remote Function Actuator (RFA) / ECU Functions / On Demand Self Test. If the fault persists, refer to the electrical circuit diagrams and check the front right exterior door handle low frequency antenna circuit for short circuit to ground, short circuit between positive and negative. Repair the wiring harness as necessary
B1337-12	Right Front Door External Antenna - Circuit short to battery	Front right exterior door handle low frequency antenna circuit short circuit to power	Using the Jaguar Land Rover approved diagnostic equipment, run application - ECU Diagnostics / Remote Function Actuator (RFA) / Clear DTCs. Run application - ECU Diagnostics / Remote Function Actuator (RFA) / ECU Functions / On Demand Self Test. If the fault persists, refer to the electrical circuit diagrams and check the front right exterior door handle low frequency antenna circuit for short circuit to power. Repair the wiring harness as necessary
B1337-13	Right Front Door External Antenna - Circuit open	Front right exterior door handle low frequency antenna circuit open circuit, high resistance	NOTE: If any other low frequency antenna short circuit to power DTC is also set, perform the relevant corrective action(s) first. Using the Jaguar Land Rover approved diagnostic equipment, run application - ECU Diagnostics / Remote Function Actuator (RFA) / Clear DTCs. Run application - ECU Diagnostics / Remote Function Actuator (RFA) / ECU Functions / On Demand Self Test. If the fault persists, refer to the electrical circuit diagrams and check the front right exterior door handle low frequency antenna circuit for open circuit, high resistance. Repair the wiring harness as necessary

DTC	DESCRIPTION	POSSIBLE CAUSES	ACTION
B133D-00	Loadspace/Interior Boot Antenna - No sub type information	Luggage compartment right low frequency antenna circuit short circuit to ground, short circuit to power	NOTE: If any other low frequency antenna short circuit to power DTC is also set, perform the relevant corrective action(s) first. Using the Jaguar Land Rover approved diagnostic equipment, run application - ECU Diagnostics / Remote Function Actuator (RFA) / Clear DTCs. Run application - ECU Diagnostics / Remote Function Actuator (RFA) / ECU Functions / On Demand Self Test. If the fault persists, refer to the electrical circuit diagrams and check the luggage compartment right low frequency antenna circuit for short circuit to ground, short circuit to power. Repair the wiring harness as necessary
B133D-11	Loadspace/Interior Boot Antenna - Circuit short to ground	Luggage compartment right low frequency antenna circuit short circuit to ground, short circuit between positive and negative	NOTE: If any other low frequency antenna short circuit to power DTC is also set, perform the relevant corrective action(s) first. Using the Jaguar Land Rover approved diagnostic equipment, run application - ECU Diagnostics / Remote Function Actuator (RFA) / Clear DTCs. Run application - ECU Diagnostics / Remote Function Actuator (RFA) / ECU Functions / On Demand Self Test. If the fault persists, refer to the electrical circuit diagrams and check the luggage compartment right low frequency antenna circuit for short circuit to ground, short circuit between positive and negative. Repair the wiring harness as necessary
B133D-12	Loadspace/Interior Boot Antenna - Circuit short to battery	Luggage compartment right low frequency antenna circuit short circuit to power	Using the Jaguar Land Rover approved diagnostic equipment, run application - ECU Diagnostics / Remote Function Actuator (RFA) / Clear DTCs. Run application - ECU Diagnostics / Remote Function Actuator (RFA) / ECU Functions / On Demand Self Test. If the fault persists, refer to the electrical circuit diagrams and check the luggage compartment right low frequency antenna circuit for short circuit to power. Repair the wiring harness as necessary
B133D-13	Loadspace/Interior Boot Antenna - Circuit open	Luggage compartment right low frequency antenna circuit open circuit, high resistance	NOTE: If any other low frequency antenna short circuit to power DTC is also set, perform the relevant corrective action(s) first. Using the Jaguar Land Rover approved diagnostic equipment, run application - ECU Diagnostics / Remote Function Actuator (RFA) / Clear DTCs. Run application - ECU Diagnostics / Remote Function Actuator (RFA) / ECU Functions / On Demand Self Test. If the fault persists, refer to the electrical circuit diagrams and check the luggage compartment right low frequency antenna circuit for open circuit, high resistance. Repair the wiring harness as necessary

DTC	DESCRIPTION	POSSIBLE CAUSES	ACTION
B1D9A-23	Customer Foot Proximity Sensor - Signal stuck low	- Hands-free tailgate sensor circuit short circuit to ground - Hands-free tailgate sensor failure	- Refer to the electrical circuit diagrams and check the hands-free tailgate sensor circuit for short circuit to ground. Repair the wiring harness as necessary - Using the Jaguar Land Rover approved diagnostic equipment, run application - ECU Diagnostics / Remote Function Actuator (RFA) / Clear DTCs. Retest. If the fault persists, install a new hands-free tailgate sensor
U0010-88	Medium Speed CAN Communication Bus - Bus off	Medium speed CAN (body) circuit short circuit to ground, short circuit to power, open circuit, high resistance	Refer to the electrical circuit diagrams and check the medium speed CAN (body) circuit for short circuit to ground, short circuit to power, open circuit, high resistance. Repair the wiring harness as necessary
U0300-00	Internal Control Module Software Incompatibility - No sub type information	Car configuration file mismatch with vehicle specification	Using the Jaguar Land Rover approved diagnostic equipment, run application - Service / Select CCF / Copy from AS BUILT
U201F-00	External Receiver - No sub type information	- Radio frequency receiver power or ground circuit open circuit, high resistance - Radio frequency receiver communication circuit short circuit to ground, short circuit to power - Radio frequency receiver internal failure - Remote function actuator internal failure	- Refer to the electrical circuit diagrams and check the radio frequency receiver power and ground circuits for open circuit, high resistance. Repair the wiring harness as necessary - Refer to the electrical circuit diagrams and check the radio frequency receiver communication circuit for short circuit to ground, short circuit to power, open circuit, high resistance. Repair the wiring harness as necessary - Using the Jaguar Land Rover approved diagnostic equipment, run application - ECU Diagnostics / Remote Function Actuator (RFA) / Clear DTCs. Retest. If the fault persists, install a new radio frequency receiver - Using the Jaguar Land Rover approved diagnostic equipment, run application - ECU Diagnostics / Remote Function Actuator (RFA) / Clear DTCs. Retest. If the fault persists, install a new remote function actuator
U201F-31	External Receiver - No signal	- Radio frequency receiver power or ground circuit open circuit, high resistance - Radio frequency receiver communication circuit short circuit to ground, short circuit to power - Radio frequency receiver internal failure - Remote function actuator internal failure	- Refer to the electrical circuit diagrams and check the radio frequency receiver power and ground circuits for open circuit, high resistance. Repair the wiring harness as necessary - Refer to the electrical circuit diagrams and check the radio frequency receiver communication circuit for short circuit to ground, short circuit to power, open circuit, high resistance. Repair the wiring harness as necessary - Using the Jaguar Land Rover approved diagnostic equipment, run application - ECU Diagnostics / Remote Function Actuator (RFA) / Clear DTCs. Retest. If the fault persists, install a new radio frequency receiver - Using the Jaguar Land Rover approved diagnostic equipment, run application - ECU Diagnostics / Remote Function Actuator (RFA) / Clear DTCs. Retest. If the fault persists, install a new remote function actuator
U201F-95	External Receiver - Incorrect assembly	- Car configuration file mismatch with vehicle specification - Incorrect radio frequency receiver installed - Wrong frequency	- Using the Jaguar Land Rover approved diagnostic equipment, run application - Service / Select CCF / Copy from AS BUILT - Install a new radio frequency receiver as necessary

DTC	DESCRIPTION	POSSIBLE CAUSES	ACTION
U2100-00	Initial Configuration Not Complete - No sub type information	Remote function actuator software is not at latest version	Using the Jaguar Land Rover approved diagnostic equipment, run application - ECU Diagnostics / Remote Function Actuator (RFA) / Update ECU
U2101-00	Control Module Configuration Incompatible - No sub type information	Car configuration file mismatch with vehicle specification	Using the Jaguar Land Rover approved diagnostic equipment, run application - Service / Select CCF / Copy from AS BUILT
U3000-44	Control Module - Data memory failure	Remote function actuator internal failure	Using the Jaguar Land Rover approved diagnostic equipment, run application - ECU Diagnostics / Remote Function Actuator (RFA) / Clear DTCs. Retest. If the fault persists, install a new remote function actuator
U3000-45	Control Module - Program memory failure	Remote function actuator internal failure	Using the Jaguar Land Rover approved diagnostic equipment, run application - ECU Diagnostics / Remote Function Actuator (RFA) / Clear DTCs. Retest. If the fault persists, install a new remote function actuator
U3000-46	Control Module - Calibration/parameter memory failure	Remote function actuator internal failure	Using the Jaguar Land Rover approved diagnostic equipment, run application - ECU Diagnostics / Remote Function Actuator (RFA) / Clear DTCs. Retest. If the fault persists, install a new remote function actuator
U3000-63	Control Module - Circuit/component protection time-out	Remote function actuator internal failure	Using the Jaguar Land Rover approved diagnostic equipment, run application - ECU Diagnostics / Remote Function Actuator (RFA) / Clear DTCs. Retest. If the fault persists, install a new remote function actuator
U3000-95	Control Module - Incorrect assembly	Incorrect remote function actuator installed. Car configuration parameter indicates the vehicle should support full passive entry / passive start functionality, but installed module supports passive start only	Using the Jaguar Land Rover approved diagnostic equipment, run application - ECU Diagnostics / Remote Function Actuator (RFA) / Clear DTCs. Retest. If the fault persists, install a new remote function actuator
U3002-81	Vehicle Identification Number - Invalid serial data received	Car configuration file mismatch with vehicle specification	Using the Jaguar Land Rover approved diagnostic equipment, run application - Service / Select CCF / Copy from AS BUILT