

## GENERAL INFORMATION

# VEHICLE INSPECTION [G2148924]

### DESCRIPTION AND OPERATION

#### NOTE:

For additional information on systems/components that must be checked, refer to the relevant section in the Workshop Manual.

Vehicle inspections may be completed for various reasons. the following sections provide clarity on specific systems/components that must be checked.

- Inspect windshield, door, tailgate and rear quarter glass for damage.
- Check operation of door locks, door hinges, door check straps, hood latches, fuel flap and charge flap.

#### CAUTIONS:

- Brake fluid level should be between MIN and MAX based upon brake pad wear.
- Only top-up brake fluid level to MAX after new brake pads have been installed.
- If the brake fluid level is below MIN, visually check for any leaks.

Check vehicle fluid levels. Refer to the workshop manual.

- Check coolant concentration level.
- Check condition of accessory drive belt(s).
- Check startup battery and auxiliary battery (if equipped) visual condition and perform a test using the Jaguar Land Rover (JLR) approved hand-held battery diagnostic equipment. Record the resulting battery test code.
- Check expiry date on tire repair system fluid (if equipped).
- Check tire condition and for signs of uneven wear and suitability (including spare - if equipped).
- Check tire pressures and adjust if required (including spare - if equipped).
- Check and record tire tread depths (including spare - if equipped).

#### NOTES:

- Do not remove any undertrays to access the engine and transmission mounting rubbers.
- Non visible engine and transmission mounting rubbers can be checked, if the undertrays are removed to replace a service item.

Check engine and transmission mounting rubbers where visible.

- Check visually brake, coolant, fuel hoses/pipes and unions for chafing, leaks and corrosion.

▪



**The following applies to:**

Range Rover (LG), L494 - RANGE ROVER SPORT

- Check dynamic response hoses and unions for chafing, leaks and corrosion.
- Check visually electrical harnesses for chafing and corrosion.
- Check exhaust system for leaks, security and damage.
- Inspect brake pads, brake calipers and brake discs for wear, leaks, security and condition.

▪



**The following applies to:**

JAGUAR X152 F-TYPE

- Connect Jaguar Land Rover approved diagnostic equipment and perform Disc Wear Prediction Algorithm (Carbon Ceramic Brakes only).
- Check condition of all suspension components, driveshafts and steering boots and gaiters where visible.

▪



**The following applies to:**

Range Rover (LG), L494 - RANGE ROVER SPORT

- Check torque of towbar fixings (multi-height towbar ball only).
- Clear debris from auxiliary oil cooler and radiator pack.