HOW[TO[PROCEED[WITH[TROUBLESHOOTING]			
1 VEHICLE BROUGHT TO WORK SHOP			
2 CUSTOMER PROBLEM ANALYSIS (See page 05-974)			
3 CHECK[BODY[MULTIPLEX[COMMUNICATION[\$YSTEM[(See[page[05-1274)			
(a) Check that the DTC outputs.			
DTC OUTPUTS (PROCEED TO "BODY MULTI- PLEX COMMUNICATION SYSTEM")			
DTC DOES NOT OUTPUT (GO TO STEP 4)			
4 DTC[CHECK[(See[Page[05-975)			
MALFUNCTION CODE (GO TO STEP 5)			
NORMAL CODE (GO TO STEP 6)			
5 DTC[CHART[(See[Page[05-976)			
GO TO STEP 8			
6 PROBLEM SYMPTOMS TABLE (See page 05-981)			
7 TERMINAL OF ECU (See page 05-979)			
8 CIRCUIT NSPECTION See Page 5-983)			
9 IDENTIFICATION OF PROBLEM			
10 REPAIR OR REPLACE			

11	CONFIRMATION TEST		
END			