

## : Parts Location

Code		See Page	Code		See Page	Code		See Page
A13	А	42	F11	В	40 (*2)	J22	Α	43
A40	В	42		Α	38 (*1)	J23	В	43
C7	Α	42	F12		40 (*2)	R6		45
C11		42	' '^	В	38 (*1)	R	7	45
	А	38 (*1)	.	"	40 (*2)	Т	7	43
F11		40 (*2)	H10		43			
	В	38 (*1) J2		43				

## : Junction Block and Wire Harness Connector

Code	See Page	Junction Block and Wire Harness (Connector Location)		
1B	25	Engine Room Main Wire and Engine Room J/B (Engine Compartment Left)		
2G	28	Engine Room Main Wire and Driver Side J/B (Lower Finish Panel)		
2K	28	Floor Wire and Driver Side J/B (Lower Finish Panel)		
2M				
2N	29	Instrument Panel Wire and Driver Side J/B (Lower Finish Panel)		
2R				
3A	34	Instrument Panel Wire and Passenger Side J/B (Instrument Panel Brace RH)		
3B		instrument and vire and rassenger side 3/b (instrument and brace Kri)		

## : Connector Joining Wire Harness and Wire Harness

Code	See Page	Joining Wire Harness and Wire Harness (Connector Location)
IF3	50	Engine Room Main Wire and Instrument Panel Wire (Right Side of Steering Column Tube)

## : Ground Points

Code	See Page	Ground Points Location	
EB	48 (*1)	- Right Fender	
	49 (*2)		
EC	48 (*1)	Left Fender	
	49 (*2)	Lettrender	
II	50	Cowl Side Panel LH	
IJ	50	Instrument Panel Brace LH	
BQ	52	Front Side of Rear Quarter Wheel House LH	
BS	52	Lower Back Panel Center	