

: Parts Location

Code		See Page	Code		See Page	Code	See Page
J4		43	J20	Α	47 (*4)	S5	43
J18	Α	46 (*3)	J21	В	46 (*3)	S17	46 (*3)
J 10	С	46 (*3)			47 (*4)	S18	46 (*3)
J19	В	46 (*3)		С	46 (*3)		47 (*4)
	D	46 (*3)			47 (*4)		
J20	Α	46 (*3)	S4		43		

: Junction Block and Wire Harness Connector

Code	See Page	Junction Block and Wire Harness (Connector Location)
2B	28	Instrument Panel Wire and Driver Side J/B (Lower Finish Panel)

: Connector Joining Wire Harness and Wire Harness

Code	See Page	Joining Wire Harness and Wire Harness (Connector Location)
IC2	50	Instrument Panel Wire and Floor Wire (Left Kick Panel)
IN4	51	Instrument Panel Wire and Floor No.2 Wire (Right Kick Panel)

7 : Ground Points

Code	See Page	Ground Points Location	
IK	50	Instrument Panel Brace LH	
ВО	52	Under the Driver's Seat	
BP	52	Under the Front Passenger's Seat	