AIR CONDITIONING SYSTEM
HOW[TO[PROCEED[WITH[TROUBLESHOOTING]
1 VEHICLE[BROUGHT[TO[WORK[\$HOP
2 CUSTOMER[PROBLEM[ANALYSIS[See[page[05-686)]
3 CHECK[AND[CLEAR[DTC[See[page[05-687)]
4 PROBLEM SYMPTOM CONFIRMATION
SYMPTOM[OCCUR[GO]TO[STEP[6)
SYMPTOM[DOES[NOT[DCCUR[[GO[TO STEP[5])
5 SYMPTOM SIMULATION (See page 01-21)
6 DTC CHECK (See page 05-687)
MALFUNCTION CODE (GO TO STEP)
NORMAL[CODE[GO[TO[STEP]8)
7 DTC[CHART[[See[page[05-690]
GO TO STEP 10
8 PROBLEM SYMPTOMS TABLE (See page 05-697)
9 ACTUATOR CHECK (See page 05-687)

10 CIRCUIT[INSPECTION[See[page[05-699-[05-752]
11 IDENTIFICATION OF PROBLEM
12 PARTS INSPECTION
13 REPAIR
14 CONFIRMATION TEST
15 END