

R 4(A), R13(B) Radio and Player with Display SW1 SWG SW2 GND 8 **B** 20 **(**A) BR Y(\*1) 12 AU1 EAU AU2 MODE Steering Pad SW Seek-C10 Combination SW Volume+ Volume-S12(A), S13(B) Stereo Component Amplifier RL+ RL-RR+ RR-GND 4 (A) 11 (A) 3 **(**A) 10 (A) BR 3 IH1 7 IH2 2 IH3 1 IH1 2 IH1 ≥ BR 1 IN2 4 IN2 2

R 8 Rear Speaker LH R 9 Rear Speaker RH

# **Audio System for Separate Type Amplifier without Navigation System**

## O : Parts Location

Code		See Page	Code		See Page	Code		See Page
С	10	42	R4	Α	43	S13	В	43
F6	Α	44	R8		45	T9		43
	В	44	R9		45	T10		43
F7	Α	44	R13	В	43			
	В	44	S12	Α	43			

### : Junction Block and Wire Harness Connector

	Code	See Page	Junction Block and Wire Harness (Connector Location)
I	2A	28	Instrument Panel Wire and Driver Side J/B (Lower Finish Panel)

#### : Connector Joining Wire Harness and Wire Harness

Code	See Page	Joining Wire Harness and Wire Harness (Connector Location)
IB2	50	Front Door LH Wire and Instrument Panel Wire (Left Kick Panel)
IH1		
IH2	50	Instrument Panel Wire and Instrument Panel No.2 Wire (Instrument Panel Brace RH)
IH3	]	
IM2	51	Front Door RH Wire and Instrument Panel Wire (Right Kick Panel)
IN2	51	Instrument Panel Wire and Floor No.2 Wire (Right Kick Panel)

#### : Ground Points

Code	See Page	Ground Points Location
IL	50	Instrument Panel Brace RH