









: Parts Location

Co	de	See Page	Code		See Page	Code	See Page
G1	Α	38 (*1)	G1	Α	40 (*2)	l15	43

) : Relay Blocks

	Code	See Page	Relay Blocks (Relay Block Location)
ſ	1	22	Engine Room R/B (Engine Compartment Left)

: Junction Block and Wire Harness Connector

Code	See Page	Junction Block and Wire Harness (Connector Location)	
1A		Engine Room Main Wire and Engine Room J/B (Engine Compartment Left)	
1C			
1D	25		
1E	725		
1F			
1G			
2A	28	Instrument Panel Wire and Driver Side J/B (Lower Finish Panel)	
2E	_ 28	Engine Room Main Wire and Driver Side J/B (Lower Finish Panel)	
2F			
2R	29	Instrument Panel Wire and Driver Side J/B (Lower Finish Panel)	

: Connector Joining Wire Harness and Wire Harness

Code	See Page	Joining Wire Harness and Wire Harness (Connector Location)
IF1	- 50	Engine Room Main Wire and Instrument Panel Wire (Right Side of Steering Column Tube)
IF6		

: Ground Points

	Code	See Page	Ground Points Location
ſ	П	50	Cowl Side Panel LH