



Power Seat

O : Parts Location

Code		See Page	Code	See Page	Code		See Page
J18	А	46 (*3)	J21 C	47 (*4)	P24		46 (*3)
	С	46 (*3)	P15	46 (*3)	P25		46 (*3)
J19	В	46 (*3)	P16	46 (*3)	P28		46 (*3)
1 319	D	46 (*3)	P17	46 (*3)	F20		47 (*4)
J20	А	46 (*3)	P18	46 (*3)		P29 A	46 (*3)
320		47 (*4)	P19	46 (*3)	D20		47 (*4)
J21	В	46 (*3)	P20	46 (*3)	F29	В	46 (*3)
		47 (*4)	P22	46 (*3)			47 (*4)
	С	46 (*3)	P23	46 (*3)			

: Junction Block and Wire Harness Connector

Code	See Page	Junction Block and Wire Harness (Connector Location)	
2B	28	Instrument Panel Wire and Driver Side J/B (Lower Finish Panel)	
2J 28 Floor Wire and Driver Side J/B (Lower Finish Panel)		Floor Wire and Driver Side J/B (Lower Finish Panel)	

: Connector Joining Wire Harness and Wire Harness

	Code	See Page	Joining Wire Harness and Wire Harness (Connector Location)
ſ	IN4	51	Instrument Panel Wire and Floor No.2 Wire (Right Kick Panel)

: Ground Points

Code	See Page	Ground Points Location	
ВО	52	Under the Driver's Seat	
BP	52	Under the Front Passenger's Seat	

^{* 1 : 1}MZ-FE, 3MZ-FE

^{* 2 : 2}AZ-FE

^{* 3 :} w/ Power Seat

^{* 4 :} w/o Power Seat