055VG-02

## DIAGNOSTIC TROUBLE CODE CHART

DTC[No. (See[page)	DTC[detection[condition	Trouble[area
B2795 (05-1 <b>2</b> 69)	Unmatched key code	• Key
B2796 (05–1 <u>2</u> 70)	No communication in immobiliser system	Key     Transponder key amplifier     Wire harness     ECM
B2797 (05–1 <u>2</u> 73)	Communication malfunction No.1	Wire harness     Transponder key amplifier     Key     ECM
B2798 (05–1 <mark>2</mark> 70)	Communication malfunction No. 2	Key     Transponder key amplifier     Wire harness     ECM

## **NOTICE:**

- Codes B2795, B2797 and B2798 may remain as a record that the immobiliser system has activated in the past.
- The diagnosis code on the immobiliser system is specified in this chart. If any other code is output, check the diagnostic code chart on the engine control system.

```
(1AZ-FE@ngine: See page 05-17)
(2AZ-FE@ngine: See page 05-145)
(1MZ-FE@ngine: See page 05-301)
```

## HINT:

- The [] SAE code [] Indicates a code [] output [] when [] using [] he [] hand held [] ester.
- The "lamp" indicates a code output when using the malfunction indicator lamp.

```
(1AZ-FE@ngine: [05-1]])
(2AZ-FE@ngine: [05-1]]5)
(1MZ-FE@ngine: [05-301)
```