RESET

1. RESET SLIDING ROOF POSITION

NOTICE:

When the battery negative (–) terminal is disconnected or PWR No.1 fuse is removed due to the repair, the sliding roof position memory is erased. After reconnecting the battery negative (–) terminal, make sure to reset the zero point.

If the sliding roof has not been reset, the sliding roof AUTO operation functions will not operate.

Vehicle type	Condition	Proceed to
TMC made CAMRY	 Battery negative (-) terminal is disconnected. Component parts of sliding roof are replaced. PWR No.1 fuse is removed. 	Reset A
	Sliding roof dose not stop at the fully closed position even if AUTO close switch is operated.	Reset B
TMMK made CAMRY	Battery negative (–) terminal is disconnected. PWR No.1 fuse is removed.	Reset A
	 Component parts of sliding roof are replaced. Sliding roof dose not stop at the fully closed position even if AUTO close switch is operated. 	Reset C

(a) Reset A

- (1) To reset the sliding roof to the zero point, push and hold the switch on the TILT UP position until the sliding roof tilts all the way up and tilts down a little automatically.
- (2) Confirm "one-touch side open and close" and "one-touch tilt up and down" functions by pushing the switch briefly to the SLIDE/OPEN position and TILT/UP position.

(b) Reset B

- (1) Push and hold the switch on the TILT UP/CLOSE position until the sliding roof stops.
- (2) Continue to push and hold the switch on the TILT UP/CLOSE position for 10 seconds or more. The sliding roof closes to the fully closed position.
- (3) Continue to push and hold the switch on the TILT UP/CLOSE position until the sliding roof tilts all the way up and tilts down a little automatically.
- (4) Confirm "one-touch side open and close" and "one-touch tilt up and down" functions by pushing the switch briefly to the SLIDE/OPEN position and TILT/UP position.

(c) Reset C

- (1) To reset the sliding roof to the zero point, push and hold the switch on the TILT UP position until the sliding roof tilts all the way up and tilts down a little automatically.
- (2) Release the switch. Within 5 seconds, re–push and hold the switch on the TILT UP/CLOSE position.
- (3) The sliding roof automatically moves to the fully open position and then reverses towards the closed position.
- (4) Release the switch.
- (5) Confirm "one-touch side open and close" and "one-touch tilt up and down" functions by pushing the switch briefly to the SLIDE/OPEN position and TILT/UP position.

7404C-03