## 055T9-02

## DIAGNOSTIC TROUBLE CODE CHART

If a malfunction code is displayed during the DTC check, check the suspected area listed for that code in the table below and proceed to the appropriate page.

| DTC<br>(See F | - | Symptom           | Suspect Area  |
|---------------|---|-------------------|---|
| (05–1         |   | Light sensor fail | Light sensor Wire harness Instrument panel J/B assy |