

: Parts Location

Code	See Page	Code	See Page	Code	See Page
C11	42	F1	40 (*2)	F2	40 (*2)
F1	38 (*1)	F2	38 (*1)	J4	43

: Relay Blocks

Code	See Page	Relay Blocks (Relay Block Location)	
1	22	Engine Room R/B (Engine Compartment Left)	

: Junction Block and Wire Harness Connector

Code	See Page	Junction Block and Wire Harness (Connector Location)
1F	25	Engine Room Main Wire and Engine Room J/B (Engine Compartment Left)
2C	28	Instrument Panel Wire and Driver Side J/B (Lower Finish Panel)
2G	28	Engine Room Main Wire and Driver Side J/B (Lower Finish Panel)
2R	29	Instrument Panel Wire and Driver Side J/B (Lower Finish Panel)
3A	34	Instrument Panel Wire and Passenger Side J/B (Instrument Panel Brace RH)

: Connector Joining Wire Harness and Wire Harness

Code	See Page	Joining Wire Harness and Wire Harness (Connector Location)	
IF2	50	Engine Room Main Wire and Instrument Panel Wire (Right Side of Steering Column Tube)	

: Ground Points

Code	See Page	Ground Points Location	
EB	48 (*1)	RightFender	
	49 (*2)	right ender	
EC	48 (*1)	Left Fender	
	49 (*2)		
IK	50	Instrument Panel Brace LH	