

: Parts Location

Co	de	See Page	Code		See Page	Code		See Page
A13	Α	42	E7	В	42	J23	В	43
A40	С	42	L	F	42	T11	Α	43
D3		42 H10		В	43	''' В	В	43
D6	Α	44 114 43		U1		43		
D6	В	44	J22	Α	43			

0

: Junction Block and Wire Harness Connector

Code	See Page	Junction Block and Wire Harness (Connector Location)	
1B	25	Engine Room Main Wire and Engine Room J/B (Engine Compartment Left)	
2M	29	Instrument Panel Wire and Driver Side J/B (Lower Finish Panel)	
2R	29	Institution to a new order order of the content in the content and order	
3A	34	Instrument Panel Wire and Passenger Side J/B (Instrument Panel Brace RH)	
3B			

: Connector Joining Wire Harness and Wire Harness

Code	See Page	Joining Wire Harness and Wire Harness (Connector Location)	
IC2	50	Instrument Panel Wire and Floor Wire (Left Kick Panel)	
IF1	50	Engine Room Main Wire and Instrument Panel Wire (Right Side of Steering Column Tube)	
IJ1	51	Instrument Panel Wire and Instrument Panel Wire (Instrument Panel Reinforcement RH)	

: Ground Points

	Code	See Page	Ground Points Location
I	П	50	Cowl Side Panel LH