

: Parts Location

Co	Code See Page Code		See Page	Code	See Page		
B7	В	42	G1	Α	40 (*2)	l15	43
C7	Α	42	G2	В	38 (*1)		
G1	Α	38 (*1)			40 (*2)		

: Relay Blocks

ĺ	Code	See Page	Relay Blocks (Relay Block Location)	
I	1	22	Engine Room R/B (Engine Compartment Left)	

: Junction Block and Wire Harness Connector

Code	See Page	Junction Block and Wire Harness (Connector Location)	
1A			
1C	25	Engine Room Main Wire and Engine Room J/B (Engine Compartment Left)	
1E			
1L	25	Engine Wire and Engine Room J/B (Engine Compartment Left)	
2G	28	Engine Room Main Wire and Driver Side J/B (Lower Finish Panel)	
2M	29	Instrument Panel Wire and Driver Side J/B (Lower Finish Panel)	
20	Histianian rana vine and Driva Side 3/D (Lower Fillish Fallet)		
3A	34	Instrument Panel Wire and Passenger Side J/B (Instrument Panel Brace RH)	
3B] 34	instrument Fanel Wile and Fassenger Side 3/b (instrument Fanel blace KH)	

: Connector Joining Wire Harness and Wire Harness

	Code	See Page	Joining Wire Harness and Wire Harness (Connector Location)	
	IF1	50	Engine Room Main Wire and Instrument Panel Wire (Right Side of Steering Column Tube)	
ſ	IF6		Engine Room Main whe and instrument raner whe (Right Side of Steering Column rube)	
	IL2	51	Engine Wire and Instrument Panel Wire (Behind the Glove Box)	