## DTC C1201/51 ENGINE CONTROL SYSTEM MALFUNCTION

## **CIRCUIT** DESCRIPTION

DTC[No.	DTC[Detecting[Condition	Trouble[ <b>A</b> rea
C1201/51	Conditions 1.[and[2.[continue]]or[\$[sec.: 1.[Engine[speed:[\$00[]pm[or[]more. 2.[A[]rouble[signal[]n[]he[engine[control[system[]s]]nput.	Engine[control[system

## HINT:

If [rouble occurs in the engine control system, the ECU prohibits TRAC and VSC control.

## INSPECTION PROCEDURE

1[	CHECK[DTC[FOR[ENGINE[See]page[05-290)
----	---------------------------------------

Α	Normal@ode
В	Malfunction[Code

B REPAIR ENGINE CONTROL SYSTEM ACCORDING TO CODE OUTPUT

Α

CHECK AND REPLACE ECM