HOW	TO PROCEED WITH TROUBLESHOOTING
1	VEHICLE BROUGHT TO WORK SHOP
2	CUSTOMER PROBLEM ANALYSIS (See page 05-1790)
3	CHECK BODY MULTIPLEX COMMUNICATION SYSTEM (See page 05-2148)
(a) Cł	neck that the DTC outputs.
	DTC OUTPUTS (PROCEED TO "BODY MULTI-PLEX COMMUNICATION SYSTEM")
	DTC DOES NOT OUTPUT (GO TO STEP 4)
4	DTC CHECK
	MALEUNOTION CODE (OC TO STER T)
	MALFUNCTION CODE (GO TO STEP 7)
	NORMAL CODE (GO TO STEP 6)
5	DTC CHART (See Page 05–1792)
	GO TO STEP 8
6	PROBLEM SYMPTOMS TABLE (See page 05–1797)
7	TERMINAL OF ECU (See page 05–1795)
8	CIRCUIT INSPECTION (See Page 05–1799)
9	IDENTIFICATION OF PROBLEM
10	REPAIR OR REPLACE

11	CONFIRMATION TEST
END	