

: Parts Location

Code		See Page	Code		See Page	Code		See Page
A13	Α	42	J22	Α	43	МЗ	Α	45
A40	В	42	J23	В	43	IVIS	С	45
C13		44	M2	Α	45			
H10		43		С	45			

0

: Junction Block and Wire Harness Connector

Code	See Page	Junction Block and Wire Harness (Connector Location)	
2C	28	Instrument Panel Wire and Driver Side J/B (Lower Finish Panel)	
2J	28	Floor Wire and Driver Side J/B (Lower Finish Panel)	
2K	20	Thou wife and Direct Side 3/D (Lower Finish)	
2M			
2R	29	Instrument Panel Wire and Driver Side J/B (Lower Finish Panel)	
2S	2S		
3A	34	Instrument Panel Wire and Passenger Side J/B (Instrument Panel Brace RH)	

: Connector Joining Wire Harness and Wire Harness

Code	See Page	Joining Wire Harness and Wire Harness (Connector Location)	
IA1	50	Front Door LH Wire and Floor Wire (Left Kick Panel)	
IM1	51	Front Door RH Wire and Instrument Panel Wire (Right Kick Panel)	

∇

: Ground Points

Code	See Page	Ground Points Location	
II	50	Cowl Side Panel LH	
ВО	52	Under the Driver's Seat	