POWER[DOOR[LOCK[CONTROL[\$YSTEM HOW]TO[PROCEED[WITH[TROUBLESHOOTING

0564G-0

Troubleshoot[]n[accordance[with[t]he[procedure[pn[t]he[f]ollowing[pages.
1 VEHICLE BROUGHT IN
2 CUSTOMER PROBLEM ANALYSIS CHECK AND SYMPTOM CHECK See page 05-1225)
3 DIAGNOSTIC TROUBLE CODE CHECK See page 5-1226)
(a) Check the diagnostic trouble to de. (1) Without to de to utputs, throceed to the december of the december
B[] > Go[to[step[6
A
4 PROBLEM SYMPTOMS TABLE (See page 05-1232)
(a) Without applicable symptoms, proceed on Br. (b) With applicable symptoms, proceed on Br.
B□ Go[to[step[6
A
5 PERFORM TROUBLESHOOTING IN FOLLOWING METHOD, DEPENDING ON MALFUNCTION SYMPTOM
(a) Terminals of ECU. (See page 05-1228) (b) Inspection. (See page 73-3) (c) On-vehicle inspection. (See page 73-1)
6 ADJUSTMENT, REPAIR OR REPLACEMENT
END
END