

# ) : Parts Location

| Code | See Page | Code |   | See Page | Code |   | See Page |
|------|----------|------|---|----------|------|---|----------|
| A4   | 38 (*1)  | A34  |   | 42       | A35  | В | 42       |
|      | 40 (*2)  | A35  | Α | 42       |      |   |          |

#### : Relay Blocks

| Code | See Page | Relay Blocks (Relay Block Location)       |
|------|----------|---|
| 1    | 22       | Engine Room R/B (Engine Compartment Left) |

### : Junction Block and Wire Harness Connector

| Code | See Page | Junction Block and Wire Harness (Connector Location)                     |
|------|----------|--|
| 1E   | 25       | Engine Room Main Wire and Engine Room J/B (Engine Compartment Left)      |
| 2B   | 28       | Instrument Panel Wire and Driver Side J/B (Lower Finish Panel)           |
| 3A   | 34       | Instrument Panel Wire and Passenger Side J/B (Instrument Panel Brace RH) |

# : Connector Joining Wire Harness and Wire Harness

| Code | See Page | Joining Wire Harness and Wire Harness (Connector Location)                           |
|------|----------|--|
| IF4  | 50       | Engine Room Main Wire and Instrument Panel Wire (Right Side of Steering Column Tube) |
| IL1  | 51       | Engine Wire and Instrument Panel Wire (Behind the Glove Box)                         |
| IL2  | 31       | Engine vine and instrument i and vine (Definite the Glove Box)                       |

# : Ground Points

| Code | See Page | Ground Points Location |  |
|------|----------|------------------------|--|
| EC   | 48 (*1)  | Left Fender            |  |
|      | 49 (*2)  | Lettrefider            |  |