

## O : Parts Location

Code	See Page	Code	See Page	Code	See Page
C10	42	H8	40 (*2)	H9	40 (*2)
H8	38 (*1)	H9	38 (*1)		

## : Junction Block and Wire Harness Connector

Code	See Page	Junction Block and Wire Harness (Connector Location)	
1D	25	Engine Room Main Wire and Engine Room J/B (Engine Compartment Left)	
1H	23		
2G	28	Engine Room Main Wire and Driver Side J/B (Lower Finish Panel)	
2Q	29	Instrument Panel Wire and Driver Side J/B (Lower Finish Panel)	