

## : Parts Location

Code		See Page	Code		See Page	Code		See Page
M2	Α	45		Α	45	R10	Α	45
	В	45	M3	В	45		В	45
	С	45		С	45			

## : Junction Block and Wire Harness Connector

Code	See Page Junction Block and Wire Harness (Connector Location)	
2H	28	Floor Wire and Driver Side J/B (Lower Finish Panel)

## : Connector Joining Wire Harness and Wire Harness

Code	See Page	Joining Wire Harness and Wire Harness (Connector Location)			
IA1 50 Front Door LH Wire and Floor Wire (Left Kick Panel)		Front Door LH Wire and Floor Wire (Left Kick Panel)			
IB1	50	Front Door LH Wire and Instrument Panel Wire (Left Kick Panel)			
IB2	30	Tront Door Lit wile and institution trailer wile (Lett Nok Faller)			
IM1 51 Front Do		Front Door RH Wire and Instrument Panel Wire (Right Kick Panel)			

## 7 : Ground Points

Code	See Page	Ground Points Location
ВО	52	Under the Driver's Seat